

Please follow procedure below for the squeak at the back of the counter:

1. Remove upper drawer just below stove top.
2. Remove the farthest screw on the right side of the Induction stove.



3. Remove the left side screw of the induction stove.



4. Cut the tape under the front of the induction stove and pull out.
5. Once the induction is pulled out, on the upper right hand corner of the inside back wall of the galley very close to the perpendicular wall, measure 2" down from the top back corner and then measure 2" in and mark this spot. The using a 1.25" wood screw, secure the kitchen galley to the MB metal body frame. That will hold the galley permanently from any sway.



