



Mack Chassis - Air Restriction Light On In The Instrument Cluster - US07 Emissions And Newer



> Internal Content

PRE US17 MRU/LEU Models

The procedure to eliminate the Mack Chassis "Air Restriction Light On" seen in the cluster is to confirm that the parameter YYT is set to "Enable" with Premium Tech Tool.

If there is NO parameter YYT available refer to the following instructions:

1. Using the correct schematic locate the " Air Restriction Light " connector and add a jumper harness.
2. Locate the correct fuse location and add the fuse.
3. Confirm that the " Air Restriction Light " in the cluster is no longer illuminated.

US17 and newer models

For the US17 and newer models the level 2 parameter RWN - Air Filter Restriction Activation Mode needs to be changed by Dealer Tech Support.

Start an eService case. Add a detailed description of the complaint, and reference this CBR solution number.



Tags

[k00584524](#)

[air restriction](#)

[mack](#)



Live UI **ed links and attachments**

No links or attachments available



Feedback

[Give feedback](#)

to help improve the content of this article