

STONKAM® DVR System Settings for McNeilus Mixers

Date: August 25, 2022
Bulletin Name: MXR-TSIB-036
Model: Bridgemaster (93) and Standard Mixer (90)
Units Affected: Those with STONKAM® DVR System

Purpose:

McNeilus Truck and Manufacturing offers these instructions for changing the Record DVR settings on STONKAM® DVR system installed on some McNeilus Rear Discharge Mixers.

Notice:

- This bulletin should be read and understood in its entirety before performing this procedure.
- All procedures outlined in the bulletin must be performed by skilled service personnel. Refer to the product service manual for descriptions of maintenance procedures.

SAFETY NOTICE

Perform your company's Lockout/Tagout procedure. If your company does not have a Lockout/Tagout procedure, follow OSHA 1910.147 and 1910.146 Confined Space as appropriate.

SAFETY NOTICE

Use appropriate Personal Protective Equipment (PPE) as required by your company.

Procedure:

1. Perform your company's Lockout/Tagout procedure. If your company does not have a Lockout/Tagout procedure, follow OSHA 1910.147 and 1910.146 Confined Space as appropriate. Chock wheels and engage the service brake.
2. Click on the bottom of the DVR screen.
 - The options menu will display on the bottom of the screen.
3. Select the Settings icon (gear symbol) (Figure 1).



Figure 1

- Click on "Record" and you will be able to view the options as shown below (Figure 2, Item 1).
- Change the settings to enable/turn on the "Power On Rec" (Figure 2, Item 2) and "Cyclic Rec." (Figure 2, Item 3) by touching the on/off toggle option to ON on the screen.



Figure 2



(888) 686-7278

www.streetsmartparts.com