



SIB 51 14 22

2022-09-14

## AUTOMATIC LOCKING CANNOT BE DEACTIVATED WHEN DRIVING OFF

### MODEL

E-Series	Model Description
G26	4 Series Gran Coupe
G42	2 Series Coupe

### SITUATION

The vehicle doors lock automatically when driving off.

### CAUSE

Due to legal requirements.

### CORRECTION

The customer is to be informed that this feature cannot be deactivated in the vehicle settings, due to event of an accident the doors won't open. In the event of an accident, the doors unlock and can be opened from either inside or outside of the vehicle.

Note: Even though this automatic door locking cannot be deactivated, different settings for the door unlocking are offered using the Central Information Display (CID). This unlocking carries over not only to the next drive cycle, but until it is changed in the CID. Select the path-

- "CAR"
- "Settings"
- "Doors/vehicle access"
- Choose the desired setting-
- "Unlock doors when in Park"- the doors unlock when the transmission selector lever is moved to the Park position
- "Unlock at end of trip"- the doors unlock when pressing the Start/Stop button

### FEEDBACK REGARDING THIS BULLETIN

Technical Feedback	To submit feedback for the technical topics of this bulletin: Submit your feedback in the rating box at the top of this bulletin
Warranty Feedback	To submit feedback for the CLAIMS section of this bulletin: Submit an IDS ticket to the Warranty Department, or use the chat available in the Warranty Documentation Portal
Parts Feedback	To submit feedback for the PARTS section of this bulletin: Submit an IDS ticket to the Parts Department