



Front wheel hub spigot clicking noise on conventional & Light-weight Discs.



Remove corrosion from
wheel hub spigot



Apply- MOLYKOTE® Cu-7439 Plus
Paste
to wheel hub spigot area as
below



Apply onto the wheel hub inner
annulus hub face.

