1/4-turn Manual Shutoff Valve Description, Operation, and Location

PDO.0042 Ver. 1.0 December 10, 2022

Located on the fuel management module (FMM) faceplate, the 1/4-turn manual shutoff valve (*circled* in the images below) is also known as an “emergency shutoff valve” for its ability to isolate fuel from the cylinders. As the 1/4-turn name implies, valve position is changed from OPEN to CLOSED by rotating the red handle 90-degrees.

Integrated ProRail® SM FMM



Box FMM



Integrated ProCab® BTC FMM – driver side



Integrated ProCab® BTC FMM – passenger side

