

In limited cases, a small pin hole may exist in adhesion that results in a leak. In very limited cases, adhesion failure may occur on the glass.

Indicators can be:

- Leaking from the front window
- Separation of the window from the front cap.

One way to visually check is the perimeter gapping of the window will not be uniform and sagging/slipping would be visible. Example: Lower part of window, touching the fiberglass on one side only. This would result in a non-uniform perimeter spacing.

A water test can determine a leak and/or adhesion issue.

To remedy any of the above instances, the window will need to be extracted, reset and/or replaced.