



TECH TIP

**CUMMINS ECU PARAMETER
CHANGES REQUIRES OEM2
PASSWORD**

**GROUP: 0-GENERAL
TECH TIP NO: TT-23-010
DATE: 1-16-23**

SUBJECT VEHICLES: 23MY Hino Conventional trucks equipped with a Cummins Engine

Note: This tech tip is provided as technical information and is not authorization for a warrantable repair.

OVERVIEW:

The purpose of this TechTip is to provide technical information related to changing the following parameters in the Cummins engine ECU using Cummins INSITE diagnostic software.

- Maximum Accelerator Vehicle Speed
- Maximum Cruise Control Speed
- Maximum Vehicle Speed
- Maximum Engine Speed without Vehicle Speed Source

INFORMATIONAL DETAILS:

When changing any of the parameters above, the Cummins INSITE diagnostic tool may request an OEM2 Password, message may read “***Parameter is locked because ECM OEM2 password is not valid***”.

To change any one of these parameters, use the following password: ***HMLPP6***

IMPORTANT:

Prior to changing any parameters, refer to the proper service information to understand the changes being made.

