



# Preliminary Information

## PIT5960A Rear Map/Reading Lamps Stay On When Attempting To Start The Vehicle

Models

Brand:	Model:	Model Years:	VIN:		Engine:	Transmissions:
			from	to		
Buick	Envision	2021 - 2023	All	All	All	All

Involved Region or Country	North America
Condition	Some customers may comment that the rear map/reading lamps come on when starting the vehicle. If the map/reading lamp button is pressed the lamps will turn off.
Cause	Weak battery could cause the overhead console to command on the map/reading lamps while cranking.

Correction:

Test the battery using GM approved methods. If test fails, replace the battery. If it passes follow SI diagnostics.

Warranty Information

For vehicles repaired under the Bumper-to-Bumper coverage (Canada Base Warranty coverage), use the following labor operation. Reference the Applicable Warranties section of Investigate Vehicle History (IVH) for coverage information.

Labor Operation	Description	Labor Time
4041510	Battery Replacement	Use Published Labor Operation Time
*This is a unique Labor Operation for Bulletin use only.		

Version History

Version	2
Modified	11/29/2022 - Created on. 03/29/2023- Updated add 2023 Model year.



GENERAL MOTORS

© 2023 General Motors. All Rights Reserved.