



Guidelines to Replace the Fuel Tank Pipe Upon Each Removal

Panigale V4 (all versions)

Streetfighter V4 (all versions)

Service Repair Bulletin SRV-SRB-23-029

Date: June 5, 2023
To: Dealer Principal, General Manager, Service Manager, North American Dealer Network
From: Richard Kenton, Technical Director
Dan Schwartz, Service Area Manager

Dear Dealers,

This Service Bulletin is to stress the importance of a topic covered in the Tips & Tricks Bulletin from October 2022.

Mandatory Replacement is required upon each removal of fuel **Pipe part no. 59018461C**. The Pipe can be easily damaged or torn during removal and/or maintenance operations. Therefore, the **Pipe (59018461C)** and the relevant **Ties (A)**, which connect the fuel tank and the injector pipes, MUST be replaced every time it is removed by removing ties (A), as shown in the dedicated spare parts table and in the workshop manual.



WARNING

ALWAYS replace the **2 ties (A)** as well.



NOTE

No replacement is necessary if it is removed by disconnecting the **quick-release couplings (B)** on the 3-way union side. ALWAYS replace the **2 ties (A)** when Pipe is replaced.

For questions about this Service Bulletin,
please contact your Service Area Manager.