Rows beginning with * are modified
Note! If using a printed copy of this Technical Journal, first check for the latest online version.

DESCRIPTION:

If any of the DTCs listed below are set in the ECM or CEM for the pre-heated thermostat in the cooling system, along with a customer complaint of a charging system warning message in the Driver's Information Module (DIM), follow advice under SERVICE.

ECM = Engine Control Module

CEM = Central Electronic Module

CSC Customer Symptom Codes

Code	Description
LN	12 V main battery/Weak or low electrical power
6J	Text window and warning symbol/Low battery
DL	Warning lights and chimes/Malfunction Indicator Light ("Check engine" light) indication/no indication
HA	Warning lights and chimes/Generator warning indication/no indication
3L	Technician information/Repair information/Not for warranty use

DTC Diagnostic Trouble Codes

Control Module	Code	Fault Type
ECM	B139F11	Intermittent
ECM	B139F12	Intermittent
ECM	B139F13	Intermittent
ECM	B139D01	Intermittent
CEM	B123E11	Intermittent
CEM	B139F01	Intermittent
ECM	P059700	Intermittent
ECM	P059800	Intermittent
ECM	P059900	Intermittent

Vehicle Type

Type	Eng	Eng Desc	Sales	Body	Gear	Steer	Model Year	Plant	Chassis range	Struc Week Range
138	40	B4204T11					2016-2017	36	-	201517-201628
1XX	26						2014-2016		-	201346-201618
1XX	40						2014-2016		-	201346-201618
1XX	49						2014-2016		-	201346-201618
256	10	B4204T23					2016-2016		-	201537-201618
256	A2	B4204T27					2016-2016		-	201505-201618
256	BC	B1BPHEV					2016-2016		-	201526-201618

SERVICE:

Replace the thermostat according to instructions in VIDA and erase the DTC(s). Not replacing the thermostat can cause consequential damages.

VST Operation Number

VST Operation Number	Description
26214-2	Thermostat replace
36001-2	DTC read/reset/known DTC with VIDA

VEHICLE REPORT:

Yes, please submit a Vehicle Report if the service solution described in this TJ has no effect. Use concern area “Vehicle Report” and sub concern area “Support needed”, use function group 2627.