

Model series 206 mobile phone cradle inductive charging for mobile phone

| | |
|-------------------|---|
| Topic number | LI82.70-P-077769 |
| Version | 1 |
| Function group | 82.70 - Telephone, Voice-control-system(VCS) |
| Date | 4/30/24 |
| Validity | Model series 206 with WMI (Code 897 Wireless telephone charging at front) |
| Reason for change | |

Complaint

Wireless Media Interface:

Smartphone cannot be charged or charging process is interrupted.

Cause

Smaller size smartphones can slip on the charging tray.

Remedy

In the event of a complaint, the rubber mat can be replaced.

Old part number ----- New part number

A 223 823 04 00 ----- A 223 823 52 00

A 223 823 27 00 ----- A 223 823 53 00

Note: Please refer to this LI in the "Notes" section of the warranty claim!

NOTE: The information contained in this document is intended for use by trained, professional technicians with the knowledge to properly and safely perform diagnosis and repairs on Mercedes-Benz vehicles, using Mercedes-Benz approved tools and equipment. It informs service technicians about conditions that could occur in certain vehicles and provides information that could assist in proper vehicle diagnosis, service, or repair. It does not indicate that a defect is present in any vehicle referenced in this document nor does it imply warranty coverage. DO NOT assume that a symptom or condition, or a described cause of a symptom or condition, affects any particular vehicle or groups of vehicles, or that a described repair applies to any particular vehicle or groups of vehicles. There can be multiple causes resulting in the same or similar symptoms or conditions described in this document, and trained professional service technicians must use their diagnostic skills to make evaluations on a case-by-case basis. The information contained in this document does not guarantee warranty coverage nor does it extend the vehicle's warranty in any way.

XENTRY Tips

Symptoms

| |
|---|
| Communication/information > Entertainment > iPod > Not detected |
| Communication/information > Entertainment > USB input > Malfunction |
| Communication/information > Entertainment > USB input > Not detected |
| Communication/information > Communication > Mobile phone > Telephone > Telephone/cell phone is not detected |
| Communication/information > Communication > Mobile phone > Telephone > Device error |
| Communication/information > Communication > Mobile phone > Telephone > Telephone is not charged |

Parts

| Part number | ES1 | ES2 | Designation | Quantity | Note | EPC |
|-----------------|-----|-----|-------------|----------|------|-----|
| A 223 823 52 00 | | | rubber matt | 1 | | X |
| A 223 823 53 00 | | | rubber matt | 1 | | X |

Operation numbers/damage codes

| Op. no. | Operation text | Time | Damage code | Note |
|---------|----------------|------|-------------|--|
| | | | 820DK42 | Insert for control unit of inductive charging for mobile phone |