

Active Steering Assist and Active Emergency Assist Cluster Messages with Tire Pressure Light

Topic number	LI54.71-P-078498
Version	1
Function group	54.71 - Camera and radar-assisted assistance systems
Date	10/15/24
Validity	Vehicles with driver assistance package (Active Emergency Stop Assist and Active Steering Assist).
Reason for change	

Complaint

"Active Emergency Stop Assist Currently Unavailable" and "Active Steering Assist Inoperative" instrument cluster messages along with Tire Pressure Light on in Instrument Cluster.

Cause

Both systems are temporarily unavailable due to low tire pressures.

An active tire pressure monitor light may result in some assistance features being temporarily unavailable until tire pressures are corrected.

Remedy

Check/adjust tire pressures and reset monitoring through the instrument cluster.

WIS-References		
Document number	Title	Note
AP40.15-P-4061a	Check/correct tire pressure	Check/correct tire pressure
AP40.15-P-4069u	General overview of restarting tire pressure monitoring systems	General overview of restarting tire pressure monitoring systems

Disclaimer

NOTE: The information contained in this document is intended for use by trained, professional technicians with the knowledge to properly and safely perform diagnosis and repairs on Mercedes-Benz vehicles, using Mercedes-Benz approved tools and equipment. It informs service technicians about conditions that could occur in certain vehicles and provides information that could assist in proper vehicle diagnosis, service, or repair. It does not indicate that a defect is present in any vehicle referenced in this document nor does it imply warranty coverage. DO NOT assume that a symptom or condition, or a described cause of a symptom or condition, affects any particular vehicle or groups of vehicles, or that a described repair applies to any particular vehicle or groups of vehicles. There can be multiple causes resulting in the same or similar symptoms or conditions described in this document, and trained professional service technicians must use their diagnostic skills to make evaluations on a case-by-case basis. The information contained in this document does not guarantee warranty coverage nor does it extend the vehicle's warranty in any way.

XENTRY Tips

Symptoms

Chassis/suspension > Wheels/tires > Tire pressure monitor TPM display > Display in yellow > Tire pressure Check tires

Chassis/suspension > Wheels/tires > Tire pressure monitor TPM display > Display in yellow > Tire pressure Please rectify!

Lighting > Exterior lights > Driving lights > Adaptive Highbeam Assist > Warning message in instrument cluster

Overall vehicle > Power supply > Fuel cell > Malfunction

Operation numbers/damage codes

Op. no.	Operation text	Time	Damage code	Note
---------	----------------	------	-------------	------