



## STAR ONLINE PUBLICATION



**Case Number:** S2523000005

**Release Date:** January 2025

**Symptom/Vehicle Issue:** Squeak Noise From Brake Pedal When Pressed And Or Released.

**Discussion:** By operating the brake pedal, isolate the area of the noise. The buzz squeak rattle (BSR) noise could from one of the following:

1. Pedal pivot on pivot shaft.
2. At the booster input rod interface to the pedal
3. Booster input rod interface to the booster boot.

Use a spray lithium grease such as 04318066AE Mopar Spray White Lithium Grease applied to the source of the noise. Shield the surrounding area with a shop cloth to ensure over spray or drips do not spread to carpeting and other components. Work the pedal to allow the spray grease to penetrate the joint.



### SPRAY WHITE LUBE LITHIUM GREASE

An all-purpose, lithium-based white grease for automotive and general purpose applications. Ideal for hinges, slide tracks and lock mechanisms.

12 Oz. Aerosol Can  
MSQ: 12 Cans  
Part No. 04318066AE

This document does not authorize warranty repairs. This communication documents a record of past experiences. STAR Online does not provide any conclusions about what is wrong with the vehicle. Rather, it captures all previous cases known that appear to be similar or related to the vehicle symptom / condition. You are the expert, and you are responsible for deciding on the appropriate course of action.

**Contact STAR Center, or your Technical Assistance Center Via TechConnect, eCONTACT or Service Library entry if no solution is found.**