


Luggage Compartment Lighting Switches Off And Back On Erratically

Topic number	LI82.20-P-079002
Version	1
Function group	82.20 - Interior lights
Date	3/10/25
Validity	Model 206, 236, 223, 254, 214, 294, 295, 296, 297 - modification year 23/1 or later
Reason for change	

Complaint

The luggage compartment lighting switches off and back on erratically if the tailgate is opened with the ignition switched off.

Attachments	
File	Description
Gepäckraumbeleuchtung_Darstellung.png	Illustration of affected component part
	

Cause

The problem was caused by a software error in the control unit N10/8 (Rear SAM).

Remedy

Software update to the control unit N10/8 (Rear SAM - Signal acquisition and actuation module rear control unit).

Disclaimer

NOTE: The information contained in this document is intended for use by trained, professional technicians with the knowledge to properly and safely perform diagnosis and repairs on Mercedes-Benz vehicles, using Mercedes-Benz approved tools and equipment. It informs service technicians about conditions that could occur in certain vehicles and

XENTRY Tips

provides information that could assist in proper vehicle diagnosis, service, or repair. It does not indicate that a defect is present in any vehicle referenced in this document nor does it imply warranty coverage. DO NOT assume that a symptom or condition, or a described cause of a symptom or condition, affects any particular vehicle or groups of vehicles, or that a described repair applies to any particular vehicle or groups of vehicles. There can be multiple causes resulting in the same or similar symptoms or conditions described in this document, and trained professional service technicians must use their diagnostic skills to make evaluations on a case-by-case basis. The information contained in this document does not guarantee warranty coverage nor does it extend the vehicle's warranty in any way.

Symptoms

Lighting > Interior illumination > Interior lamp > Goes off after a delay

Operation numbers/damage codes

Op. no.	Operation text	Time	Damage code	Note
			540RRF1	F1: Faulty variant coding