

DTNA Solutions > Service Solutions > Freightliner
> SS 3174-FTL ICC5 B-Panel Gauges Intermittently Not...

SS 3174-FTL ICC5 B-Panel Gauges Intermittently Not Being Displayed

Applicable Vehicles

Freightliner New Cascadia With ICC5 Cluster

Symptoms

Intermittently during first start the custom gauges in the B-panel are not being displayed. Subsequently trying to add them in again will not work. The B-panel could also become unresponsive to different inputs. This can also cause your SiriusXM to stop outputting audio. Below is an example picture of what it could look like.



Issue

The symptoms resemble an issue with the way the memory is being loaded. Currently it is under investigation.

