

DTNA Solutions > Service Solutions > Western Star
> SS 782-WST ICC5 B-Panel Gauges Intermittently Not ...

SS 782-WST ICC5 B-Panel Gauges Intermittently Not Being Displayed

Applicable Vehicles

47X, 49X, 57X With ICC5 Cluster

Symptoms

Intermittently during first start the custom gauges in the B-panel are not being displayed. Subsequently trying to add them in again will not work. The B-panel could also become unresponsive to different inputs. This can also cause your SiriusXM to stop outputting audio. Below is an example picture of what it could look like.




Issue

The symptoms resemble an issue with the the way the memory is being loaded. Currently it is under investigation.

Solution

The solution is to key cycle the truck and if that does not work then pull the F16 fuse to the Connect5 ECU wait 10-15 seconds before reinserting. This will typically reboot the ICC5 module restoring normal functionality to the B-panel.



Labels :

- 47X
- 49X
- 57X

Add tags



Comment

