CONNECTANYWHERE® 2.0 WI-FI EXTENDER CONNECTION GUIDE

ELECTRONICS

Purpose

This document outlines how to activate the ConnectAnywhere 2.0 All-in-One or LTE Wi-Fi Extender.

Additional Information

Additional information about this product can be obtained from lci1.com/support or by downloading the free LippertNOW app. The app is available on Apple App Store® for iPhone® and iPad® and also on Google Play™ for Android™ users.

For information on the assembly or individual components of this product, please visit: https://support.lci1.com/connectanywhere

Safety


Warning, Caution and Danger symbols indicate that an installation procedure has a safety risk involved and may cause death, serious injury or property damage if not performed safely and within the parameters set forth in this manual.



Do not try to activate Wi-Fi Extender while towing the trailer and operating the tow vehicle. Distracted driving impairs ability to mind the rules of the road and adhere to safety rules and regulation that could result in personal or property damage and/or death.

Resources Required

- ConnectAnywhere 2.0 AIO or LTE antenna and router installed
- Connectivity plan providing Internet services
- Smart device or personal computer with web browser (such as Chrome or Edge)
- The ConnectAnywhere label





CONNECTANYWHERE® 2.0 WI-FI EXTENDER CONNECTION GUIDE

ELECTRONICS

NOTE: The Router is set to Hotspot (Fig. 3A). This provides long-range connectivity to support telematics and data plans.

3. To access local Wi-Fi networks, select "Add Network" (Fig. 4A). This will search for available networks.



Fia. 5

E→ Log Ou

OneControl

Wi-Fi Networks

Network1234



- 4. Select the preferred local network (Fig. 5). Enter its credentials and press APPLY (Fig. 5A).
- When Extender is on, the Router's LED will turn BLUE. 5. Press COMPLETE (Fig. 6A).
- From your smart device, connect to the Router's SSID. 6. Login again with Router credentials.

NOTE: From your smart devices, use local networks to access data-heavy services.

Return to Hotspot

- Enter wifi.Lippert.ext in a browser and select Hotspot on the Home page.
- · Or, if Wi-Fi network connection is lost, Router switches automatically to Hotspot.

Preferences 1. From the home page, you can

Set the Router to connect 2. automatically to trusted networks (Fig. 8A).

password (Fig. 7A).

change your Router's

NOTE: The last 5 networks are stored. "Favorite" (Fig. 9A) up to 3 for Auto-Connect.









As a supplier of a broad array of highly-engineered components in the recreation and transportation product markets, safety, education and customer satisfaction are our primary concerns. Should you have any questions, please do not hesitate to contact us at 432-LIPPERT (432-547-7378) or by email at customerservice@lci1.com. Self-help tips, technical documents, product videos and a training class schedule are available at lippert.com or by downloading the LippertNOW app.