

SLINGSHOT
HELP CENTER

What can we help you find?

SEARCH

Help Center Home / [Article](#)


04/15/2025

Fuse Replacement for Model Year 2019 and Older Slingshot

To replace a fuse on your model year 2019 and older Slingshot, first find the fuse box. The fuse box (1) is located under the hood near the brake fluid reservoir. The three main system fuses are located in the battery compartment.

Replace a fuse by following these steps:

1. Open the hood.
2. Squeeze the fuse box cover tabs (2) inward and remove the cover.
3. Use the fuse puller provided in the tool kit to remove the spent fuse. Always use the recommended fuse to prevent electrical system damage. Refer to the label on the fuse box cover.
4. Install the new fuse.
5. Reinstall the fuse box cover.



POWERTRAIN RELAY	STARTER RELAY	PRIMARY LIGHTS RELAY	EPAS RELAY	ECM 10A BRKR	GAUGES 5A FUZE
4016819	4016819	4016819	4016819	4011371	4011652
				POWERTRAIN 20A BRKR	TS / HORN 20A FUZE

				4011372	4012811
FUEL PUMP RELAY 4016819	FOG LIGHTS RELAY 4016819	TURN SIGNAL RELAY 4016819	AUX LIGHTS RELAY 4016819	FAN 20A BRKR 4011372	FUEL PUMP 10A FUSE 2434016
				IGNITION 10A BRKR 4011371	EPAS 30A FUSE 2434015
COOLING FAN RELAY 4016819	ACCESSORY RELAY 4016819	HORN RELAY 4016819	FOG LIGHTS 10A FUSE 2434016	PRI LIGHTS 30A BRKR 4013894	RADIO 25A FUSE 4011653
			AUX LIGHT 20A FUSE 4012811	ABS 25A FUSE 4011653	ACCESSORY 25A FUSE 4011653

For more information, see your authorized Slingshot Dealer. Find a dealer near you with the [Dealer Locator](#).

Maintenance tips, procedures and specifications can be found in your [Owner's Manual](#).

To find diagrams and replacement part numbers, use the [online parts catalog](#).

Unless noted, trademarks are the property of Polaris Industries Inc.

© 2022 Polaris Industries Inc

Was this article helpful?

- Yes, it answers my question
- No, it's missing information or visuals
- No, the instructions are unclear
- No, What are the next steps?
- No, I'm experiencing a technical error
- Other