

167 GLE53 - Repeat workshop visit for vehicle vibration under braking from 60MPH through to 40MPH - Front Brakes Only

Topic number	LI42.10-P-078779
Version	1
Function group	42.10 - Service brake
Date	5/9/25
Validity	AMG GLE 53
Reason for change	

Complaint

Repeat workshop visit for vehicle vibration under braking from 60MPH through to 40MPH.

Cause

Under investigation.

Remedy

Leave vehicle in as-received condition and please open a TIPS case and direct to the BCE (Body, Chassis, Entertainment) inbox.

Please provide any notes of aftermarket modifications that are visually obvious, if any, to the vehicle. After market modifications may be items such as painted calipers or powder coated wheels.

Disclaimer

NOTE: The information contained in this document is intended for use by trained, professional technicians with the knowledge to properly and safely perform diagnosis and repairs on Mercedes-Benz vehicles, using Mercedes-Benz approved tools and equipment. It informs service technicians about conditions that could occur in certain vehicles and provides information that could assist in proper vehicle diagnosis, service, or repair. It does not indicate that a defect is present in any vehicle referenced in this document nor does it imply warranty coverage. DO NOT assume that a symptom or condition, or a described cause of a symptom or condition, affects any particular vehicle or groups of vehicles, or that a described repair applies to any particular vehicle or groups of vehicles. There can be multiple causes resulting in the same or similar symptoms or conditions described in this document, and trained professional service technicians must use their diagnostic skills to make evaluations on a case-by-case basis. The information contained in this document does not guarantee warranty coverage nor does it extend the vehicle's warranty in any way.

Symptoms
Power transmission > Function > Blocks
Chassis/suspension > Brake system > Service brake > Function > Brakes general
Chassis/suspension > Brake system > Service brake > Function > Vibrates/shudders

XENTRY Tips

Operation numbers/damage codes				
Op. no.	Operation text	Time	Damage code	Note