

Uncontrolled Copy

ID # CBR-2396

Version 13

Title

Pre-Delivery Mode Deactivation - VN (4) - PR (4)

Abstract

For newly delivered vehicles it may be found that the key fob will not unlock the door. The message "Pre-delivery Mode" maybe displayed on the instrument cluster.

Content

Published 9 July 2025

Valid For

Volvo Chassis - VN (4)

Mack Chassis - PR (4)

Model Year 2025 to current

Solution

For newly delivered vehicles it may be found that the key fob will not unlock the door. The message "Pre-delivery Mode" maybe displayed on the instrument cluster.

Door Unlocking & Pre-Delivery Deactivation

1. Manually Unlock the Driver's Door:

- Insert the key and turn it firmly to unlock the driver's door.

2. Use the key fob to unlock all other doors.

3. Disable Pre-Delivery Mode:



Live UI

a. For vehicles with Push-Button Start:

- Without pressing the brake pedal, push the start button one time to switch the truck to accessory mode.

3.1b. For vehicles with Key Start:

- Turn the Key **counter-clockwise** to the ACC position.

3.2. Press and hold the hazard light button for 5 to 10 seconds to deactivate pre-delivery mode.

Note: There is no message to confirm pre-delivery mode is off, but the Pre-Delivery Mode message will no longer appear in the cluster after successful deactivation.

4. Perform Pre-Delivery Inspection (PDI):

- Complete the standard Pre-Delivery Inspection process.

 Tags

vnl 4	volvo	key fob	pre-delivery	predelivery	pdi
b1-hdv	b1-v4	v4	vnl4	vn4	mack
pr4	pr 4				

Categories

- Make and Model > Volvo > All-New VNL - VN (4)
- Make and Model > Mack Americas > PR (4) - Pioneer
- Vehicle System > Electrical
- Vehicle System > Instrumentation
- Vehicle System > Control Systems