

Dynamic or Park Camera Push Button Switch In The Lower Control Panel (LCP) Is Stuck or Inoperative

Topic number	LI54.25-P-079602
Version	1
Function group	54.25 - Switches
Date	9/3/25
Validity	GLA/GLB + CLA as from modification year 23/1 (804)
Reason for change	

Complaint

The Dynamic or Park Camera button in the LCP is stuck or does not react.



Attachments	
File	Description
01.jpg	Lower control panel



Cause

In rare cases, tension between the component parts of the LCP and trim of the center console could result in the buttons sticking.

Remedy

Remove LCP and reinstall while ensuring it is free of any tension. Replacement is not necessary.

WIS-References		
Document number	Title	Note
AR54.21-P-0503MFA	Remove/install touchpad control unit	

Disclaimer

NOTE: The information contained in this document is intended for use by trained, professional technicians with the knowledge to properly and safely perform diagnosis and repairs on Mercedes-Benz vehicles, using Mercedes-Benz approved tools and equipment. It informs service technicians about conditions that could occur in certain vehicles and provides information that could assist in proper vehicle diagnosis, service, or repair. It does not indicate that a defect is present in any vehicle referenced in this document nor does it imply warranty coverage. DO NOT assume that a symptom or condition, or a described cause of a symptom or condition, affects any particular vehicle or groups of vehicles, or that a described repair applies to any particular vehicle or groups of vehicles. There can be multiple causes resulting in the same or similar symptoms or conditions described in this document, and trained professional service technicians must use their diagnostic skills to make evaluations on a case-by-case basis. The information contained in this document does not guarantee warranty coverage nor does it extend the vehicle's warranty in any way.

Symptoms				
Communication/information > Entertainment > Overall system/operation > Button jams				
Operation numbers/damage codes				
Op. no.	Operation text	Time	Damage code	Note

XENTRY Tips

54229	Remove/install touchpad control unit	H	82666H2	Lower control panel switch group - stuck
-------	--------------------------------------	---	---------	--