



Pleasure-Way

phone 306.934.6578
fax 306.934.7085
toll free 1.800.364.0189

Pleasure-Way Industries Ltd. | 302 Portage Avenue | Saskatoon, SK | S7J 4C6

TO STRAIGHTEN SCISSOR LIFT ASSEMBLY.

1. Unlatch the seatbelt safety strap for the roof and do not let the roof extend. Hook a ratchet strap from the male buckle to around the female buckle on the roof. Slowly extend the roof up until you can see the scissor hinge, only around 2-3'. The roof will not want to pivot or shift if it is kept from fully extending which could cause more damages.



2. Depending on which bolt has fallen out, you may need to block the back end to support the roof from sagging. With the roof partially extended as described in line 1, you should be able to manipulate or float the roof slightly into position so that you can re-secure the bolt that has fallen out. Once the bolt is back into position, add ratchet straps on the exterior as shown in green.



Note: Do not undo the front shocks ever. Do not undo bottom and top long brackets for the scissor hinge. It wouldn't hurt to have some cardboard between scissor and the canvas to prevent unforeseen damages.

3. With the rear of the roof blocked and strapped at the front as shown in the photo, loosen nut from the bolt and add Loctite 290 – medium grade wicking type thread sealer. Do this for each nut and bolt 1 at a time on both side hinges. This should help to prevent this from happening in the future. The nut/bolt assemblies should still be checked regularly for tightness.



