

**DTC:** Multiple List

**Bulletin:** GDC26-02

**Date:** May 29, 2026

**Description:** Supplemental Restraint System/Airbag Inflation System (SRS)

**Applies To:** US24 and Newer Emissions Product Class (B2)

For Spanish click here: [ESPAÑOL](#) For French click here: [FRANÇAIS](#)

## General Information

If you have received this document, it is because one or more of the following Faults has been active for at least 5 minutes and can potentially prevent the Supplemental Restraint System/Airbag Inflation System (SRS) from functioning properly in the event of a collision. Tech Tool will need to be used for more detailed diagnostics.

DTC	Description
B0001-11	Driver Frontal Stage 1 Ignition Loop
B0001-12	Driver Frontal Stage 1 Ignition Loop
B0001-1A	Driver Frontal Stage 1 Ignition Loop
B0001-1B	Driver Frontal Stage 1 Ignition Loop
B0001-2B	Driver Frontal Stage 1 Ignition Loop
B0001-55	Driver Frontal Stage 1 Ignition Loop
B0070-11	Driver Seatbelt Pretensioner Ignition Loop
B0070-12	Driver Seatbelt Pretensioner Ignition Loop
B0070-1A	Driver Seatbelt Pretensioner Ignition Loop
B0070-1B	Driver Seatbelt Pretensioner Ignition Loop
B0070-2B	Driver Seatbelt Pretensioner Ignition Loop
B0070-55	Driver Seatbelt Pretensioner Ignition Loop
B0072-11	Passenger Seatbelt Pretensioner Ignition Loop
B0072-12	Passenger Seatbelt Pretensioner Ignition Loop
B0072-1A	Passenger Seatbelt Pretensioner Ignition Loop
B0072-1B	Passenger Seatbelt Pretensioner Ignition Loop
B0072-2B	Passenger Seatbelt Pretensioner Ignition Loop
B0072-55	Passenger Seatbelt Pretensioner Ignition Loop
B1000-86	Chassis ID Mismatch

B1000-87	Chassis ID Mismatch
B1001-56	SRS Configuration Data Inconsistent
B1002-56	SRS ASIC ID Mismatch
B1003-57	SRS Software Version Mismatch
B1004-41	Internal SRS Error: CRC
B1005-00	Airbag Control Unit Rollover Crash Detected
B1006-11	SRS Crash Output Pin
B1006-12	SRS Crash Output Pin
B1007-11	SRS Analog Output Pin 1
B1007-12	SRS Analog Output Pin 1
B1008-11	SRS Analog Output Pin 2
B1008-12	SRS Analog Output Pin 2
B1009-07	SRS Central Sensor Monitoring X Axis HighG
B100A-07	SRS Central Sensor Monitoring X Axis LowG
B100B-07	SRS Central Sensor Monitoring Y Axis HighG
B100C-07	SRS Central Sensor Monitoring Y Axis LowG
B100D-07	SRS Central Sensor Monitoring Y Axis LowG Plausibility
B100E-07	SRS Central Sensor Monitoring Z Axis LowG
B100F-07	SRS Central Sensor Monitoring RollRate
B1010-11	Driver Rollover Stage 1 Ignition Loop
B1010-12	Driver Rollover Stage 1 Ignition Loop
B1010-1A	Driver Rollover Stage 1 Ignition Loop
B1010-1B	Driver Rollover Stage 1 Ignition Loop
B1010-2B	Driver Rollover Stage 1 Ignition Loop
B1010-55	Driver Rollover Stage 1 Ignition Loop
B1011-11	Passenger Rollover Stage 1 Ignition Loop
B1011-12	Passenger Rollover Stage 1 Ignition Loop
B1011-1A	Passenger Rollover Stage 1 Ignition Loop
B1011-1B	Passenger Rollover Stage 1 Ignition Loop

B1011-2B	Passenger Rollover Stage 1 Ignition Loop
B1011-55	Passenger Rollover Stage 1 Ignition Loop
B1012-11	Driver Seat Pulldown Ignition Loop
B1012-12	Driver Seat Pulldown Ignition Loop
B1012-1A	Driver Seat Pulldown Ignition Loop
B1012-1B	Driver Seat Pulldown Ignition Loop
B1012-2B	Driver Seat Pulldown Ignition Loop
B1012-55	Driver Seat Pulldown Ignition Loop
B1013-11	Passenger Seat Pulldown Ignition Loop
B1013-12	Passenger Seat Pulldown Ignition Loop
B1013-1A	Passenger Seat Pulldown Ignition Loop
B1013-1B	Passenger Seat Pulldown Ignition Loop
B1013-2B	Passenger Seat Pulldown Ignition Loop
B1013-55	Passenger Seat Pulldown Ignition Loop
B1014-11	SRS External Sensor
B1014-12	SRS External Sensor
B1014-13	SRS External Sensor
B1014-2B	SRS External Sensor
B1014-52	SRS External Sensor
B1014-55	SRS External Sensor
B1014-87	SRS External Sensor
B1014-96	SRS External Sensor
B1015-56	SRS Sensor ID Mismatch
B1016-00	Crash Event Data Memory Full
B1017-11	SRS External Sensor 2
B1017-12	SRS External Sensor 2
B1017-13	SRS External Sensor 2
B1017-2B	SRS External Sensor 2
B1017-52	SRS External Sensor 2

B1017-55	SRS External Sensor 2
B1017-87	SRS External Sensor 2
B1017-96	SRS External Sensor 2
B1502-00	Airbag Control Unit Front Crash Detected
U0037-88	CAN Communication Cab Net
U0046-88	CAN Communication Infotainment Net
U0064-88	CAN Communication Diagnostic Link Net
U1000-68	DTC Notification Max Limit Reached
U1FFF-68	Factory Mode Active
U3000-41	Electronic control unit
U3000-44	Electronic control unit
U3000-45	Electronic control unit
U3000-46	Electronic control unit
U3000-49	Electronic control unit
U3000-54	Electronic control unit
U3000-56	Electronic control unit
U3000-64	Electronic control unit
U3000-94	Electronic control unit
U3003-16	Battery Power
U3003-17	Battery Power