


EV9

Owner's manual leaflet



This leaflet contains revised information for wipers.
Please keep this leaflet with the Owner's manual.




Movement that inspires

Features of your vehicle

Wipers and washers

The wipers and washers remove water and foreign substances from the windshield and rear window, helping to maintain visibility.



1 Wiper speed control

- MIST - Single wiper
- OFF - Off
- AUTO: Auto control wipe
- LO - Low wiper speed
- HI - High wiper speed

2 Rear wiper/washer control

- HI - Continuous wipe
- LO - Intermittent wipe
- OFF - Off

3 Wash with brief wipes (Pull lever towards you)

4 Wash with brief wipes (Rear/Push lever away from you)

Windshield wipers

Operate as follows when the EV button is on.

- MIST: For a single wiping cycle, move the lever to this position and release it.

The wipers will operate continuously if the lever is held in this position.

- OFF: Wiper is not in operation
- LO: Normal wiper speed
- HI: Fast wiper speed

⚠ CAUTION


If there is heavy accumulation of snow or ice on the windshield, remove it before operating the wipers, defrost the windshield for about 10 minutes, or until the snow and/or ice is removed before using the windshield wipers. If you do not remove the snow and/or ice before using the wiper and washer, it may damage the wiper and washer system.

⚠ WARNING

Do not use the washer in freezing temperatures without first warming the windshield with the defroster; the washer solution could freeze on the windshield and obscure your vision.

* NOTICE

- Before driving, remove all accumulated snow or ice from the roof, windshield, and windshield cowl area (the area below the windshield wipers).



- If the wipers remain outside the normal stop position due to accumulated snow or another obstruction after starting the vehicle, the warning message "Wipers may be disabled. Turn off vehicle, open hood, and clear snow from wiper area & roof" may appear. Follow the instructions in the message, and then resume operation.

- If the wipers stop operating due to accumulated snow or another obstruction, the warning message "Wipers disabled temporarily. Wipers will resume after snow or ice is melted/cleared," will appear. This is normal, and temporary and does not indicate a malfunction. The system limits wiper operation to prevent damage caused by overloading the wiper motor. Once the obstruction is removed, the wipers will resume operation.
- If snow is forecast and the vehicle is parked outside, place the wipers in Service Mode within 20 seconds of turning off the vehicle by moving the wiper control stalk upward to the MIST position and holding it for more than 2 seconds. This provides easier access to the wipers and the windshield cowl area when clearing snow or ice before the next use of the vehicle.

