
SUBARU Select Monitor 4 - DTC - Occupant Detection
Start Diagnosis
Vehicle Forester
Target Each System
System Occupant Detection
Select Function
DTC
Cancel Code
Data Monitor
Active Test
Work Support
Customize
--.--V
Service INFO
Status
Description & trouble part
FFD
No DTC
Reading code
Start
Clear memory
Status
All