Nissan

**Response to** 

PE06-050

2/2/2007

# **INTRODUCTION**

In responding to this Information Request ("IR"), information has been obtained from those places within Nissan likely to contain such information in the regular and ordinary course of business. When a particular Request seeks "documents" as defined in the IR, reasonable, good faith searches have also been made of corporate records in those places likely to maintain them in the regular and ordinary course of business.

The definitions of "documents" and "Nissan", however, are unreasonably broad, vague and ambiguous in the context of the information sought by this IR. For example, "calendars", "appointment books", "financial statements" and "personnel records" would not contain owner complaints, field reports or other information sought by Request 2 pertaining to the alleged defect. Therefore, searches were not made for such "documents", inasmuch as they would not likely contain responsive information. In addition, Nissan has not provided information from persons or entities over which it does not ordinarily exercise control. Nissan understands this IR to seek information on vehicles manufactured for sale in the United States.

Responses are provided after each request, and Attachments are utilized as appropriate. The source of information used as a basis for the data in each Attachment, including the date the data were updated and retrieved, is identified at the beginning of each Attachment, as applicable. If a document itself is the source for the requested information and it is provided, we assume no further source identification is called for. If a document, drawing or component is requested, or if no responsive information is available, we assume no further source identification is called for.

With regard to claims of privilege, Nissan understands that it is acceptable to the Agency for Nissan to identify specific categories of privileged documents rather than any specific document. These specific categories are: 1) communications between outside counsel and Nissan Legal Department employees, other Nissan employees, or other Nissan-represented parties in litigation and claims; 2) communications between Nissan Legal Department employees and other Nissan employees or other Nissan-represented parties in litigation or claims; 3) notes and other work product of outside counsel or of Nissan Legal Department employees concerning communications with Nissan employees or consultants, and the work product of those employees or consultants done for or at the request of outside counsel or Legal Department employees; and 4) other categories to be identified later as necessary. For any privileged documents that are not included in these categories, such documents, if any, will be specifically identified on a separate privilege index at a later time. To the extent that a document is furnished, Nissan is not asserting a privilege claim for that document, although the disclosure of such document does not waive the attorney-client privilege or work-product protection with respect to other documents prepared in connection with the specific litigation or claim or other litigation or claims. In addition, in submitting such documents, we reserve our right to claim the attorney-client privilege and/or workproduct protection with respect to analyses that may be prepared subsequently in connection with these and other cases. Also, we understand documents specifically related to the preparation of the responses are not sought.

Nissan believes NHTSA's policy is to protect the privacy of individuals under exemption 6 of the Freedom of Information Act, 5 U.S.C. Section 552(b)(6). We understand that name, address, and other personal information of owners or other individuals, including Nissan

personnel, contained in any of the attachments in this response will not be made available to the public. Therefore, Nissan is not requesting confidential treatment for this information pursuant to 49 CFR, Part 512, but we believe any private information concerning individuals should not be made public.

\* \* \* \* \*

- 1. State, by model year and wheel, the number of subject vehicles Nissan has manufactured for sale or lease in the United States. Separately, for each subject vehicle manufactured to date by Nissan, state the following:
  - a. Vehicle identification number (VIN);
  - b. Part number of the original equipment wheel installed at the time of manufacture;
  - c. Date of manufacture;
  - d. Date warranty coverage commenced; and
  - e. Dealer code.

<u>Provide the table in Microsoft Access 2000, or a compatible format, entitled</u>
<u>"PRODUCTION DATA." See Enclosure 1, Data Collection Disc, for a pre-formatted table, which provides further details regarding this submission.</u>

The information requested in 1.a through 1.e is provided, when known, in a file titled, "PRODUCTION DATA (PE06050).mdb" on a CD enclosed as Attachment A.

- 2. Provide a table of all Nissan dealers in the United States with the following information:
- a. Dealer code;
- b. Dealer name;
- c. Dealer address;
- d. Name and title of dealer point of contact; and
- e. Dealer telephone number.

Tables containing the requested Nissan dealer information (by State) are provided on the CD enclosed as Attachment A. The Excel file containing the dealer information is labeled Dealer Data.

- 3. State the number of each of the following, received by Nissan, or of which Nissan is otherwise aware, which relate to, or may relate to, the alleged defect in the subject vehicles:
  - a. Consumer complaints, including those from fleet operators;
  - b. Field reports, including dealer field reports;
  - c. Reports involving a crash, injury, or fatality, based on claims against the manufacturer involving a death or injury, notices received by the manufacturer alleging or proving that a death or injury was caused by a possible defect in a subject vehicle, property damage claims, consumer complaints, or field reports;
  - d. Property damage claims;
  - e. Third-party arbitration proceedings where Nissan is or was a party to the arbitration; and
  - f. Lawsuits, both pending and closed, in which Nissan is or was a defendant or codefendant.

For subparts "a" through "e," state the total number of each item (e.g., consumer complaints, field reports, etc.) separately. Multiple incidents involving the same vehicle are to be counted separately. Multiple reports of the same incident are also to be counted separately (i.e., a consumer complaint and a field report involving the same incident in which a crash occurred are to be counted as a crash report, a field report and a consumer complaint).

In addition, for items "c" through "f," provide a summary description of the alleged problem and causal and contributing factors and Nissan's assessment of the problem, with a summary of the significant underlying facts and evidence. For items "e" and "f", identify the parties to the action, as well as the caption, court, docket number, and date on which the complaint or other document initiating the action was filed.

Nissan has located the following categories of consumer complaints that may relate to the alleged defect:

5 reports of aftermarket chromed rims cracking or fracturing (reporting 4 incidents)

3 reports of impact damage to the wheel (no apparent wheel separation from vehicle)

3 reports of cracking with no details (no apparent wheel separation from vehicle)

Nissan has located the following categories of field reports that may relate to the alleged defect:

1 dealer field report

3 field reports

Reports involving a crash: 2 Reports involving an injury: 1 Reports involving a fatality: 0 Property damage claims: 1 Third-party arbitrations: 0

Lawsuits: 0

There are no reports of death claims responsive to 3.c. There are no applicable third party arbitration proceedings or lawsuits.

Multiple report types of the same incident have been counted separately, so there are duplicate counts in several categories.

The claim summary is located on the CD enclosed as Attachment A in a file titled Claim Summary.

- 4. Separately, for each item (complaint, report, claim, notice, or matter) within the scope of your response to Request No. 2 (sic), state the following information:
  - a. Nissan's file number or other identifier used;
  - b. The category of the item, as identified in Request No. 2 (sic) (i.e., consumer complaint, field report, etc.);

- c. Vehicle owner or fleet name (and fleet contact person), address, and telephone number;
- d. Vehicle's VIN;
- e. Vehicle's mileage at time of incident;
- f. Part number of the wheel(s) which allegedly failed;
- g. Whether the allegedly failed wheel(s) were unmodified OE fitment or not;
- h. Incident date;
- i. Report or claim date;
- j. Whether a crash is alleged;
- k. Whether property damage is alleged;
- I. Number of alleged injuries, if any; and
- m. Number of alleged fatalities, if any.

Provide this information in Microsoft Access 2000, or a compatible format, entitled "REQUEST NUMBER TWO DATA." See Enclosure 1, Data Collection Disc, for a preformatted table, which provides further details regarding this submission.

The information requested in 3.a through 3.l is provided, when known, in the following file: "REQUEST NUMBER THREE DATA(PE06050).mdb", on a CD enclosed as Attachment A.

5. Produce copies of all documents, including all document attachments, related to each item within the scope of Request No. 2 (sic). Organize the documents separately by category (i.e., consumer complaints, field reports, etc.) and describe the method Nissan used for organizing the documents.

Nissan understands this question to request copies of the specific consumer complaint documents, field report documents, and lawsuit documents (such as the initial legal complaint) for those items included within the response to Request No. 3 above. Consumer complaints, field reports, and the claim summary is contained on a CD in Attachment A. The documents are organized by the date Nissan received the information.

6. State, by model year and wheel, a total count for all of the following categories of claims, collectively, that have been paid by Nissan to date that relate to the alleged defect in the subject vehicles: warranty claims; extended warranty claims; claims for good will services that were provided; field, zone, or similar adjustments and reimbursements; and warranty claims or repairs made in accordance with a procedure specified in a technical service bulletin or customer satisfaction campaign.

Separately, for each such claim, state the following information:

- a. Nissan's Claim Number;
- b. Vehicle owner or fleet name (and fleet contact person) and telephone number;
- c. VIN;

- d. Repair date;
- e. Vehicle mileage at time of repair;
- f. Repairing dealer's or facility's name, telephone number, city and state or ZIP code;
- g. Labor operation number;
- h. Problem code;
- i. Replacement part number(s) and description(s);
- j. Concern stated by customer; and
- k. Comment, if any, by dealer/technician relating to claim and/or repair.

Provide this information in Microsoft Access 2000, or a compatible format, entitled "WARRANTY DATA." See Enclosure 1, Data Collection Disc, for a pre-formatted table, which provides further details regarding this submission.

The main purpose of the warranty system is to reimburse dealers for performing warranty repairs. Claims are submitted by dealers through an on-line computer system through the use of a set of codes. The codes are designed to allow flexibility for their use and, as such, do not supply a significant amount of information about why a particular repair was made, or specific details about the nature of the repair itself.

Within the limitations of our warranty system as it relates to the subject matter of this inquiry, the total count for all of the categories of paid warranty claims, as described in Request No. 6, is contained in Attachment B. In addition, the information requested in 6.a and 6.c through 6.k is provided, when known, in a file titled, "WARRANTY DATA (PE06-050).mdb" on a CD enclosed in Attachment A. Owner information requested by item 6.b is not present in the warranty system.

7. Describe in detail the search criteria used by Nissan to identify the claims identified in response to Request No. 6, including the labor operations, problem codes, part numbers and any other pertinent parameters used. Provide a list of all labor operations, labor operation descriptions, problem codes, and problem code descriptions applicable to the alleged defect in the subject vehicles. State, by model year, the terms of the new vehicle warranty coverage offered by Nissan on the subject vehicles (i.e., the number of months and mileage for which coverage is provided and the vehicle systems that are covered). Describe any extended warranty coverage option(s) that Nissan offered for the subject vehicles and state by option, model, and model year, the number of vehicles that are covered under each such extended warranty.

The search criteria used by Nissan to identify the claims identified in response to Request No. 6 are outlined in Attachment B.

Copies of the applicable warranties for the subject vehicles are contained in Attachment C. There are no extended warranties applicable to the subject vehicles as we understand this request. Nissan offers "Security Plus" service contract plans on Nissan vehicles and are available for separate purchase by customers. Information about Nissan's Security Plus programs is contained in Attachment D. There are 9,442 MY2005 and 9,980 MY2006 350Z vehicles covered by Security Plus contracts.

8. Produce copies of all service, warranty, and other documents that relate to, or may relate to, the alleged defect in the subject vehicles, that Nissan has issued to any dealers, regional or zone offices, field offices, fleet purchasers, or other entities. This includes, but is not limited to, bulletins, advisories, informational documents, training documents, or other documents or communications, with the exception of standard shop manuals. Also include the latest draft copy of any communication that Nissan is planning to issue within the next 120 days.

Nissan has located two service bulletins concerning wheels chromed by the aftermarket. The service bulletins are provided as Attachment E. Nissan is in the early planning stage for potential communications that would be relevant to item 8 within the next four months, but no drafts have been developed at this time.

9. For each unique part number identified in response to question 1.b, and for any other wheels Nissan sells for use on the subject vehicles, state the number of wheels that Nissan has sold by component name, part number (both service and engineering/production), model of the vehicle in which it is used and month/year of sale (including the cut-off date for sales, if applicable).

For each component part number, provide the supplier's name, address, and appropriate point of contact (name, title, and telephone number) Also identify by make, model and model year, any other vehicles of which Nissan is aware that contain the identical component, whether installed in production or in service, and state the applicable dates of production or service usage.

The information provided in response to this request reports the total number of parts sold. Parts may be ordered for appearance issues, repair, dealer stock, or vehicle collision repair. Therefore, we are unable to identify the specific use of parts that have been sold.

The total number of the above components or assemblies that have been sold is listed by component name, part number, supplier (name and address), and vehicle applicability by model, and model year on a CD enclosed as Attachment A in a file labeled Part Sales.

- 10. State, by model year and original equipment wheel, the number of vehicles sold by the following dealers with wheels altered in any way from Nissan approved original equipment or service replacement parts and provide a list of all such vehicles by VIN and a summary of each alteration (e.g., aftermarket re-chroming):
  - a. Raceway Nissan in Riverside, CA;
  - b. Antelope Valley Nissan in Palm Dale (sic), CA; and
  - c. Nissan of Thousand Oaks, CA.

The number of subject vehicles with original equipment wheels sold to Raceway Nissan, Antelope Valley Nissan and Nissan of Thousand Oaks is supplied in our responses to

requests number 1 and 2 of this inquiry. Other than documents provided in response to requests 4 and 5, Nissan has no information regarding wheels modified from original equipment or any vehicles that may have modified wheels sold by the above dealers. This is because Nissan dealers are entities independent from Nissan, and are not obligated to report on vehicles that they may have modified. However, Nissan has issued two TSB's cautioning against aftermarket chroming of Nissan alloy wheels.

11. Provide a detailed description of, and copies of all documents relating to, Nissan's decision to issue Technical Service Bulletins (TSB's) concerning aftermarket rechroming of Nissan alloy wheels. Summarize the field experience, by model, wheel and dealer code, with the problems relating to aftermarket re-chromed wheels that Nissan was aware of when the orginal TSB was issued and when it was reissued.

Nissan has issued two TSB's concerning aftermarket chroming of Nissan alloy wheels. The first of these was issued in December 1992 for Infiniti and Nissan vehicles. We no longer have any records related to the issuance of this TSB because of its age. However, it was issued because of reports of wheel failure on Infiniti Q45 wheels that had been chromed using a process not approved by Nissan by third parties in the aftermarket. A new TSB concerning aftermarket chroming was issued in August 2006 because Nissan field staff were observing aftermarket chromed wheels on Nissan vehicles at dealerships and we wanted to remind dealers again of the concerns.

12. Describe in detail, and provide copies of all documents relating to, Nissan's understanding of the potential adverse effects of various aftermarket re-chroming processes on wheel properties and field performance. Include an explanation of a proper chroming process and examples of improper processes and the effects on wheel material properties and structural integrity.

Genuine Nissan approved accessory or optional chromed wheels are manufactured to meet or exceed specified design standards for road wheels. Our suppliers are monitored for quality control procedures and adherence to standards. Genuine Nissan chromed wheels are created by chroming a wheel blank.

In contrast, some third parties in the aftermarket providers use a different process. Specifically, these third parties take original equipment wheels and remove the factory finish in order to chrome the wheels. We understand that the factory finish is removed by "burning" or by "chemical" methods. These methods may change the heat treatment of the alloy. Further, the application of chrome plating has the potential to affect the heat treatment of the OEM wheels, if it is not controlled correctly.

In summary, Nissan believes the process of removing the factory finish from the wheel prior to chroming and/or the chroming process used may change the heat treatment of the wheel alloy. Because of this, Nissan has issued two TSBs cautioning against aftermarket chroming of Nissan alloy wheels.

# 13. Furnish Nissan's assessment of the alleged defect in the subject vehicle, including:

- a. The causal or contributory factor(s);
- b. The failure mechanism(s);
- c. The failure mode(s);
- d. The risk to motor vehicle safety that it poses;
- e. What warnings, if any, the operator and the other persons both inside and outside the vehicle would have that the alleged defect was occurring or subject component was malfunctioning; and
- f. The reports included with this inquiry.

Nissan has received no consumer complaints; field reports; claims; reports involving a crash or an injury or a fatality; or property damage claims indicating that MY 2005 and 2006 350Z wheels in their original condition are experiencing wheel separations.

In connection with the incidents described in answers to questions 3 and 4, we have not had the opportunity to perform a metallurgical analysis. As indicated above, however, we understand that the process of chroming of a wheel that has already been manufactured with a final finish can affect the metallurgical structure of the wheel. For this reason, Nissan has issued two TSB's cautioning against aftermarket chroming of Nissan alloy wheels.

# **ATTACHMENT A**

CD with Vehicle sales information

This attachment contains a CD containing the information related to Request Numbers 1, 2, 3, 4, 5, 6 and 9. The information was obtained from the Consumer Affairs database, the Tech Line Database, and the field reports database as of February 1, 2007. Legal Department Files were searched on January 31, 2006. The databases and Legal Files are updated daily.

# **ATTACHMENT B**

# Warranty Claims Data

Warranty claims data were gathered from Warranty database as of February 1, 2007.

The total counts of warranty claims are as follows: 10

The search criteria used by Nissan to identify the claims identified in response to Request No. 6 is as follows:

# **PNC Codes**

40300 = Road Wheel

# **Word Search in Comments**

The following keywords were searched to identify claims in which the wheel may have cracked: "\*CRACK\*", "\*FRACTURE\*", "\*BROKE\*"

Descriptions of information in WARRANTY DATA response to Request No. 6 are as follows:

# **Labor Op Codes**

PW10AA = RPL ONE ROAD WHEEL/TIRE

PW101A = RPL ONE ADDITIONAL WHEEL/TIRE

# **ATTACHMENT C**

Vehicle Warranties



Summary of Warranty Coverage\*

<sup>\*</sup> See the express terms of the appropriate warranty printed in this booklet, which terms control if there is a conflict with this chart.

<sup>\*\*</sup> Sentra with 1.8 engine and California Emission Altima with 2.5 engine ONLY: Warranty coverage is 15 years/150,000 miles, whichever occurs first.

# NISSAN CARES...

Both Nissan and your Nissan dealer are dedicated to serving all your automotive needs. Your complete satisfaction with your vehicle and your Nissan dealer are our primary concerns. Your Nissan dealer is always available to assist you with all your automobile service requirements.

If, however, a situation arises that you believe has not been addressed to your satisfaction, we ask that you take the following steps:

#### STEP 1:

Discuss the situation with the dealership's manager. If a problem still exists, contact the dealership's Consumer Affairs Manager or owner. They are best equipped to resolve the matter for you.

#### STED 2

If the concern has still not been addressed to your satisfaction, please contact our (Nissan's) Consumer Affairs Department using our toll free number:



The Consumer Affairs Department will ask for the following information:

- Your name, address, and telephone number
- Vehicle identification number (on dashboard)
- Date of purchase
- Current odometer reading
- Your Nissan dealer's name
- Details of the concern

Or you can write to Nissan with the above information at:

Nissan North America, Inc. Consumer Affairs Department P.O. Box 191 Gardena, CA 90248

#### STEP 3

In the event that you believe Nissan has been unable to satisfactorily address the issue with your vehicle, a special automotive complaint resolution program called BBB AUTO LINE is available to you. The BBB AUTO LINE program is independently operated by the Council of Better Business Bureaus, Inc. (BBB).

For information about the BBB AUTO LINE in your area, please call us (Nissan) at the same toll free number (1-800-NISSAN-1). We will be happy to provide you with information about BBB AUTO LINE. Or, you may contact the BBB directly at:

BBB Auto Line Council of Better Business Bureaus, Inc. 4200 Wilson Blvd. Arlington, VA 22203 1 (800) 955-5100

If you call the BBB, its staff will take down details of your complaint by telephone. They will ask for the same information as described in Step 2.

The BBB AUTO LINE program consists of two parts, **mediation** and **arbitration**. The BBB will attempt to assist you to resolve the problem during mediation. If a satisfactory resolution has not been achieved during mediation, you will have the opportunity to personally present your case before an impartial arbitrator or three-person panel. The arbitrator(s) will make a decision after the arbitration hearing.

The BBB will, in most cases, send you a final decision within forty (40) days (plus 7 if you have not contacted the proper person from the dealership or Nissan) unless you delay the process. If you accept the decision, it will be legally binding on you and Nissan. If you do not accept the decision, it will not be legally binding on you or Nissan. (However in some states, if the decision is not accepted, it may be introduced either by you or by Nissan, as evidence in any potentially related court action.)

BBB AUTO LINE is an informal dispute settlement mechanism operated to comply with applicable Federal law and regulations. In states where BBB AUTO LINE is available, you are required to use BBB AUTO LINE before exercising rights or seeking remedies under Title I of the Federal Magnuson-Moss Warranty Act, 15 U.S.C. §2301, et. seq. If you choose to seek remedies other than those created by Title I of the Magnuson-Moss Warranty Act, (for example, under state law), that Federal Act does not require you to first use BBB AUTO LINE. The program is still available to you, however, and may be of considerable assistance. Some states specify that informal dispute settlement mechanisms such as BBB AUTO LINE must be used before you may use state-operated complaint resolution processes, before you may file a lawsuit under state law, and/or before you may have certain other rights or remedies available under state law. In accordance with those states' laws, Nissan requires the prior use of BBB AUTO LINE in good faith before you resort to such other processes, file a lawsuit, or seek other remedies provided by state law. Please see the "2005 Nissan Warranty Information Booklet & 2005 Nissan Owner's Manual" for additional information.

BBB AUTO LINE may not be available in all states. We, Nissan, would be pleased to provide you with information about the availability of BBB AUTO LINE in your state, or call the BBB AUTO LINE number listed above.

Nissan vehicles less than three years old from date of original delivery with fewer than 36,000 miles, are eligible for the BBB AUTO LINE program.

# TANCE OUTSIDE OF WARRANTY

ontinuing effort to convey our commitment to and customer satisfaction, Nissan may occapifier to pay or reimburse for part or all of the naking certain, specific repairs beyond or outhe terms of the warranty for some specific nodels. (Some states refer to such programs stment programs"). In such circumstances iails notices to all known registered owners of vehicles. You may additionally inquire of your d Nissan Dealer or of Nissan directly at the isted below of the applicability of such proyour vehicle.

Nissan may occasionally offer special assistance that may pay for part or all of vehicle repairs beyond the expiration of the limited warranty period on a case by case basis. Should you experience unusual difficulties with your vehicle please discuss the situation with your dealer. If your dealer is unable to assist you, you may call the Nissan Consumer Affairs Department at 1-800-NISSAN-1 to discuss your concern. You will need to provide the Model, Model Year, VIN (Vehicle Identification Number), mileage, maintenance history, a detailed explanation of the concern, and why you believe that Nissan should be responsible for the repair. Your request will be individually investigated and you will be informed of Nissan's decision.



Please also review the "Supplement to the 2005 Nissan Warranty Information Booklet & 2005 Nissan Owner's Manual" for important information concerning consumer rights in your state.

# WHO IS THE WARRANTOR

Nissan¹ warrants all parts of your 2005 Nissan vehicle supplied by Nissan, except for those listed elsewhere under the caption \*WHAT IS NOT COVERED."

#### **APPLICABILITY**

- This warranty is provided to the original and subsequent owner(s) of a Nissan vehicle originally distributed by Nissan which is originally sold by a Nissan authorized Nissan dealership in the United States, and which is registered in the U.S. and normally operated in the United States (including Alaska and Hawaii), the United States territories (specifically Guam, Saipan, American Samoa, Puerto Rico and the U.S. Virgin Islands), and Canada.
- This warranty is generally transferable from the original 'owner other than a Nissan dealer' (OWNER) to subsequent owners of the vehicle at any time ownership of the vehicle is transferred, without any action on your part; except that this warranty is not transferable but is instead void if during the first six months after delivery to the original OWNER: (1) ownership of the vehicle is transferred from the original OWNER, and (2) the vehicle is registered outside of the United States.
- Your Nissan vehicle is manufactured to meet U.S. regulations and environmental requirements. With the exception of privately owned vehicles belonging to members of the U.S. military or employees and officers of the United States Government stationed abroad, this warranty does not apply if an otherwise covered vehicle is operated in, or relocated to, a country other than those listed above under this caption, except that it continues to apply if the vehicle is operated in full compliance with its proper use as described in the applicable OWNER'S MANUAL² while touring outside of the United States, the U.S. territories or

Canada for a period not exceeding sixty (60) consecutive days or sixty (60) days in any one 12 month period. Subject to the transferability restriction described above, this warranty applies to a relocated vehicle which is returned to, and is registered and normally operated in the United States, the U.S. territories or Canada, except for conditions due to the vehicle's foreign operation, e.g., use of inappropriate fuels or other fluids.

# LIMITATION OF WARRANTIES AND OTHER WARRANTY TERMS AND STATE LAW RIGHTS

EXTRA EXPENSES - LIMITATIONS OF DAMAGES
This warranty does not cover incidental or consequential
damages such as loss of the use of the vehicle, inconvenience or commercial loss.

ANY IMPLIED WARRANTY OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE SHALL BE LIMITED TO THE DURATION OF THIS WRITTEN WARRANTY.

Some states do not allow the exclusion or limitation of incidental or consequential damages or limitations on how long an implied warranty lasts, so the above limitations or exclusions may not apply to you. This warranty gives you specific legal rights, and you may also have other rights which vary from state to state.

Nissan does not authorize any person to create for it any other warranty, obligation or liability in connection with this vehicle.

Nissan makes available to you, and you are specifically required by Federal Law to use BBB AUTO LINE [(800) 955-5100] before exercising rights or seeking remedies under the Federal Magnusom Moss Warranty Act, 15 U.S.C. §2301, et. seq. You are not required to first use BBB AUTO LINE if you seek remedies not created by Title I of that Federal law, but may be required to do so under state law, including your state lemon law. Please refer to pp. 2-3 of this booklet and the "Supplement to 2005 Nissan Warranty Information Booklet & 2005 Nissan Owner's Manual" for additional information.

### THE WARRANTY BEGINS

The warranty period begins on the date the vehicle is delivered to the first retail buyer or put into use, whichever is earlier.

# FOR HOW LONG AND WHAT IS COVERED

## BASIC COVERAGE

- The basic coverage period is 36 months or 36,000 miles, whichever comes first.
- This warranty covers any repairs needed to correct defects in materials or workmanship of all parts and components of each new Nissan vehicle supplied by Nissan except for the exclusions or items listed under the caption "WHAT IS NOT COVERED" or as indicated below.
- Bedliners will be repaired to commercially acceptable standards subject to the conditions and limitations listed in "WHAT IS NOT COVERED."

### **■ POWERTRAIN COVERAGE**

- The Powertrain coverage period is 60 months or 60,000 miles, whichever comes first.
- This warranty covers any repairs needed to correct defects in materials or workmanship.
- Powertrain coverage applies to components listed below, supplied by Nissan except for those items listed under the caption "WHAT IS NOT COVERED".

#### **ENGINE**

Cylinder heads and block and all internal parts, rocker covers and oil pan, valve train and front cover, timing chain and tensioner, oil pump, water pump and fuel pump, fuel injectors, intake and exhaust manifolds and supercharger, flywheel, seals, and gaskets.

### TRANSMISSION AND TRANSAXLE

Case and all internal parts, torque converter and converter housing, automatic transmission control module, transfer case and all internal parts, seals and gaskets, clutch cover and housing, and electronic transmission controls.

¹ Nissan indicates Nissan North America, Inc., P.O. Box 191, Gardena, California, 90248-0191 which distributes Nissan vehicles in the United States.

<sup>2</sup> See the Owner's Manual for information relevant to proper operation of the vehicle, including the recommended fuels and fluids.

#### IVETRAIN

ve shafts, final drive housing and all internal parts, peller shafts, universal joints, bearings, seals and gas-

# STRAINT SYSTEM

bags and related electronic control systems.

# )RROSION COVERAGE (PERFORATION FROM )RROSION)

y body sheet metal panel supplied by Nissan found to ve developed perforation (rust-through) due to corron in normal use is covered for 60 months, regardless of eage, except for those items listed under "WHAT IS DT COVERED". No additional rust proofing applications prequired. Perforation is a condition in which any body eet metal panel has corroded from one surface through another.

# RIGINAL EQUIPMENT BATTERY COVERAGE

e coverage period is 36 months or 36,000 miles, whicher comes first. A defective original equipment battery ich is unserviceable within the first 12 months and ,000 miles will be replaced free of charge. After 12 mths but within 24 months and 36,000 miles, you will y 50% of the replacement battery's suggested retail ce plus any applicable taxes. After 24 months but within i months and 36,000 miles, you will pay 75% of the blacement battery's suggested retail price plus any apcable taxes. Nissan will pay the rest, including all labor to move and replace the defective battery.

# **WING COVERAGE**

rour vehicle is inoperative due to the failure of a warranted urt, towing service to the nearest authorized asan dealer is covered for 36 months or 36,000 miles, nichever comes first.

### DJUSTMENTS

ervice adjustments not usually associated with the

replacement of parts, such as wheel alignment, are covered only during the first 12 months or 12,500 miles, whichever comes first.

### ■ REFRIGERANT RECHARGE ONLY

Refrigerant recharge not associated with the repair or replacement of a warranted part is covered only during the first 12 months, regardless of the mileage.

# **NO CHARGE**

Warranty repairs will be made at no charge for parts and/or labor (except for batteries and tires, in which case you may pay certain charges as noted above or as described in the applicable tire warranty found later in this booklet). Any needed parts replacement will be made using genuine Nissan or Nissan approved new or remanufactured parts.

# **OBTAINING WARRANTY SERVICE**

- You must take the vehicle to an authorized Nissan dealer in the United States or Canada during regular business hours at your expense in order to obtain warranty service. The names and addresses of authorized Nissan dealers are listed in telephone directories.
- If you require warranty service outside of the United States (see terms under caption "APPLICABILITY"), contact an authorized Nissan dealer in that country. Note that complaints related to failure to comply with proper use of the vehicle as described in the applicable OWNER'S MANUAL (including the lack of availability or use of proper fuel and fluids), or the vehicle's lack of compliance with local regulations or environmental requirements of any country (other

than the U.S., the listed U.S. territories or Canada) are <u>not</u> covered by this warranty.

# **MAINTENANCE AND RECORDS**

As a condition of this warranty, you are responsible for properly using, maintaining and caring for your vehicle as outlined in your OWNER'S MANUAL and your NISSAN SERVICE & MAINTENANCE GUIDE, and maintaining copies of all maintenance records & receipts for review by Nissan. Failure to do so is likely to result in the denial of warranty coverage.

Evidence of the performance of the required maintenance should be kept and presented as proof of such maintenance in connection with related warranty repairs. To assist you in maintaining appropriate records, the maintenance log located in your NISSAN SERVICE & MAINTENANCE GUIDE can be used along with supporting repair invoices, receipts and other such records.

(Continued on page 6)

(See following page for "WHAT IS NOT COVERED.")

### WHAT IS NOT COVERED

# DAMAGE, FAILURES OR CORROSION DUE TO ACCIDENTS, MISUSE OR ALTERATIONS

This warranty does not cover damage, failures or corrosion resulting from:

- Accident, theft, fire, driving through water (including engine water ingestion) or misuse (Proper use is outlined in your OWNER'S MANUAL).
- Alteration, tampering or improper repair.
- Installation of non-Nissan approved accessories or components.
- Improper installation of any Nissan approved or aftermarket accessory or component.
- Glass breakage, unless resulting from defects in material or workmanship.
- Normal wear and tear, including dings, dents, chips or scratches.

# **ALTERED OR UNCERTAIN ODOMETER MILEAGE**

This warranty does not cover repair of any vehicle or any part of a vehicle of which the odometer mileage has been altered, or the odometer repaired or replaced and the actual vehicle mileage cannot be correctly and readily determined.

### **SALVAGE TITLE**

This limited warranty does not apply to any vehicle, and is rendered void if the vehicle is (or ever has been) issued a "salvage" or similar title under any state's law; or has ever been determined to be a "total loss" or equivalent by any insurance company, such as by payment of a cash payment of claim in lieu of repairs because of a determination that the cost of repairs exceeded the actual cash value of the vehicle.

# DAMAGE, FAILURES OR CORROSION FROM ENVIRONMENTAL CONDITIONS

4

This warranty does not cover damage, failures or corrosion resulting from:

- Stone chipping, chemical fallout (acid rain), tree sap, salt, hail, wind-storm, lightning, flood or other environmental conditions.
- The items listed below are not covered under corrosion

coverage (perforation from corrosion).

- Exhaust system components.
- Corrosion of outer trim parts, such as moldings. However, corrosion of outer trim parts is warranted for 12 months or 12,500 miles, whichever comes first.
- Corrosion other than perforation, such as cosmetic or surface corrosion due to defects in materials or workmanship. This is covered under the Basic Coverage of the New Vehicle Limited Warranty.
- Special bodies or equipment not manufactured or supplied by Nissan.

# DAMAGE, FAILURES OR CORROSION DUE TO LACK OF OR IMPROPER MAINTENANCE

This warranty does not cover damage, failures or corrosion resulting from:

- Lack of performance of proper maintenance services as outlined in your NISSAN SERVICE & MAINTENANCE
- Use of improper or dirty fuel, fluids or lubricants.
- Use of parts not equivalent in quality or design to parts supplied by Nissan.

#### MAINTENANCE SERVICE EXPENSE

This warranty does not cover normal maintenance services as specified in your NISSAN SERVICE & MAINTENANCE GUIDE such as engine tune-up; cleaning and polishing; wheel alignment; headlight aiming; replacement of filters, replacement of windshield wiper inserts, lubricants, coolant; worn brake shoes, pads, drums and rotors and worn clutch diece.

# SEAT BELTS, TIRES, AND EMISSION CONTROL SYSTEM

Seat belts, tires, and the emission control system are not covered by this warranty, but are covered by separate warranties

(See following pages for separate warranties which may apply to your Nissan, such as those covering vehicle emissions, seat belts, and tires.)

### WHAT IS COVERED

Nissan\* warrants to correct defects in materials or work-manship in all genuine Nissan replacement parts, Genuine NISMO S-tune parts, and Genuine Nissan accessories, distributed by Nissan North America in the United States, installed and used on Nissan or Infiniti (if an appropriate use and application of the part, accessory, or Genuine NISMO S-tune part) vehicles only, except as described under the caption below, "WHAT IS NOT COVERED."

This warranty covers any repairs needed to correct defects in materials or workmanship. Bedliners will be repaired to commercially acceptable standards subject to the conditions and limitations listed in "WHAT IS NOT COVERED."

 Nissan indicates Nissan North American, Inc., P.O. Box 191, Gardena, California 90248-0191 which distributes and provides consumer services for Nissan Vehicles in the United States.

# **HOW LONG IS THE WARRANTY**

Except for replacem ent audio components, this warranty is for 12 months or 12,000 miles from the date of installation or purchase, whichever is earlier. However, the warranty on Genuine Nissan replacement parts, Genuine NISMO S-tune parts, and Genuine Nissan accessories installed in a Nissan or Infiniti vehicle while the vehicle is covered by a Nissan warranty, which would have covered the part had it been installed in the vehicle at manufacture, will not end before the end of that warranty.

### **REPLACEMENT AUDIO COMPONENTS**

A replacement Radio, Tape Deck, Amplifier or Compact Disc Player/Auto Changer or Cellular Phone supplied by Nissan is covered for 12 months/unlimited mileage from the time of installation or the balance of the Basic Vehicle Warranty as it applies to audio components, whichever is greater.

## WHAT IS NOT COVERED

This warranty does not cover:

- Tires or batteries. These items are covered by separate warranties.
- Nissan Motorsports and NISMO R-tune parts, including NISMO Legacy parts are sold "AS IS" without warranties, express or implied unless expressly prohibited from doing so by applicable law, in which case the warranty provided is the minimum required by law.
- Normal maintenance service and parts replacement as outlined in the maintenance schedule of your OWNER'S MANUAL.
- 4. Damage or failures of parts resulting from:
  - Misuse (your OWNER'S MANUAL is your guide to proper use).
  - Accident, theft, fire, driving through water resulting in engine water ingestion.
  - Chemical fallout, tree sap, salt, sand, hail, flood or other environmental conditions.
  - Modification or improper repair of the part or of the vehicle in which the part is installed.
  - Use of parts not equivalent in quality or design to parts supplied by Nissan.
  - Lack of performance of required maintenance services as outlined in your OWNER'S MANUAL.
  - Use of improper or dirty fuel, fluids or lubricants.
  - Normal wear and tear, including dings, dents, dents, chips or scratches.
- 5. SALVAGE TITLE. This warranty does not cover damage, failures or corrosion to any Nissan replacement part, Genuine NISMO S-Tune Part, or Genuine Nissan Accessory, installed in the vehicle, if the vehicle is issued a "salvage" or similar title. (This exclusion does not extend to

new Genuine Nissan replacement parts, NISMO S-tune parts or Genuine Nissan accessories, installed in a Nissan or Infiniti vehicle after the issuance of a "salvage" or similar title.)

# WHAT YOU MUST DO

In order to obtain warranty service you must deliver the warranted part or accessory, or the vehicles, on which the part or accessory is installed, to an authorized Nissan or Infiniti dealer in the United States or Canada at your expense with proof of purchase (parts invoice or service repair order from an authorized Nissan or Infiniti dealer). (Continued on page 39)

# LIMITATION OF WARRANTIES AND OTHER WARRANTY TERMS AND STATE LAW RIGHTS

EXTRA EXPENSES - LIMITATIONS OF DAMAGES
This warranty does not cover incidental or
consequential damages such as loss of the use
of the vehicle, inconvenience or commercial
loss.

ANY IMPLIED WARRANTY OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE SHALL BE LIMITED TO THE DURATION OF THIS WRITTEN WARRANTY.

Some states do not allow the exclusion or limitation of incidental or consequential damages or limitations on how long an implied warranty lasts, so the above limitations or exclusions may not apply to you. This warranty gives you specific legal rights, and you may also have other rights, which vary from state to state.

Nissan does not authorize any person to create for it any other warranty, obligation or liability in connection with this vehicle. Part No. RPLW001, Rev. 12/03

d addresses of authorized Nissan and Infiniti ted in telephone directories.

pay for labor charges to remove and replace essory if it was not originally installed on your authorized Nissan or Infiniti dealer.

# SAN WILL DO

accessory to be repaired was originally authorized Nissan or Infiniti dealer, it will be installed after repair at no charge for parts a part or accessory was not installed by an an or Infiniti dealer, the part or accessory or exchanged only. Any needed parts exchange will be made using new or parts at Nissan's option.

saler Name

h America, Inc. and your Nissan dealer here are numerous sources for parts and in today's automotive parts aftermarket. enuine Nissan parts and accessories are d manufactured to meet the same factory ce and quality specifications of your Nissan

partment of your Nissan dealership mainplete inventory of high quality Genuine and remanufactured replacement parts are backed by one of the most comarts warranties available in the automotive ay.

at your warranty, maintenance and repair nents are satisfied as quickly as possible, he Nissan dealer organization maintain inventory consisting of several hundred worth of readily available parts and popular in the event a critical part is required ocked by your local dealership, Nissan's em includes a computerized means of quickest possible shipment to Nissan use of expeditious handling and premium 1 - all of which is supported by one of nsive and efficient parts distribution sys-

North America, Inc. Regional Parts Disers stock approximately 32,000 different

parts and each of five additional Area Parts Distribution Centers service over 61,000 part numbers. Nissan's Master Parts Distribution Center in Compton, California maintains an inventory of 150,000 low volume part numbers and services all Nissan dealers nationally to ensure that even the most rarely ordered parts are available in the quickest possible time. Additionally, all Nissan parts distribution facilities are linked via a sophisticated computer search and order system to ensure coordinated parts ordering, inventory and distribution. Through this system, you are assured of maximum parts availability at the time the parts are needed to keep your Nissan vehicle on the road not in the shop.

The Nissan name represents quality and a commitment to your satisfaction as a valued customer. So when you select parts or accessories for your Nissan vehicle, see your Nissan dealer. Only Nissan builds Nissan replacement parts and accessories to exact factory specifications.

# RECOMMENDATION FOR MAINTENANCE SERVICE AND REPLACEMENT PARTS FOR YOUR VEHICLE'S EMISSION SYSTEM

To assure best results and to maintain the original quality built into the emission control systems, it is recommended that genuine Nissan parts be used when

Servicing or repairing the systems. THE WARRANTY OBLIGATIONS ARE NOT DEPENDENT UPON THE USE OF ANY PARTICULAR BRAND OF REPLACEMENT PARTS AND THE OWNER MAY ELECT TO USE NON-GENUINE NISSAN PARTS FOR REPLACEMENT PURPOSES.

The use of replacement parts which are not equivalent to genuine Nissan parts may reduce the effectiveness of the emission control system.

Therefore, if it becomes necessary to use other than genuine Nissan parts, the owner should assure himself that such parts are warranted by their manufacturer to be equivalent in quality to genuine Nissan parts.

MAINTENANCE, REPLACEMENT OR REPAIR OF THE EMISSION CONTROL DEVICES AND SYS-TEMS MAY BE PERFORMED BY ANY AUTO-MOTIVE REPAIR ESTABLISHMENT OR INDI-VIDUAL USING ANY REPLACEMENT PART.

HOWEVER, UNLESS OTHERWISE AUTHORIZED BY LAW, WARRANTY SERVICE MUST BE PER-FORMED BY AN AUTHORIZED NISSAN DEALER.

The emission standards may be satisfied by having the vehicle inspected periodically and by following the requirements outlined in your OWNER'S MANUAL and your NISSAN SERVICE MAINTENANCE GUIDE.

# **NISSAN**

©2004 Nissan North America, Inc. All rights reserved.

05 DP05

Printing: May 2004



# 2806 WARRANTY INFORMATION ESOMET

1	SUMMARY OF WARRANTY COVERAGE AT A GLANCE	14	SEAT BELT LIMITED WARRANTY
2	NISSAN'S CUSTOMER CARE PROGRAM	15	BFGOODRICH TIRE LIMITED WARRANTY
4.	MISSAN'S COSTOWER CARE PROGRAM		
3	NISSAN'S COMMITMENT TO CUSTOMER SATISFACTION	17	BRIDGESTONE / FIRESTONE TIRE LIMITED WARRANTY
4	2006 NEW VEHICLE LIMITED WARRANTY	19	DUNLOP PASSENGER TIRE LIMITED WARRANTY
7	FEDERAL VEHICLE EMISSION CONTROL LIMITED WARRANTIES	23	GENERAL TIRE LIMITED WARRANTY
10	CALIFORNIA VEHICLE EMISSION CONTROL WARRANTIES	26	GOODYEAR TIRE LIMITED WARRANTY

28	MICHELIN TIRE LIMITED WARRANTY	41	GENUINE NISSAN ORIGINAL EQUIPMENT MUFFLER, GENUINE NISSAN SHOCK
30	TOYO TIRE LIMITED WARRANTY		ABSORBER AND STRUT LIFETIME LIMITED WARRANTY
32	ORIGINAL EQUIPMENT TIRE LIMITED WARRANTIES	43	REPLACEMENT BATTERY LIMITED WARRANTY
33	IMPORTANT TIRE SAFETY INFORMATION	44	GENUINE NISSAN PARTS AND ACCESSORIES
38	LIMITED WARRANTY ON GENUINE NISSAN REPLACEMENT PARTS, GENUINE NISMO S-TUNE PARTS, AND GENUINE NISSAN ACCESSORIES	45	CORROSION PROTECTION GUIDELINES
		46	NISSAN'S SECURITY+PLUS®
40	SUMMARY OF NISSAN LIFETIME REPLACEMENT PANEL CORROSION WARRANTY		VEHICLE PROTECTION PLAN

Summary of Warranty Coverage\*

36 months / 36,000 miles

36 months / 36,000 miles

60 months / UNLIMITED MILEAGE

60 months / 60,000 miles

24 months / 24,000 miles

36 months / 36,000 miles

96 months / 80,000 miles

36 months / 50,000 miles\*\*

36 months / 50,000 miles\*\*

120 months/unlimited mileage

<sup>\*</sup> See the express terms of the appropriate warranty printed in this booklet, which terms control if there is a conflict with this chart.

<sup>\*\*</sup> California Emission Altima with 2.5 engine ONLY: Warranty coverage is 15 years/150,000 miles, whichever occurs first.

# NISSAN CARES...

Both Nissan and your Nissan dealer are dedicated to serving all your automotive needs. Your complete satisfaction with your vehicle and your Nissan dealer are our primary concerns. Your Nissan dealer is always available to assist you with all your automobile service requirements.

If, however, a situation arises that you believe has not been addressed to your satisfaction, we ask that you take the following steps:

#### STEP 1:

Discuss the situation with the dealership's manager. If a problem still exists, contact the dealership's Consumer Affairs Manager or owner. They are best equipped to resolve the matter for you.

### STEP 2:

If the concern has still not been addressed to your satisfaction, please contact our (Nissan's) Consumer Affairs Department using our toll free number:



The Consumer Affairs Department will ask for the following information:

- Your name, address, and telephone number
- Vehicle identification number (on dashboard)
- Date of purchase
- Current odometer reading
- Your Nissan dealer's name
- Details of the concern

Or you can write to Nissan with the above information at:

Nissan North America, Inc. Consumer Affairs Department P.O. Box 191 Gardena, CA 90248

#### STEP 3:

In the event that you believe Nissan has been unable to satisfactorily address the issue with your vehicle, a special automotive complaint resolution program called BBB AUTO LINE is available to you. The BBB AUTO LINE program is independently operated by the Council of Better Business Bureaus, Inc. (BBB).

For information about the BBB AUTO LINE in your area, please call us (Nissan) at the same toll free number (1-800-NISSAN-1). We will be happy to provide you with information about BBB AUTO LINE. Or, you may contact the BBB directly at:

BBB Auto Line Council of Better Business Bureaus, Inc. 4200 Wilson Blvd. Arlington, VA 22203 1 (800) 955-5100

If you call the BBB, its staff will take down details of your complaint by telephone. They will ask for the same information as described in Step 2.

The BBB AUTO LINE program consists of two parts, mediation and arbitration. The BBB will attempt to assist you to resolve the problem during mediation. If a satisfactory resolution has not been achieved during mediation, you will have the opportunity to personally present your case before an impartial arbitrator or three-person panel. The arbitrator(s) will make a decision after the arbitration hearing.

The BBB will, in most cases, send you a final decision within forty (40) days (plus 7 if you have not contacted the proper person from the dealership or Nissan) unless you delay the process. If you accept the decision, it will be legally binding on you and Nissan. If you do not accept the decision, it will not be legally binding on you or Nissan. (However in some states, if the decision is not accepted, it may be introduced either by you or by Nissan, as evidence in any potentially related court action.)

BBB AUTO LINE is an informal disoute settlement mechanism operated to comply with applicable Federal law and regulations. In states where BBB AUTO LINE is available, you are required to use BBB AUTO LINE before exercising rights or seeking remedies under Title I of the Federal Magnuson-Moss Warranty Act, 15 U.S.C. §2301, et. seq. If you choose to seek remedies other than those created by Title I of the Magnuson-Moss Warranty Act, (for example, under state law), that Federal Act does not require you to first use BBB AUTO LINE. The program is still available to you, however, and may be of considerable assistance. Some states specify that informal dispute settlement mechanisms such as BBB AUTO LINE must be used before you may use state-operated complaint resolution processes, before you may file a lawsuit under state law, and/or before you may have certain other rights or remedies available under state law. In accordance with those states' laws, Nissan requires the prior use of BBB AUTO LINE in good faith before you resort to such other processes, file a lawsuit, or seek other remedies provided by state law. Please see the "2006 Nissan Warranty Information Booklet & 2006 Nissan Owner's Manual" for additional information.

BBB AUTO LINE may not be available in all states. We, Nissan, would be pleased to provide you with information about the availability of BBB AUTO LINE in your state, or call the BBB AUTO LINE number listed above.

Nissan vehicles less than three years old from date of original delivery with fewer than 36,000 miles, are eligible for the BBB AUTO LINE program.

# **INCE OUTSIDE OF WARRANTY**

inuing effort to convey our commitment to I customer satisfaction, Nissan may occarr to pay or reimburse for part or all of the ing certain, specific repairs beyond or outterms of the warranty for some specific tels. (Some states refer to such programs nent programs"). In such circumstances s notices to all known registered owners of nicles. You may additionally inquire of your Nissan Dealer or of Nissan directly at the ad below of the applicability of such prour vehicle.

Nissan may occasionally offer special assistance that may pay for part or all of vehicle repairs beyond the expiration of the limited warranty period on a case by case basis. Should you experience unusual difficulties with your vehicle please discuss the situation with your dealer. If your dealer is unable to assist you, you may call the Nissan Consumer Affairs Department at 1-800-NISSAN-1 to discuss your concern. You will need to provide the Model, Model Year, VIN (Vehicle Identification Number), mileage, maintenance history, a detailed explanation of the concern, and why you believe that Nissan should be responsible for the repair. Your request will be individually investigated and you will be informed of Nissan's decision.



Please also review the "Supplement to the 2006 Nissan Warranty Information Booklet & 2006 Nissan Owner's Manual" for important information concerning consumer rights in your state.

# **WHO IS THE WARRANTOR**

Nissan¹ warrants all parts of your 2006 Nissan vehicle supplied by Nissan, except for those listed elsewhere under the caption "WHAT IS NOT COVERED."

## **APPLICABILITY**

- This warranty is provided to the original and subsequent owner(s) of a Nissan vehicle originally distributed by Nissan which is originally sold by a Nissan authorized Nissan dealership in the United States, and which is registered in the U.S. and normally operated in the United States (including Alaska and Hawaii), the United States territories (specifically Guam, Saipan, American Samoa, Puerto Rico and the U.S. Virgin Islands), and Canada.
- This warranty is generally transferable from the original 'owner other than a Nissan dealer' (OWNER) to subsequent owners of the vehicle at any time ownership of the vehicle is transferred, without any action on your part; except that this warranty is not transferable but is instead void if during the first six months after delivery to the original OWNER: (1) ownership of the vehicle is transferred from the original OWNER, and (2) the vehicle is registered outside of the United States.
- Your Nissan vehicle is manufactured to meet U.S. regulations and environmental requirements. With the exception of privately owned vehicles belonging to members of the U.S. military or employees and officers of the United States Government stationed abroad, this warranty does not apply if an otherwise covered vehicle is operated in, or relocated to, a country other than those listed above under this caption, except that it continues to apply if the vehicle is operated in full compliance with its proper use as described in the applicable OWNER'S MANUAL² while touring outside of the United States, the U.S. territories or Canada for a period not exceeding sixty (60) consecutive days or sixty (60) days in any one 12 month period. Subject to the

transferability restriction described above, this warranty applies to a relocated vehicle which is returned to, and is registered and normally operated in the United States, the U.S. territories or Canada, except for conditions due to the vehicle's foreign operation, e.g., use of inappropriate fuels or other fluids.

# LIMITATION OF WARRANTIES AND OTHER WARRANTY TERMS AND STATE LAW RIGHTS

EXTRA EXPENSES - LIMITATIONS OF DAMAGES
This warranty does not cover incidental or consequential
damages such as loss of the use of the vehicle, inconvenience or commercial loss.

ANY IMPLIED WARRANTY OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE SHALL BE LIMITED TO THE DURATION OF THIS WRITTEN WARRANTY.

Some states do not allow the exclusion or limitation of incidental or consequential damages or limitations on how long an implied warranty lasts, so the above limitations or exclusions may not apply to you. This warranty gives you specific legal rights, and you may also have other rights which vary from state to state.

Nissan does not authorize any person to create for it any other warranty, obligation or liability in connection with this vehicle.

Nissan makes available to you, and you are specifically required by Federal Law to use BBB AUTO LINE [(800) 955-5100] before exercising rights or seeking remedies under the Federal Magnuson-Moss Warranty Act, 15 U.S.C. §2301, et. seq. You are not required to first use BBB AUTO LINE if you seek remedies not created by Title 1 of that Federal law, but are required to first use BBB AUTO LINE if you seek remedies created by state law, including your state's lemon law, if applicable state law provides for using a 703 compliant or similar process before filing suit. Please refer to pp. 2-3 of this booklet and the "Supplement to 2006 Nissan Warranty Information Booklet & 2006 Nissan Owner's Manual" for additional information.

### THE WARRANTY BEGINS

The warranty period begins on the date the vehicle is delivered to the first retail buyer or put into use, whichever is earlier,

# FOR HOW LONG AND WHAT IS COVERED

#### M BASIC COVERAGE

- The basic coverage period is 36 months or 36,000 miles, whichever comes first.
- This warranty covers any repairs needed to correct defects in materials or workmanship of all parts and components of each new Nissan vehicle supplied by Nissan except for the exclusions or items listed under the caption "WHAT IS NOT COVERED" or as indicated below.
- Bedliners will be repaired to commercially acceptable standards subject to the conditions and limitations listed in "WHAT IS NOT COVERED."

#### ■ POWERTRAIN COVERAGE

- The Powertrain coverage period is 60 months or 60,000 miles, whichever comes first.
- This warranty covers any repairs needed to correct defects in materials or workmanship.
- Powertrain coverage applies to components listed below, supplied by Nissan except for those items listed under the caption "WHAT IS NOT COVERED".

#### **ENGIN**

Cylinder heads and block and all internal parts, rocker covers and oil pan, valve train and front cover, timing chain and tensioner, oil pump, water pump and fuel pump, fuel injectors, intake and exhaust manifolds and supercharger, flywheel, seals, and gaskets.

# TRANSMISSION AND TRANSAXLE

Case and all internal parts, torque converter and converter housing, automatic transmission control module, transfer case and all internal parts, seals and gaskets, clutch cover and housing, and electronic transmission controls.

<sup>1</sup> Nissan indicates Nissan North America, Inc., P.O. Box 191, Gardena, California, 90248-0191 which distributes Nissan vehicles in the United States.

<sup>2</sup> See the Owner's Manual for information relevant to proper operation of the vehicle, including the recommended fuels and fluids.

#### ETRAIN

shafts, final drive housing and all internal parts, ler shafts, universal joints, bearings, seals and gas-

#### **RAINT SYSTEM**

gs and related electronic control systems.

# OSION COVERAGE (PERFORATION FROM OSION)

idy sheet metal panel supplied by Nissan found to eveloped perforation (rust-through) due to corronomal use is covered for 60 months, regardless of a, except for those items listed under "WHAT IS OVERED". No additional rust proofing applications uired. Perforation is a condition in which any body het.

# **NAL EQUIPMENT BATTERY COVERAGE**

erage period is 36 months or 36,000 miles, whichmes first. A defective original equipment battery s unserviceable within the first 12 months and miles will be replaced free of charge. After 12 but within 24 months and 36,000 miles, you will be of the replacement battery's suggested retail sany applicable taxes. After 24 months but within the and 36,000 miles, you will pay 75% of the nent battery's suggested retail price plus any aptaxes. Nissan will pay the rest, including all labor to and replace the defective battery.

### G COVERAGE

hicle is inoperative due to the failure of a warranted wing service to the nearest authorized lealer is covered for 36 months or 36,000 miles, ar comes first.

#### **IMENTS**

adjustments not usually associated with the

replacement of parts, such as wheel alignment, are covered only during the first 12 months or 12,000 miles, whichever comes first.

### **■ REFRIGERANT RECHARGE ONLY**

Refrigerant recharge not associated with the repair or replacement of a warranted part is covered only during the first 12 months, regardless of the mileage.

# **NO CHARGE**

Warranty repairs will be made at no charge for parts and/or labor (except for batteries and tires, in which case you may pay certain charges as noted above or as described in the applicable tire warranty found later in this booklet). Any needed parts replacement will be made using genuine Nissan or Nissan approved new or remanufactured parts.

# **OBTAINING WARRANTY SERVICE**

- You must take the vehicle to an authorized Nissan dealer in the United States or Canada during regular business hours at your expense in order to obtain warranty service. The names and addresses of authorized Nissan dealers are listed in telephone directories.
- If you require warranty service outside of the United States (see terms under caption "APPLICABILITY"), contact an authorized Nissan dealer in that country. Note that complaints related to failure to comply with proper use of the vehicle as described in the applicable OWNER'S MANUAL (including the lack of availability or use of proper fuel and fluids), or the vehicle's lack of compliance with local regulations or environmental requirements of any country (other

than the U.S., the listed U.S. territories or Canada) are <u>not</u> covered by this warranty.

# **MAINTENANCE AND RECORDS**

As a condition of this warranty, you are responsible for properly using, maintaining and caring for your vehicle as outlined in your OWNER'S MANUAL and your NISSAN SERVICE & MAINTENANCE GUIDE, and maintaining copies of all maintenance records & receipts for review by Nissan. Failure to do so is likely to result in the denial of warranty coverage.

Evidence of the performance of the required maintenance should be kept and presented as proof of such maintenance in connection with related warranty repairs. To assist you in maintaining appropriate records, the maintenance log located in your NISSAN SERVICE & MAINTENANCE GUIDE can be used along with supporting repair invoices, receipts and other such records.

(Continued on page 6)

SOME THE PROPERTY OF THE STATE OF THE STATE

(See following page for "WHAT IS NOT COVERED.")

# WHAT IS NOT COVERED DAMAGE, FAILURES OR CORROSION DUE TO ACCIDENTS, MISUSE OR ALTERATIONS

This warranty does not cover damage, failures or corrosion resulting from:

- Accident, theft, fire, driving through water (including engine water ingestion) or misuse (Proper use is outlined in your OWNER'S MANUAL).
- Alteration, tampering or improper repair.
- Installation of non-Nissan approved accessories or components.
- İmproper installation of any Nissan approved or aftermarket accessory or component.
- Glass breakage, unless resulting from defects in material or workmanship.
- Normal wear and tear, including dings, dents, chips or scratches

# ALTERED OR UNCERTAIN ODOMETER MILEAGE

This warranty does not cover repair of any vehicle or any part of a vehicle of which the odometer mileage has been altered, or the odometer repaired or replaced and the actual vehicle mileage cannot be correctly and readily determined.

### **SALVAGE TITLE**

This limited warranty does not apply to any vehicle, and is rendered void if the vehicle is (or ever has been) issued a "salvage" or similar title under any state's law; or has ever been determined to be a "total loss" or equivalent by any insurance company, such as by payment of a cash payment of claim in lieu of repairs because of a determination that the cost of repairs exceeded the actual cash value of the vehicle.

# DAMAGE, FAILURES OR CORROSION FROM ENVIRONMENTAL CONDITIONS

This warranty does not cover damage, failures or corrosion resulting from:

- Stone chipping, chemical fallout (acid rain), tree sap, salt, hail, wind-storm, lightning, flood or other environmental
- The items listed below are not covered under corrosion

ä.

coverage (perforation from corrosion).

- Exhaust system components.
- Corrosion of outer trim parts, such as moldings. However, corrosion of outer trim parts is warranted for 12 months or 12,500 miles, whichever comes first.
- Corrosion other than perforation, such as cosmetic or surface corrosion due to defects in materials or workmanship. This is covered under the Basic Coverage of the New Vehicle Limited Warranty.
- Special bodies or equipment not manufactured or supplied by Nissan.

# DAMAGE, FAILURES OR CORROSION DUE TO LACK OF OR IMPROPER MAINTENANCE

This warranty does not cover damage, failures or corrosion resulting from:

- Lack of performance of proper maintenance services as outlined in your NISSAN SERVICE & MAINTENANCE
- Use of improper or dirty fuel, fluids or lubricants.
- Use of parts not equivalent in quality or design to parts supplied by Nissan.

# MAINTENANCE SERVICE EXPENSE

This warranty does not cover normal maintenance services as specified in your NISSAN SERVICE & MAINTENANCE GUIDE such as engine tune-up; cleaning and polishing; wheel alignment; headlight aiming; replacement of filters, replacement of windshield wiper inserts, lubricants, coolant; worn brake shoes, pads, drums and rotors and worn clutch discs.

# SEAT BELTS, TIRES, AND EMISSION CONTROL SYSTEM

Seat belts, tires, and the emission control system are not covered by this warranty, but are covered by separate warranties.

(See following pages for separate warranties which may apply to your Nissan, such as those covering vehicle emissions, seat belts, and tires.)

# **ION DEFECTS WARRANTY**

warrants that your vehicle was designed, d equipped to conform at the time of sale applicable United States emission stan-

rranty covers any repairs needed to correct in materials or workmanship which would our vehicle not to meet these standards.

# IS COVERED UNDER THE DEFECTS ANTY

components are listed below under the cap-ARRANTY PARTS LIST." Exceptions to this are listed below under the caption "WHAT IS VERED UNDER EITHER THE DEFECTS OR MANCE WARRANTIES."

# **ONG IS THE DEFECTS WARRANTY**

anty is for 3 years or 36,000 miles, whichever st. The warranty begins the date the vehicle is to the first retail buyer or put into use, whichever Additionally, the engine control module/onboard c device and catalytic converter(s) listed below ated by an "O" under the caption "Warranty t" are covered for 8 years or 80,000 miles, r occurs first.

# IONS PERFORMANCE WARRANTY DOES THIS WARRANTY APPLY

sion Performance warranty applies to your 2006 hicle ONLY when both of the following occur. shicle fails to meet applicable emissions stan-

- dards as judged by an emissions test approved by the Environmental Protection Agency (EPA).
- This failure results or will result in some penalty to you, such as a monetary fine or the denial of the right to use your vehicle, under local, state or federal law.

For example, if your state requires an EPA approved yearly vehicle inspection before you receive a renewed license, this warranty applies to your vehicle. In areas where there is no approved test program, this warranty does not apply.

# WHAT IS COVERED AND FOR HOW LONG UNDER THE PERFORMANCE WARRANTY

Nissan¹ warrants that it will remedy any non-conformity in your vehicle which causes it to fail an approved emissions test during the first 24 months or 24,000 miles, whichever occurs first. This warranty begins the date the vehicle is delivered to the first retail buyer or put in to use, whichever is earlier.

Additionally, failure of an approved emissions test resulting from the failure of those parts listed below under the caption "Warranty Parts List" are covered by the Emissions Defects Warranty described above.

Exceptions to this warranty are listed below under the caption "WHAT IS NOT COVERED UNDER EITHER THE DEFECTS OR PERFORMANCE WARRANTIES."

# LIMITATION OF WARRANTIES AND OTHER WARRANTY TERMS AND STATE LAW RIGHTS

EXTRA EXPENSES - LIMITATIONS OF DAMAGES

These emissions warranties do not cover incidental or consequential damages such as loss of the use of the vehicle, inconvenience or commercial loss.

ANY IMPLIED WARRANTY OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE SHALL BE LIMITED TO THE DURATION OF THESE WRITTEN WARRANTIES.

Some states do not allow the exclusion or limitation of incidental or consequential damages or limitations on how long an implied warranty lasts, so the above limitations or exclusions may not apply to you. These warranties give you specific legal rights, and you may also have other rights which vary from state to state.

Nissan does not authorize any person to create for it any other warranty, obligation or liability in connection with this vehicle.

(Continued on page 8)

ndicates Nissan North America, Inc., P.O. Box 191, Gardena, California 90248-0191 which distributes Nissan vehicles nited States.

# WHAT IS NOT COVERED UNDER EITHER THE DEFECTS OR PERFORMANCE WARRANTIES

These warranties do not cover:

- Normal maintenance, service and parts replacement as outlined in the emissions control maintenance instructions of your OWNER'S MANUAL and your NISSAN SERVICE & MAINTENANCE GUIDE.
- 2. Failures directly as a result of:
  - Failure to perform required emission control maintenance as outlined in your OWNER'S MANUAL and your NISSAN SERVICE & MAINTENANCE GUIDE.
  - Misuse, accident or modification.
  - Improper adjustment or installation of parts during the performance of maintenance services.
  - Tampering with or disconnecting any part affecting vehicle emissions.
  - The use of contaminated fuel or fuel other than that specified in your OWNER'S MANUAL.
- In the case of the Performance Warranty, the use of any part not certified in accordance with Federal requirements which is defective or not equivalent from an emissions standpoint to the original equipment part.
- In the case of the Performance Warranty, costs of determining the cause of a vehicle failing an EPA approved emissions test if such failure is found not to be covered.
- In the case of the Defects Warranty, parts not supplied by Nissan or damage to other parts caused directly by non-Nissan parts.

# WHAT YOU MUST DO

In order to obtain warranty service you must deliver the vehicle to an authorized Nissan dealer in the United States at your expense.

You must also maintain your vehicle as outlined in the maintenance instructions in your NISSAN SERVICE & MAINTENANCE GUIDE.

# WHAT NISSAN WILL DO

Warranty repairs will be made at no charge for parts and/ or labor, including diagnosis and tax. Any needed parts replacement will be made using new or remanufactured parts.

# OTHER WARRANTY TERMS PERFORMANCE WARRANTY CLAIMS PROCEDURE

You may make a claim under the Performance Warranty immediately after the failure of an EPA approved emissions test. You must provide proof of this failure when making your claim.

You will be told whether Nissan will honor your claim within 30 days of the date you make the claim unless a shorter time period is required by law. If your claim is denied, Nissan will notify you in writing of the reason. If we do not notify you within this time period, we will repair your vehicle under this warranty at no cost to you. The time period for notification will not apply if you request a delay or a delay is caused by events not under the control of Nissan dealers.

No claim will be denied under the Performance Warranty because you use a non-Nissan but EPA certified part for maintenance or repair.

# MAINTENANCE SERVICE AND REPLACEMENT PARTS

Important information concerning maintenance service and replacement parts is in the Limited Warranty on Nissan Parts and Accessories section of this booklet.

### **MAINTENANCE RECORDS**

Receipts covering the performance of regular maintenance should be kept in the event questions arise concerning maintenance. The receipts should be transferred to subsequent owners.

# IF YOU HAVE QUESTIONS

You may obtain further information concerning these warranties by following the procedure outlined in the "CUSTOMER CARE" section of this booklet. In the case of the Performance Warranty, you may also contact or report any violations to the Office of Transportation and Air Quality, Vehicle Compliance Programs Group, U.S. Environmental Protection Agency, Ariel Rios Building (6405J), 1200 Pennsylvania Avenue, N.W, Washington, D.C. 20460

(Continued on page 9)

# **RRANTY PARTS LIST**

Fuel injection system

 Engine control module/onboard diagnostic device

Oxygen sensor(s)

Mass air flow sensor

Intake manifold

Throttle body

) Catalytic converter(s)

Exhaust manifold(s)

Exhaust tube from manifold to catalytic

converter

Camshaft position sensor(s)

Crankshaft position sensor(s)

Spark plugs, ignition coil and wires

Ignition control module

- Evaporative emission control system
- Fuel filler neck restrictor and check valve
- Fuel tank and filler cap
- Idle air control system
- · Positive crankcase ventilation system
- Exhaust gas recirculation (EGR) control system
- Pulsed secondary air injection system and valves
- Hoses, clamps, fittings, tubing, sealing gaskets or devices and mounting hardware used in above systems
- Vacuum and temperature sensitive valves and switches used in above systems
- Electronic sensors and controls used in above systems

The Emission Performance or Defect Warranty may be subject to future governmental administrative action. Nissan reserves the right to change the terms of the warranty to be consistent with these actions. See your dealer for information regarding possible changes.

The following statement is required to be provided by regulations of the California Air Resources Board.

## YOUR WARRANTY RIGHTS AND OBLIGATIONS

The California Air Resources Board is pleased to explain the emission control system warranty on your 2006 vehicle. In California, new motor vehicles must be designed, built and equipped to meet the State's stringent anti-smog standards. Nissan¹ must warrant the emission control system on your vehicle for the periods of time listed below provided there has been no abuse, neglect or improper maintenance of your vehicle.

Your emission control system may include parts such as the fuel-injection system, the ignition system, catalytic converter and engine computer. Also included may be hoses, belts, connectors and other emission-related assemblies.

Where a warrantable condition exists, Nissan will repair your vehicle at no cost to you including diagnosis, parts and labor.

## MANUFACTURER'S WARRANTY COVERAGE<sup>5</sup>

For 3 years or 50,000 miles (whichever occurs first):

 If your vehicle fails a Smog Check inspection, all necessary repairs and adjustments will be made by Nissan to ensure that your vehicle passes the inspection. This is your emission control system PERFORMANCE WARRANTY.

 If any emission-related part on your vehicle is defective, the part will be repaired or replaced by Nissan. This is your short-term emission control system DEFECTS WARRANTY.

For 7 years or 70,000 miles (whichever occurs first):

If an emission-related part listed in this warranty booklet specially noted with coverage for 7 years or 70,000 miles is defective, the part will be repaired or replaced by Nissan. This is your long-term emission control system DEFECTS WARRANTY.

## OWNER'S WARRANTY RESPONSIBILITIES

As the vehicle owner, you are responsible for the performance of the required maintenance listed in your owner's manual. Nissan recommends that you retain all receipts covering maintenance on your vehicle, but Nissan cannot deny warranty solely for the lack of receipts or for your failure to ensure the performance of all scheduled maintenance.

You are responsible for presenting your vehicle to a Nissan dealer as soon as a problem exists. The warranty repairs should be completed in a reasonable amount of time, not to exceed 30 days.

As the vehicle owner, you should also be aware that Nissan may deny you warranty coverage if your vehicle or a part has failed due to abuse, neglect, improper maintenance or unapproved modifications.

If you have any questions regarding your warranty rights and responsibilities, you should contact Nissan's Consumer Affairs Department at 1-800-NISSAN-1 (1-800-647-7261) or the California Air Resources Board at 9528 Telstar Avenue, El Monte CA 91731.

(Continued on page 11)

<sup>1</sup> These warranties apply to all California and 50-state emission equipped 2006 model year Nissan vehicles sold for registration as new vehicles in California, Maine, Massachusetts, or Vermont only.

<sup>&</sup>lt;sup>2</sup> These warranties also apply to all Model Year 2006 Partial Zero Emissions Vehicles (PZEVs) sold in the states of New York, Maine, Massachusetts, Rhode Island, or Connecticut

<sup>&</sup>lt;sup>3</sup> Throughout this Limited Emission Control Warranty, "vehicle" means a Nissan model vehicle.

Nissan indicates Nissan North America, Inc., P.O. Box 191, Gardena, California 90248-0191 which distributes Nissan vehicles in the United States.

The performance and defect warranty coverage for the California Emission Altima with 2.5 engine ONLY is 15 years/150,000 miles, whichever occurs first.

wing is Nissan's new vehicle emission conanty statement for vehicles certified for sale rmia and sold for registration as a new California, Massachusetts, or Vermont only<sup>2</sup>.

## ATION OF WARRANTIES AND R WARRANTY TERMS AND LAW RIGHTS

EXPENSES - LIMITATIONS OF DAMAGES missions warranties do not cover incidental equential damages such as loss of the use shicle. Inconvenience or commercial loss.

# PLIED WARRANTY OF MERCHANTABILITY TNESS FOR A PARTICULAR PURPOSE BE LIMITED TO THE DURATION OF THESE IN WARRANTIES.

tates do not allow the exclusion or limitation intal or consequential damages or limitations long an implied warranty lasts, so the above ns or exclusions may not apply to you. These es give you specific legal rights, and you may e other rights which vary from state to state.

does not authorize any person to create for it ar warranty, obligation or liability in connecthis vehicle.

## IONS DEFECTS WARRANTY S COVERED

warrants that your vehicle was designed, d equipped to conform with all applicable nents of the California Air Resources Board. rranty covers any part which affects appligulated emission(s).

ns to this warranty are listed below under the

caption "WHAT IS NOT COVERED."

## HOW LONG IS THE WARRANTY

This warranty is for 3 years or 50,000 miles, whichever occurs first. Additionally, the components listed under the caption "Long-Term Emission System Defects Warranty Parts List" are covered for 7 years or 70,000 miles, whichever occurs first, except that the catalytic converter and engine control module (ECM) are warranted for 8 years or 80,000 miles, whichever occurs first. The warranty begins the date the vehicle is delivered to the first retail buyer or put into use, whichever is earlier.

Some items require scheduled replacement before 50,000 miles. These items are warranted only up to the replacement interval. The replacement intervals are outlined in the maintenance instructions in your NISSAN SERVICE & MAINTENANCE GUIDE.

## LONG-TERM EMISSION SYSTEM DEFECTS WARRANTY PARTS LIST

- Engine Control Module (all models).
- Catalytic converter(s) (Sentra w/1.8 engine, Altima w/ 3.5 engine, Maxima, 350Z, Murano, Quest, Frontier w/ 4.0 engine, Xterra, and Pathfinder).
- Intake manifold (Sentra w/1.8 engine, 350Z, Murano, and Frontier w/2.5 engine).
- Intake manifold collector (Sentra w/1.8 engine, and Murano upper only).
- Exhaust manifold (Sentra w/1.8 engine, Maxima rear only 350Z, Frontier w/4.0 engine RH only, Xterra RH only, and Pathfinder RH only).
- Exhaust manifold with catalytic coverter (Sentra w/2.5 engine, Altima w/2.5 engine, Frontier w/2.5 engine, Titan, and Armada).
- Front exhaust tube (350Z)
- Front exhaust tube with catalytic converter (Sentra, Maxima, and Murano).

- Throttle body (Sentra, Altima, Maxima, 350Z, Murano, and Quest).
- Mass air flow sensor (all models).
- EGI wiring harness (Sentra, Altima w/2.5 engine A/T only, Altima w/3.5 engine, Maxima, 350Z, and Murano).
- Fuel tank (Altima, Maxima, 350Z, Murano, Quest, Frontier, Xterra, Pathfinder, Titan, and Armada).
- Flywheel (Sentra, Altima, Maxima, 350Z, Frontier, and Xterra).
- Torque coverter drive plate (Sentra w/1.8 engine, Altima w/3.5 engine, Maxima, 350Z, Murano, Quest, Frontier, Xterra, Pathfinder, 4WD Titan, and Armada).
- Automatic transmission control module (Sentra, Altima, Maxima, Murano, and Quest).
- Knock sensor (Frontier w/4.0 engine, Xterra, and Pathfinder).

## EMISSIONS PERFORMANCE WARRANTY

## WHEN DOES THIS WARRANTY APPLY

This warranty applies to your 2006 Nissan vehicle only if it fails to pass a California "smog check" test or equivalent.

## WHAT IS COVERED AND FOR HOW LONG

Nissan\* warrants that if your vehicle fails to pass a California "smog check" test, it will make the necessary repairs so that your vehicle will pass. This warranty is for 3 years or 50,000 miles, whichever occurs first. The warranty begins the date the vehicle is delivered to the first retail buyer or the date it is first put in to service, whichever is earlier.

Exceptions to this warranty are listed under the caption "WHAT IS NOT COVERED".

(Continued on page 12)

## WHAT IS NOT COVERED

These warranties do not cover:

Normal maintenance, service and parts replacement as outlined in the emission control maintenance instructions of your OWNER'S MANUAL and your NISSAN SERVICE & MAINTENANCE GUIDE.

ROUGHNAUGHOR

2. Failures directly as a result of:

Lack of performance of required emission control maintenance as outlined in your OWNER's MANUAL and your NISSAN SERVICE & MAIN-TENANCE GUIDE.

Misuse, accident or modification.

Improper adjustment or installation of parts during the performance of maintenance (non-warranty) services.

■ Tampering with or disconnecting any part af-

fecting vehicle emissions.

- The use of fuel other than that specified in your OWNER'S MANUAL or fuel with contaminants which the fuel filter is not designed to remove.
- 3. In the case of the Performance Warranty, the use of any non-Nissan part not certified in accordance with Federal requirements which is defective or not equivalent from an emissions stand point to the original equipment part.
- In the case of the Defects Warranty, parts not supplied by Nissan or damage to other parts caused directly by non-Nissan parts.
- In the case of the Performance Warranty, costs of determining the cause of a vehicle failing a California "smog check" test if such failure is found not to be covered.

## WHAT YOU MUST DO

In order to obtain warranty service you must deliver the vehicle to any authorized Nissan dealer in the United States at your expense. You are responsible for the required maintenance on your vehicle as outlined in the maintenance instructions in your NISSAN SERVICE & MAINTENANCE GUIDE. Nissan recommends that you retain all receipts covering maintenance on your vehicle, but Nissan cannot deny warranty solely for the lack of receipts or for your failure to ensure the performance of all scheduled maintenance.

## WHAT NISSAN WILL DO

Warranty repairs will be made at no charge for parts and/or labor, including diagnosis and tax. Any needed parts replacement will be made using new or remanufactured parts.

## **OTHER WARRANTY TERMS**

### **Performance Warranty Claims Procedure**

You may make a claim under the Performance Warranty immediately after the failure of a "smog check" test. You must provide proof of this failure when making your claim in order to avoid additional "smog check" test charges.

You will be told whether Nissan will honor your claim within 30 days of the date you make the claim, unless a shorter time period is required by law. If your claim is denied, Nissan will notify you in writing of the reason. If we do not notify you within this time period, we will repair your vehicle under this warranty at no cost to you. The time period for notification will not apply if you request a delay or a delay is caused by events not under the control of Nissan dealers. No claim will be denied under the Performance Warranty because you use a certified part for maintenance or repair.

## **Maintenance Service and Replacement Parts**

Important information concerning maintenance service and replacement parts is in the Limited Warranty on Nissan Replacement Parts and Accessories section of this booklet. No warranty claim will be denied solely because a non-Nissan part was used for maintenance or repair.

California Vehicle Inspection Program

Under this program, if your vehicle fails a "smog check" test, you may choose to have diagnosis of the failure and repairs made at a Nissan dealer or at another service facility. If the inspection failure is the result of a condition covered by these warranties, you must take your vehicle to an authorized Nissan dealer for warranty repairs. This includes parts, labor and diagnosis. You must pay for diagnostic costs if performed at another service facility except in the case of emergency repairs as outlined below.

You must pay for all diagnostic and repair costs of an inspection failure as required by law if the failure was caused by conditions not covered by these warranties. If the failure is the result of a combination of conditions, you must pay for only the diagnostic and repair costs related to items not covered by these warranties.

After the 3 year/50,000 mile performance warranty has passed, a "smog check" test failure due to a defect in a part which is warranted for 7 years/70,000 miles is covered.5

#### **Emergency Repairs**

In case of an emergency, when an authorized Nissan dealer is not reasonably available, warranty repairs may be performed at any service facility or by the owner using any replacement parts. Nissan will reimburse you for such repairs, including diagnosis, up to the amount of Nissan's suggested retail price for parts and labor charges based on Nissan's recommended time allowance for the warranty repair and the geographically appropriate hourly

(Continued on page 13)

A part not being available or a repair not being within 30 days also constitutes an emergency. take the replaced part and paid receipts to an Nissan dealer for repayment in such emerations.

## nce Records

covering the performance of regular maintenot required but should be kept in the event arise concerning maintenance. The receipts transferred to subsequent owners.

## re Questions

otain further information concerning these warfollowing the procedure outlined in the "CUS-ARE" section of this booklet. You may also report any violations to the Office of Transpor-Air Quality, Vehicle Compliance Programs S. Environmental Protection Agency, Ariel ling (6405J), 1200 Pennsylvania Avenue, shington, D.C. 20460 or the Chief, Mobile ision, Air Resources Board, 9528 Telstar Ave., A. 91731.

## igations

s not authorize any person to create for it any anty, obligation or liability in connection with

for 2006 vehicles certified for sale in may be subject to future governmental tive or judicial action. As a result, this nay be changed because Nissan reserves ), and, will make those changes required aw, regulation, or judicial or administral in order to be consistent with such ntal actions.

## WHO IS THE WARRANTOR

Nissan\* warrants all parts of your 2006 Nissan vehicle seat belt system supplied by Nissan.

\*Nissan indicates Nissan North America, Inc., P.O. Box 191, Gardena, California 90248-0191, which distributes Nissan vehicles in the United States.

## WHAT IS COVERED AND FOR HOW LONG

This warranty covers any Nissan supplied seat belt or related component, that fails to function properly during normal use within ten (10) years of the date the vehicle is delivered to the first retail buyer or put into service, whichever is earlier. Warranty repairs are free of charge for parts and labor.

## **OBTAINING WARRANTY SERVICE**

You must take the vehicle to an authorized Nissan dealer in the United States or Canada during regular business hours at your expense in order to obtain warranty service. The names and addresses of authorized Nissan dealers are listed in telephone directories.

## WHAT IS NOT COVERED

- Damage or failure due to misuse, alteration, accident or collision damage. (Proper use is outlined in your OWNER'S MANUAL).
- Color fading, spotting or other cosmetic items when the belt is otherwise functioning properly.
- Air bags and related electronic control systems which are covered by the Powertrain warranty.

## LIMITATION OF WARRANTIES AND OTHER WARRANTY TERMS AND STATE LAW RIGHTS

## EXTRA EXPENSES - LIMITATIONS OF DAMAGES

This warranty does not cover incidental or consequential damages such as loss of the use of the vehicle, inconvenience or commercial loss.

ANY IMPLIED WARRANTY OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE SHALL BE LIMITED TO THE DURATION OF THIS WRITTEN WARRANTY.

Some states do not allow the exclusion or limitation of incidental or consequential damages or limitations on how long an implied warranty lasts, so the above limitations or exclusions may not apply to you. This warranty gives you specific legal rights, and you may also have other rights which vary from state to state.

Nissan does not authorize any person to create for it any other warranty, obligation or liability in connection with this vehicle.

### **O IS COVERED**

wner of a BFGoodrich Passenger or Light Truck tire bears the BFGoodrich name and complete DOT fication number.

### IT IS COVERED AND FOR HOW LONG

podrich Passenger and Light Truck tires, used in all service on the vehicle on which they were originally and in accordance with the maintenance recommens and safety warnings contained in the owner's all and in the Important Tire Safety Information Sectif this booklet, are covered by this warranty against its in workmanship and material for the life of the all usable tread, or 6 years from the date of purchase, never comes first. At that time, all warranties, express blied, are terminated. The usable tread is the original down to the level of the tread wear indicators - 2/s of an inch (1.6mm) of tread remaining. Date of asse is documented by new vehicle registration or tire invoice. If no proof of purchase, coverage will be d on date of manufacture.

### AT IS NOT COVERED

which become unserviceable due to:

'oad hazard injury (e.g., a cut, snag, bruise, impact amage, puncture, whether repairable or not);

icorrect mounting of the tire, tire/wheel imbalance, or nproper repair;

Inderinflation, overinflation, improper maintenance or ther abuse:

**lechanical** irregularity in the vehicle such as wheel isalignment resulting in uneven or rapid wear; ccident, fire, chemical corrosion, tire alteration, or andalism:

)zone or weather cracking.

## WHAT BFGOODRICH WILL DO

## **PASSENGER AND LIGHT TRUCK TIRES**

A tire which becomes unserviceable due to a condition covered by this warranty will be replaced with a comparable new BFGoodrich tire, free of charge, when 2/32nds of an inch (1.6mm) or less of the original tread is worn, (or 25% or less, whichever is most beneficial to the user) and within 12 months of the date of purchase. Mounting and balancing of tires is included. The cost of any other service charges and applicable taxes are payable by the user.

When more than 2/32nds of an inch of original tread has been worn (or more than 25%, whichever is most beneficial to the user) or after 12 months from date of purchase, the user must pay the cost of a comparable new BFGoodrich passenger or light truck replacement tire on a pro rata basis. The dealer shall determine the charge by multiplying the percentage of the original usable tread worn by the current actual selling price at the adjustment location or the price on the current BFGoodrich Brand Base Price List, whichever is lower. This List is based on a predetermined price intended to fairly represent the actual selling price of the tire. The cost of mounting, balancing and any other service charges and applicable taxes are payable by the user.

(Continued on page 16)

## WHAT THE CONSUMER MUST DO

When making a claim under the terms of this warranty, the consumer must present the tire to an authorized BFGoodrich Dealer. To locate an Authorized Tire Dealer, check the yellow pages under "Tire Dealers - Retail."

The vehicle on which the tire was used should be available for inspection.

It is essential that you read and understand the safety and maintenance recommendations (see Safety Maintenance Information) for your tires.

### **CONDITIONS AND EXCLUSIONS**

THIS WARRANTY DOES NOT PROVIDE COMPENSATION FOR LOSS OF TIME, LOSS OF USE OF VEHICLE, INCONVENIENCE OR CONSEQUENTIAL DAMAGE.

TIRES PRESENTED FOR CLAIM REMAIN THE PROPERTY OF THE CONSUMER AND BEGOODRICH BRAND ACCEPTS NO RESPONSIBILITY FOR LOSS OF, OR DAMAGE TO, TIRES WHICH ARE IN THE CUSTODY OR CONTROL OF A BEGOODRICH TIRE DEALER FOR THE PURPOSE OF INSPECTION FOR WARRANTY ADJUSTMENT. IN THE EVENT OF A DISPUTED CLAIM, THE CONSUMER MUST MAKE THE TIRE AVAILABLE FOR FURTHER INSPECTION.

NO BFGOODRICH REPRESENTATIVE, EMPLOYEE OR DEALER HAS THE AUTHORITY TO MAKE OR IMPLY ANY REPRESENTATION, PROMISE OR AGREEMENT, WHICH IN ANY WAY VARIES THE TERMS OF THIS WARRANTY.

THIS WARRANTY APPLIES ONLY IN THE UNITED STATES AND CANADA.

### **CONSUMER RIGHTS**

THIS WARRANTY GIVES YOU SPECIFIC LEGAL RIGHTS, AND YOU MAY ALSO HAVE OTHER RIGHTS WHICH VARY FROM STATE TO STATE AND PROVINCE TO PROVINCE.

### SAFETY MAINTENANCE INFORMATION

Read your vehicle owners manual, the information on the sidewall of your tires, the vehicle tire information placard and the Important Tire Safety Information section of this booklet for essential safety and maintenance information.

## THE WARRANTOR

The warrantor of BFGoodrich Tires is Michelin North America, Inc. 1 Parkway South, P.O. Box 19001, Greenville, South Carolina 29602-9001.

For Consumer Assistance, Please Call Toll Free: 1-877-788-8899 Or Write: Consumer Relations P.O. Box 19026, Greenville, SC 29602-9026

## DANGER

Disregarding any of the safety precautions and instructions contained in the Owner's Manual or the Important Tire Safety Information in this booklet may result in tire failure or explosion causing serious personal injury or death.

## **ELIGIBILITY**

You are covered under the terms of this warranty if you are he first retail purchaser or authorized agent of the first retail purchaser of any new Bridgestone or Firestone tire bearing he Bridgestone or Firestone name and Department of ransportation (DOT) assigned identification number, proluced after July 3, 1994 (274), and if your tire has been used only on the vehicle on which it was originally installed non-commercial service and is of a size equivalent to or reater than that specified by the vehicle's manufacturer.

## **VHAT THIS WARRANTY COVERS & FOR IOW LONG**

. (i) before wearing down to 2/32nds of an inch of tread epth remaining (i.e., worn down to the top of the built-in dicators in the tread grooves), (ii) before 6 years from the ate of purchase (proof of purchase required), or (iii) store 6 years from the date of manufacture (whichever cours first), any Bridgestone or Firestone tire covered by is warranty becomes unusable for any reason within the anufacturer's control, such tire will be replaced with an puivalent Bridgestone or Firestone tire on the basis set th below.

## 'HAT THE WARRANTY DOES NOT

Tire damage or irregular wear due to:

- A. Road Hazards.
  - Including, without limitation, puncture, cut, impact break, bruise, bulge, snag, etc.
- B. Continued use while run flat or under acute underinflation.

## C. Improper Use or Operation.

Including, without limitation, improper inflation pressure, overloading, use of an improper rim, vehicle misalignment, tire/wheel assembly imbalance or other vehicle conditions, worn suspension components, improper mounting or demounting, misuse, misapplication, negligence, tire spinning, tire chain damage, chemical contamination, fire or other externally generated heat, water or other material trapped inside the tire during mounting, tire alteration, racing or competition purposes, improper insertion of sealant, balance or filler materials.

#### D. Improper Repair.

- 2. Ride disturbance claims submitted after 1/32nd inch of treadwear or for 4 or more tires from the same vehicle.
- 3. The cost of applicable federal, state, and local taxes.
- Tires purchased and normally used outside the continental United States.
- Claims for weather/ozone cracking after 4 years from the date of purchase (proof of purchase required) or if not known, 4 years from the date of manufacture.
- Failure to observe any of the safety and maintenance precautions contained in the "Important Tire Safety Information" section of this booklet.

This warranty is in addition to and/or may be limited by any other applicable written warranty concerning special tires or situations you may have received.

## "LIMITED WARRANTY" Bridgestone and Firestone Brand Passenger & Light Truck Tires

## REPLACEMENT PRICE

Radial passenger and light truck tires adjusted under this warranty will be replaced free of charge during the first 25% of treadwear or within the first 12 months after purchase (Proof of Purchase and Purchase Date are required), whichever occurs first.

During the free replacement period, mounting and balancing are included free of charge.

After the free replacement period, to determine the replacement price, the percent of used treadwear is multiplied by the owner-user's regular buying price. Taxes, mounting, balancing, and other service charges will be added to the adjustment replacement price.

IN CANADA, the tire will be adjusted at dealerships (subject always to dealer discretion) at a predetermined "Adjustment Price".

Replacement Warranty. If you receive a tire under this warranty, it will be covered by the warranty then given on that tire.

Where to go. See your Bridgestone or Firestone retailer listed in Yellow Pages under Tire Dealers-Retail.

## **CONSUMER RIGHTS**

This warranty gives you specific legal rights, and you may also have other rights which vary from state to state and in Canada from province to province.

(Continued on page 18)

## **CONDITIONS & EXCLUSIONS**

TO THE EXTENT PERMITTED BY LAW, BRIDGESTONE/ FIRESTONE, INC. DISCLAIMS LIABILITY FOR ANY CONSEQUENTIAL DAMAGES, LOSS OF TIME, OR LOSS OF VEHICLE USE, OR INCONVENIENCE.

Some states do no allow the exclusion or limitation of incidental or consequential damages, so the above limitation or exclusion may not apply to you.

This warranty applies only to consumers actually using the tire in the United States and Canada. For warranty conditions outside the United States and Canada, see your local Bridgestone or Firestone distributor.

Obligations under this policy may not be enlarged or altered by anyone.

Important: In accordance with Federal Law, this warranty has been designated as a "Limited Warranty". Nothing in this warranty is intended to be a representation that tire failures cannot occur. This warranty is given by Bridgestone/Firestone, Inc., One Bridgestone Park, Nashville, TN 37214 and in Canada by Bridgestone Canada, Inc., 5770 Hurontario St. Suite 400, Mississauga, Ontario, Canada L5R 3G5.

## **OWNER-USER'S OBLIGATION**

It is owner-user's obligation to operate tires within tire load and specification limits and at cold air pressures specified by your vehicle manufacturer for load and speed according to individual tire size, type, and load capacity. It is also the owner-user's obligation to maintain proper alignment of wheels, and to maintain proper tire/wheel assembly balance.

In case of adjustment claim, owner-user must present the tire to a Bridgestone or Firestone retailer, complete and sign the customer section of the Bridgestone/Firestone, Inc. warranty claim form, and pay appropriate replacement price, taxes and service charges.

We strongly recommend that you have your Bridgestone or Firestone retailer inspect tires any time you notice irregular or uneven treadwear or every 5,000 miles or at vehicle manufacturer's recommended mileage, if sooner.

Note: For your convenience, your nearest authorized Nissan Dealership will also assist you with your Tire Service Requirements or in obtaining tire warranty service from the tire manufacturer.

## THE WARRANTOR

The warrantor of Bridgestone and Firestone tires is: Bridgestone/Firestone, Inc., ATTN: Technical Services, One Bridgestone Park, Nashville, TN 37214.

For Customer Assistance: 1-800-847-3272

## SAFETY INFORMATION

Any tire, no matter how well constructed, may fail in use as a result of punctures, impact damage, improper inflation, overloading, or other conditions resulting from use or misuse. Tire failure may create a risk of serious personal injury or property damage. To reduce risk of tire failure, we strongly recommend you read and follow all safety information contained in the Important Tire Safety Information section contained in this booklet, the tire placard in the vehicle or the Owner's Manual.

### :LIGIBLE?

le for the benefits of this Limited Warranty if:

ne owner or authorized agent of the owner of
lop highway auto, light truck or temporary
s supplied as original equipment on your
nd

3 bear Department of Transportation prere identification numbers and your tires have d only on the vehicle on which they were installed according to the vehicle manufacunlop recom-mendations, and

sle was purchased on or after March 1, 2003.

## **COVERED AND FOR HOW**

#### REPLACEMENT

e eligible under the provisions of this limited removed from service due to a covered lition during the first 2/32" treadwear or 12 late of purchase, whichever occurs first, will with a comparable new Dunlop tire at no ting and balancing are included. (Without hase, date of manufacture will be used to 1.)

#### Y SPARE TIRES

mporary spare tire eligible under the proviited warranty and removed from service due arranty condition during the first 50 percent twear will be replaced with a comparable imporary spare tire at no charge, including

#### **ADJUSTMENT**

ble for no-charge replacement that is rervice due to a covered warranty condition d with a comparable new Dunlop tire on a

## HOW WILL PRORATED CHARGES BE CALCULATED?

Replacement price will be calculated by multiplying the tire's advertised retail selling price at the time of adjustment by the percentage of usable original tread that has been worn off. You pay for mounting, balancing and applicable taxes

Example: If your disabled tire had an original 8/32" of usable treadwear and is worn to 4/32" usable tread remaining, you have used 50 percent and, therefore, must pay 50 percent of the current advertised selling price of the replacement tire. If the price of the new replacement tire is \$80, the cost to you would be \$40 plus any additional charges such as mounting, balancing and applicable taxes.

### WHAT IS A COMPARABLE TIRE?

A comparable new Dunlop tire may either be the same line of tire or, in the event that the tire is not available, a tire of the same basic construction and quality with a different side-wall or tread configuration. If a higher priced tire is accepted as replacement, the difference in price will be at an additional charge to you.

## ADDITIONAL PROVISIONS

A tire has delivered its full original treadlife and the coverage of this warranty ends when the treadwear indicators become visible (worn to 2/32"), or six (6) years from the date of original tire manufacture or new tire purchase date. (Without proof of purchase, date of manufacture will be used to determine age.)

Any replacement tire provided pursuant to this warranty will be covered by the Dunlop warranty in effect at the time of replacement.

### **LIMITATIONS**

This limited warranty is applicable only in the United States and Canada.

## WHAT IS NOT COVERED BY THIS WARRANTY?

This limited warranty does not cover the following:

- Tires submitted for ride disturbance complaints that are worn beyond the first two thirty-seconds of an inch (2/32") tread depth.
- Dunlop does not warrant or give credit in any adjustment transaction for any kind of material added to a tire (e.g., tire fillers, sealants, balancing substances) after the tire leaves a factory producing Dunlop tires, nor will it adjust any tire that has failed as a result of adding such material.
- Irregular wear or damage due to mechanical condition of the vehicle, improper inflation, overloading, high speed spin-up, misapplication, misuse, negligence, racing, use of tire chains, improper mounting or demounting, improper repair, wreck, collision or fire.
- Road hazards (includes, but not limited to, punctures, cuts, snags, impact breaks, etc.).
- Any tire that after leaving a factory producing Dunlop tires has been intentionally altered to change its appearance (e.g., white inlay on a black tire, regrooving or siping).
- Tires with weather-cracking that were purchased more than four (4) years prior to presentation for adjustment or, if purchase date cannot be verified, manufactured more than four (4) years prior to presentation for adjustment.
- Loss of time, inconvenience, loss of vehicle use, incidental or consequential damages.

(Continued on page 20)

## WHAT ARE YOUR LEGAL RIGHTS?

Some states and provinces do not allow the exclusion or limitation of incidental or consequential damages, so the above limitations or exclusions may not apply to you. No representative or dealer has authority to make any representation, promise, or agreement on behalf of Goodyear Dunlop Tires North America, Ltd. (GDTNA), except as stated herein.

Any tire, no matter how well constructed, may fail in service or otherwise become unserviceable due to conditions beyond the control of the manufacturer. Under no circumstances is this warranty a representation that a tire failure cannot occur.

This warranty gives you specific legal rights, and you may also have other rights that vary from state to state and in Canada province to province.

## HOW DO YOU OBTAIN AN ADJUSTMENT?

- A. You must present the tire to be adjusted to an authorized Dunlop service facility. Tires replaced on an adjustment basis become the property of Goodyear Dunlop Tires North America, Ltd. or Goodyear Canada Inc.
- B. You must pay for taxes and any additional services you order at the time of adjustment.
- C. You must submit your claim on a GDTNA claim form supplied by an authorized Dunlop service facility. The form must be filled out completely and signed by you, the owner of the tire presented for adjustment, or your authorized agent.

## TIRE CARE AND MAINTENANCE GUIDE

The easiest way to help ensure satisfactory mileage and performance from your Dunlop tires is to give them a simple but frequent inspection for proper inflation, even treadwear, and the presence of any damage.

## DO MAINTAIN PROPER INFLATION PRESSURE IN YOUR TIRES

Proper inflation pressure is necessary for optimum tire performance, safety and fuel economy. To maintain proper inflation pressure, frequently check tires (when they are cool) with an accurate tire pressure gauge.\*

For example, it is difficult to tell just by looking at radial tires whether they are underinflated.

Furthermore, when operating a vehicle equipped with radial tires, it is difficult to notice when a tire has gone flat or nearly flat since the "feel" of the vehicle does not change significantly.

\*Evidence of air loss or repeated underinflation always requires expert inspection to determine the source of leakage and tire removal to determine repairability. To avoid injury, NEVER attempt to reinflate a tire that has been run severely underinflated.

Progressive air loss may result from punctures, cuts, curbing, impacts or partial bead unseating. Some fitment causes for air loss are (1) incomplete bead seating, (2) bead tearing caused by a machine tool due to insufficient lubrication or improper adjustment, (3) leaking valve core or rubber valve components. These should be replaced when problems are detected and whenever tires are replaced.

Always maintain inflation pressure at the level recommended by the vehicle manufacturer as shown on the vehicle placard or in the owner's manual: Underinflation is the leading cause of tire failure and may result in severe cracking, component separation or "blow-out." It reduces tire load capacity, allows excessive sidewall flexing and increases rolling resistance, resulting in heat and mechanical damage. Maintaining proper inflation pressure is the single most important thing you can do to ensure tire durability and maximum treadlife.

Overinflation increases stiffness, which may deteriorate ride and generate unwanted vibration. Overinflation also increases the chances of impact damage.

## **DON'T OVERLOAD YOUR VEHICLE**

Check your vehicle owner's manual to determine the load limits. Overloading your vehicle places stress on your tires and other critical vehicle components. Overloading a vehicle can cause poor handling, increased fuel consumption and may cause tire failure.

Never fit your vehicle with new tires that have less load capacity than shown on the vehicle tire placard and remember that optimum rim width is important for proper tire load distribution and function.

The maximum load capacity stamped on the sidewalls of P-Metric tires is reduced by 10 percent when used on a light truck, utility vehicle or trailer. Never fit P-Metric tires to light trucks that specify LT-type replacement tires.

## DON'T SPIN YOUR TIRES EXCESSIVELY

Avoid excessive tire spinning when your vehicle is stuck in snow, ice, mud or sand. The centrifugal forces generated by a free-spinning tire/wheel assembly may cause sudden

(Continued on page 21)

psion resulting in vehicle damage and/or serious injury to you or a bystander. Never exceed 35 km/h as indicated on your speedometer. Use a ackward and forward rocking motion to free your or continued driving. Never stand near or behind a ting at high speed as, for example, while attemptish a vehicle that is stuck or when an on-the-car nce machine is in use.

### **IECK YOUR TIRES FOR WEAR**

emove tires from service when they reach two conds of an inch (2/32") remaining tread depth. All have treadwear indicators which appear as anks in the tread grooves when they wear to the resconds of an inch (2/32") level. Many wet accidents result from skidding on bald or nearly Excessively worn tires are also more susceptible ations.

## **ALL TREATMENTS**

**Jewalls** are specially compounded to resist ozone or weather-cracking.

I soap solution to clean sidewalls, white striping , and rinse off with plain water. Instruct service I and customers never to apply any other mateance sidewall appearance. These may degrade I remove inherent ozone resistance.

## **ECK YOUR TIRES FOR DAMAGE**

nspection of your tires for signs of damage and ral condition is important for safety. If you have ons, have your tire dealer inspect them. Impacts, ns, cracks, knots, bulges, or air loss always removal and expert inspection. Never perform y repair or use an innertube as a substitute for

a proper repair. Only qualified persons should repair tires.

### PROPER TIRE REPAIR

**NOTE**: Dunlop does not warrant any inspection or repair process. The repair is entirely the responsibility of the repairer and should be made in accordance with established Rubber Manufacturers Association (RMA) procedures

## DON'T ATTEMPT TO MOUNT YOUR OWN TIRES

Serious injury may result from explosion of tire/rim assembly due to improper mounting procedures. Follow tire manufacturer's instructions and match tire diameter to rim surfaces. Lock assembly on mounting machine or place in safety cage. STAND BACK and never exceed 40 psi to seat beads. Never use a volatile substance or a rubber "donut" (also known as a bead expander or "O-Ring") to aid bead seating. Only specially trained persons should mount tires

## DON'T MIX TIRES OF DIFFERENT SIZES AND TYPES ON THE SAME AXLE

For optimum handling and control, Dunlop recommends fitment of four (4) tires of the same type and size unless otherwise specified by the vehicle manufacturer.

## FOLLOW THESE ADDITIONAL GUIDELINES:

Fit newest tires on rear axle. If radials and non-radials must be fitted to the same vehicle, fit radials on rear axle. Never mix radials and non-radials on the same axle. When fitting snow tires or all-season tires to performance vehicles, always fit in sets for four. Do not fit tires with different speed ratings.

Use of lift kits with some vehicle/tire combinations can cause instability. When changing tire sizes, always consult dealer for optimum rim width and carefully check vehicle/tire clearances.

## RETREADED TIRES

Retreaded passenger and light truck tires are not warranted by Dunlop for any reason. Dunlop speed ratings and U.S. Department of Transportation test compliance certifications are voided for retreaded tires.

## DO MAINTAIN VEHICLE SUSPENSION, WHEEL ALIGNMENT AND BALANCE AND ROTATE YOUR TIRES

Lack of rotation, worn suspension parts, underinflation/over-inflation, wheel imbalance, and misalignment can cause vibration or irregular tire wear. Rotate your tires according to your vehicle manufacturer's recommendations or at maximum intervals of 6,000 miles/10,000 km.

## LIGHTWEIGHT TEMPORARY SPARE TIRES IMPORTANT SAFETY INSTRUCTIONS

- Limit vehicle speed when using the lightweight temporary spare tire to 50 mph/80 km/h or less.
- Check the inflation pressure before using and at least weekly. Maintain cold tire pressure in accordance with that molded on the tire sidewall or found in your vehicle owner's manual. When inflating or adding air to lightweight temporary spare tire, be very careful, since the smaller tire volume can gain pressure quickly. Leave

(Continued on page 22)

valve core in place and add inflation air in short bursts. Check the pressure often with an in-line or hand gauge until the specified pressure is reached.

- The lightweight temporary spare tire may lower ground clear-ance when used. Reduce speed and avoid driving over large obstacles or through chuckholes and other road hazards.
- Check your car owner's manual for other special clearance precautions when using the lightweight temporary spare tire provided in your vehicle.
- Because your lightweight temporary spare tire was specifically designed for your car, it should not be used on any other vehicle.
- Do not use snow chains on your lightweight temporary spare tire. This could cause damage to your vehicle.
- Your lightweight temporary spare has very limited wear potential (up to 300 miles/500 km).
- In order to conserve tire treadlife, the lightweight temporary spare tire should be returned to your trunk as soon as the standard tire has been repaired or replaced. Never use the spare if treadwear indicator (TWI) bars are exposed or it is worn to the last 2/32" tread depth.
- Do not use your original equipment lightweight temporary spare tire on any other than its original equipment rim. The replacement lightweight temporary spare tire must match the original equipment tire removed from your lightweight temporary spare rim. Check the tire for the lightweight temporary spare tire size marking designation and compare size markings with those found on both your original lightweight temporary spare and

NOTE: Your original equipment lightweight temporary spare tire and rim combination is not the same size as the other tires and rims with which your vehicle is equipped. Standard tires, snow tires, conventional wheel covers or rim rings should not be fitted to your lightweight temporary spare tire rim or assembly.

Improper mounting can cause tire/rim assembly explosion and serious injury. Tire Fitters: Follow tire manufacturer's instructions and match tire diameter to rim diameter. Mount the lightweight temporary spare tire only on a rim originally fitted with a temporary spare of the same size. Lubricate beads and rim contact surfaces. Lock assembly on mounting machine or place in a safety cage. STAND BACK; inflate in short bursts with extension hose, clip-on chuck on in-line gauge. Never exceed 40 psi to seat beads or use a volatile substance or a rubber "donut" to aid bead seating. Only specially trained persons should mount lightweight temporary spare tires.

Dunlop brand tires are serviced by The Goodyear Tire & Rubber Company and Goodyear Canada Inc. through authorized Dunlop outlets.

You must go to an authorized Dunlop outlet for replacement tires and all warranty service.

### THE WARRANTOR

The warrantor of Dunlop tires is Goodyear/Dunlop N.A. Limited at 1144 East Market Street, Akron, Ohio 44136-

## FOR SERVICE ASSISTANCE OR INFORMATION:

• FIRST CONTACT THE NEAREST DUNLOP RETAILER. • IF ADDITIONAL ASSISTANCE IS REQUIRED: IN THE UNITED STATES: Call (800) 321-2136, or write: Goodyear/Dunlop Consumer Relations Dept. 728

1144 East Market Street, Akron, OH 44316-0001 IN CANADA:

Call (800) 387-3288, or write: Goodyear/Dunlop Consumer Relations Department 450 Kipling Avenue Toronto, Ontario M8Z 5E1

## SAFETY WARNINGS

- Serious injury or property damage may result from:

  TIRE FAILURE DUE TO UNDERINFLATION/OVER-LOADING:
  - Follow the owner's manual, tire placard in vehicle, or Important Tire Safety Information located in this book-
- EXPLOSION OF TIRE/RIM ASSEMBLY DUE TO IM-PROPER MOUNTING:
- Only specially trained persons should mount tires. FAILURE TO MOUNT RADIAL TIRES ON APPROVED
- FAILURE TO DEFLATE SINGLE OR DUAL ASSEM-BLIES COMPLETELY BEFORE DEMOUNTING.
- TIRE SPINNING ON SLIPPERY SURFACES SUCH AS SNOW, MUD, ICE, ETC. DO NOT SPIN TIRES IN EXCESS OF 35 MPH (55 KPH), AS INDICATED ON THE SPEEDOMETER, PERSONAL INJURY AND SE VERE DAMAGE MAY RESULT FROM EXCESSIVE WHEEL SPINNING, INCLUDING TIRE DISINTEGRA TION OR AXLE FAILURE.

## **ENERAL TIRE LIMITED WARRANTY IND ADJUSTMENT POLICY**

his Limited Warranty and Adjustment (the "Policy") is sued by Continental Tire North America, Inc. (the "Comany") and is applicable for General-brand original equipment tires and is a promise of replacement under certain secified conditions. This Policy applies to tires in normal strice displaying adjustable conditions (see Section 4) and does not require the existence of a workmanship or atterial related condition in order to qualify for adjustment—IIS POLICY IS NOT A WARRANTY THAT YOUR TIRE ILL NOT FAIL OR BECOME UNSERVICEABLE IF EGLECTED OR MISTREATED.

### **ELIGIBILITY**

- a. This Policy applies to the owner of Passenger Car, Light Truck and Serva-Spare tires bearing the General brand name and serial numbers, and operated in normal service.
- b. Eligible tires must be the original equipment tires, used on the vehicle on which they were originally installed by the vehicle manufacturer.
- Tires branded "used" are not eligible under this Policy.

## WHAT IS THE ADJUSTMENT POLICY AND FOR HOW LONG?

nited warranty coverage is for a maximum period of 72 inths from the date of purchase\*, determined by the new nicle registration date or new vehicle sales invoice owing date of purchase.

If an eligible Passenger or Light Truck or Serva-Spare tire, used in normal service, becomes unserviceable from a condition other than those listed under Section 4, during or after the time or treadwear periods shown below, it will be replaced with a comparable\*\* new General brand tire according to (A) and (B) below.

## (A) Free Replacement Policy:

Passenger Tire

First 12 Months or First 2/32nds,
(whichever comes first).

Mounting & balancing included free of charge. Owner pays all

free of charge. Owner pays all applicable taxes.

Light Truck Tire First 12 Months or First 3/32nds,

(whichever comes first).

Mounting & balancing included free of charge. Owner pays all applicable taxes. (Excluding F.E.T.)

Serva-Spare Tires

No Time Limit First 1/32nd
Mounting & balancing included
free of charge. Owner pays all
applicable taxes.

(B) Pro Rata Replacement Policy: Passenger/Light Truck Tires

After the "Free Replacement Policy" expires (set forth in section 2A), and the tire is still within 72 months from the date of purchase", you will pay, on a pro rata basis, for a comparable" new General brand replacement tire. A tire is eligible for an adjustment on a pro rata basis until the tread is worn down to the tread wear indicators (2/32nds of an inch of tread remaining). The tire tread is worn out at this point and this Policy ends regardless of time period. Owner pays all applicable taxes (including F.E.T.), mounting and balancing charges.

## **Serva-Spare Tires**

After the "Free Replacement Policy" expires (set forth in section 2A), no adjustment will be made.

- At the time of claim, you need to present your new vehicle registration or new vehicle sales invoice showing date of purchase. If satisfactory proof-of-purchase date is not provided, the D.O.T. certification date of manufacture (tire serial number) will be used.
- \*\* A "comparable" new General brand tire may be either the same tire line or the same basic construction but with a different sidewall or tread configuration. If a higher-priced tire is accepted as replacement, the owner will pay the difference in price. Any tire replaced under this Policy will be covered by the current General Tire Limited Warranty and Adjustment Policy

## 3. HOW A PRO RATA PRICE IS CALCULATED

The replacement tire price will be determined by multiplying the percentage of the usable tread worn by the Dealers Selling Price (excluding all applicable taxes) at the time of the adjustment or the General brand current published Adjustment Base Price, whichever is lower. The usable tread is the original tread down to the tread wear indicators (2/32nds of an inch of tread remaining). The Ajustment Base Price is intended to fairly represent a Dealer's Selling Price for the same or comparable tire.

(Continued on page 24)

## WHAT IS NOT COVERED BY THE ADJUSTMENT POLICY

#### a. The following conditions are not covered:

Road Hazard: Cuts, snags, punctures, bruises or impact breaks and any damage caused by puncture or tire repair.

Ride/Vibration: After "Free Replacement Policy" (set forth in section 2A) expires.

Tire Damage or Failure Resulting From Improper Operation or Maintenance: Load, speed, and inflation practices causing excessive operational temperatures to exceed the tire capabilities.

Tire damage (including irregular treadwear) or failure resulting from: improper mounting or demounting, damaged rim, wheel alignment, tire trueing, chain damage, brakes or any similar mechanical problem, extreme temperature exposure, misuse, negligence, and abusive driving such as tire spinning, racing or accident damage.

Tire failure resulting from intentional alterations: such as adding a white inlay on a blackwall or sealant materials.

Age Conditions: Weather checking/cracking coverage is for a maximum period of 48 months from the date of purchase.

#### b. General Exclusions -

Tire(s) submitted for an adjustment in service for longer than 72 months from date of purchase\*, are not covered by this policy.

Tire(s) on any vehicle registered and normally operated outside the United States and Canada are not covered under this Policy. For tires on vehicles normally operated outside the United States and Canada, see the nearest General Tire dealer or distributor for local coverage.

Tire(s) transferred from the vehicle on which they were originally installed are not covered under this Policy

Company does not offer tread wearout coverage up to a predetermined mileage under this Policy. Tire(s) used in racing related activities or competitive events are not covered by this Policy.

THIS LIMITED WARRANTY IS IN LIEU OF ALL OTHER WARRANTIES, EXPRESS OR IMPLIED, INCLUDING. BUT NOT LIMITED TO, WARRANTIES OF MERCHANT-ABILITY OR FITNESS FOR A PARTICULAR PURPOSE. NO OTHER WARRANTIES, EXPRESS OR IMPLIED, IN-CLUDING, BUT NOT LIMITED TO, WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE, ARE MADE OR INTENDED BY COMPANY. COMPANY DISCLAIMS ALL IMPLIED WARRANTIES, INCLUDING WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE. ANY IM-PLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, ANY WARRANTY OF MERCHANTABILITY OR FIT-NESS FOR A PARTICULAR PURPOSE, ARE LIMITED IN DURATION TO THE DURATION OF THIS WRITTEN WARRANTY. SOME STATES DO NOT ALLOW LIMITA-TIONS ON HOW LONG AN IMPLIED WARRANTY LASTS, SO THE ABOVE LIMITATION MAY NOT APPLY TO YOU.

NO COMPANY EMPLOYEE, RETAILER OR DEALER HAS THE AUTHORITY TO MAKE ANY WARRANTY, REPRESENTATION, PROMISE OR AGREEMENT ON BEHALF OF COMPANY EXCEPT AS STATED IN THIS LIMITED WARRANTY.

TO THE EXTENT PERMITTED BY LAW, COMPANY DISCLAIMS LIABILITY FOR ALL CONSEQUENTIAL AND INCIDENTAL DAMAGES. THE REMEDIES SET FORTH IN THIS LIMITED WARRANTY ARE THE SOLE AND

EXCLUSIVE REMEDIES FOR BREACH OF WARRANTY. SOME STATES DO NOT ALLOW THE EXCLUSION OR LIMITATION OF INCIDENTAL OR CONSEQUENTIAL DAMAGES SO THE ABOVE LIMITATIONS OR EXCLUSION MAY NOT APPLY TO YOU. THIS WARRANTY GIVES YOU SPECIFIC LEGAL RIGHTS, AND YOU MAY ALSO HAVE OTHER RIGHTS WHICH MAY VARY FROM STATE TO STATE.

## 5. COMPANY'S OBLIGATIONS

Any replacement qualifying under this Adjustment Policy will be made by any General brand authorized dealer or vehicle dealer authorized to handle General brand tire adjustments. Company will replace the tire pursuant to the terms of this Adjustment Policy.

## 6. OWNER'S OBLIGATIONS

To make a claim under this Policy concerning any tire which is covered by this Policy, you must present your claim with the tire to any General brand tire dealer or vehicle dealer authorized to handle General brand tires. For the nearest General brand tire dealer, check the Yellow Pages, or use the General brand Internet address, or one of the "800" numbers shown under "For Customer Assistance." To be eligible for the terms of this Policy, you need to present your new vehicle registration form or new vehicle sales invoice showing date of purchase. Tires replaced on an adjustment basis become the property of Company. You will be required to sign the Company Limited Warranty Claim Form or dealer replacement sales receipt.

You are responsible for payment of all applicable taxes demounting, mounting and balancing charges set forth under this Policy. You are also responsible for payment of local tire-disposal fees and any parts or service regardless of mileage or months of service. This includes payment for tire rotation, alignment, towing, road service, valve stems and tire repairs.

(Continued on page 25)

**sponsible for maintaining proper tire air pres- proper maintenance of the tire.** 

## RRANTOR

tor of General brand tires is Continental America, Inc., 1800 Continental Blvd., C 28273.

er Assistance: 3349 (Nationwide) 1776 (In Canada) generaltire.com

## **'WARNING**

ng any of the safety precautions and instrucined in the Owner's Manual or the Important Information in this booklet may result in tire xplosion causing serious personal injury or

You are eligible for the benefits of this policy if you are the owner or authorized agent of the owner of new Goodyear highway auto and light truck tires bearing Department of Transportation prescribed tire identification numbers, and if your tires have been used only on the vehicle on which they were originally installed according to the vehicle manufacturer's recommendations.

## **COVERAGE (REPLACEMENT FREE)**

Any new Goodyear highway radial auto tire or radial light truck tire, except Unisteel radial light truck tires, covered by this policy, that does not deliver satisfactory highway service due to a workmanship or material related condition (see Adjustment Policy Limitations) during the first 25% of usable treadwear, or twelve months from date of purchase, whichever comes first, will be replaced with a comparable new Goodyear tire without charge. Mounting and balancing are included.

Any Goodyear temporary spare tire that does not deliver satisfactory highway service due to a workmanship or material related condition during the first 50% of usable tread depth (1/32 of an inch) will be replaced with a comparable new Goodyear temporary spare tire without charge. Mounting is included. After the first 50% of usable treadwear, you pay only an adjustment charge for the treadwear received, plus any mounting charge.

## COVERAGE (PRORATED ADJUSTMENT)

Tires not eligible for no charge adjustment that do not deliver satisfactory service due to a workmanship or material related condition will be replaced with comparable new Goodyear tires on a pro rata basis. The replacement price will be calculated by multiplying the current Goodyear "predetermined price for adjustment" or current advertised price at adjustment location (whichever is lower) by the percentage of usable original tread that has been worn off at the time of the adjustment. You pay for mounting, balancing, and an amount equal to the full current Federal Excise Tax applicable to the comparable new replacement

The "predetermined price for adjustment," available at all Goodyear Auto Service Centers and participating dealers. fairly represents the actual regular retail selling price of the comparable tire at the time of adjustment. If a "predetermined price for adjustment" is not available, adjustment will be based on the price at which you are entitled to buy at the time of adjustment.

A tire has delivered its full original tread life and this warranty ends when the treadwear indicators become visible, regardless of age or mileage.

## **DEFINITION OF COMPARABLE TIRE**

A "comparable" new Goodyear tire may either be the same line of tire or, in the event the disabled tire is out of production, the same basic construction and quality with different sidewall or tread configuration.

If a higher priced tire is accepted as replacement, the difference in price will be additional.

Any tire replacement under this warranty will be covered by the Goodyear warranty in effect at time of replacement.

## **ADJUSTMENT POLICY LIMITATIONS**

This limited warranty is applicable only in the United States

No representative or dealer has authority to make any representation, promise, or agreement on behalf of Goodyear, except as stated herein.

The following are not covered by this policy:

Goodyear does not warrant and will not give credit in any adjustment transaction for any kind of material added to the tire after leaving a Goodyear factory, nor will it adjust any tire which has failed as a result of adding any such material. (Example: Tire fillers, sealants, or balancing substances.)

(Continued on page 27)

Irregular wear or tire damage due to:

- Road hazards (including punctures, cuts, snags, impact breaks, etc.).
- Wreck, collision, or fire.
- Improper inflation, overloading, high speed spinup, mis-application, misuse, negligence, racing, chain damage or improper mounting or demounting.
- Mechanical condition of the vehicle.
- Ride disturbance after the first 25% of usable treadwear or due to damaged wheels or any vehicle condition.
- Temporary spare tires used on vehicle used in racing and on passenger cars in special applications, such as police pursuit service.
- Any tire intentionally altered after leaving a Goodyear factory to change its appearance. (Example: White inlay on a black tire.)
- Tires with weather cracking which were purchased more than four (4) years prior to presentation for adjustment. If you have no proof of purchase date, tires manufactured four (4) or more years prior to presentation are not covered.
- Loss of time, inconvenience, loss of use of the vehicle or consequential damage.

some states do not allow the exclusion or limitation of holdental or consequential damages so the above limitaions or exclusion may not apply to you. Any tire, no matter how well constructed, may fail in service or otherwise become unserviceable due to conditions beyond the control of the manufacturer. This warranty is not intended as a representation that a tire failure cannot occur.

## **OWNER'S OBLIGATIONS**

- a. You must present the tire to be adjusted to a Goodyear Auto Service Center or Goodyear Tire Dealer. (Please consult your telephone directory for locations.) Tires replaced on an adjustment basis become the property of The Goodyear Tire & Rubber Company.
- You must pay for taxes or any additional service you order at the time of adjustment.
- c. No claim will be recognized unless submitted on a Goodyear claim form (supplied by Goodyear dealer or Auto Service Center) completely filled out and signed by you, the owner of the tire presented for adjustment, or your authorized agent.

### LEGAL RIGHTS

This warranty gives you specific legal rights, and you may also have other rights which vary from state to state.

## THE WARRANTOR

The warrantor of Goodyear tires is The Goodyear Tire & Rubber Company, 1144 E. Market Street, Akron, Ohio 44316.

For Customer Assistance: 1-800-321-2136 (Nationwide)

### SAFETY WARNING

Follow safety precautions and instructions contained in the Owner's Manual, tire placard in the vehicle or the Important Tire Safety Information in this booklet. Disregarding tire safety information may result in tire failure or explosion causing serious personal injury or death.

## WHO IS COVERED

The owner of a Michelin Passenger or Light Truck tire which bears the Michelin name and complete DOT identification number.

## WHAT IS COVERED AND FOR HOW LONG

Michelin Passenger and Light Truck tires, used in normal service on the vehicle on which they were originally fitted and in accordance with the maintenance recommendations and safety warnings contained in the owner's manual and in the Important Tire Safety Information Section of this booklet, are covered by this warranty against defects in workmanship and material for the life of the original usable tread, or 6 years from the date of purchase, whichever comes first. At that time, all warranties, express or implied, are terminated. The usable tread is the original tread down to the level of the tread wear indicators - 2/32nds of an inch (1.6mm) of tread remaining. Date of purchase is documented by new vehicle registration or tire sales invoice. If no proof of purchase, coverage will be based on date of manufacture.

## WHAT IS NOT COVERED

Tires which become unserviceable due to:

- Road hazard injury (e.g., a cut, snag, bruise, impact damage, puncture, whether repairable or not);
- Incorrect mounting of the tire, tire/wheel imbalance, or improper repair;
- Underinflation, overinflation, improper maintenance or other abuse:
- Mechanical irregularity in the vehicle such as wheel misalignment resulting in uneven or rapid wear;
- Accident, fire, chemical corrosion, tire alteration, or vandalism;
- Ozone or weather cracking.

## WHAT MICHELIN WILL DO

### **PASSENGER AND LIGHT TRUCK TIRES**

A tire which becomes unserviceable due to a condition covered by this warranty will be replaced with a comparable new Michelin tire, free of charge, when 2/32nds of an inch (1.6mm) or less of the original tread is worn, (or 25% or less, whichever is most beneficial to the user) and within 12 months of the date of purchase. Mounting and balancing of tires is included. The cost of any other service charges or applicable taxes are payable by the user.

When more than 2/32nds of an inch of original tread has been worn (or more than 25%, whichever is most beneficial to the user) or after 12 months from date of purchase, the user must pay the cost of a comparable new Michelin passenger or light truck replacement tire on a pro-rata basis. The dealer shall determine the charge by multiplying the percentage of the original usable tread worn by the current actual selling price at the adjustment location or the price on the current Michelin Base Price List, whichever is lower. This List is based on a predetermined price intended to fairly represent the actual selling price of the tire. The cost of mounting, balancing and any other service charges or applicable taxes are payable by the user.

(Continued on page 29)

## WHAT THE CONSUMER MUST DO

When making a claim under the terms of this warranty, the onsumer must present the tire to an authorized Michelin ealer. To locate an Authorized Tire Dealer, check the ellow pages under "Tire Dealers - Retail."

he vehicle on which the tire was used should be available br inspection.

is essential that you read and understand the safety and haintenance recommendations (see Safety Maintenance formation) for your tires.

## **CONDITIONS AND EXCLUSIONS**

HIS WARRANTY DOES NOT PROVIDE COMPENSAION FOR LOSS OF TIME, LOSS OF USE OF VEICLE, INCONVENIENCE OR CONSEQUENTIAL DAMGE.

RES PRESENTED FOR CLAIM REMAIN THE PROP-TTY OF THE CONSUMER AND MICHELIN ACCEPTS OR RESPONSIBILITY FOR LOSS OF, OR DAMAGE ), TIRES WHICH ARE IN THE CUSTODY OR CON-IOL OF A MICHELIN TIRE DEALER FOR THE PUR-SES OF INSPECTION FOR WARRANTY ADJUST-INT. IN THE EVENT OF A DISPUTED CLAIM, THE ONSUMER MUST MAKE THE TIRE AVAILABLE FOR RTHER INSPECTION. NO MICHELIN REPRESENTATIVE, EMPLOYEE OR DEALER HAS THE AUTHORITY TO MAKE OR IMPLY ANY REPRESENTATION, PROMISE OR AGREEMENT, WHICH IN ANY WAY VARIES THE TERMS OF THIS WARRANTY.

THIS WARRANTY APPLIES ONLY IN THE UNITED STATES AND CANADA.

### **CONSUMER RIGHTS**

THIS WARRANTY GIVES YOU SPECIFIC LEGAL RIGHTS, AND YOU MAY ALSO HAVE OTHER RIGHTS WHICH VARY FROM STATE TO STATE AND PROVINCE TO PROVINCE.

### SAFETY MAINTENANCE INFORMATION

Read your vehicle owners manual, the information on the sidewall of your tires, the vehicle tire information placard and the Important Tire Safety Information section of this booklet for essential safety and maintenance information.

## THE WARRANTOR

The warrantor of Michelin Tires is Michelin North America, Inc. 1 Parkway South, P.O. Box 19001, Greenville, South Carolina 29602-9001.

For Customer Assistance:

1-800-TIRE HELP (800-847-3435) - U. S.

1-800-461-8473 - Canada (outside Quebec)

1-800-565-7638 - Canada (Quebec)

## **DANGER**

Disregarding any of the safety precautions and instructions contained in the Owner's Manual or the Important Tire Safety Information in this booklet may result in tire failure or explosion causing serious personal injury or death

## PASSENGER TIRES AND LIGHT TRUCK TIRES LIMITED WARRANTY

Toyo Tire (U.S.A.) Corporation warrants Toyo brand passenger tires and light truck tires mounted on vehicles as original equipment for adjustable conditions as follows:

### 1. What is covered by the warranty:

Toyo brand passenger and light truck tires are warranted for adjustable conditions other than those listed under "What Is Not Covered" for the new original usable tread down to the treadwear indicators (2/32nd" tread remaining) or for 60 months from the date of manufacture, whichever comes first. The DOT serial number on the sidewall of the tire will be used to determine date of manufacture. This time limit does not apply to Toyo temporary spare tires. Presence of a manufacturing anomaly is not necessarily required to qualify for adjustment.

- (A) When less than 25% of the original usable tread of a radial tire, or less than 50% of the original usable tread of a temporary spare tire has been worn, the tire will be replaced with a new Toyo tire free of charge, including mounting and balancing. (Adjustments for ride disturbances or vibration, which cannot be corrected by balancing are only adjustable in the first 25% of usable tread.) Service charges or any applicable taxes are payable by you.
- (B) When more than 25% of the original usable tread of a radial tire, or more than 50% of the original usable tread of a temporary spare tire has been worn the user must pay for the cost of a replacement tire based on the amount of tread used. This

is calculated by dividing the number of 32nds of an inch used by the original usable tread depth and multiplying by the actual current dealer selling price. Service charges or any applicable taxes are payable by you.

## 2. What is not covered by the warranty:

- (A) Mileage is not warranted.
- (B) Damage due to road hazards whether repairable or not (such as cuts, snags, bruises, impact or punctures, improper tire chains).
- (C) Irregular tread wear or rapid tread wear due to failure to rotate the tires at recommended intervals, or from vehicle misalignment.
- (D) Damage resulting from improper repair materials or procedures.
- (E) Damage from incorrect mounting or dismounting of the tire, incorrect wheel size, or failure to balance the tires.
- (F) Damage or uneven tread wear from incorrect inflation, overloading, fire, theft, defective mechanical conditions such as brakes, shocks, rims, wreck or collision, and willful damage or abuse.
- (G)Damage, corrosion, or rubber deterioration due to the use of oil-based chemicals, water-based sealers, balancing substances, or flammable gases.
- (H) Ride, balance, or vibration complaints after the first 25% of tread wear.
- Minor surface blemishes due to weathering and normal wear and tear which do not affect the serviceability of the tire.

- (J) Any tire which has been run to destruction while flat.
- (K) Tires used in commercial service.
- (L) Claims after 5 years from the date the tire was manufactured.
- (M) Tires on vehicles normally operated outside the United States.
- (N) Claims made by anyone other than the original retail purchaser of the vehicle.
- (O)Tires with the D.O.T. identification number removed or rendered illegible, or branded "used".
- (P) Any claim where the tire is not presented and available for Toyo's inspection.
- (Q) Any tire for which mileage and tire rotation records are not available or verifiable.
- (R) Any tires worn beyond the wear bars (less than 2/ 32" remaining tread).
- (S) Temporary spare tires used at speeds over 50 miles per hour.
- (T) Dealer service charges are not covered for routine or required maintenance of the tires such as alignments or rotation.

## **CONSUMER'S OBLIGATION**

The consumer is responsible for proper tire care and maintenance:

- Tires must be rotated every 7,500 miles or sooner if upon inspection, irregular or erratic tread wear is beginning to appear. Keep a record of the rotation.
- (2) The consumer must maintain the recommended air

(Continued on page 31)

sure in the tires according to Nissan's recomdation.

**>onsumer must** maintain the vehicle's alignment in **rdance** with Nissan's specifications.

oad capacity of the tires must not be exceeded.
tire's maximum speed capability must not be aded.

## KE A CLAIM UNDER THIS D WARRANTY

Int that you make a claim under the terms of the you must:

nt your tires, and your vehicle to an authorized Dealer. (Call consumer relations at 442-8696 or check dealer locator at http://toyo.com for the nearest dealer location.)

lete and sign the Toyo Standard Claim form led by the dealer and leave the tire with the dealer rranty processing.

or your convenience, your nearest authorized ssan Dealership will also assist you with your tire rvice requirements or in obtaining tire warranty rvice from the tire manufacturer.

mer is entitled to an adjustment in accordance varranty that was in effect when the tire was 1 the vehicle as original equipment. The adjusty provides for replacement with a comparable ire if a Toyo tire becomes unserviceable due to be condition verified by Toyo's inspection of the eplacement or a pro-rated charge depends on

the remaining usable tread when the tire is presented for adjustment.

### **EXCLUSIONS AND LIMITATIONS**

This warranty is limited to the 50 United States, and the District of Columbia. All implied warranties, including warranty of merchantability or fitness for a particular purpose are expressly limited to the duration of this warranty. All obligations or liabilities for incidental or consequential damages are hereby excluded (such as loss of time, loss of use of vehicle, towing charges or road service or inconvenience). Some states do not allow limitations on how long an implied warranty lasts, or the exclusion or limitation of incidental or consequential damages, so the above limitations or exclusions may not apply to you. No Toyo employee, representative or dealer has the authority to make or imply any representation, promise or agreement which in any way varies the terms of this warranty. This warranty gives you specific legal rights and you may also have other rights which vary from state to state.

Important: In accordance with Federal Law, this warranty has been designated as a "Limited Warranty".

Nothing in this warranty is intended to be a representation that tire failures cannot occur.

### THE WARRANTOR

The warrantor of Toyo Tires is Toyo Tire U.S.A. Corp., 6415 Katella Ave., Suite 200, Cypress, CA 90630.

## IMPORTANT SAFETY AND MAINTENANCE INFORMATION!

Any tire, no matter how well constructed, can fail as a result of punctures, impact damage, improper inflation or other conditions resulting from use. Tire failures may create a risk of property damage or personal injury. To reduce the risk of tire failure, we strongly recommend the following:

## **WARNING!**

## SERIOUS INJURY MAY RESULT FROM:

- Tire failure due to underinflation, vehicle overloading, or use in excess of legal speeds – follow owner's manual or tire information placard in your vehicle
- Explosion of tire/rim assembly due to improper mounting – only specially trained persons should mount tires.

Refer to Important Tire Safety Information and instructions contained in this booklet, the tire placard in the vehicle or the Owner's Manual.

,

your new Nissan vehicle is the tire manufacturer or tire distributor of your specific tires. Nissan is NOT the warrantor of your original equipment tires. The warrantor for each of the tire brands which may be installed as original equipment on your new Nissan is listed below.

BFGoodrich Tires
 P.O. Box 19026
 Greenville, South Carolina 29602-9026
 1-877-788-8899

Bridgestone and Firestone Tires Bridgestone/Firestone, Inc.

Attn: Technical Services One Bridgestone Park Nashville, Tennessee 37214 1-800-TIREBSA (1-800-847-3272)

Continental General Tire, Inc. 1800 Continental Blvd.
Charlotte, North Carolina 28273 1-800-847-3349 1-800-461-1776 (In Canada) http://www.contigentire.com

Goodyear Tire & Rubber Company (Goodyear and Duniop Tires)

1144 E. Market Street Akron, Ohio 44316 1-800-321-2136 1 Parkway South P.O. Box 19001 Greenville, South Carolina 29602-9001 1-800-TIRE HELP (1-800-847-3435) - U. S. 1-800-461-8473 - Canada (outside Quebec) 1-800-565-7638 - Canada (Quebec)

■ Toyo (U.S.A.) Corporation 6415 Katella Ave., Suite 200 Cypress, California 90630 1-800-442-8696 http://www.toyo.com

## WHAT IS COVERED

The tire manufacturer's warranty for the specific tires supplied as original equipment on your vehicle may be found on the preceeding pages.

Please refer to the following pages for important safety information.

### WHAT YOU MUST DO

To obtain information on tire warranties and tire dealer service locations or for customer service, contact the appropriate warrantor listed above.

In order to obtain warranty service, you must present the unserviceable tire to an authorized Nissan dealer or to an authorized dealer of the warrantor in the United States or Canada. Their names and addresses are listed in your local telephone directory. Your Nissan dealer will also assist you with your tire service requirements or in obtaining tire warranty service from the tire manufacturer.

r tire, no matter how well constructed, may fail due to roper maintenance or service factors. This could create sk of property damage and serious or fatal injury. regarding any of the safety precautions and instructions tained in this manual may result in tire failure or explorations perious personal injury or death. For your ity, comply with the following:

## **RE INFLATION**

p tires inflated to the pressures recommended on the data placard. (See your OWNER'S MANUAL for tion.) These inflation pressures must be maintained as nimum. However, do not exceed the maximum presarating indicated on the tire sidewall.

ECKINFLATION PRESSURES ON ALL YOUR TIRES, LUDING THE SPARE, WHEN TIRES ARE COLD, AT ST ONCE A MONTH BEFORE DRIVING.

re to maintain correct inflation may result in improper the handling and may cause rapid and irregular tire r, sudden tire destruction, loss of vehicle control and us personal injury. Therefore, inflation pressures ild be checked at least once a month and always prioring distance trips.

sures should be checked when tires are cold. The tires old when your vehicle has been driven less than a mile derate speed after being stopped for three or more

ovided by and published at the request of the tire nufacturers/warrantors.

## CHECKING PRESSURE WHEN TIRES ARE HOT

If you must add air when your tires are hot, add four pounds per square inch (psi) (28kPa) above the recommended cold air pressure. Recheck the inflation pressure when the tire is cold.

For Example Only:

Gauge reading of hot tire: 32psi If recommended pressure is: 30psi

Desired gauge reading of hot tire 30 + 4psi = 34psi

Check cold pressures as soon as possible, at least by the next day. Never "bleed" air from hot tires as your tire will be underinflated. Use an accurate tire gauge to check pressures. Never allow children to air up tires.

DRIVING ON ANY TIRE THAT DOES NOT HAVE THE CORRECT INFLATION PRESSURE IS DANGEROUS. For replacement tires, the correct inflation pressure will be provided by your tire dealer, if not, refer to the vehicle decal

Underinflation produces extreme flexing of the sidewalls and builds up heat which may result in sudden tire destruction and serious personal injury. Overinflation can cause the tire to be more susceptible to impact damage.

#### LOAD LIMITS

DO NOT OVERLOAD. DRIVING ON ANY OVER-LOADED TIRE IS DANGEROUS. Never load your tires beyond the load carrying limits molded into the sidewall of the tires or the maximum vehicle load limit as shown on the vehicle tire data placard, whichever is less. Overloading causes heat to build up which can lead to sudden tire failure and serious personal injury.

## SPEED LIMITS AND SPEED RATED TIRES

HIGH SPEED DRIVING CAN BE DANGEROUS. Never operate your vehicle in excess of lawful speeds or the maximum speeds justified by the driving conditions. Excessive speeds or racing can cause heat buildup in a tire leading to possible failure and serious personal injury.

Correct inflation pressure is especially important. However, at high speeds, even with the correct inflation pressure, a road hazard, for example, is more difficult to avoid and if contact is made, there is a greater chance of causing tire damage than at the lower speed. Moreover, driving at high speed reduces the reaction time available to avoid accidents and bring your vehicle to a safe stop. If you see any damage to a tire or wheel, replace it with your spare tire and see your tire dealer at once.

Tire speed ratings do not imply that a vehicle can be safely driven at the maximum speed for which the tire is rated. In addition, some damages or improper repairs may cause a speed-rated tire to lose its speed rating. Exceeding the tire's maximum speed rating will cause the tire to build up excessive heat which can cause tire damage that could result in sudden tire destruction and rapid air loss. Failure to control a vehicle with sudden air loss can lead to an accident. In any case, you should not exceed reasonable speeds as indicated by the legal limits and driving conditions.

(Continued on page 34)

**SPEED SYMBOLS** - are shown on the sidewall of some ires. The following table shows the maximum speed coresponding to the symbol.

SPEED RATINGS		
<sup>†</sup> Speed Rating	Speed mph	Maximum km/Hr
М	81	130
N	87	140
Р	93	150
Q	99	160
R	106	170
S	112	180
T	118	190
Н	130	210
V*	149	240
Z**	149	240

\*Some V (or VR) rated tires may have a speed capacity of greater than 149 mph (240 km/h). Consult your tire manufacturer for maximum speed ratings if your vehicle capability exceeds this speed.

\*\*Z (or ZR) rated tires are designed for use on cars with maximum speed capabilities in excess of 149 mph (240 km/h). Consult your tire manufacturer for maximum speed capabilities.

<sup>†</sup>Although a tire may be speed rated, we do not endorse the operation of any vehicle in an unsafe or unlawful manner.

Speed ratings are based on laboratory tests which relate to performance on the road, but are not applicable if tires are underinflated, overloaded, worn out, damaged, altered, improperly repaired, or retreaded. Furthermore, tire speed ratings do not imply that vehicles can be safely driven at the maximum speed for which the tire is rated, particularly under adverse road and weather conditions or if the vehicle has unusual characteristics. Most highway passenger tires that do not have a speed symbol in the sidewall have a maximum speed rating of 105 mph. Light truck highway tires that do not have a speed symbol on the sidewall of the tire have a maximum speed of 87 mph. Some light truck tires may have higher maximum speeds; consult your tire dealer. The speed and other ratings of retreaded tires are assigned by the retreader and voids the original manufacturer's ratings.

**IMPORTANT:** In order to maintain the speed capability of the vehicle, replacement tires must have speed ratings equal to or higher than those fitted as original equipment (as indicated on the vehicle placard or owners manual). If tires with lower speed ratings are fitted, the speed capability of the vehicle will be lowered to the maximum speed capability of the replacement tire as indicated on the above table.

Remember...High speed driving can be dangerous and may be damaging to your tires.

And...When driving at highway speeds, correct inflation pressure is especially important.

Contact the manufacturer of your tires for their position and assistance on the repair of speed-rated tires. When you are replacing tires that have a speed rating, you must replace with tires of the same or higher speed rating if the speed capability of the vehicle is to be maintained.

## **VISUAL INSPECTION**

INSPECT YOUR TIRES. DO NOT DRIVE ON A DAMAGED TIRE OR WHEEL. Check your tires frequently for scrapes, bulges, separations, cuts, snags, cracks, penetrations or excessive localized wear from hard braking. Also check for abnormal tire wear, particularly on the edges of the tire tread which may be caused by misalignment or underinflation. Impacts can damage the inner portion of the tire without being visible on the outside. If damage can be seen on the tires or wheels, or if you suspect that possible impact damage may have occurred, replace with spare at once and have your tire store or dealer inspect your tires immediately. Use of a damaged tire could result in tire destruction. When inspecting your tires, including the spare, check your air pressures. If your pressure check indicates that one of your tires has lost pressure of two pounds or more, look for signs of penetrations, valve leakage, or wheel damage that may account for the air

All tires will wear out faster when subjected to high speeds as well as hard cornering, rapid starts, sudden stops, frequent driving on roads which are in poor condition, and off-road use. Roads with holes and rocks or other objects can damage tires and cause misalignment of your vehicle. When you drive on such roads, drive on them carefully and slowly, and before driving again at normal or highway speeds, examine your tires for any damage, such as cuts, bulges, penetrations, unusual wear patterns, etc.

(Continued on page 35)

\* Provided by and published at the request of the tire manufacturers/warrantors.

EAD WEAR INDICATORS (WEAR BARS): Tires tain Tread Wear Indicators (Wear Bars) in the grooves he tire tread which show up when only 2nds of an inch (1.6mm) of tread is remaining. this stage, your tires must be replaced. Tires rn beyond this stage are dangerous.

### ZARDS

ects in the road that threaten a tire should be safely ided. These objects are potholes, glass, metal, rocks, ad debris and the like. Unavoidable contact should mpt a thorough tire inspection.

I may not always recall hitting an object that can hage or injure your tires. If while driving your vehicle eriences any unusual vibrations, ride disturbance or se and/or you suspect that possible damage to the tires ehicle has occurred. DO NOT JAM OR LOCK YOUR AKES! Rather reduce your speed and drive with tion until you can safely pull off the road. Stop and sect the tires. If the tire is underinflated or damaged, late, remove the tire and rim assembly and replace it so your spare. If you cannot detect a cause, have the icle towed to the nearest vehicle or tire dealer to have vehicle inspected.

## :PAIRING, MOUNTING AND :MOUNTING OF TIRES

not attempt to repair, mount or demount a tire irself. Tire changing can be dangerous and must be to by professionally trained persons using proper tools i procedures as specified by the Rubber Manufacturers ociation (RMA). Follow these mounting recommations. Your tires should be mounted on wheels of rect size and type and which are in good, clean condi-

Provided by and published at the request of the tire nanufacturers/warrantors.

tion. Bent, chipped or rusted wheels may cause tire damage. The inside of the tire must be free from foreign materials. Have your dealer check the wheels before mounting new tires. Mismatched tires and rims can explode during mounting. Also, mismatched tires and rims can result in dangerous tire failure on the road. If a tire is mounted by error on the wrong-sized rim, do not remount it on the proper rim - scrap it. It may be damaged internally (which is not externally visible) by being dangerously stretched and could fail on the highway.

Old valves may leak. When new tubeless tires are mounted, have new valves of the correct type installed. Tubeless tires must be mounted only on wheels designed for tubeless tires, i.e., wheels which have safety humps or ledges.

Never perform a temporary repair, use an innertube or inject sealant as a permanent substitute for a proper repair. Only qualified persons should repair tires.

Be sure that all your valves have suitable valve caps. This will keep valve cores clean and clear and guard against leakage.

REPAIRS - WHENEVER POSSIBLE, SEE A TIRE DEALER AT ONCE. Some tire manufacturers do not warrant any inspection or repair process. The repair is entirely the responsibility of the repairer. Punctures in the tread of a passenger tire which do not exceed 1/4 of an inch (6mm) in diameter can usually be repaired by following the Rubber Manufacturer's Association (RMA) Passenger and Light Truck Repair procedures. Contact the manufacturer of your tires for its position and assistance as to the acceptable location for a proper repair and the repair of speed rated tires. Do not use plug repairs. They may cause further damage to the tire. They are not

always air tight and the plug may fail. Do not exceed posted speed limits on any repaired tire. Certain tire manufacturers speed ratings are voided if the tire is repaired.

Although a tire was properly repaired, internal structural damage resulting from the puncture may have occurred. Sometime later the damage may cause the tire to be removed from service.

If the tire has a puncture in the tread which exceeds 1/4 inch (6mm), the tire must be replaced. If any tire has sustained a puncture, have the tire inspected internally by a tire dealer for possible damage that may have occurred.

Improper mounting and inflation procedures can cause an explosion of the tire/rim assembly. Only specially trained persons should perform these tasks. Contact your tire store or dealer for assistance.

CAUTION - Never, under any circumstance, introduce a flammable substance into a tire.

## WHEEL ALIGNMENT AND BALANCING

Wheel alignment and balancing are important for safety and maximum mileage from your tires. Check how your tires are wearing at least once a month. If your tires are wearing unevenly, such as the inside shoulder of the tire wearing faster than the rest of the tread, or if you detect excessive vibration, your vehicle may be out of alignment or balance. These conditions not only shorten the life of your tires, but adversely affect the handling characteristics of your vehicle which could be dangerous. If you detect irregular wear or vibration, have your alignment and balance checked immediately. Tires which have been run underinflated will show more wear on the shoulders than in the center of the tread.

(Continued on page 36)

## HARD BRAKING

You must inspect your tires after any hard braking circumstances or after tires have slid on the pavement. This can cause a flat spot in a section of the tire tread.

## TIRE SPINNING

Never spin your tires above a speedometer reading of 35 mph (55 km/h) if your vehicle becomes stuck. The centrifugal force generated by the free spinning tire/wheel assembly may cause a sudden tire explosion, resulting in vehicle damage and/or serious personal injury or death. Never allow anyone to stand near or behind a tire spinning at high speed while attempting to push a vehicle that is stuck. When in mud, sand, snow, ice or other slippery conditions, do not indulge in excessive wheel spin. In such conditions, with automatic transmission vehicles, by accelerating the engine excessively, it is possible to spin one of the drive tires beyond its speed capability. This is also true when balancing a drive tire/wheel assembly using the engine of the vehicle to spin the wheel.

## TIRE TREAD

Tires must be replaced when the depth of the tread reaches 2/32 inch (1.6 mm). Tires are manufactured with tread wear indicators molded into the tire grooves which indicate tread wearout. As tires approximate 2/32 inch (1.6 mm) wearout, the tread gauge becomes thinner and more vulnerable to the effects of road hazards. Also, worn tires are more subject to hydroplaning, which can cause loss of control. Therefore, visual tire inspection becomes more crucial as the tires wear out.

## **WORN TIRES**

Never drive on worn tires. Tires should be replaced by trained personnel when 2/32nds of an inch tread depth remains, as indicated by the tread wear indicators molded into the tread grooves. In most states, it is illegal to drive with less than 2/32nds of an inch of tread remaining.

## TIRE MIXING

For best performance select tires similar in size and load rating to the original equipment tires. It is recommended that the same size and type of tire be used on all four wheel positions. In certain tires, casing ply material and ply construction may vary as indicated on the sidewall of the tire. When changing or replacing tires, it is preferred that all four tires are the same construction type (i.e., High Performance, All Season, Mud & Snow) and construction (Radial or Bias Ply). Before mixing tires of different types on a vehicle in any configuration, be sure to check the vehicle owner's manual for its recommendations.

Tires which meet the Rubber Manufacturer's Association (RMA) definition of mud and snow tires are marked M/S, M+S, M&S. On such tires, this designation is molded into the sidewall. Tires without this notation are not recommended for mud and/or snow driving.

If snow tires are needed, it is necessary to select tires equivalent in size and load rating to the original equipment tires. Always fit performance snow tires in sets of four (4) for optimum mud & snow traction and maintenance of vehicle handling characteristics. If you do not, it may adversely affect the safety and handling of your vehicle. It is also important to check the vehicle owner's manual before mixing or matching tires on 4-wheel drive vehicles as this may require special precautions.

Please refer to your Owner's Manual for more information on tire replacement precautions.

### TIRE ROTATION

Tires on your Nissan vehicle should be rotated every 7,500 miles or as irregular wear develops. If irregular wear becomes apparent or if the wear rate on the tires is perceptibly uneven, the tires should be rotated in such a way to alleviate the problem. Check your vehicle for any mechanical problems and correct if necessary. Any rotation pattern or procedure may be followed including those indicated in the Owner's Manual. Some tires have arrows on the sidewall showing the direction in which the tire should turn. When rotating this type of tire, care must be taken to maintain the proper turning direction as indicated by the arrows. Some vehicles have different tire sizes specified for front and rear axles. Tires on these vehicles should not be rotated side to side (unless they are directional). Where a temporary type spare tire is available, it should not be included in the tire rotation schedule. Such tires are intended for temporary use only. Whenever only two tires are replaced, the new tires should be put on the rear axle of vehicles equipped with the same size tire on all four wheel positions.

(Continued on page 37)

\* Provided by and published at the request of the tire manufacturers/warrantors.

## **LER TOWING**

nticipate towing a trailer, you should see a tire dealer ice concerning the correct size of tire and pressure. :e and pressure will depend on the type and size of iller and hitch utilized, but in no case must the am cold inflation pressure or the tire load rating be led. Check the tire decal and your Owner's Manual her recommendations on trailer towing.

## **ALTERATIONS**

perform any alterations on your tires. Alterations event proper performance, leading to tire damage, can result in an accident. Tires which become iceable due to alterations such as truing, whitewall addition of balancing or sealant liquids, may be ad from warranty coverage. Consult your tire war-

## I PRESSURE TEMPORARY SPARE

•

ne high-pressure spare tire in your Nissan vehicle designed for temporary use only and must not be ned continually as a regular tire. The standard tire would be repaired and/or replaced as soon as assible.

roid driving over obstacles that may damage the tire rough impact or cutting, such as potholes, glass, stal, etc.

 Speed must not exceed 50MPH (80km/h) for nonspeed-rated temporary spare tires.

Temporary spare tires have a limited treadlife which can vary depending on road conditions and your driving habits. The spare tire should be returned to the trunk as soon as the standard tire can be repaired or replaced.

 Because the high-pressure spare tire was specifically designed for your car, it should not be used on any other vehicle.

Do not use snow chains on your high-pressure spare.
 This could cause damage to your vehicle.

 Check the tire's cold inflation pressure monthly and maintain at 60psi (4.2kg/cm²) even when not in use.

8) The high-pressure spare tire should not be used with any other rim nor should standard tires, wheel covers, or trim rings be used on the high-pressure spare tire rim which was originally installed.

 When the tread wear indicator appears on the tire, replace it only with the same type spare tire.

 Do not enter an automatic carwash with a temporary spare tire fitted.

 Do not make a sharp turn or apply the brakes suddenly when driving on a high-pressure temporary spare.

Note: When using any temporary type spare tire, be sure to follow the vehicle Owner's Manual instructions.

### TIRE STORAGE

All tires should be stored in a cool dry place indoors so that there is no danger of water collecting inside them.

When tires are stored they should be stored in a cool place away from sources of heat and ozone such as hot pipes and electric generators. Be sure that surfaces on which tires are stored are clean and free from grease, gasoline or other substances which could deteriorate the rubber. (Tires exposed to these materials during storage or driving could be subject to sudden failure.)

## To Avoid Damage to your Tires and Possible Accident:

- Check tire pressure at least once a month when tires are cold and before long trips.
- Do not underinflate/overinflate.
- Do not overload.
- Drive at moderate speeds, observe legal limits.
- Avoid driving over potholes, obstacles, curbs or edges of pavement.
- Avoid excessive wheel spinning.
- If you see any damage to a tire, replace with spare and see the tire manufacturer's dealer or your Nissan dealership.

For further information, the Consumer Tire Guide on passenger tire care, safety and mileage performance is available in the United States by writing the Tire Industry Safety Council, Box 1801, Washington, D.C. 20013.

ded by and published at the request of the tire facturers/warrantors.

### WHAT IS COVERED

Nissan\* warrants to correct defects in materials or work-manship in all genuine Nissan replacement parts, Genuine NISMO S-tune parts, and Genuine Nissan accessories, distributed by Nissan North America in the United States, installed and used on Nissan or Infiniti (if an appropriate use and application of the part, accessory, or Genuine NISMO S-tune part) vehicles only, except as described under the caption below, "WHAT IS NOT COVERED."

This warranty covers any repairs needed to correct defects in materials or workmanship. Bedliners will be repaired to commercially acceptable standards subject to the conditions and limitations listed in "WHAT IS NOT COVERED."

 Nissan indicates Nissan North American, Inc., P.O. Box 191, Gardena, California 90248-0191 which distributes and provides consumer services for Nissan Vehicles in the United States.

## **HOW LONG IS THE WARRANTY**

Except for replacem ent audio components, this warranty is for 12 months or 12,000 miles from the date of installation or purchase, whichever is earlier. However, the warranty on Genuine Nissan replacement parts, Genuine NISMO S-tune parts, and Genuine Nissan accessories installed in a Nissan or Infiniti vehicle while the vehicle is covered by a Nissan warranty, which would have covered the part had it been installed in the vehicle at manufacture, will not end before the end of that warranty.

## **REPLACEMENT AUDIO COMPONENTS**

A replacement Radio, Tape Deck, Amplifier or Compact Disc Player/Auto Changer or Cellular Phone supplied by Nissan is covered for 12 months/unlimited mileage from the time of installation or the balance of the Basic Vehicle Warranty as it applies to audio components, whichever is greater.

## WHAT IS NOT COVERED

This warranty does not cover:

- Tires or batteries. These items are covered by separate warranties.
- Nissan Motorsports and NISMO R-tune parts, including NISMO Legacy parts are sold "AS IS" without warranties, express or implied unless expressly prohibited from doing so by applicable law, in which case the warranty provided is the minimum required by law.
- Normal maintenance service and parts replacement as outlined in the maintenance schedule of your OWNER'S MANUAL.
- 4. Damage or failures of parts resulting from:
  - Misuse (your OWNER'S MANUAL is your guide to proper use).
  - Accident, theft, fire, driving through water resulting in engine water ingestion.
  - Chemical fallout, tree sap, salt, sand, hail, flood or other environmental conditions.
  - Modification or improper repair of the part or of the vehicle in which the part is installed.
  - Use of parts not equivalent in quality or design to parts supplied by Nissan.
  - Lack of performance of required maintenance services as outlined in your OWNER'S MANUAL.
  - · Use of improper or dirty fuel, fluids or lubricants.
  - Normal wear and tear, including dings, dents, dents, chips or scratches.
- 5. SALVAGE TITLE. This warranty does not cover damage, failures or corrosion to any Nissan replacement part, Genuine NISMO S-Tune Part, or Genuine Nissan Accessory, installed in the vehicle, if the vehicle is issued a "salvage" or similar title. (This exclusion does not extend to

new Genuine Nissan replacement parts, NISMO S-tune parts or Genuine Nissan accessories, installed in a Nissan or Infiniti vehicle after the issuance of a "salvage" or similar title.)

## WHAT YOU MUST DO

In order to obtain warranty service you must deliver the warranted part or accessory, or the vehicles, on which the part or accessory is installed, to an authorized Nissan or Infiniti dealer in the United States or Canada at your expense with proof of purchase (parts invoice or service repair order from an authorized Nissan or Infiniti dealer). (Continued on page 39)

## LIMITATION OF WARRANTIES AND OTHER WARRANTY TERMS AND STATE LAW RIGHTS

EXTRA EXPENSES - LIMITATIONS OF DAMAGES
This warranty does not cover incidental or
consequential damages such as loss of the
use of the vehicle, inconvenience or commercial loss.

ANY IMPLIED WARRANTY OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE SHALL BE LIMITED TO THE DURATION OF THIS WRITTEN WARRANTY.

Some states do not allow the exclusion or limitation of incidental or consequential damages or limitations on how long an implied warranty lasts, so the above limitations or exclusions may not apply to you. This warranty gives you specific legal rights, and you may also have other rights, which vary from state to state.

Nissan does not authorize any person to create for it any other warranty, obligation or liability in connection with this vehicle.

The names and addresses of authorized Nissan and Infiniti dealers are listed in telephone directories.

You must also pay for labor charges to remove and replace the part or accessory if it was not originally installed on your vehicle by an authorized Nissan or Infiniti dealer.

## WHAT NISSAN WILL DO

If the part or accessory to be repaired was originally installed by an authorized Nissan or Infiniti dealer, it will be removed and reinstalled after repair at no charge for parts and labor. If the part or accessory was not installed by an authorized Nissan or Infiniti dealer, the part or accessory will be repaired or exchanged only. Any needed parts replacement or exchange will be made using new or remanufactured parts at Nissan's option.

## WHAT IS COVERED

Nissan² warrants to the first retail purchaser ("Original Repairing Vehicle Owner"), that Nissan will either repair or replace the Genuine Nissan Outer Sheet Metal Panels you install or have installed on your Nissan vehicle should the purchased panels develop inside out rust-through corrosion perforation. Replacement sheet metal panels must be installed on vehicles owned and operated in the United States and Canada. Nissan warrants to the Original Repairing Vehicle Owner that the replacement and refinishing of panels will be carried out at no cost to the Original Repairing Vehicle Owner subject to the exclusions listed.

## WHAT IS NOT COVERED

This warranty becomes void when damage results from:

- Accidents, collision, faulty installation, or any alteration to the panel, panels, or vehicle that could be reasonably expected to affect the performance of the covered panels.
- Environmental pollution or conditions, including acid rain, hail, or lightning.
- Vehicle neglect, abuse, or use of the vehicle for unintended purposes.
- Stone chips, scratches, or other paint damage that lead to surface rust damage.
- Cleaning and polishing agents, chemicals, and solvents, including improper undercoating or use of other rust prevention materials.

### WHAT YOU MUST DO

The purchaser must present the Nissan Lifetime Replacement Panel Corrosion Warranty Form, original receipts

and/or repair orders, and personal identification to a Nissan dealership in order to invoke this warranty. The dealership will then authorize the replacement of the panels at a Nissan dealership's collision repair shop or an independent collision repair shop.

## WHAT NISSAN WILL DO

Nissan will pay for the cost of the repair, including parts, labor, paint, and supplies necessary to repair or replace and refinish the panels purchased.

The repair may be completed at an authorized Nissan dealership's collision repair shop or an independent collision repair shop that will install Genuine Nissan replacement parts. Whether a Nissan dealership collision repair shop or independent collision repair shop completes the repair, only authorized Nissan dealership personnel or authorized Nissan personnel can approve a repair or replacement under this warranty.

# ILIMITATION OF WARRANTIES AND OTHER WARRANTY TERMS AND STATE LAW RIGHTS

EXTRA EXPENSES - LIMITATIONS OF DAMAGES

This warranty does not cover incidental or consequential damages such as loss of the use of the vehicle, inconvenience or commercial loss.

ANY IMPLIED WARRANTY OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE SHALL BE LIMITED TO THE DURATION OF THIS WRITTEN WARRANTY.

Some states do not allow the exclusion or limitation of incidental or consequential damages or limitations on how long an implied warranty lasts, so the above limitations or exclusions may not apply to you. This warranty gives you specific legal rights, and you may also have other rights which vary from state to state.

Nissan does not authorize any person to create for it any other warranty, obligation or liability in connection with this vehicle.

The actual warranty is provided with the product purchased and should be read carefully.

Nissan indicates Nissan North America, Inc., P.O. Box 191, Gardena, California 90248-0191, which distributes Nissan vehicles in the United States.

## IAT IS COVERED AND FOR HOW

NG

an\* warrants to correct defects in materials or manship, or for failure due to normal wear and tear, of placement Genuine Nissan Original Equipment fler assemblies, Genuine Nissan vehicle suspensystem shock absorbers and strut assemblies illed on Nissan vehicles only, except as described or the caption below, "WHAT IS NOT COVERED". LIFETIME FEATURE OF THIS WARRANTY APIS ONLY IF the parts are purchased and paid for by the ware installed, and if they are installed by an authorized Nissan dealer, for

is only if the parts are purchased and paid for by twner of the vehicle on which they are installed, and if they are installed by an authorized Nissan dealer, for any as the original purchaser of the replacement fler assembly, shock absorber and/or strut asbly owns the Nissan vehicle on which the parts are lied.

ORTANT: The lifetime feature of this warranty does pply to parts (a) paid for in whole or in part by Nissan, clude warranty replacement, campaigns or goodwill itments, or (b) which are paid for under the terms of service contract. Such parts are instead warranted ist defects in material or workmanship only (but not a due to normal wear and tear) for 12 months or 00 miles from the date of installation or purchase, never is earlier. In no case shall the warranty from its in material or workmanship end prior to the end of pplicable Nissan New Vehicle Limited Warranty on issan vehicle on which the parts are installed, had the 3) been installed in the vehicle at manufacture.

n indicates Nissan North America, Inc., P.O. Box 191, Gardena, nia 90248-0 91 which provides consumer service for Nissan is in the United States.

## LIMITATION OF WARRANTIES AND OTHER WARRANTY TERMS AND STATE LAW RIGHTS

Extra Expenses - Limitations of Damages
This warranty does not cover incidental or consequential damages such as loss of the use of a
vehicle, substitute transportation, inconvenience or
commercial loss.

ANY IMPLIED WARRANTY OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE SHALL BE LIMITED TO THE DURATION OF THIS WRITTEN WARRANTY

Some states do not allow the exclusion or limitation of incidental or consequential damages or limitations on how long an implied warranty lasts, so the above limitations may not apply to you. This warranty gives you specific legal rights, and you may also have other rights which vary from state to state.

Nissan does not authorize any person to create for it any other warranty, obligation or liability in connection with the part(s) subject to this express limited warranty.

## WHAT IS NOT COVERED

This warranty does not cover:

- 1. Genuine Nissan Key Value® Muffler Assemblies.
- Shock absorbers and strut assemblies installed before July 1, 1999. Muffler assemblies installed before October 1, 1999.
- Motorsports Parts and Genuine NISMO R-Tune parts are sold "AS IS" without warranties, express or implied unless expressly prohibited from doing so by applicable law, in which case the warranty is the minimum

provided by law.

- 4. Damage or failure(s) of parts resulting from:
  - Misuse (your OWNER'S MANUAL is your guide to proper use.)
  - · Accident, theft, fire, driving through water.
  - Salt, sand, flood or other environmental conditions.
  - Modification or improper repair of the part or of the vehicle in which the part is installed.
  - Use of parts not equivalent in quality or design to parts supplied by Nissan.
- 5. Salvage Title. This warranty does not apply and is rendered VOID if the vehicle is issued a "salvage," "flood," or similar title under any state's law after the part(s) is purchased unless state law expressly states otherwise. (This exclusion does not extend to new Genuine Nissan Original Equipment muffler assemblies, Genuine Nissan shock absorbers or strut assemblies purchased and installed in the vehicle after the issuance of a "salvage," "flood," or similar title.)

(Continued on page 42)

## WHAT YOU MUST DO

In order to obtain lifetime limited warranty service, bring your vehicle, proof-of-purchase (service repair order from an authorized Nissan dealer in the United States) and personal identification (driver's license, etc.) to any authorized Nissan dealer in the United States. The names and addresses of authorized Nissan dealers are listed in telephone directories.

## WHAT NISSAN WILL DO

If the lifetime feature of this warranty applies to a Genuine Nissan Original Equipment **muffler assembly, shock absorber** or **strut assembly** it will be removed and reinstalled after repair at an authorized Nissan dealer at no charge for parts or labor.

Otherwise a warranted Genuine Nissan Original Equipment muffler assembly, shock absorber or strut assembly will be exchanged only unless you can provide proof that it was originally installed by a Nissan dealer, in which case it will be removed and reinstalled after repair at no charge to you for parts or labor during the term of the warranty. Any needed parts replacement or exchange will be made using new or remanufactured parts at Nissan's option.

### WITAL IS COVERED?

Nissan \* Warrants your Genuine Nissan Replacement Battert as described below except as stated under "What is not covered?"

This warranty covers defects in materials and workmanship.

## HOW LONG IS THE WARRANTY AND WHAT WILL NISSAN DO

Nissan will replace your battery without charge if it becomes unserviceable within the first 24 months of service.

If the battery becomes unserviceable after 24 months of use, Nissan will provide a replacement battery at a reduced price, charging only for the portion of the life of the battery actually used. This is called a "pro-rata adjustment". Nissan will pay for all labor charges in replacing the battery if it was originally installed by an authorized Nissan dealer.

This warranty and the "pro-rata adjustment" end 84 months after the date of the battery's purchase or installation, whichever is earlier.

### WHAT IS NOT COVERED?

This warranty does not cover:

- 1. Damage or failure resulting from:
  - Accident, theft, fire or freezing.
  - Misuse of the battery or vehicle in which it is installed, including the use in applications for which the battery was not designed. Proper use is described in the vehicles Owner's Manual.
  - Improper installation or battery charging.
  - Vehicle electrical malfunctions not covered by your New Vehicle Limited Warranty.

- Modification or improper repair of the vehicle or a part of the vehicle.
- Use of parts not equivalent in quality or design to parts supplied by Nissan.
- Environmental conditions, including, but not limited to flood, and salt spray or salt water.
- Normal maintenance service and recharging of discharged batteries.
- 3. Batteries in service more that 84 months.
- 4. Salvage Title. This warranty does not cover damage, failure, or corrosion to any Genuine Nissan battery installed in the vehicle, if the vehicle is issued a "salvage" or similar title under any state's law, and this warranty is rendered void for any battery installed in a vehicle prior to the vehicle being issued a "salvage" or similar title unless state law expressly states otherwise. (This exclusion does not extend to a new Genuine Nissan battery installed in the vehicle after the issuance of a "salvage" or similar title).

## WHAT YOU MUST DO

In order to obtain warranty service, you must deliver the warranted battery or the vehicle in which the battery is installed to an authorized Nissan dealer in the U.S. or Canada at your expense, with proof of purchase (parts invoice or service repair order from an authorized Infiniti dealer). The names and addresses of authorized Nissan dealers are listed in telephone directories or <a href="https://www.NissanUSA.com">www.NissanUSA.com</a>

If the "pro-rata adjustment" applies, you must pay for the portion of the 84 month warrantable life that you actually used. The amount you pay is computed in two steps. First, the customer pay percentage is determined from the chart shown below based upon the months of actual battery service.

\* NISSAN indicates Nissan North America, Inc. PO Box 191 Gardena, CA 90278-0191, which distributes Nissan vehicles and provides related consumer services in the United States of America

Months	Customer Pay
In Service	Percentage
0-24	0%
25-32	25%
33-50	50%
51_B/	7506

Second, the current suggested retail price of the new battery is multiplied by the customer pay percentage. For example, should the battery fail after 40 months of service you would pay 50% of the suggested retail price of the new battery.

You must also pay for the labor charge to remove and replace the battery if it was not originally installed in your vehicle by an authortized Nissan Dealer.

## LIMITATION OF WARRANTIES AND OTHER WARRANTY TERMS AND STATE LAW RIGHTS

EXTRA EXPENSES-LIMITATIONS OF DAMAGES
This warranty does not cover incidental or
consequential damages such as, but not
limited to, loss of wages or loss of use of the
vehicle, inconvenience, or commercial loss.

ANY IMPLIED WARRANTY OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE IS LIMITED TO THE DURATION OF THE LIMITED WARRANTY.

Some states do not allow the exclusion or limitation of incidental or consequential damages or limitations, so the above limitations or exclusions may not apply to you. This warranty gives you specific legal rights, and you may also have other rights, which vary from state to state.

Nissan does not authorize any person to create for it any other warranty, obligation or liability in connection with this vehicle.

Nissan North America, Inc. and your Nissan dealer realize that there are numerous sources for parts and accessories in today's automotive parts aftermarket. However, Genuine Nissan parts and accessories are designed and manufactured to meet the same factory fit, performance and quality specifications of your Nissan vehicle.

The Parts Department of your Nissan dealership maintains a complete inventory of high quality Genuine Nissan new and remanufactured replacement parts - parts that are backed by one of the most comprehensive parts warranties available in the automotive industry today.

To ensure that your warranty, maintenance and repair parts requirements are satisfied as quickly as possible, Nissan and the Nissan dealer organization maintain a combined inventory consisting of several hundred million dollars worth of readily available parts and popular accessories. In the event a critical part is required that is not stocked by your local dealership, Nissan's ordering system includes a computerized means of ensuring the quickest possible shipment to Nissan dealers by the use of expeditious handling and premium transportation - all of which is supported by one of the most extensive and efficient parts distribution systems in the United States.

Two Nissan North America, Inc. Regional Parts Distribution Centers stock approximately 32,000 different

parts and each of five additional Area Parts Distribution Centers service over 61,000 part numbers. Nissan's Master Parts Distribution Center in Compton, California maintains an inventory of 150,000 low volume part numbers and services all Nissan dealers nationally to ensure that even the most rarely ordered parts are available in the quickest possible time. Additionally, all Nissan parts distribution facilities are linked via a sophisticated computer search and order system to ensure coordinated parts ordering, inventory and distribution. Through this system, you are assured of maximum parts availability at the time the parts are needed to keep your Nissan vehicle on the road not in the shop.

The Nissan name represents quality and a commitment to your satisfaction as a valued customer. So when you select parts or accessories for your Nissan vehicle, see your Nissan dealer. Only Nissan builds Nissan replacement parts and accessories to exact factory specifications.

## RECOMMENDATION FOR MAINTENANCE SERVICE AND REPLACEMENT PARTS FOR YOUR VEHICLE'S EMISSION SYSTEM

To assure best results and to maintain the original quality built into the emission control systems, it is recommended that genuine Nissan parts be used when

SERVICING OF REPAIRING THE SYSTEMS. THE WARRANTY OBLIGATIONS ARE NOT DEPENDENT UPON THE USE OF ANY PARTICULAR BRAND OF REPLACEMENT PARTS AND THE OWNER MAY ELECT TO USE NON-GENUINE NISSAN PARTS FOR REPLACEMENT PURPOSES.

The use of replacement parts which are not equivalent to genuine Nissan parts may reduce the effectiveness of the emission control system.

Therefore, if it becomes necessary to use other than genuine Nissan parts, the owner should assure himself that such parts are warranted by their manufacturer to be equivalent in quality to genuine Nissan parts.

MAINTENANCE, REPLACEMENT OR REPAIR OF THE EMISSION CONTROL DEVICES AND SYS-TEMS MAY BE PERFORMED BY ANY AUTO-MOTIVE REPAIR ESTABLISHMENT OR INDI-VIDUAL USING ANY REPLACEMENT PART.

HOWEVER, UNLESS OTHERWISE AUTHORIZED BY LAW, WARRANTY SERVICE MUST BE PER-FORMED BY AN AUTHORIZED NISSAN DEALER.

The emission standards may be satisfied by having the vehicle inspected periodically and by following the requirements outlined in your OWNER'S MANUAL and your NISSAN SERVICE MAINTENANCE GUIDE.

der to help protect your vehicle against corrosion, important that you care for your vehicle regularly, wing these suggestions:

**Vash your vehicle** regularly using cold clean water and mild vehicle wash soap.

insects, tar or other similar deposits have accumuted on your vehicle, wash it as soon as ossible.

you drive on salted or dust controlled roads, or if you rive near the ocean, hose off the under carriage at sast once a month.

is important that the drain holes in the lower edges of ne doors and rocker panels be kept clear.

- If you detect any stone chips or scratches in the paint, touch them up immediately.
- If you do much driving on gravel roads, consider installing mud or stone shields behind each wheel.
- If your Nissan is damaged due to an accident or similar cause which destroys the paint and protective coating, have your vehicle repaired as soon as possible. The cost of such repairs is considered the responsibility of the owner.
- This corrosion warranty does not cover non-genuine sheet metal parts or damage caused by the installation of such non-genuine sheet metal parts.

SEE YOUR OWNER'S MANUAL FOR FURTHER DETAILS.



#### LONG TERM MECHANICAL PROTEC-TION FOR YOUR NISSAN...

For extra peace of mind you can add Nissan's own Security+Plus® Vehicle Protection Plan which provides you with long term mechanical protection. Backed by Nissan, and designed exclusively for Nissan owners, Security+Plus® is available from your Nissan dealer in a variety of comprehensive coverages.

#### Just a few of its major features:

- With Security+Plus<sup>®</sup>, you can choose from a full spectrum of term options to fit your ownership (time) and driving (mileage) needs.
- Repairs can be performed at participating Nissan dealerships throughout the U.S., excluding U.S. Territories. Repairs at these dealerships are performed by factory trained technicians using Genuine Nissan parts, to keep your vehicle in top running condition.
- 3. All new Security+Plus® Service Agreements are transferable to subsequent owners, thus ensuring flexibility of your investment and enhancing the resale value of your Nissan.

#### YOU SIMPLY CAN'T GET BETTER LONG-TERM PRO-TECTION FOR YOUR MONEY THAN WITH NISSAN'S SECURITY+PLUS®!

For details, please contact your authorized Nissan Dealer or complete the attached business reply card (no postage necessary) and mail it to:

#### Nissan Security+Plus\* Headquarters P.O. Box 680 Gardena, CA 90247-9987

We'll send you a complete information packet by return mail. Do it today! The quicker you act, the sooner you can have the full protection of a Nissan Security+Plus\* Service Agreement.

NOTE: Security+Plus® Service Agreements for previously owned Nissan vehicles can only be purchased from your authorized Nissan dealership at the time of vehicle sale. **EMO** 

# **MEMO**

	NO POSTA NECESSAF MAILED IN THE UNITED STA
BUSINESS	REPLY MAIL
FIRST CLASS MAIL PER	MIT NO. 133 GARDENA, CA
POSTAGE WI	L BE PAID BY ADDRESSEE
NISSAN SECI PO BOX 680 GARDENA CA	PRITY + PLUS® HEADQUARTERS 90247-9987
* Hdullium	ddidhiidhdidididhiidhd
	NO POSTAC NECESSAR MAILED IN THE

# **BUSINESS REPLY MAIL**

FIRST CLASS MAIL PERMIT NO. 133

RMIT NO. 133 GARDENA, CA

POSTAGE WILL BE PAID BY ADDRESSEE

NISSAN NORTH AMERICA, INC. PO BOX 191 GARDENA CA 90248-9981

Mahallan adalah dalah da

**OWNER INFORMATION** Owner's Name Address City State **VEHICLE IDENTIFICATION** Vehicle Identification Date of Delivery Selling Dealer Name Mileage at Delivery Address State **SECURITY+PLUS® INFORMATION Expiration Date** Policy No. Months of Coverage **Expiration Mileage** Security+Plus® coverage must be confirmed. See your Security+Plus® Agreement for details. **ODOMETER REPLACEMENT** Date Mileage Dealer's Name Address

City

NOTE: read this booklet carefully and keep it in your vehicle. Present it to an authorized NISSAN deale when warranty service is required. It should remain with your vehicle when you sell it so subsequer owners will know any remaining warranty coverage.

State

Zip Code

miles

Zip Code

miles

Zip Code

# NISSAN


'06 DP06

Printing: June 2005

©2005 Nissan North America, Inc. All rights reserved.

# ATTACHMENT D

Security Plus service contracts



GADIED PROM

Component Coverage Guide



## **NISSAN SECURITY+PLUS**

# THE BEST PROTECTION FOR YOUR NISSAN

Nissan's Security+Plus Vehicle Protection Plan provides you with quality long-term mechanical protection and extra peace of mind.

It covers the most important components of your Nissan vehicle: Engine, Transmission, Steering, Drive Axle Assembly, Electrical, and many more. Repairs to these parts can run as high as \$4,000 or more. But with Security+Plus, if a covered part fails, Nissan pays...not you.

This guide lists the covered components for the Gold Plan, by major category, in Nissan part number code (PNC) numeric sequence. For complete information regarding other coverage features, and those excluded from coverage, contact your Nissan Dealer.

Unlike other service agreements, Security+Plus is exclusively for Nissan owners, and **backed by Nissan North America, Inc.**\*

### NISSAN SECURITY+PLUS: THE SMART CHOICE

Nissan's Security+Plus Vehicle Protection Plan is designed for new and previously-owned Nissan'vehicles—by Nissan—and offers Nissan owners:

Cost-effective coverage up to 7 years, or 100,000 miles, to protect your investment. Guards against loss from the escalating cost of major repairs (including parts and labor).

**Nationwide Nissan repair** at Authorized Nissan dealerships by Nissantrained technicians. No payment hassles because the dealer is paid directly by Nissan.

Customer Assistance available throughout the United States. Just contact your nearest Nissan dealer, or call us at 1:800-NISSAN-1.

Optional terms of coverage (years and miles) to fit your driving needs, and an optional zero or \$50 deductible for each eligible component repair.

Transfer Security+Plus to a new owner if you sell your Nissan before coverage expires.\*\*

Convenient and economical coverage, costing only pennies a day. Your Nissan dealer will be happy to explain the various financing options available to you.

The cost of **Genuine Nissan replacement parts** is included for covered repairs—not inferior substitutes.

In Florida, Security+Plus is backed by Nissan Extended Service Corporation, Inc., P.O. Box 191 Gardena, California 90248-0191, License #60062.

<sup>\*\*</sup> A nominal transfer fee may apply. For détails, please refer to the Security+Plus Service Agreement or contact your local Nissan dealer.

# CONTENTS

EN	IGINE	
	ENGINE & INTERNAL PARTS	
	LUBRICATION & COOLING	
	FUEL SYSTEM	
	MANIFOLDS & TURBOCHARGER	
	ENGINE ELECTRICAL	
	FUEL INJECTION	
	EMISSION CONTROLS	
PO	WER TRAIN	
	PROPELLER SHAFTS & DIFFERENTIAL	
	CLUTCH, TRANSMISSION, TRANSAXLE & TRANSFER CASE	
	EERING, SUPENSION, BRAKES	)
	STEERING SYSTEM	
	AXLES & SUSPENSION	
	BRAKES	E
	ECTRICAL	Ġ
	BODY FLECTRICAL	6
	HEATER & AIR CONDITIONING	7
во	DY & INTERIOR COMPONENTS	7
	BODY	7
	INTERIOR	3
	ACCES <mark>SORI</mark> ES	Ś
	240SX CONVERTIBLE TOP	
	3507/3007X CONVERTIRES TOP	

COMPONENT	P.N.C.
CYLINDER BLOCK	11010
CYLINDER BLOCK WELSH PLUG	11021
CYLINDER HEAD	11041
CYLINDER HEAD GASKET	11044
CYLINDER HEAD COVER	11046 11051
CYLINDER HEAD WELSH PLUG CYLINDER HEAD BOLT	11056
INTAKE VALVE SEAT	11098
EXHAUST VALVE SEAT	11099
OIL PAN	11110
OIL PAN GASKET	11121
OIL PAN DRAIN PLUG	11128
DIPSTICK	11140
FRONT ENGINE MOUNT	11220
MOUNT - TRANSMISSION LOWER	11221
FRONT MOUNT BRACKET	11232
CENTER MEMBER	11240
ENGINE DAMPER ASSY	11246
GUSSET	11262
ENGINE MOUNT ACTUATOR ASSY	11273
ENGINE MOUNT DAMPER	11290
REAR ENGINE MOUNT	11320
ROLL DAMPER ENGINE MOUNT	11325
REAR MOUNT BRACKET BUFFER	11340 11390
TIMING BELT	11721
SERPENTINE BELT TENSIONER ASSY	11750
SERPENTINE BELT TENSIONER BRACKET	11927
PISTON & PIN SET	12010
PISTON RINGS	12033
CONNECTING ROD & CAP SET	12100
CONNECTING ROD BEARINGS	12111
PISTON OIL JET	12121
CRANKSHAFT	12200
MAIN BEARINGS	12207
REAR MAIN SEAL	12279
CRANKSHAFT PULLEY	12303
PULLEY BOLT	12309
BALANCER UNIT	12416
CAMSHAFT	13001
CAMSHAFT BUSHING (OHV)	13002
IDLER GEAR	13014
FUEL PUMP CAM CRANKSHAFT GEAR	13015
CAMSHAFT GEAR	13024
CAMSHAFT SPROCKET	13024
SPROCKET ASSY—VTC	13025
TIMING CHAIN	13028
FRONT COVER	13035
CRANKSHAFT FRONT OIL SEAL	13042
CAMSHAFT OIL SEAL	13043
COVER GASKET	13044
WATER INLET	13049
LIFTER GUIDE	13051
CHAIN TENSIONER	13070
TIMING CHAIN OIL JET	13081
CHAIN TENSIONER SIDE GUIDE	13085
JACK SHAFT JACK SHAFT OIL SEAL	13161
JACK SHAFT GEAR	13170
INTAKE VALVE	13201
EXHAUST VALVE	13202
VALVE SPRING	13203
VALVE SPRING SEAT	13205
VALVE OIL SEAL	13207
VALVE SPRING RETAINER	13209
	13212
VALVE GUIDE VALVE LIFTER	13231
VALVE PIVOT (L-ENGINE)	13234
ROCKER SHAFT	13252
VALVE ROCKER/SHAFT SPRING	13256
VALVE ROCKER ARM	13257
VALVE ROCKER COVER	13264
ROCKER COVER GASKET	13270
TIMING CHAIN REAR COVER	13500
FRONT COVER GASKET	13520
DUST COVER	13560
EGR PASSAGE	14711
FRONT COVER O-RING	15066
OIL PUMP DRIVE GEAR	15043
OIL STRAINER	15050
DIPSTICK TUBE	15155 15255
OIL FILLER CAP	10400
OIL FILLER CAP COVER PLATE/GASKET	16420
OIL FILLER CAP COVER PLATE/GASKET BELT TENSIONER	16420 16805

COMPONENT	P.N.C
WATER OUTLET	11060
THERMOSTAT HOUSING	11061
WATER OUTLET GASKET	11062
CYLINDER BLOCK WATER OUTLET	11063
THERMOSTAT HOUSING GASKET	11072
A/T AIR GUIDE	11338
WATER CONNECTOR	14054
OIL PUMP	15010
OIL PUMP GASKET	15025
OIL PUMP DRIVE SPINDLE	15040
OIL PUMP REGULATOR VALVE	15132
OIL FILTER BRACKET	15238
FILTER BRACKET GASKET	15239
OIL FILTER RELIEF VALVE	15241
OIL FILTER REGULATOR VALVE	15300
WATER PUMP	21010
WATER PUMP HOUSING AND GASKET	21012
WATER PUMP GASKET	21014
WATER PUMP/FAN PULLEY	21051
FAN BLADE	21060
FAN COUPLING ASSY	21082
THERMOSTAT	21200
OIL COOLER PIPE	21302
OIL COOLER FIN TYPE	21305
OIL COOLER RADIATOR TYPE	21306
	21307
OIL COOLER PROTECTOR	21310
OIL COOLER GASKET PT—OIL COOLER HOSE	21355
RADIATOR	21400
	21430
RADIATOR CAP RADIATOR SHROUD	21475
RADIATOR DRAIN COCK	21480
INJECTOR BLOWER MOTOR	21490
BLOWER MOTOR INLET	21490
	21490
BLOWER MOTOR BRACKET BLOWER MOTOR CLAMP	21497
BLOWER MOTOR CLAMP	21499
	21510
RESERVOIR TANK	21511
RESERVOIR TANK BRACKET	21595
THERMO SWITCH	21593
RADIATOR FAN MOTOR	
A/T OIL COOLER ASSY	21606
OIL COOLER PIPING	21636
COOLANT TEMP. SENSOR	25080
RADIATOR FAN RELAY	25217
OIL PRESSURE SENDING UNIT	25240
OIL PRESSURE SWITCH	25244
BLOWER MOTOR TIMER	28912
FUEL SYSTEM	
BOOST CONTROL VALVE	14920

BOOST CONTROL VALVE	1492
PURGE CONTROL VALVE ASSY	1493
VALVE-EVAP.CAN.PURGE VOL.SOL.	1493
RESONATOR - EVAP PURGE	1493
VAPOR CANISTER ASSY	1494
CARBON CANISTER	1495
EPC VALVE	1495
CARBURETOR	1601
CHOKE CHAMBER	1601
JET/AIR BLEEDS	1603
ALTITUDE COMPENSATOR	1604
POWER VALVE	1605
FLOAT	1606
NEEDLE VALVE	1610
AIR-FUEL RATIO SOLENOID	1610
ENRICHMENT SOLENOID	1610
FUEL CONNECTOR	1611
THROTTLE CHAMBER	1611
CARBURETOR LINKAGE	1613
ACCELERATOR PUMP	1615
THROTTLE RETURN SPRING	1616
MIXTURE HEATER/INSULATOR	1617
DASH POT	1618
THROTTLE POSITIONER	1618
IDLE SPEED CONTROL	1626
SERVO DIAPHRAGM	1626
DIAPHRAGM CHAMBER	1631
THROTTLE CONTROL DIAPHRAGM	1631
IDLE COMPENSATOR	1633
ACCELERATOR TERMINAL	1636
FLOAT CHAMBER GASKET	1645
AIR CLEANER ASSY	1650
VACUUM MOTOR ASSY	1651
IDLE COMPENSATOR TUBE	1652
AIR CLEANER INSULATOR	1652
HOT AIR DUCT	1653

COMPONENT	P.8.6
AIR DUCT ASSY	16577
AIR TEMP SENSOR	16580
RESONATOR	16585
EXHAUST MANIFOLD COVER	16590
FUEL PUMP CONTROL UNIT	17001
FUEL PUMP	17010
ELECTRIC FUEL PUMP	17012
FUEL PUMP CHECK VALVE	17014
FUEL PUMP GASKET	17099
FUEL CONNECTOR	17103
FUEL TANK	17201
TUBE ASSY FILLER	17220
FUEL FILLER NECK	17222
FUEL FILLER CAP	17251
FUEL HOSE PROTECTOR	17271
FUEL TANK PROTECTOR	17285
FUEL TANK DRAIN PLUG	17310
FUEL CHECK VALVE	17330
O-RING	17342
BREATHER VALVE	17368
EVAPORATOR SHUT-OFF VALVE	17371
VACUUM CUT VALVE	17372
FUEL OUTLET TUBE	17501
VAPOR VENT LINE	17508
FUEL RETURN TUBE	17510
FRONT FUEL TUBE	17520
ACCELERATOR ARM	18010
ACCELERATOR BRACKET	18021
PEDAL STOPPER BRACKET	18050
ACCELERATOR WIRE	18150
RETURN SPRING	18215
TORSION SHAFT ASSY	18300
SHAFT SUPPORT	18314
M/H WATER TEMP SWITCH	22121
MIXTURE HEATING RELAY	22122
WATER TEMP SENSOR	22630
FUEL DAMPER	22675
ECC MAIN RELAY	22696
DROPPING RESISTOR	22698
ECC CONTROL UNIT	23710
CRANKSHAFT POS. SENSOR (OBD POS)	23731
CRANKSHAFT POS. SENSOR (REF)	23732
VACUUM CONTROL MODULATOR	23771
FUEL TANK SENSOR	25060
VACUUM SENSOR	25085
FUEL CUT OFF SWITCH	25146
AUTO-CHOKE RELAY	25235
FRESH AIR DUCT	62860
MANUFILDS I THROUGHAN	ROFF

INTAKE MANIFOLD	14001
EXHAUST MANIFOLD	14004
CAP BOLT/STUD	14006
LOWER MANIFOLD COLLECTOR	14011
MANIFOLD TUBE	14012
MANIFOLD COLLECTOR	14013
INTAKE MANIFOLD SUPPORT	14018
LOWER COLLECTOR GASKET	14033
MANIFOLD GASKET	14035
WATER INLET PIPE	14053
COLLECTOR GASKET	14080
EXHAUST MANIFOLD COVER	14091
HEAT SHROUD	14096
TURBOCHARGER	14411
TURBOCHARGER GASKET	14415
EXHAUST OUTLET	14440
EXHAUST OUTLET COVER	14441
GASKET	14445
HEAT INSULATOR	14450
INLET TUBE	14460
INLET TUBE GASKET	14465
EMERGENCY RELIEF VALVE	14466
RE-CIRCULATION VALVE	14483
INTERCOOLER ASSY	14496
WATERPIPE, OUTLET	14498
WATER PIPE, INLET	14499
MANIFOLD CONNECTOR	14875
OIL INLET TUBE	15192
CONNECTOR & GASKET	15194
OIL OUTLET TUBE	15197
FRONT EXHAUST GASKET	20711
CONVERTER GASKET	20712
INTAKE MANIFOLD CONNECTOR & O-RING	21049
BOOST SENSOR	22364
EXHAUST GAS SENSOR	22690
OIL TEMP SENSOR	25075
	250175

# ENGINE/POWER TRAIN GOID PRAIN

EMISSION SCRIPTOLS

COMPONENT	P.N.C.
FLOOR INSULATOR	74661
EFFORM OF CYRICAL	
ALTERNATOR BRACKET	11710
ALTERNATOR ADJUSTING BAR	11715
THERMO ELEMENT KIT	16391
TRANSISTOR IGNITION UNIT	22020
TRANSISTOR (TRIG) UNIT	22022
DISTRIBUTOR	22100
SHAFT	22108
RELUCTOR	22115
GOVERNOR WEIGHT	22127
DISTRIBUTOR PINION	22129
DISTRIBUTOR CAM	22132
ROTOR HEAD	22157
MAGNET	22158
HARNESS	22159
DISTRIBUTOR CAP	22162
STATOR	22163
DISTRIBUTOR PROTECTOR	22172
VACUUM CONTROL	22301
IGNITION COIL/PWR TRANSISTOR	22433
HIGH TENSION CABLE	22450
RESISTOR	22460
IGNITION COIL PROTECTOR	22465
AIR CUT VALVE	22622
ALTERNATOR	23100
ALTERNATOR ROTOR	23108
ALTERNATOR BEARING	23120
ALTERNATOR BRUSH & HOLDER	23133
ALTERNATOR PULLEY	23150
IC VOLTAGE REGULATOR	23215
DIODE SET	23230
STARTER MOTOR ASSY	23300
FIELD COIL	23306
ARMATURE	23310
CLUTCH PINION	23312
REDUCTION GEAR	23313
STARTER SOLENOID	23343
BRUSH	23380
BATTERY CABLE	24110
BATTERY FRAME/TRAY/ROD	24428

FUEL 004 100W

CASE CASE CONTRACTOR	
POWER VALVE ASSY	14510
POWER VALVE SOLENOID VALVE ASSY	14517
POWER VALVE SOLENOID	14952
E.P.C. VALVE	14953
PRESSURE REG. CONTROL	14960
ELECTRO INJECTION UNIT	16012
VENTURI CHAMBER	16017
ALTITUDE SWITCH	16044
THROTTLE CHAMBER	16118
THROTTLE LINKAGE	16135
MIXTURE HEATER	16175
DASH POT	16182
F.I.C.D SOLENOID VALVE	16197
I.A.S. UNIT	16250
WAX HOLDER	16394
COLD START VALVE	16601
FUEL INJECTOR	16603
INJECTOR	16604
FUEL PUMP CONTROL MODULE	17001
THROTTLE CHAMBER	17118
B.C.D.D. ASSY	17484
DETONATION SENSOR	22060
VACUUM TANK	22327
VACUUM SWITCH	22361
CONTROL UNIT (ECU)	22604
CONTROL UNIT - EFI	22611
THROTTLE VALVE SWITCH	22620
WATER TEMP SENSOR	22630
AIR TEMPERATURE SENSOR	22631
CYLINDER HEAD TEMP SENSOR	22632
THERMOTIME SWITCH	22635
AIR REGULATOR	22660
I.S.C. VALVE	22664
PRESSURE REGULATOR	22670
PRESSURE REG. CONTROL MODULE	22671
PRESSURE PUMP	22674
AIR FLOW METER	22680
AIR FLOW METER BRACKET	22682
VACUUM CONTROL VALVE	22686
MAIN RELAY	22694
DROPPING RESISTOR	22695
EFI RELAY	22696

COMPONENT	P.E.C.
MAIN & FUEL PUMP RELAY	22697
CRANK ANGLE SENSOR	23730
A.A.C. VALVE	23781
EFI HARNESS	24011
MIXTURE HEATER RELAY	25231
PCV VALVE	11810
EGR TUBE	14120
EGR CONTROL VALVE	14710
EGR PASSAGE	14711
EXHAUST TEMP SENSOR	14730
BPT VALVE	14741
A.I.V. UNIT CASE	14810
A.I.V. TUBE	14821
AIR INJECTION PIPE	14823
AIR CONTROL VALVE	14832
A.B. VALVE	14835
SERVICE PORT-EVAP.	14939
AIR INJECTION VALVE	14854
A.I.V. BOX	14880
THERMAL VACUUM VALVE	14890
SCV SOLENOID VALVE	14951
EPC VALVE	14953
EGR SOLENOID VALVE	14954
VACUUM CUT SOLENOID	14955
A.I.V. SOLENOID VALVE	14956
EGR MIXTURE SOLENOID	14956
SPARK DELAY VALVE	14958
FUEL CUT SOLENOID	16196
ENGINE REVOLUTION SWITCH	16767
DETONATION SENSOR	22060
DETONATION CONTROL UNIT	22061
EGR WATER TEMP SENSOR	22120
CK SWITCH—CANISTER VAC CNTRL	22360
EGR VACUUM CONTROL VALVE	22363
EGR VACUUM CONTROL VALVE	22365
THROTTLE VALVE SWITCH	22620
02 SENSOR	22690
REAR OXYGEN 02 SENSOR	22691
CRANK POSITION SENSOR—RING GEAR	23733
EGR CONTROL UNIT	25024
FUEL SHUT OFF CLUTCH SWITCH	25322
EGR RESERVOIR TANK	27085

# POWER TRAIN PROPELLE SMAFTS A DEFERMINAL

DRAIN PLUG 4WD	32104
PROPELLER SHAFT	37000
FRONT PROPELLER SHAFT	37010
JOURNAL ASSY	37125
CENTER BEARING BRACKET	37511
CENTER BEARING	37521
CENTER BEARING INSULATOR	37522
RING & PINION SET	38100
DRIVE GEAR BOLT	38102
REAR PINION BEARING	38120
FRONT PINION BEARING	38140
PINION BEARING SPACER	38165
PILOT BEARING SPACER	38169
DRIVE PINION OIL SEAL	38189
COMPANION FLANGE	38210
SIDE FLANGE	38220
SIDE FLANGE 4WD	38221
DIFFERENTIAL CARRIER (HOUSING)	38310
DIFFERENTIAL CARRIER-4WD	38311
REAR COVER GASKET	38320
FRONT PILOT BEARING	38335
4WD SIDE BEARING RETAINER	38341
DIFFERENTIAL SIDE OIL SEAL	38342
DIFFERENTIAL SIDE OIL SEAL 4WD	38344
SIDE RETAINER O-RING 4WD	38345
REAR COVER	38351
BREATHER	38352
BREATHER 4WD	38353
DRAIN PLUG	38355
LTD SLIP DIFFERENTIAL ASSY	38420
DIFFERENTIAL CASE	38421
SIDE GEAR	38423
SIDE GEAR THRUST WASHER	38424
PINION MATE	38425
PINION MATE THRUST WASHER	38426
PINION MATE SHAFT	38427
PINION SHAFT LOCK PIN	38428
PINION SHAFT LOCK PIN 4WD	40.000
	38429

COMPONED	May.
LSD PRESSURE RING	38431
LSD FRICTION PLATE	38432
LSD FRICTION DISC	38433
SIDE BEARING	38440
DRIVE FLANGE	38512
RING & PINION 4WD	38540
FRONT PINION BEARING 4WD	38541
RING & PINION BEARING 4WD	38542
PINION BEARING SPACER-4WD	38543
DRIVE PINION OIL SEAL 4WD	38544
COMPANION FLANGE 4WD	38545
DIFFERENTIAL CASE 4WD	38546
SIDE GEAR 4WD	38547
SIDE GEAR THRUST WASHER	38548
PINION MATE 4WD	38549
PINION MATE THRUST WASHER	38550
PINION MATE SHAFT 4WD	38551
SIDE BEARING 4WD	<b>38</b> 552
DRIVE GEAR BOLT 4WD	38553
REAR COVER 4WD	40513
REAR COVER GASKET 4WD	40515
FRONT DIFFRATL MOUNTING INSULATOR	54710
FRONT DIFFRNTL MOUNTING MEMBER	54720
FRONT DIFFRNTL MOUNTING STOPPER	54751
FRONT DIFF MOUNTING STOPPR BRACKET	54752

REAR MAIN SEAL 12279 FLYWHEEL ASSY 12310 FLYMIGE RING GEAR 12312 FIXING BOUT 12315 DRIVE PLATE ASSY 123310 DRIVE PLATE ASSY 12331 DRIVE PLATE ASSY 12331 DIFFERENTIAL OIL COOLER 21652 DIFFERENTIAL OIL COOLER 21652 DIFFERENTIAL OIL COOLER 21669 DIFFERENTIAL OIL COOLER PIPE 21669 DIFFERENTIAL COOLER PIPE 21669 DIFFERE	That are the company of the company	
FLYWHEEL RING GEAR 12312 FIXING BOLT 12315 FIXING BOLT 12315 A/T COOLER BYPASS VALVE 21607 OIL COOLER TUBE 21627 OIL COOLER TUBE 21607 OIL COOLER TUBE 21607 OIL COOLER TUBE 21652 DIFFERENTIAL OIL COOLER 21652 DIFFERENTIAL OIL PUMP 21660 THERMAL SWITCH 21669 DIFFERENTIAL OIL COOLER PIPE 21682 DIFFERENTIAL OIL COOLER 2168		12279
FIXING BOLT         12315           DRIVE PLATE ASSY         12315           DRIVE PLATE ASSY         12331           AT COOLER BYPASS VALVE         21607           OIL COOLER TUBE         21621           DIFFERENTIAL OIL COOLER         21652           DIFFERENTIAL OIL COOLER PPE         21669           DIFFERENTIAL OIL COOLER PPE         21669           DIFFERENTIAL OIL COOLER PPE         21669           DIFFERENTIAL OIL COOLER PPE         21660           DIFFERENTIAL OIL COOLER PPE         21680           CIRCUIT BREAKER         24330           O.D. CANCEU/POWER SWITCH         25131           SHIFT PATTERN SELECT SWITCH         25131           SHIFT PATTERN SELECT SWITCH         25131           SHIFT LOCK RELAY         25249           KICKDOWN SWITCH         25390           TRANSFER RELAY         25249           KICKDOWN SWITCH         25390           TRANSFER CONTROL UNIT         28491           TRANSFER CONTROL UNIT         28495           CLUTCH HOUSING         30501           CLUTCH HOUSING         30502           CLUTCH HOUSING         30502           CLUTCH HOUSING         30502           CLUTCH WITHDRAWAL LEVER		
DRIVE PLATE ASSY         12331           AT COOLER BYPASS VALVE         21602           OIL COOLER BYPASS VALVE         21602           DIFFERENTIAL OIL COOLER         21652           DIFFERENTIAL OIL COOLER         21652           DIFFERENTIAL OIL COOLER PIPE         21669           DIFFERENTIAL OIL COOLER PIPE         21669           DIFFERENTIAL OIL COOLER PIPE         21662           DROPPING RESISTOR         22693           CIRCUIT BREAKER         24330           O.D. CANCEL/POWER SWITCH         25130           SHIFT PATTERN SELECT SWITCH         25131           SHIFT LOCK RELAY         25206           KICKDOWN SWITCH         25390           INTERLOCK CONTROL UNIT         28493           KICKDOWN SWITCH         25390           INTERLOCK CONTROL UNIT         28495           CLUTCH HOUSING         30400           CLUTCH RELEASE SLEEVE         30501           CLUTCH RELEASE SELEEVE         30501           CLUTCH RELEASE BEARING         30502           CLUTCH WITHDRAWAL LEVER         30631           WITHDRAWAL LEVER PIN         30631           DUST COVER         30660           CLUTCH DAMPER         30600           CLUTCH DEPARTI		
AUT COOLER BYPASS VALVE   21607		
OIL COOLER TUBE         21621           DIFFERENTIAL OIL COOLER         21652           DIFFERENTIAL OIL COOLER         21650           DIFFERENTIAL OIL COOLER PIPE         21660           DIFFERENTIAL OIL COOLER PIPE         21600           DROPPING RESISTOR         22630           CIRCUIT BREAKER         24330           O.D. CANCEL/POWER SWITCH         25131           SHIFT PATTERN SELECT SWITCH         25131           SHIFT PATTERN SELECT SWITCH         25131           SHIFT LOCK RELAY         25206           TRANSFER RELAY         25249           KICKDOWN SWITCH         25390           TRANSFER CRUNTROL UNIT         28491           TRANSFER CONTROL UNIT         28495           CLUTCH HOUSING         30501           CLUTCH HELEASE SLEEVE         30501           CLUTCH HELEASE SLEEVE         30501           CLUTCH RELEASE SLEEVE         30501           CLUTCH RELEASE SLEEVE         30502           CLUTCH RELEASE SLEEVE         30501           CLUTCH WALLEYER PIN         30637 <tr< td=""><td></td><td></td></tr<>		
DIFFERENTIAL OIL COOLER   21652		
DIFFERENTIAL OIL PUMP		
THERMAL SWITCH   21669		
DIFFERENTIAL OIL COOLER PIPE   21682   DROPPING RESISTOR   22693   CIRCUIT BREAKER   24330   O.D. CANCEL/POWER SWITCH   25130   SHIFT PATTERN SELECT SWITCH   25131   SHIFT LOCK RELAY   25249   KICKOOWN SWITCH   25390   INTERLOCK CONTROL UNIT   28491   ITANSFER RELAY   25249   KICKOOWN SWITCH   25390   INTERLOCK CONTROL UNIT   28491   ITANSFER CONTROL UNIT   28495   CLUTCH HOUSING   30400   CLUTCH HELEASE SLEEVE   30501   CLUTCH RELEASE SLEEVE   30501   CLUTCH RELEASE BEARING   30502   CLUTCH WITHDRAWAL LEVER PIN   30537   WITHDRAWAL LEVER PIN   30637   MITHDRAWAL LEVER PIN   30630   CLUTCH MASTER CYLINDER   30600   CLUTCH OPERATING CYLINDER   30600   CLUTCH DOOD   30628   CLUTCH BOOSTER   30630   CLUTCH HOUSING   30630   CLUTCH VACUUM HOSE   30660   CLUTCH OPERATING CABLE   30670   CONVERTER BOLT   31009   A/T CONTROL UNIT   31009   A/T CONTROL UNIT   31041   VACUUM MODULATOR   31050   THROTILE CABLE   31051   THROTILE CABLE   31051   TOOL INDICATOR SWITCH   31041   VACUUM MODULATOR   31050   THROTILE CABLE   31051   THROTILE CABLE   31051   TORQUE CONVERTER   31100   OL NIDICATOR SWITCH   31061   OL LEVEL GAUGE   31080   TORQUE CONVERTER   31100   OL CASE (4 SP)   31322   REAR EXTENSION (ADAPTOR)   31330   CONTROL CYLINDER   31331   REAR EXTENSION OIL SEAL   31344   OIL PUMP HOUSING SEA		
DROPPING RESISTOR   22693   CIRCUIT BREAKER   24330   CIRCUIT BREAKER   24330   CIRCUIT BREAKER   24330   CIRCUIT BREAKER   24330   SHIFT PATTERN SELECT SWITCH   25131   SHIFT LOCK RELAY   25206   KICKDOWN SWITCH   25390   KICKDOWN SWITCH   26495   CILUTCH HOUSING   30400   CLUTCH HOUSING   30400   CLUTCH HOUSING   30400   CLUTCH HOUSING   30502   CLUTCH WITHDRAWAL LEVER   30531   WITHDRAWAL LEVER PIN   30537   WITHDRAWAL LEVER PIN   30537   UST COVER   30600   CLUTCH WITHDRAWAL LEVER PIN   30630   CLUTCH WITHDRAWAL LEVER PIN   30600   CLUTCH MASTER CYLINDER   30600   CLUTCH DAMPER   30600   CLUTCH DAMPER   30600   CLUTCH OPERATING CYLINDER   30621   CLUTCH DOSCE   200600   CLUTCH BOOSTER   30630   CHECK VALVE ASSY   30639   CLUTCH VACUUM HOSE   30660   CLUTCH VACUUM HOSE   30660   CLUTCH OPERATING CABLE   30670   CONVERTER BOLT   31009   AT CONTROL UNIT   31036   CONVERTER BOLT   31009   AT CONTROL UNIT   31036   CONVERTER BOLT   31061   CONVERTER HOUSING   31090   CONVERT		
CIRCUIT BREAKER 24330  O.D. CANCEL/POWER SWITCH 25130  O.D. CANCEL/POWER SWITCH 25131  SHIFT PATTERN SELECT SWITCH 25131  SHIFT LOCK RELAY 25206  TRANSFER RELAY 25206  TRANSFER RELAY 25206  INTERLOCK CONTROL UNIT 28491  TRANSFER CONTROL UNIT 30601  CLUTCH RELEASE BEEVE 30601  CLUTCH WITHDRAWAL LEVER PIN 30637  DUST COVER 30542  CLUTCH MASTER CYLINDER 30600  CLUTCH MASTER CYLINDER 30600  CLUTCH MASTER CYLINDER 30630  BLEEDER (CLUTCH) 30621  CLUTCH BOOSTER 30630  CLUTCH BOOSTER 30630  CLUTCH VACUUM HOSE 30660  CLUTCH VACUUM HOSE 30660  CLUTCH VACUUM HOSE 30660  CLUTCH TUBE & HOSE 30650  CLUTCH TUBE & HOSE 31009  ATI CONTROL UNIT 31036  O.D. INDICATOR SWITCH 31001  ATI CONTROL UNIT 31036  TRANSMISSION CASE 31060  TORQUE CONVERTER 31009  TRANSMISSION CASE 31090  TRANSMISSION CASE 31090  TRANSMISSION CASE 31030  CONVERTER HOUSING GASKET 31330  CONTROL CYLINDER 31331  REAR EXTENSION (ADAPTOR) 31330  CONTROL CYLINDER 31331  REAR EXTENSION OL SEAL 31334  OIL PUMP HOUSING SEAL 31344		
O.D. CANCEL/POWER SWITCH   25130		
SHIFT PATTERN SELECT SWITCH   25131		
SHIFT LOCK RELAY   25269     TRANSFER RELAY   25249     TRANSFER RELAY   25249     TRANSFER RELAY   25390     INTERLOCK CONTROL UNIT   28491     TRANSFER CONTROL UNIT   28491     SOBOOL CLUTCH RELEASE BEEVE   30501     CLUTCH RELEASE SLEEVE   30501     CLUTCH RELEASE BEARING   30502     CLUTCH DAMPER   30631     WITHDRAWAL LEVER PIN   30537     DUST COVER   30640     CLUTCH DAMPER   30600     CLUTCH DAMPER   30600     CLUTCH DAMPER   30600     CLUTCH DEPARTING CYLINDER   30610     CLUTCH OPERATING CYLINDER   30621     PUSH ROD   30628     CLUTCH BOOSTER   30630     CLUTCH HOEDSTER   30630     CLUTCH TUBE & HOSE   30650     CLUTCH VACUUM HOSE   306650     CLUTCH OPERATING CABLE   30670     CONVERTER BOLT   31009     AT CONTROL UNIT   31036     AT CONTROL UNIT   31036     AT CONTROL UNIT   31036     AT CONTROL UNIT   31036     AT CONTROL UNIT   31041     VACUUM MODUL ATOR   31050     THROTTLE CABLE   31061     OL INDICATOR SWITCH   31041     VACUUM TUBE   31061     OL INDICATOR SWITCH   31041     VACUUM TUBE   31061     OL OL STEEL BELT   31240     CONVERTER HOUSING GASKET   31309     TRANSMISSION CASE   31310     CONVERTER HOUSING GASKET   31335     CLUTUMP   31340     OL PUMP HOUSING SEAL   31341     OLI PUMP HOUSING SEAL   31344     OLI PUMP		
TRANSFER RELAY 25249 KICKDOWN SWITCH 25390 KICKDOWN SWITCH 25390 KITERLOCK CONTROL UNIT 28491 TRANSFER CONTROL UNIT 28491 TRANSFER CONTROL UNIT 28495 CLUTCH HOUSING 30400 CLUTCH RELEASE SLEEVE 30501 CLUTCH RELEASE SLEEVE 30501 CLUTCH WITHDRAWAL LEVER 30531 WITHDRAWAL LEVER MN 30531 WITHDRAWAL LEVER 30630 CLUTCH DAMPER 30600 CLUTCH DAMPER 30600 CLUTCH DAMPER 30600 CLUTCH MASTER CYLINDER 30620 BLEEDER (CLUTCH) 30621 PUSH ROD 30628 BLEEDER (CLUTCH) 30621 CLUTCH WORDAT 30630 CLUTCH BOOSTER 30630 CLUTCH WOLCOUNT 30630 CLUTCH VACUUM HOSE 30650 CLUTCH VACUUM HOSE 306640 CLUTCH WOLCOUN HOSE 306640 CLUTCH WOLCOUN HOSE 30660 CLUTCH VACUUM HOSE 31061 OL INDICATOR SWITCH 31004 VACUUM MODULATOR 31050 THROTILE CABLE 31061 OL LEVEL GAUGE 31060 OL LEVEL GAUGE 31060 OL LEVEL GAUGE 31060 CONVERTER HOUSING GASKET 31300 CONVERTER HOUSING GASKET 31300 CONTROL CYLINDER 31331 REAR EXTENSION OL SEAL 31343 OIL PUMP HOUSING SEAL 31344 OIL PUMP HOUSING SEAL 31344		
KICKDOWN SWITCH 25390 INTERLOCK CONTROL UNIT 28491 TRANSFER CONTROL UNIT 28495 CLUTCH HOUSING 30400 CLUTCH RELEASE SLEEVE 30501 CLUTCH WITHDRAWAL LEVER 30531 WITHDRAWAL LEVER PIN 30537 WITHDRAWAL LEVER PIN 30537 USIT COVER 30542 CLUTCH MASTER CYLINDER 30600 CLUTCH MASTER CYLINDER 30600 CLUTCH DAMPER 30600 CLUTCH OPERATING CYLINDER 30620 BLEEDER (CLUTCH) 30621 PUSH ROD 30631 CLUTCH BOOSTER 30630 CLUTCH BOOSTER 30630 CLUTCH VACUUM HOSE 30664 CLUTCH OPERATING CYLINDER 30630 CLUTCH VACUUM HOSE 30664 CLUTCH OPERATING CABLE 30670 CONVERTER BOLT 31003 ATT CONTROL UNIT 31036 OL INDICATOR SWITCH 31051 THROTILE CABLE 31051 THROTILE CABLE 31051 THROTILE CABLE 31050 OIL LEVEL GAUGE 31080 OIL LEVEL GAUGE 31080 OIL LEVEL GAUGE 31080 CONVERTER HOUSING 31301 CONVERTER HOUSING ASKET 31300 CONVERTER HOUSING ASKET 31303 CONTROL CYLINDER 31331 REAR EXTENSION (ADAPTOR) 31330 CIL PUMP HOUSING SEAL 31343 OIL PUMP HOUSING SEAL 31343		
INTERLOCK CONTROL UNIT   28491   TRANSFER CONTROL UNIT   28495   TRANSFER CONTROL UNIT   28495   CULTCH HOUSING   30400   CLUTCH RELEASE SLEEVE   30501   CLUTCH WITHDRAWAL LEVER   30531   WITHDRAWAL LEVER PIN   30637   UNIT COVER   30640   CLUTCH DAMPER   30600   CLUTCH DAMPER   30600   CLUTCH DAMPER   30600   CLUTCH DAMPER   30600   CLUTCH MASTER CYLINDER   30610   DISTRICT OF STATE O	RANSFER RELAY	
TRANSFER CONTROL UNIT         28495           CLUTCH HOUSING         30400           CLUTCH RELEASE SLEEVE         30501           CLUTCH RELEASE SLEEVE         30501           CLUTCH RELEASE SLEEVE         30502           CLUTCH RELEASE SLEEVE         30537           WITHDRAWAL LEVER         30631           DUST COVER         30542           CLUTCH DAMPER         30600           CLUTCH MASTER CYLINDER         30600           CLUTCH MASTER CYLINDER         30620           BLEEDER (CLUTCH)         30621           PUSH ROD         30628           CLUTCH BOOSTER         30630           PUSH ROD         30639           CLUTCH BOOSTER         30630           PUSH ROD         30631           CHECK VALVE ASSY         30639           CLUTCH TUBE & HOSE         30664           CLUTCH VACUUM HOSE         30664           CLUTCH VACUUM HOSE         30664           CLUTCH VACUUM HOSE         31067           CONVERTER BOLT         31001           VACUUM MODULATOR         31051           VACUUM MODULATOR         31051           VACUUM TUBE         31061           OIL LEVEL GAUGE         310080		
CLUTCH HOUSING         30400           CLUTCH RELEASE SLEEVE         30501           CLUTCH RELEASE BEARING         30502           CLUTCH WITHDRAWAL LEVER         30631           WITHDRAWAL LEVER PIN         30537           DUST COVER         30642           CLUTCH DAMPER         30600           CLUTCH DAMPER         30600           CLUTCH OPERATING CYLINDER         30620           DLEEDER (CLUTCH)         30621           PUSH ROD         30638           CLUTCH BOOSTER         30630           CHOTCH TUBE & HOSE         30650           CLUTCH VACUUM HOSE         30664           CLUTCH VACUUM HOSE         30664           CLUTCH OPERATING CABLE         30670           CONVERTER BOLT         31009           ATI CONTROL UNIT         31061           OL, INDICATOR SWITCH         31041           VACUUM MOOULATOR         31050           THROTILE CABLE         31061           OIL LEVEL GAUGE         31080           TORQUE CONVERTER         31100           CONVERTER HOUSING         31301           CONVERTER HOUSING GASKET         31301           CONVERTER HOUSING GASKET         31300           CONVERTER HO		
CLUTCH RELEASE SLEEVE         30501           CLUTCH RELEASE BEARING         30502           CLUTCH WITHORAWAL LEVER         30537           WITHDRAWAL LEVER         30537           DUST COVER         30547           QUITCH DAMPER         30600           CLUTCH DAMPER         30610           CLUTCH MASTER CYLINDER         30610           CLUTCH MOPERATING CYLINDER         30621           DUSH ROD         30628           CLUTCH BOOSTER         30630           CHECK MALVE ASSY         30639           CLUTCH VACUUM HOSE         30650           CLUTCH VACUUM HOSE         30650           CLUTCH OPERATING CABLE         30670           CONVERTER BOLT         31009           AT CONTROL UNIT         31034           VACUUM MODULATOR         31041           VACUUM MODULATOR         31050           THROTTLE CABLE         31061           OIL LEVEL GAUGE         31080           TORQUE CONVERTER         31100           CONVERTER HOUSING         31310           CONVERTER HOUSING GASKET         31300           CONVERTER HOUSING GASKET         31300           CONVERTER HOUSING GASKET         31300           CONVER		
CLUTCH RELEASE BÉARING         30502           CLUTCH WITHDRAWAL LEVER         30531           MYTHDRAWAL LEVER PIN         30537           DUST COVER         30542           CLUTCH DAMPER         30600           CLUTCH MASTER CYLINDER         30610           CLUTCH MASTER CYLINDER         30620           BLEEDER (CLUTCH)         30621           PUSH ROD         30628           CULTCH BOOSTER         30630           PUSH ROD         30631           CHECK VALVE ASSY         30639           CLUTCH BOOSTER         30650           CLUTCH VACUUM HOSE         30650           CLUTCH VACUUM HOSE         30660           CLUTCH VACUUM HOSE         30660           CLUTCH VACUUM HOSE         30670           CONVERTER BOLT         31031           AT CONTROL UNIT         31036           O.D. INDICATOR SWITCH         31041           VACUUM MODULATOR         31050           THROTTLE CABLE         31061           VACUUM TUBE         31061           OIL LEVEL GAUGE         31080           TORQUE CONVERTER         31100           CONVERTER HOUSING         31301           CONVERTER HOUSING GASKET         31		
CLUTCH WITHORAWAL LEVER         30531           WITHORAWAL LEVER         30537           DUST COVER         30542           20LUTCH DAMPER         30600           CLUTCH DERATING CYLINDER         30630           BLEEDER (CLUTCH)         30621           PUSH ROD         30630           PUSH ROD         30631           PUSH ROD         30631           CLUTCH BOOSTER         30630           PUSH ROD         30631           CHECK VALVE ASSY         30639           CLUTCH HOSE         30650           CLUTCH VACUUM HOSE         30664           CLUTCH VACUUM HOSE         30664           CLUTCH VACUUM HOSE         30660           CLUTCH VACUUM HOSE         30660           CLUTCH VACUUM HOSE         30660           CLUTCH VACUUM HOSE         30660           O.D. INDICATOR SWITCH         31036           O.D. INDICATOR SWITCH         31050           THROTTLE CABLE         31051           VACUUM MODULATOR         31061           OIL LEVEL GAUGE         31061           OIL LEVEL GAUGE         31060           TORQUE CONVERTER         31106           CONVERTER HOUSING         31310      <		
WITHDRAWAL LEVER PIN 30537  DUST COVER 30542  CLUTCH DAMPER 30600  CLUTCH MASTER CYLINDER 30610  CLUTCH MASTER CYLINDER 30610  CLUTCH MASTER CYLINDER 30621  PUSH ROD 30628  CLUTCH BOOSTER 30630  CHECK VALVE ASSY 30639  CLUTCH TUBE & HOSE 30650  CLUTCH VACUUM HOSE 30650  CLUTCH VACUUM HOSE 30650  CLUTCH OPERATING CABLE 30670  CONVERTER BOLT 31009  ATI CONTROL UNIT 31036  CONTROL UNIT 31050  CLUTCH CABLE 31051  THROTTLE CABLE 31051  THROTTLE CABLE 31051  CONVERTER BOLT 31050  CONVERTER BOLT 31050  CONVERTER 311050  CONVERTER 311050  CONVERTER HOUSING 31081  CONVERTER HOUSING 313310  CONVERTER HOUSING 31301  CONVERTER HOUSING ASKET 31309  TRACE EXTENSION (ADAPTOR) 31330  CONTROL CYLINDER 31331  REAR EXTENSION OL SEAL 31335  REAR EXTENSION OL SEAL 31335  REAR EXTENSION OL SEAL 31344  OIL PUMP HOUSING SEAL 31344		
DUST COVER         30542           CLUTCH DAMPER         30600           CLUTCH DAMPER         30600           CLUTCH OPERATING CYLINDER         30620           BLEEDER (CLUTCH)         30623           BLEEDER (CLUTCH)         30623           DUSH ROD         30630           PUSH ROD         30630           PUSH ROD         30630           PUSH ROD         30631           CHITCH BOOSTER         30630           PUSH ROD         30631           CHECK WALVE ASSY         30639           CLUTCH TUBE & HOSE         30650           CLUTCH OFERATING CABLE         30670           CONVERTER BOLT         31009           AT CONTROL UNIT         31030           AT CONTROL UNIT         31030           AT CONTROL UNIT         31051           THROTTLE CABLE         31051           VACUUM MODULATOR         31050           THROTTLE CABLE         31061           OLI LEVEL GAUGE         31080           TORQUE CONVERTER         31100           CONVERTER HOUSING         31301           CONVERTER HOUSING GASKET         31301           CONVERTER HOUSING GASKET         31302           R		
CLUTCH DAMPER         30600           CLUTCH DAMPER         30610           CLUTCH MASTER CYLINDER         30610           SOEZI         30621           BLEEDER (CLUTCH)         30621           PUSH ROD         30630           PUSH ROD         30631           PUSH ROD         30631           CHECK VALVE ASSY         30639           CLUTCH DEBE & HOSE         30650           CLUTCH VACUUM HOSE         30664           CLUTCH VACUUM HOSE         30660           CLUTCH VACUUM HOSE         30660           CLUTCH VACUUM HOSE         30660           CLUTCH VACUUM HOSE         30660           CONTROL UNIT         31036           VACUUM MODULATOR         31050           THROTILE CABLE         31051           VACUUM TUBE         31061           OIL LEVEL GAUGE         31080           TORQUE CONVERTER         31106           CONVERTER HOUSING         31314           CONVERTER HOUSING GASKET         3130           CONVERTER HOUSING GASKET         3130           CONTROL CYLINDER         3133           CONTROL ON (ADAPTOR)         31330           CONVERTER HOUSING GASKET         31330		
CLUTCH MASTER CYLINDER         30610           CLUTCH OPERATING CYLINDER         30620           BLEEDER (CLUTCH)         30621           PUSH ROD         30628           CLUTCH BOOSTER         30630           PUSH ROD         30631           CHECK VALVE ASSY         30639           CLUTCH TUBE & HOSE         30660           CLUTCH VACUUM HOSE         30664           CLUTCH OPERATING CABLE         30670           CONVERTER BOLT         31009           ATI CONTROL UNIT         31061           OLD. INDICATOR SWITCH         31041           VACUUM MODULATOR         31050           THROTILE CABLE         31061           OIL LEVEL GAUGE         31080           TORQUE CONVERTER         31100           CVT STEEL BELT         31240           CONVERTER HOUSING         31301           CONVERTER HOUSING GASKET         31301           CONVERTER HOUSING GASKET         31300           CONVERTER HOUSING GASKET         31301           CONVERTER HOUSING GASKET         31330           CONVERTER HOUSING GASKET         31301           CONVERTER HOUSING GASKET         31330           CONTROL CYLINDER         31331		
CLUTCH OPERATING CYLINDER         30620           BLEEDER (CLUTCH)         30621           PUSH ROD         30623           CLUTCH BOOSTER         30630           PUSH ROD         30631           PUSH ROD         30631           PUSH ROD         30631           CHECK WALVE ASSY         30639           CLUTCH TUBE & HOSE         30650           CLUTCH TUBE & HOSE         30660           CLUTCH OPERATING CABLE         30670           CONVERTER BOLT         31009           AT CONTROL UNIT         31030           AT CONTROL UNIT         31050           THROTTLE CABLE         31051           VACUUM MODULATOR         31050           TORQUE CANVERTER         31061           TORQUE CONVERTER         31060           TORQUE CONVERTER         31080           CONVERTER HOUSING         31301           CONVERTER HOUSING GASKET         31309           TRANSMISSION CASE         31310           O.D. CASE (4 SP)         31322           REAR EXTENSION (ADAPTOR)         31330           CONTROL CYLINDER         31331           CONTROL CYLINDER         31336           OLF CASE (4 SP)         31322 </td <td></td> <td></td>		
BLEEDER (CLUTCH)   30621		
PUSH ROD         30628           CLUTCH BOOSTER         30530           PUSH ROD         30631           CHECK VALVE ASSY         30639           CLUTCH TUBE & HOSE         30650           CLUTCH OPERATING CABLE         30670           CONVERTER BOLT         31009           ATI CONTROL UNIT         31061           OLD. INDICATOR SWITCH         31041           VACUUM MODULATOR         31050           THROTILE CABLE         31051           THROTILE CABLE         31061           OIL LEVEL GAUGE         31080           TORQUE CONVERTER         31100           CONVERTER HOUSING         31301           CONVERTER HOUSING GASKET         31302           REAR EXTENSION (ADAPTOR)         31330           CONTROL CYLINDER         31331           REAR EXTENSION OIL SEAL         31335           REAR EXTENSION OIL SEAL         31336           OIL PUMP         31340           OIL PUMP HOUSING SEAL         31341		
CLUTCH BOOSTER         30630           PUSH ROD         30631           CHECK VALVE ASSY         30639           CLUTCH TUBE & HOSE         30650           CLUTCH VACUUM HOSE         30660           CLUTCH OPERATING CABLE         30670           CONVERTER BOLT         31009           AT CONTROL UNIT         31030           AT CONTROL UNIT         31031           VACUUM MODULATOR         31050           THROTILE CABLE         31051           VACUUM TUBE         31061           OIL LEVEL GAUGE         31080           TORQUE CONVERTER         31100           CVT STEEL BELT         3120           CONVERTER HOUSING         31301           CONVERTER HOUSING GASKET         31309           TRANSMISSION CASE         31310           O.D. CASE (4 SP)         31322           REAR EXTENSION (ADAPTOR)         31330           CONTROL CYLINDER         31331           REAR EXTENSION OL SEAL         31336           CILL PUMP HOUSING SEAL         31340           OIL PUMP HOUSING SEAL         31341		
PUSH ROD 30631 CHECK VALVE ASSY 30639 CLUTCH TUBE & HOSE 30650 CLUTCH VACUUM HOSE 30664 CLUTCH VACUUM HOSE 30664 CLUTCH VACUUM HOSE 30664 CLUTCH VACUUM HOSE 30664 AT CONTROL UNIT 31036 O.D. INDICATOR SWITCH 31041 VACUUM MODULATOR 31050 VACUUM MODULATOR 31051 VACUUM TUBE 31061 OIL LEVEL GAUGE 31090 CVT STEEL BELT 31240 CONVERTER HOUSING 31301 CONVERTER HOUSING 31330 CONTROL CYLINDER 31330 CONTROL CYLINDER 31330 CONTROL CYLINDER 31335 REAR EXTENSION (ADAPTOR) 31336 CIL PUMP 31340 OIL PUMP HOUSING SEAL 31343 OIL PUMP HOUSING SEAL 31341		
CHECK VALVE ASSY CLUTCH TUBE & HOSE CLUTCH OPERATING CABLE CLUTCH OPERATING CABLE CLUTCH OPERATING CABLE CONVERTER BOLT AT CONTROL UNIT OLD. INDICATOR SWITCH JOSA THROTILE CABLE JIOSA THROTILE CABLE JIOSA CONVERTER BOLT TORQUE CONVERTER JIOSA CONVERTER HOUSING CONVERTER HOUSING CONVERTER HOUSING CONVERTER HOUSING CONVERTER HOUSING JISSA CONVERTER HOUSING CONVERTER HOUSING JISSA CONVERTER HOUSING JISSA CONVERTER HOUSING CONVERTER HOUSING JISSA CONVERTER HOUSING JISSA CONVERTER HOUSING JISSA CONVERTER HOUSING CONVERTER HOUSING JISSA CONVERTER HOUSING JISSA CONVERTER HOUSING GASKET JISSA CONVERTER HOUSING CONVERTER HOUSING CONVERTER HOUSING CONVERTER HOUSING CONVERTER HOUSING JISSA CONVERTER HOUSING GASKET JISSA JISSA CONVERTER HOUSING CONVERTER HOUSING CONVERTER HOUSING JISSA CONVERTER HOUSING JISSA JISSA CONVERTER HOUSING JISSA JISSA CONVERTER HOUSING JISSA JISSA CONVERTER HOUSING JISSA JISSA JISSA CONVERTER JISSA JIS		
CLUTCH TUBE & HOSE         30650           CLUTCH VACUUM HOSE         306630           CLUTCH OPERATING CABLE         30670           CONVERTER BOLT         31009           AT CONTROL UNIT         31030           AT CONTROL UNIT         31041           VACUUM MODULATOR         31050           THROTILE CABLE         31051           VACUUM TUBE         31061           OIL LEVEL GAUGE         31080           TORQUE CONVERTER         31100           CVT STEEL BEIT         31240           CONVERTER HOUSING         31301           CONVERTER HOUSING GASKET         31309           TRANSMISSION CASE         31310           OD CASE (4 SP)         31322           REAR EXTENSION (ADAPTOR)         31330           CONTROL CYLINDER         31331           REAR EXTENSION OL SEAL         31336           OIL PUMP         31340           OIL PUMP HOUSING SEAL         31341		~
CLUTCH VACUUM HOSE         30684           CLUTCH OPERATING CABLE         30670           CONVERTER BOLT         31009           A/T CONTROL UNIT         31036           O.D. INDICATOR SWITCH         31041           VACUUM MODULATOR         31050           THROTTLE CABLE         31051           VACUUM TUBE         31061           OIL LEVEL GAUGE         31080           COVI STEEL BELI         31240           CONVERTER HOUSING         31301           CONVERTER HOUSING GASKET         31302           REAR EXTENSION (ADAPTOR)         31330           O.D. CASE (4 SP)         31322           REAR EXTENSION (ADAPTOR)         31331           CONTROL CYLINDER         31331           REAR EXTENSION GASKET         31335           REAR EXTENSION OIL SEAL         31336           OIL PUMP         31340           OIL PUMP HOUSING SEAL         31343           OIL PUMP HOUSING SEAL         31343		
CLUTCH OPERATING CABLE         30670           CONVERTER BOLT         31009           AT CONTROL UNIT         31036           O.D. INDICATOR SWITCH         31041           VACUUM MODULATOR         31050           THROTTLE CABLE         31051           VACUUM TUBE         31061           OIL LEVEL GAUGE         31080           TORQUE CONVERTER         31100           CONVERTER HOUSING         31301           CONVERTER HOUSING GASKET         31301           CONVERTER HOUSING GASKET         31300           O.D. CASE (4 SP)         31322           REAR EXTENSION (ADAPTOR)         31330           CONTROL CYLINDER         31331           REAR EXTENSION GASKET         31335           REAR EXTENSION OIL SEAL         31336           OIL PUMP         31340           OIL PUMP HOUSING SEAL         31344		
CONVERTER BOLT         31009           AT CONTROL UNIT         31036           AT CONTROL UNIT         31036           D.D. INDICATOR SWITCH         31050           THROTTLE CABLE         31051           THROTTLE CABLE         31061           OIL LEVEL GAUGE         31080           TORQUE CONVERTER         31109           CVT STEEL BELT         31240           CONVERTER HOUSING         31301           COWERTER HOUSING GASKET         31302           CONVERTER HOUSING GASKET         31309           TORQUE CONVERTER         31301           CONVERTER HOUSING GASKET         31330           CONVERTER HOUSING GASKET         31330           O.D. CASE (4 SP)         31322           REAR EXTENSION (ADAPTOR)         31330           CONTROL CYLINDER         31331           REAR EXTENSION GASKET         31335           REAR EXTENSION OIL SEAL         31336           OIL PUMP         31340           OIL PUMP HOUSING SEAL         31341		
A/T CONTROL UNIT 31036 O.D. INDICATOR SWITCH 31041 VACUUM MODULATOR 31050 THROTTLE CABLE 31051 VACUUM TUBE 31061 OIL LEVEL GAUGE 31080 TORQUE CONVERTER 31100 CVT STEEL BELT 31240 CONVERTER HOUSING 31301 CONVERTER HOUSING GASKET 31309 TRANSMISSION CASE 31310 O.D. CASE (4 SP) 31322 REAR EXTENSION (ADAPTOR) 31330 CONTROL CYLINDER 31331 REAR EXTENSION GASKET 31335 REAR EXTENSION OIL SEAL 31336 OIL PUMP 31340 OIL PUMP HOUSING SEAL 31343 OIL PUMP HOUSING SEAL 31343		
VACUUM MODULATOR   31050		31036
VACUUM MODULATOR   31050	O.D. INDICATOR SWITCH	31041
VACUUM TUBE         31061           OIL LEVEL GAUGE         31080           DIC LEVEL GAUGE         31080           DORQUE CONVERTER         31100           CVT STEEL BELT         31240           CONVERTER HOUSING         31301           CONVERTER HOUSING GASKET         31302           TRANSMISSION CASE         31310           O.D. CASE (4 SP)         31322           REAR EXTENSION (ADAPTOR)         31330           CONTROL CYLINDER         31331           REAR EXTENSION GASKET         31335           REAR EXTENSION OIL SEAL         31336           OIL PUMP         31340           OIL PUMP HOUSING SEAL         31343           OIL PUMP HOUSING SEAL         31343	VACUUM MODULATOR	31050
OIL LEVEL GAUGE         31080           TORQUE CONVERTER         31100           CVT STEEL BEIT         31240           CONVERTER HOUSING         31301           CONVERTER HOUSING GASKET         31309           TRANSMISSION CASE         31310           O.D. CASE (4 SP)         31322           REAR EXTENSION (ADAPTOR)         31330           CONTROL CYLINDER         31331           REAR EXTENSION GASKET         31335           REAR EXTENSION OGL SEAL         31336           OIL PUMP         31340           OIL PUMP HOUSING SEAL         31343           OIL PUMP HOUSING SEAL         31343	THROTTLE CABLE	31051
TORQUE CONVERTER   31100	VACUUM TUBE	31061
CVT STEEL BEIT         31240           CONVERTER HOUSING         31301           CONVERTER HOUSING GASKET         31309           TRANSMISSION CASE         31310           O.D. CASE (4 SP)         31322           REAR EXTENSION (ADAPTOR)         31331           CONTROL CYLINDER         31331           REAR EXTENSION GASKET         31335           REAR EXTENSION OIL SEAL         31336           OIL PUMP         31340           OIL PUMP HOUSING SEAL         31343           OIL PUMP HOUSING SEAL         31343		31080
CONVERTER HOUSING         31301           CONVERTER HOUSING GASKET         31309           TRANSMISSION CASE         31310           O.D. CASE (4 SP)         31322           REAR EXTENSION (ADAPTOR)         31330           CONTROL CYLINDER         31331           REAR EXTENSION GASKET         31335           REAR EXTENSION OIL SEAL         31336           OIL PUMP         31340           FRONT OIL SEAL         31343           OIL PUMP HOUSING SEAL         31343	TORQUE CONVERTER	31100
CONVERTER HOUSING GASKET         31309           TRANSMISSION CASE         31310           O.D. CASE (4 SP)         31322           REAR EXTENSION (ADAPTOR)         31330           CONTROL CYLINDER         31331           REAR EXTENSION GASKET         31335           REAR EXTENSION OIL SEAL         31336           OIL PUMP         31340           OIL PUMP HOUSING SEAL         31343           OIL PUMP HOUSING SEAL         31343		
TRANSMISSION CASE         31310           O.D. CASE (4 SP)         31322           REAR EXTENSION (ADAPTOR)         31330           CONTROL CYLINDER         31331           REAR EXTENSION GASKET         31335           REAR EXTENSION OIL SEAL         31336           OIL PUMP         31340           FRONT OIL SEAL         31343           OIL PUMP HOUSING SEAL         31343		31301
O.D. CASE (4 SP)     31322       REAR EXTENSION (ADAPTOR)     31330       CONTROL CYLINDER     31331       REAR EXTENSION GASKET     31335       REAR EXTENSION OIL SEAL     31336       OIL PUMP     31340       OIL PUMP HOUSING SEAL     31343       OIL PUMP HOUSING SEAL     31343		
REAR EXTENSION (ADAPTOR)         31330           CONTROL CYLINDER         31331           REAR EXTENSION GASKET         31335           REAR EXTENSION OIL SEAL         31336           OIL PUMP         31340           REAR TOIL SEAL         31343           OIL PUMP HOUSING SEAL         31343		31310
CONTROL CYLINDER         31331           REAR EXTENSION GASKET         31335           REAR EXTENSION OIL SEAL         31336           OIL PUMP         31340           FRONT OIL SEAL         31343           OIL PUMP HOUSING SEAL         31344		
REAR EXTENSION GASKET         31335           REAR EXTENSION OIL SEAL         31336           OIL PUMP         31340           FRONT OIL SEAL         31343           OIL PUMP HOUSING SEAL         31344		
REAR EXTENSION OIL SEAL         31336           OIL PUMP         31340           FRONT OIL SEAL         31343           OIL PUMP HOUSING SEAL         31344		
OIL PUMP         31340           FRONT OIL SEAL         31343           OIL PUMP HOUSING SEAL         31344		
FRONT OIL SEAL 31343 OIL PUMP HOUSING SEAL 31344		
OIL PUMP HOUSING SEAL 31344		
OIL PUMP ROTOR SET 31345		
	OIL PUMP ROTOR SET	31345

TEACH ST.	
TMAN COLORAD	
continued	
COMPONENT	P.N.C.
O-RING (AUTO TRANS SECTION)	31362 31366
OIL PUMP GASKET BEARING RETAINER (3 SP)	31370
BREATHER	31381
DRUM SUPPORT (4 SP)	31385
OIL PAN/VALVE COVER	31390
SIDE COVER	31391
GASKET INPUT SHAFT	31397 31411
INTERMEDIATE SHAFT (4 SP)	31416
FRONT PLANETARY CARRIER	31420
NEEDLE BEARING	31428
REAR PLANETARY CARRIER	31440
CONNECTING DRUM	31471 31473
ONE-WAY CLUTCH FORWARD CLUTCH HUB	31475
OUTPUT SHAFT	31480
PARKING GEAR/OIL DISTRIBUTOR	31486
OUTPUT & IDLER GEAR SET	31493
DIRECT CLUTCH (4 SP)	31505
LOW CLUTCH (4 SP) FRONT CLUTCH ASSY	31505 31510
FRONT/REV. CLUTCH ASSY	31510
REVERSE CLUTCH DRUM	31512
REVERSE CLUTCH ASSY	31515
REAR CLUTCH ASSY	31540
REAR/HIGH CLUTCH	31540
HIGH CLUTCH DRUM HIGH CLUTCH ASSY	31541 31545
HIGH CLUTCH HUB	31550
FORWARD CLUTCH ASSY	31570
FORWARD CLUTCH DRUM	31571
O.D. PLANETARY CARRIER-4 SP	31580
OVERRUN CLUTCH HUB OVERRUN CLUTCH ASSY	31591 31595
BAND SERVO	31615
BRAKE BAND	31630
LOW & REVERSE BRAKE	31645
LOW & REVERSE BRAKE	31650
ACCUMULATOR PISTON ACCUMULATOR (4 SP)	31671 31671
SPEEDOMETER PINION ASSY	31703
CONTROL VALVE ASSY	31705
OIL STRAINER	31728
GOVERNOR	31860
GOVERNOR SEAL RING CAP SPEEDOMETER CASE & GEAR	31877 31883
RANGE SELECT LEVER	31913
GASKET & O-RING	31916
INHIBITOR SWITCH	31918
MANUAL SHAFT	31921
MANUAL PLATE ASSY VACUUM DIAPHRAGM	31924 31931
O-RING SEAL	31933
REVOLUTION SENSOR	31935
TURBINE REVOLUTION SENSOR	31936
DOWNSHIFT SOLENOID	31941
LOCK-UP SOLENOID SHIFT SOLENOID A	31942 31943
SHIFT SOLENOID B	31944
O.D. CANCEL SOLENOID	31945
LINE PRESSURE SOLENOID	31946
OVERRUN, CLUTCH SOLENOID	31947
LOW TEMP SENSOR PARKING ROD ASSY	31958 31970
PARKING PAWL	31986
REVERSE LAMP SWITCH	32005
TOP/NEUTRAL SWITCH	32006
INDICATOR SWITCH-4WD	32007
NEUTRAL SWITCH TRANSMISSION CASE	32008 32100
DRAIN PLUG	32103
DRAIN PLUG	32104
DRAIN PLUG (4WD)	32104
OIL GUIDE/GUTTER	32107
TRANSMISSION FRONT COVER	32110
FRONT COVER GASKET FRONT COVER/OIL INPUT SEAL	32112 32113
CASE COVER	32129
REAR EXTENSION ASSY	32130
BREATHER	32131
REAR EXTENSION OIL SEAL	32136
MAIN DRIVE GEAR OUTPUT SHAFT	32200 32200
PILOT BEARING	32202

COMPONENT	P.N.C.
DRIVE GEAR BEARING ROLLER BEARING	32203 32203
SNAP RING	32204
COUNTERSHAFT	32211
COUNTER GEAR INPUT SHAFT	32213 32213
COUNTERSHAFT BEARING	32219
INPUT SHAFT BEARING	32219
ROLLER BEARING	32219 32220
REVERSE COUNTER GEAR GEAR, 1ST SPEED	32230
MAIN GEAR (1ST)	32230
COUNTERSHAFT NUT MAINSHAFT	32236 32241
MAINSHAFT LOCK NUT	32243
REVERSE GEAR	32245
REVERSE MAIN GEAR GEAR, 2ND SPEED	32245 32250
MAIN GEAR (2ND)	32250
GEAR, 3RD SPEED	32260
MAIN GEAR (3RD) 3RD GEAR INPUT SHAFT	32260 32261
NEEDLE BEARING	32264
MAIN GEAR (4TH)	32270
4TH GEAR INPUT SHAFT NEEDLE ROLLERS	32271 32272
PILOT BEARING	32272
MAINSHAFT BEARING	32273
ROLLER BEARING REVERSE IDLER SHAFT	32273 32281
REVERSE IDLER GEAR	32282
REVERSE IDLER BEARING	32283
RETAINING PIN COUNTERSHAFT GEAR (5TH)	32293 32310
INPUT GEAR (5TH)	32310
OVERDRIVE COUNTER GEAR	32310
MAIN GEAR (5TH) MAINSHAFT GEAR (5TH) BW-T5	32340 32340
O.D. (5TH) MAIN GEAR	32340
C RING HOLDER	32351
SYNCHRO ASSY SYNCHRONIZER HUB	32601 32601
SYNCHRO SLEEVE	32601
SPREAD RING INSERT SPRING	32602 32603
SPREAD RING	32603
BAULK RING	32604
COUPLING SLEEVE INSERT	32606 32609
SHIFTING INSERT	32609
REVERSE BAULK RING	32617
BAULK RING BAULK RING (1ST)	32680 32680
BLOCKER RING	32680
BAULK RING (2ND) BLOCKER RING	32681 32681
BAULK RING (3RD)	32682
BLOCKER RING	32682
BAULK RING (4TH) BLOCKER RING	32683 32683
BAULK RING (5TH)	32684
BLOCKER RING	32684
SYNCHRO RING SET (5TH) SPEEDMASTER DRIVE GEAR	32689 32701
SPEEDOMETER PINION	32703
CHECK BALL & SPRING	32721
SHIFT ROD FORK ROD	32801
SHIFT FORK	32805
CHECK BALL & SPRING	32829
CONTROL LEVER CONTROL LEVER BOOT (RWD)	32841 32841
O-RING	32845
OIL CONTROL SEAL	32858
CONTROL LEVER SOCKET (RWD) CONTROL LEVER BOOT (RWD)	32861 32862
SHIFT KNOB	32865
STRIKING ROD	32890
CONTROL SELECTOR ARM STRIKING LEVER	32896 32896
STRIKING ROD PIN	32917
TRANSFER FRONT CASE	33102
TRANSFER REAR CASE TRANSFER CENTER CASE	33103 33105
FRONT CASE OIL SEAL	33112
MAIN GEAR	33113
DRIVESHAFT OIL SEAL	33114

RING GEAR	P.M.C.
BALL BEARING	3311
BALL BEARING (MAIN GEAR)	3311
END COVER	3311
COUNTERSHAFT	33120
COUNTER GEAR	3312
NEEDLE BEARING	3312
HYPOID GEAR	3312
COUNTER GEAR BEARING	3312
TRANSFER DRIVE SHAFT TRANSFER MAIN SHAFT	3313
LOW SPEED GEAR	33137
FRONT DRIVE SPROCKET	33134
DRIVE SHAFT BEARING	33135
REAR CASE OIL SEAL	33142
REAR COVER OIL SEAL	33142
PINION SLEEVE	33143
COUPLING SLEEVE HUB	33144
FRONT COVER OIL SEAL	33147
TRANSFER FRONT CASE	33150
TRANSFER FRONT COVER	33150
FRONT DRIVE SHAFT NEEDLE BEARING	33151
COUPLING SLEEVE	33154
COMPANION FLANGE	33156
HYPOID PINION	33158
DRIVE CHAIN	33159
SHIFT ROD	33161
SHIFT FORK	33162
FRONT SHIFT BRACKET	33164
SHIFT FORK SPRING	33169
SHIFT SHAFT	33180
SHIFT SHAFT OIL SEAL TRANSFER CONTROL LEVER	33185 33210
CENTER CASE OIL SEAL	33216
TRANSFER SHIFT KNOB	33219
CROSS SHAFT	33822
TRANSFER PROTECTOR	33940
CONTROL ROD	34103
CONTROL ROD (FWD)	34103
ACTUATOR ASSY	34310
CONTROL ROD LOWER BRACKET	34400
SHIFT ROD TRUNNION	34410
SELECT LEVER ASSY (RWD) CROSS SHAFT LEVER	34415 34430
LOWER CONTROL ROD	34441
CONTROL CABLE (RWD)	34445
SUB TRANSMISSION ROD	34451
SUB TRANSMISSION ROD	34452
DUST COVER HOLDER	34504
DUST COVER (FWD)	34506
CROSS SHAFT LEVER CROSS SHAFT ASSY	34507
SUPPORT ROD (FWD)	34520 34559
SUPPORT ROD BRACKET	34560
SUPPORT ROD DAMPER	34582
CROSS OVER SHAFT	34692
A/T CONTROL DEVICE	34903
KEY INTERLOCK CABLE ASSY	34908
COMPRESSION ROD	34912
LEVER SHAFT	34915
POSITION PLATE PIN	34917
CONTROL LEVER	34920
RETURN SPRING	34926 34935
SELECTOR ROD/CONTROL CABLE  A/T CABLE	34936
	34970
NTERLOCK SOLENOID	
	34980
PARK* POSITION SWITCH-A/T VEHICLES	34980 38101
PARK" POSITION SWITCH A/T VEHICLES Final Gear Final Gear	38101 38106
PARK' POSITION SWITCH AT VEHICLES Final Gear Final Gear Pinion Bearing	38101 38106 38121
Park" Position Switch-AT Vehicles Final Gear Pinion Bearing Hypoid Pinion	38101 38106 38121 38158
PARK' POSITION SWITCH-A/T VEHICLES  FINAL GEAR  FINAL GEAR  PINION BEARING  1YPOID PINION  COMPANION FLANGE	38101 38106 38121 38158 38212
PARK' POSITION SWITCHAIT VEHICLES FINAL GEAR FINAL GEAR PINION BEARING 4YPOID PINION COMPANION FLANGE FRANSFER BREATHER	38101 38106 38121 38158 38212 38323
PARK' POSITION SWITCH-A/T VEHICLES  TINAL GEAR  PINION BEARING  1YPOID PINION  COMPANION FLANGE  TRANSFER BREATHER  DIFFERENTIAL SIDE OIL SEAL	38101 38106 38121 38158 38212 38323 38342
PARK' POSITION SWITCH-A/T VEHICLES  FINAL GEAR  FINAL GEAR  PINION BEARING  HYPOID PINION  COMPANION FLANGE  FRANSFER BREATHER  DIFFERENTIAL SIDE OIL SEAL  DIFFERENTIAL CASE	38101 38106 38121 38158 38212 38323 38342 38410
PARK' POSITION SWITCHAIT VEHICLES FINAL GEAR FINAL GEAR PINION BEARING PYPOID PNION COMPANION FLANGE FRANSFER BREATHER DIFFERENTIAL SIDE DIL SEAL DIFFERENTIAL CASE SIDE GEAR	38101 38106 38121 38158 38212 38323 38342 38410 38413
PARK' POSITION SWITCHAIT VEHICLES  INAL GEAR  PINION BEARING  1YPOID PINION  COMPANION FLANGE  FRANSFER BREATHER  DIFFERENTIAL SIDE OIL SEAL  JIFFERENTIAL CASE  SIDE GEAR  SIDE GEAR	38101 38106 38121 38158 38212 38323 38342 38410 38413 38414
PARK' POSITION SWITCH-AT VEHICLES  INAL GEAR  PINION BEARING  1YPOID PINION  COMPANION FLANGE  FRANSFER BREATHER  DIFFERENTIAL SIDE OIL SEAL  DIFFERENTIAL CASE  SIDE GEAR  PINION MATE	38101 38106 38121 38158 38212 38323 38342 38410 38413 38414 38415
PARK' POSITION SWITCHAIT VEHICLES FINAL GEAR FINAL GEAR PINION BEARING PYPOID PNION COMPANION FLANGE FRANSFER BREATHER DIFFERENTIAL SIDE DIL SEAL DIFFERENTIAL CASE SIDE GEAR PINION MATE PINION MATE	38101 38106 38121 38158 38212 38323 38342 38410 38413 38414 38415
PARK' POSITION SWITCHAIT VEHICLES FINAL GEAR FINAL GEAR PINION BEARING 4YPOID PINION COMPANION FLANGE FRANSFER BREATHER DIFFERENTIAL SIDE OIL SEAL DIFFERENTIAL CASE SIDE GEAR SIDE GEAR SIDE GEAR FINION MATE PINION MATE	38101 38106 38121 38158 38212 38323 38342 38410 38413 38414 38415 38416 38417
INTERLOCK SOLENOID PARK' POSITION SWITCHAT VEHICLES FINAL GEAR FIN	38101 38106 38121 38158 38212 38323 38342 38410 38413 38414 38415
PARK' POSITION SWITCH AT VEHICLES  INAL GEAR  PINION BEARING  1YPOID PINION  COMPANION FLANGE  FRANSFER BREATHER  DIFFERENTIAL CASE  SIDE GEAR  PINION MATE  PINION MATE  PINION MATE  PINION MATE SHAFT  PINION MATE SHAFT	38101 38106 38121 38158 38212 38323 38342 38410 38413 38414 38415 38416 38417
PPARK POSITION SWITCH-A/T VEHICLES  FINAL GEAR  FINAL GEAR  FINAL OF THE PROPERTY OF THE PROPE	38101 38106 38121 38158 38212 38323 38342 38410 38413 38414 38415 38416 38417 38418

COMPONENT	P.N.C.
VISCOUS COUPLING	38760
CLEVIS PIN	46123
CLUTCH PEDAL BUSHING	46526
CLUTCH PEDAL	46540
CLUTCH PEDAL RET. SPRING	46586
VACUUM TANK	47100
VACUUM TANK ASSY	47110
AT CONTROL INDICATOR	48475
A/T SHIFTLOCK SYSTEM	48712

# STEERING, SUSPENSION, BRAKES

SELEVINE CYSTAM

IDLER PULLEY	11925
IDLER PULLEY BRACKET	11935
POWER STEERING PUMP BRACKET	11940
ADJUSTING BAR	11945
LAMP - HICAS WARNING	25020
HICAS RELAY	25247
SLIP RING	25694
HEAD AMPLIFIER	25697
STEERING SENSOR ASSY	28475
HICAS CONTROL UNIT	28505
RACK & PINION ASSY	48001
CTEFOING CEAD ASSIV	
STEERING GEAR ASSY	48010
STEERING GEAR HOUSING	48011
STEERING GEAR PINION	48023
PINION GEAR BEARING	48025
PINION OIL SEAL	48025
WORM GEAR BEARING	48025
FILLER PLUG	48060
STEERING LOWER JOINT	48080
STEERING RACK	48100
SECTOR SHAFT	48103
WORM OIL SEAL	48125
SECTOR SHAFT BEARING	48127
SECTOR SHAFT ADJUST SCREW/NUT	48135
SECTOR SHAFT OIL SEAL	48137
STEERING WORM ASSY	48150
	48201
SECTOR SHAFT COVER	
STEERING GEAR BOOT	48203
SECTOR SHAFT COVER GASKET	48204
REAR HOUSING	48210
REAR HOUSING CAP	48212
REAR HOUSING OIL SEAL	48214
ADJUSTER	48231
RACK MOUNT CLAMP	48353
RACK MOUNT INSULATOR	48376
STEERING WHEEL	48400
LOCK NUT	48401
HORN BUTTON ASSY	48420
STEERING GEAR ARM	48502
STEERING GEAR LOCK NUT	48503
SIDE ROD ASSY	48510
SIDE ROD BAR	48512
LOCK NUT	48514
OUTER SOCKET	48520
INNER SOCKET	48521
DUST COVER	48522
SLOTTED NUT	48523
STEERING IDLER ARM	48530
STEERING IDLER FIXING BOLT	48534
STEERING IDLER LOCK NUT	48535
CROSS ROD	48560
SIDE ROD CLIP	48562
STEERING DAMPER	48611
STEERING LOCK	48700
TRANSFER GEAR ASSY	48760
STEERING COLUMN ASSY	48805
STEERING COLUMN SHAFT	48820
UPPER COLUMN SHAFT	48821
JACKET TUBE	48860
UPPER JACKET TUBE	48861
STEERING COLUMN CLAMP	48960
JOINT COVER	48967
TILT LEVER	48970
POWER STEERING GEAR ASSEMBLY	49001
POWER STEERING PUMP	49110
	49115
PUMP RESERVOIR TANK	
PUMP CAP	49181
POWER STEERING GEAR ASSEMBLY	49200

O-RING PINION OIL SEAL RACK PACKING	49203 49226
RACK PACKING	
	49297
STUB SHAFT SEAL	49365
RACK BUSHING	49522
O-RING	49525
CYLINDER TUBE	49541
HOSE/TUBE-PUMP TO GEAR	49710
PRESSURE TUBE ASSY	49716
HOSE/TUBE-GEAR TO PUMP	49720
P/S TUBE HOSE	49722
POWER STEERING RETURN HOSE	49725
BREATHER TUBE	49731
POWER STEERING OIL SWITCH	49761
FLOW CONTROL VALVE	49810
PRESSURE CONTROL VALVE ASSY	49836
REAR AXLE BALL JOINT ASSY	55154
ELECTRIC CYLINDER ASSY	55705
HICAS POWER CYLINDER ASSY	55710
HICAS MOTOR ASSEMBLY	55740
POSITION SENSOR ASSY - MAIN	55741
POSITION SENSOR ASSY - SUB	55742
PRESSURE REAR TUBE/HOSE SET	55750
	55780

ANLES & SUSPENSION

AVERAGE DATE OF THE OWNER.	
SELECT SWITCH	25140
SUSPENSION CONTROL UNIT SONAR ROAD SENSOR	25963
SONAR ROAD SENSOR	25965
STEERING ANGLE SENSOR	28476
CENTER BEARING BRACKET	37519
CENTER DRIVE BEARING	37520
AXLE SHAFT	38162
REAR AXLE SHAFT	38162
REAR AXLE SHAFT NUT	38163
BREATHER	38352
DRAIN PLUG	38355
FRONT DRIVE SHAFT 4WD	38519
FRONT DRIVE SHAFT	39100
DRIVE SHAFT	39600
SPIDER ASSY	39625
DRIVE SHAFT BOOT	39655
SLIDE JOINT HOUSING	39714
SLIDE JOINT SPIDER	39720
KNUCKLE SPINDLE (FWD)	40014
KNUCKLE SPINDLE (REAR)	40014
KING PIN	40022
KING PIN BEARING	40030
STEERING STOPPER BOLT	40038
STOPPER BOLT CAP	40039
KNUCKLE ARM	40052
DUST COVER (CV BOOT) DRIVE SHAFT BOOT	40088
	40088
UPPER BALL JOINT	40110
LOWER BALL JOINT	40160
LOWER BALL JOINT SEAT FRONT WHEEL HUB	40173 40202
DRIVE SHAFT BEARING 4WD FRONT WHEEL BEARING	40213
FRONT HUB BOLT	40222
GREASE SEAL	40232
FREE RUNNING HUB 4WD	40250
DRIVE CLUTCH GEAR, 4WD	40252
LOCK NUT	40262
BEAM—REAR AXLE	43011
HOUSING—RR AXLE	43018
BUSHING ASSY-AXLE HOUSING	43052
REAR WHEEL HUB	43204
REAR AXLE COMPANION FLANGE	43213
REAR AXLE BEARING	43215
REAR HUB BOLT	43222
SEAL, GREASE, RR HUB	43232
REAR AXLE OIL SEAL	43252
OCK NUT	43262
FRONT COIL SPRING (STRUT)	54010
FRONT LEAF SPRING	54010
FRONT TORSION BAR	54010
SPRING SEAT	54036
BOUND BUMPER	54050
REBOUND BUMPER	54053
STRUT DUST COVER	54055
STRUT DUST SEAL	54059
TORQUE ARM	54080
ANCHOR ARM	54210
ANCHOR ADJ. BOLT & NUT	54216
STRUT ASSY	54302
GLAND PACKING	54308

COMPONENT	P.N.C
STRUT INSULATOR	54320
STRUT BEARING	54325
REBUND STOPPER ADJ. SHOCK SUB-HARNESS	54342 54390
FRONT SUSPENSION MEMBER	54401
SUPRT BRACKET - FRNT. SUSPENSION MBR.	54402
LINK SPINDLE LOWER LINK SPINDLE	54419 54419
TENSION ROD	54470
TENSION/COMPRESSION ROD	54471
BUSHING TENSION ROD BUSHING	54476 54476
TENSION ROD BRACKET	54480
TRANSVERSE LINK GUSSETT	54499
BUSHING UPPER LINK BUSHING	54504 54507
UPPER LINK ASSY	54524
UPPER LINK BRACKET	54527
LOWER LINK	54529
TRANSVERSE LINK UPPER LINK	54529 54533
BUSHING	54535
UPPER LINK SPINDLE	54536
STEERING KNUCKLE EXTENSION FRONT STABILIZER	54590 54611
BRACKET & BUSHING	54614
CONNECTING ROD BUSHING	54618
ROC-RR STAB. LAUNCHING BRACKET	54619 55015
LOWER LINK ASSY	55019
LOWER LINK (IRS-4WD)	55019
REAR COIL SPRING (IRS) REAL COIL SPRING (STRUT)	55020 55020
REAR COIL SPRING-LINK TYPE	55020
REAR SPRING (LEAF)	55020
TORSION BAR UPPER LINK	55020 55023
PARALLEL ROD	55024
REAR SPRING SEAT (IRS)	55036
REAR SPRING SEAT (STRUT) SPRING SEAT (LINK TYPE)	55036 55036
INNER BUSHING	55042
OUTER BUSHING	55043
SPRING MOUNT BUSHING SUSPENSION ARM BUSHING	55044 55045
SHACKLE BUSHING	55046
LOWER LINK BUSHING UPPER LINK BUSHING	55047 55048
LOCATION PLATE	55054
REAR SUSPENSION LOWER LINK ASSY	55100
LINK ASSYRR SUSPENSION UPPER FR PANHARD ROD BUSHING	55121 55135
CONTROL ROD	55122
PANHARD ROD LINK ASSY-RR SUSPENSION UPPER RR	55130
RADIUS ROD AND BOLT	55131 55140
RADIUS ROD BUSHING	55142
SPRING MOUNT	55202
SPRING SHACKLE REAR SPRING PIN	55220 55225
SUSPENSION ARM BOLT	55226
SPRING LOCK PLATE BOUND BUMPER (IRS)	55227 55240
BOUND BUMPER-LEAF SPRING	55240
BOUND BUMPER LINK TYPE	55240
STRUT BOUND BUMPER SPRING PAD (LEAF)	55241 55243
SPRING CLIP	55247
LOWER LINK BRACELET	55252
SPRING SEAT (LEAF) UPPER LINK BRACKET	55262 55270
REAR STRUT ASSY	55302
GLAND PACKING	55308
MOUNTING INSULATOR REAR SUSPENSION MEMBER	55320 55401
TORQUE ARRESTER	55425
STAY-RR SUSPENSION MEMBER	55451
REAR SUSPENSION MOUNT DIFFERENTIAL MOUNTING MEMBER	55466 55470
DIFFERENTIAL MOUNTING BRACKET	55471
PARALLEL ROD BUSHING	55480
SUSPENSION BAR (MULTI-LINK) TORSION BEAM — REAR AXLE	55495 55500
SUSPENSION ARM ASSY	55501
REAR ARM ASSY	55502
ANCHOR ARM PARALLEL ROD BOLT	55520 55524

# STEERING, SUSPENSION, BRAKES OF PERCENTION OF THE PERCENT OF THE P

rn	21	í,	115	10	

COMPONENT	P.N.C.
ANCHOR ARM SLEEVE	55525
REAR ARM BRACKET	55530
TORSION BAR STOPPER	55539
SPRING SEAT STAY	55545
BUSHING	55743
LINK DAMPER	56220
REAR STABILIZER	56230
CONNECT ROD BUSHING	56231
BRACKET-RR STABILIZER	56233
MOUNTING BRACKET BUSHING	56243

BRASES

ABS MOTOR RELAY 25187  TOP LAMP SWITCH 25320  HAND BRAKE CONTROL 36010  PARKING BRAKE SWITCH 36011  RATCHET NAIL 36520  HAND BRAKE STEM 36326  PARKING BRAKE SELEASE ROD 36327  HAND BRAKE STEM 36326  PARKING BRAKE RELEASE ROD 36327  HAND BRAKE BRACKET 36328  HAND BRAKE GUIDE 36335  HAND BRAKE SPRING 36337  HAND BRAKE SPRING 36337  HAND BRAKE CONTROL LEVER YOKE 36339  HAND BRAKE CONTROL LEVER YOKE 36339  HAND BRAKE LEVER 36302  CLEVIS PIN (HAND BRAKE) 36381  FRONT CABLE 36402  CENTER LEVER BRACKET 36421  ADJUSTER NUT 36437  REAR CABLE 36450  CROSS CABLE 36451  REAR CABLEROD 36452  CENTER LEVER 36510  GOUALIZER 36518  HANGER STRAP/SWING ARM 36525  SWING ARM 36525  CLEVIS & PIN (HAND BRAKE) 36518  REAR CABLE ADJUSTER 36514  CALIPER YOKE 41025  RETURN SPRING 41026  FRONT CALIPER SEAL & PISTON 41100  PIVOT PIN 41041  ANTI-SQUEAK SPRING 41081  REAR CABLE PLATE 41115  REAR CALIPER BOY 44020  CALIPER BODY 44025  HOLD DOWN PIN 41040  ANTI-RATTLE PIN 44081  HAND BRAKE CONTROL LIVR YOKE 44082  REAR BBAKE RETURN SPRING 46083  REAR BBAKE RETURN SPRING 46082  FULID STRAINGER 46093  CLEVIS PIN 46063  BRAKE PEDAL BUSHING 46520  REAR BBAKE RETURN SPRING 46080  FULIOL STRAINER 46093  CLEVIS PIN 46060  GREEN WASTER CYLINDER BRACKET 46518  BRAKE BOOSTER SPACER 47211  BRAKE BOO	104 110700 001 111	
HAND BRAKE CONTROL   36010   PARKING BRAKE SWITCH   36011   NATIONAL   36011   PARKING BRAKE STEM   36326   PARKING BRAKE GUIDE   36336   PARKING BRAKE GUIDE   36337   PAND BRAKE GUIDE   36337   PAND BRAKE CONTROL LEVER YOKE   36339   PAND BRAKE CONTROL LEVER YOKE   36372   PAND BRAKE CONTROL LEVER YOKE   36372   PAND BRAKE CONTROL LEVER YOKE   36372   PAND BRAKE LEVER   36372   PAND BRAKE CONTROL LEVER YOKE   36372   PAND BRAKE LEVER   36402   PAND BRAKE   36508   PAND BRAKE   36509   PAND B	ABS MOTOR RELAY	25187
PARKING BRAKE SWITCH	STOP LAMP SWITCH	25320
PARKING BRAKE SWITCH	HAND BRAKE CONTROL	36010
RATCHET NAIL 36320 HAND BRAKE STEM 36326 PARKING BRAKE RELEASE ROD 36327 HAND BRAKE GRAKE RELEASE ROD 36327 HAND BRAKE SPRING 36338 HAND BRAKE SPRING 36337 HAND BRAKE SPRING 36339 HAND BRAKE CONTROL LEVER YOKE 36339 HAND BRAKE LEVER 36372 CLEVIS PIN (HAND BRAKE) 363612 RETURN SPRING 36361 REAR CABLE 36450 CROSS CABLE 36502 CLEVIS PIN (HAND BRAKE) 36518 HANGER STRAP/SWING ARM 36526 CLEVIS & PIN (HAND BRAKE) 36518 HANGER STRAP/SWING ARM 36526 CLEVIS & PIN (HAND BRAKE) 36538 RETURN SPRING 36540 CLEVIS & PIN (HAND BRAKE) 36538 RETURN SPRING 36547 CALIPER YOKE 41025 HOLD DOWN PIN 41040 PIVOT PIN 41041 ANTI-SQUEAK SPRING 41086 FRONT CALIPER 441010 FRONT BAFFLE PLATE 41151 REAR CALIPER HAVE 44002 CALIPER BODY 44025 HOLD DOWN PIN 44000 FRONT CALIPER 44002 CALIPER BAKE RETURN SPRING 44080 TOGGLE LEVER 44020 CALIPER BAKE RETURN SPRING 44080 TOGGLE LEVER 44002 CALIPER BODY 44025 HOLD DOWN PIN 44000 LEVER ASSY 44080 TOGGLE LEVER 44095 TOGGLE LEVER 44095 TOGGLE LEVER 44095 TOGGLE LEVER 44096 TOGGLE LEVER		
HAND BRAKE STEM   36326   PARKING BRAKE RELEASE ROD   36127   AND BRAKE BRACKET   36328   HAND BRAKE BRACKET   36328   HAND BRAKE GUIDE   36335   HAND BRAKE SPRING   36337   HAND BRAKE CONTROL LEVER YOKE   36339   HAND BRAKE CONTROL LEVER YOKE   36339   HAND BRAKE CONTROL LEVER YOKE   36339   HAND BRAKE LEVER   36372   CLEVIS PIN (HAND BRAKE)   36381   HAND BRAKE LEVER   36402   CENTER LEVER BRACKET   36421   ADJUSTER NUT   36437   REAR CABLE   36450   GROSS CABLE   36451   GROSS CABLE   36451   GROSS CABLE   36451   GROSS CABLE   36451   GROSS CABLE   36510   GRO		
PARKING BRAKE RELEASE ROD 36327 HAND BRAKE BRACKET 36328 HAND BRAKE GUIDE 36335 HAND BRAKE GUIDE 36335 HAND BRAKE SPRING 36337 HAND BRAKE CONTROL LEVER YOKE 36339 HAND BRAKE LEVER 36337 CLEVIS PIN (HAND BRAKE) 36381 FRONT CABLE 36402 CENTER LEVER BRACKET 36412 ADJUSTER NUT 36437 REAR CABLE 36402 CROSS CABLE 36502 CROSS CABLE 36510 EQUALIZER 41020 E		
HAND BRAKE BRACKET   36328   HAND BRAKE GUIDE   36335   HAND BRAKE SPRING   36337   HAND BRAKE SPRING   36339   HAND BRAKE LEVER   36339   HAND BRAKE LEVER   36339   HAND BRAKE LEVER   36339   HAND BRAKE LEVER   36381   FRONT CABLE   36402   CENTER LEVER BRACKET   36412   ADJUSTER LEVER BRACKET   36421   REAR CABLE   36450   CROSS CABLE   36450   CROSS CABLE   36451   REAR CABLE/ROD   36452   CENTER LEVER   36510   EQUALIZER   36518   HANGER STRAP/SWING ARM   36526   CLEVIS & PIN (HAND BRAKE)   36538   RETURN SPRING   36538   RETURN SPRING   36547   CALIPER YOKE   41025   HOLD DOWN PIN   41040   PIVOT PIN   41041   ANTI-SQUEAK SPRING   41083   CLIP   41086   FRONT CALIPER   41110   FRONT BAFFLE PLATE   41151   REAR CABLE REAL & PISTON   41120   FRONT BAFFLE PLATE   41151   REAR CALIPER   44002   CALIPER BODY   44025   HOLD DOWN PIN   44004   ANTI-RATTLE PIN   44081   HAND BRAKE CONTROL LIVR YOKE   44082   HOLD DOWN PIN   44005   ANTI-RATTLE PIN   44081   HAND BRAKE CONTROL LIVR YOKE   44082   TORGEL EVER   44095   REAR BAFFLE PLATE   44116   HAND BRAKE CONTROL LIVR YOKE   44082   HOLD DOWN PIN   44006   CALIPER SSY   44118   HAND BRAKE CONTROL LIVR YOKE   44080   TOGGLE LEVER   44095   REAR BAFFLE PLATE   44110   REAR BAFFLE PLATE   44110   REAR BAFFLE PLATE   44110   ROUNT PIN   44006   ANDISTER SSY   44200   MASTER CYLINDER   46010   OIL RESERVOIR CAP   46026   REAR BRAKE PEDAL   46045   EVER ASSY   46063   BRAKE PIDE   46284   CONNECTOR   46000   BRAKE PEDAL   46525   BRAKE PEDAL   46526   BRAKE PEDAL   46526   BRAKE PEDAL   46580   BRAKE PEDAL   46580   BRAKE PEDAL   46580   BRAKE PEDAL   46580   BRAKE BOOSTER SPACER   47210   BRAKE BOOSTER		
HAND BRAKE GUIDE   36335     HAND BRAKE SPRING   36337     HAND BRAKE CONTROL LEVER YOKE   36339     HAND BRAKE CONTROL LEVER YOKE   36339     HAND BRAKE LEVER   36372     CLEVIS PIN (HAND BRAKE)   36831     HAND BRAKE LEVER   36402     CENTER LEVER BRACKET   36402     CENTER LEVER BRACKET   36421     ADJUSTER NUT   36437     CROSS CABLE   36450     CROSS CABLE   36450     CROSS CABLE   36450     CROSS CABLE   36510     EVALUATION OF SEAL O	PARKING BRAKE RELEASE ROD	36327
HAND BRAKE SPRING	HAND BRAKE BRACKET	36328
HAND BRAKE SPRING	HAND BRAKE GUIDE	36335
HAND BRAKE CONTROL LEVER YOKE   36339   HAND BRAKE LEVER   36372   CEVIS PIN (HAND BRAKE)   36381   FRONT CABLE   36402   CENTER LEVER BRACKET   36402   CENTER LEVER BRACKET   36407   REAR CABLE   36450   GENTER LEVER BRACKET   36450   GENTER LEVER BRACKET   36450   GENTER LEVER   36450   GROSS CABLE   36451   GROSS CABLE   36451   GROSS CABLE   36451   GROSS CABLE   36510   GROSS CABLE   36510   GOLULIZER   36510   GOLU		
HAND BRAKE LEVER   36312		
CLEVIS PIN (HAND BRAKE)         36381           FRONT CABLE         364021           ADJUSTER NUT         36421           ADJUSTER NUT         36437           REAR CABLE         36451           GROSS CABLE         36451           REAR CABLE         36502           GROSS CABLE         36451           REAR CABLE ROD         36452           CENTER LEVER         36510           GOUALIZER         36518           HANGER STRAP/SWING ARM         36525           SWING ARM         36525           SWING ARM         36525           CLEVIS & PIN (HAND BRAKE)         36536           REETURN SPRING         36547           CALIPER YOKE         41026           REAR CABLE ADJUSTER         36547           CALIPER YOKE         41026           REOLD DOWN PIN         41040           PNOT PIN         41041           ANTI-SQUEAK SPRING         41086           FRONT CALIPER         41110           CALIPER SEAL & PISTON         41120           FRONT BAFFLE PLATE         41151           REAR CABLE PLEATE         44010           BACK PLATE         44020           CALIPER BODY		
RONT CABLE   36402	HAND BRAKE LEVER	36372
RONT CABLE   36402	CLEVIS PIN (HAND BRAKE)	36381
CENTER LEVER BRACKET         36421           ADJUSTER NUT         36437           REAR CABLE         36450           CROSS CABLE         36451           REAR CABLEROD         36452           CEVETER LEVER         36510           EQUALIZER         36518           HANGER STRAP/SWING ARM         36525           CLEVIS & PIN (HAND BRAKE)         36538           RETURN SPRING         36547           CALIPER YOKE         41025           HOLD DOWN PIN         41026           HOLD DOWN PIN         41041           ANTI-SQUEAK SPRING         41083           CLIP         41086           FRONT CALIPER         41110           CALIPER SEAL & PISTON         41120           FRONT BAFFLE PLATE         41111           REAR CALIPER         44010           FRONT BAFFLE PLATE         41151           REAR CALIPER         44020           CALIPER BODY         44025           HOLD DOWN PIN         44002           CALIPER BODY         44025           HOLD DOWN PIN         44002           EXTENSION LINK         44075           ANTI-RATTLE PIN         44081           HAND BRAKE CONTROL LVR		
ADJUSTER NUT REAR CABLE 36437 REAR CABLE 36450 REAR CABLE 36451 REAR CABLE/ROD 36452 CENTER LEVER 36510 GUALIZER 36518 HANGER STRAP/SWING ARM 36525 SWING ARM 36526 CLEVIS & PIN (HAND BRAKE) 36538 RETURN SPRING 36545 REAR CABLE ADJUSTER 36547 CALIPER YOKE 41025 REAR CABLE ADJUSTER 41026 REAR CABLE ADJUSTER 41086 FRONT CALIPER 41110 CALIPER SEAL & PISTON 41120 FRONT BAFFLE PLATE 41151 REAR CALIPER 44010 BACK PLATE 44020 CALIPER BODY 44025 HOLD DOWN PIN 44040 EXTENSION LINK 44015 ANT-RATTLE PIN 44081 RATT-RATTLE PIN 44081 RATT-RATTLE PIN 44081 RATT-RATTLE PIN 44081 REAR BRAKE RETURN SPRING 44080 TOGGLE LEVER 44090 TOG	CENTED LEVED DDACKET	
REAR CABLE         38450           CROSS CABLE         36452           CROSS CABLE         36510           BEAR CABLE/ROD         36525           CENTER LEVER         36510           EQUALIZER         36518           HANGER STRAP/SWING ARM         36525           SWING ARM         36525           CLEVIS & PIN (HAND BRAKE)         36538           RETURN SPRING         36545           FEAR CABLE ADJUSTÉR         36547           CALIPER YOKE         41026           HOLD DOWN PIN         41040           ANTI-SQUEAK SPRING         41083           CLIP         41084           FRONT CALIPER         41110           CALIPER SEAL & PISTON         41120           FRONT BAFFLE PLATE         41110           CALIPER SEAL & PISTON         41120           FRONT BAFFLE PLATE         41151           CALIPER BODY         44025           ANTI-RATTLE PIN         44020           CALIPER BODY         44025           ANTI-RATTLE PIN         44040           EXTENSION LINK         44075           ANTI-RATTLE PIN         44040           EXTENSION LINK         44075           ANTI-RATTLE P		
CROSS CABLE         36451           REAR CABLE/ROD         36452           CENTER LEVER         36510           EQUALIZER         36518           HANGER STRAP/SWING ARM         36526           SWING ARM         36526           CLEVIS & PIN (HAND BRAKE)         36538           RETURN SPRING         36538           RETURN SPRING         36547           CALIPER YOKE         41025           HOLD DOWN PIN         41041           ANTI-SQUEAK SPRING         41081           CLIP         41086           FRONT CALIPER         41110           CLIP         41086           FRONT CALIPER         41110           FRONT BAFFLE PLATE         411151           REAR CALIPER         44010           FRONT BAFFLE PLATE         41151           REAR CALIPER BODY         44025           HOLD DOWN PIN         44002           CALIPER BODY         44025           HOLD DOWN PIN         44002           CALIPER BODY         44025           HOLD DOWN PIN         44081           HAND BRAKE CONTROL LVR YOKE         44082           EVER ASKY         44181           HAND BRAKE CONTROL LVR YOKE		
REAR CABLE/ROD         36512           CENTER LEVER         36510           CQUALIZER         36518           EQUALIZER         36518           HANGER STRAP/SWING ARM         36525           SWING ARM         36526           SWING ARM         36525           SWING ARM         36526           CEVIS & PIN (HAND BRAKE)         36538           RETURN SPRING         36538           REAR CABLE ADJUSTER         36547           CALIPER YOKE         41025           HOLD DOWN PIN         41040           PIVOT PIN         41041           ANTI-SQUEAK SPRING         41083           CLIP         41086           FRONT CALIPER         41100           CALIPER SEAL & PISTON         41120           FRONT BAFFLE PLATE         41151           REAR CALIPER         44010           BACK PLATE         44020           CALIPER BODY         44028           HOLD DOWN PIN         44040           EXTENSION LINK         44075           HOLD DOWN PIN         44060           HAND BRAKE CONTROL LVR YOKE         44081           HAND BRAKE CONTROL LVR YOKE         44082           REAR BRAKE RETURN	REAR CABLE	36450
REAR CABLE/ROD         36512           CENTER LEVER         36510           CQUALIZER         36518           EQUALIZER         36518           HANGER STRAP/SWING ARM         36525           SWING ARM         36526           SWING ARM         36525           SWING ARM         36526           CEVIS & PIN (HAND BRAKE)         36538           RETURN SPRING         36538           REAR CABLE ADJUSTER         36547           CALIPER YOKE         41025           HOLD DOWN PIN         41040           PIVOT PIN         41041           ANTI-SQUEAK SPRING         41083           CLIP         41086           FRONT CALIPER         41100           CALIPER SEAL & PISTON         41120           FRONT BAFFLE PLATE         41151           REAR CALIPER         44010           BACK PLATE         44020           CALIPER BODY         44028           HOLD DOWN PIN         44040           EXTENSION LINK         44075           HOLD DOWN PIN         44060           HAND BRAKE CONTROL LVR YOKE         44081           HAND BRAKE CONTROL LVR YOKE         44082           REAR BRAKE RETURN	CROSS CABLE	36451
CENTER LEVER         36510           EQUALIZER         36518           HANGER STRAP/SWING ARM         36525           SWING ARM         36525           CLEVIS & PIN (HAND BRAKE)         36538           RETURN SPRING         36547           CALIPER YOKE         41025           HOLD DOWN PIN         41040           PIVOT PIN         41041           ANTI-SQUEAK SPRING         41083           CLIP         41086           FRONT CALIPER         41110           CALIPER SEAL & PISTON         41120           FRONT BAFFLE PLATE         41110           REAR CABLE RELEVATE         44010           BACK PLATE         44020           CALIPER BODY         44025           HOLD DOWN PIN         44040           EXTENSION LINK         44075           ANTI-RATTLE PIN         44081           HAND BRAKE CONTROL LVR YOKE         44082           REAR BRAKE RETURN SPRING         44090           TOGGLE LEVER         44100           NEAR WHEEL CYLINDER         44100           LEVER ASSY         44111           PISTON & SEAL         44112           REAR BRAKE RETURN SPRING         4690		
EQUALIZER 35518 HANGER STRAP/SWING ARM 36526 SWING ARM 36526 CLEVIS & PIN (HAND BRAKE) 36538 RETURN SPRING 36546 RETURN SPRING 36547 CALIPER YOKE 41025 HOLD DOWN PIN 41040 PINOT PIN 41041 ANTI-SQUEAK SPRING 41083 CLIP 41086 FRONT CALIPER 41110 CALIPER SEAL & PISTON 41120 FRONT BAFFLE PLATE 41151 REAR CALIPER 44010 FRONT BAFFLE PLATE 4105 BACK PLATE 44020 CALIPER BODY 44025 HOLD DOWN PIN 44040 CALIPER BODY 44025 HOLD DOWN PIN 44040 TORSTENSION LINK 44075 ANTI-RATTLE PIN 44081 HAND BRAKE CONTROL LVR YOKE 44082 TORGILE LEVER 44080 TORGILE LEVER 44080 TORGILE LEVER 44080 TORGILE LEVER 44095 REAR WHEEL CYLINDER 44108 TORGILE LEVER 44108 TORGILE PLATE 44151 ANCHOR - PARKING BRAKE 441180 ADJUSTER ASSY 44200 MASTER CYLINDER 46010 OL RESERVOIR CAP 46020 FLUID STRAING 46082 FLUID STRAING 46083 FLUID STRAING 46082 FLUID STRAI		
HANGER STRAP/SWING ARM   36525		
SWING ARM         35525           CLEVIS & PIN (HAND BRAKE)         36536           RETURN SPRING         36547           REAR CABLE ADJUSTER         36547           CALIPER YOKE         41025           HOLD DOWN PIN         41040           PNOT PIN         41041           ANTI-SQUEAK SPRING         41086           FRONT CALIPER         41110           CALIPER SEAL & PISTON         41120           FRONT BAFFLE PLATE         41151           FRONT BAFFLE PLATE         44010           BACK PLATE         44020           CALIPER BOOY         4025           HOLD DOWN PIN         44040           EXTENSION LINK         44075           ANTI-RATTLE PIN         44081           HAND BRAKE CONTROL LVR YOKE         44082           TOGGLE LEVER         44095           REAR WHEEL CYLINDER         44090           TOGGLE LEVER         44090           TOGGLE LEVER         44090           MASTER CYLINDER         44110           LEVER ASSY         44118           PISTON & SEAL         44120           REAR WHEEL CYLINDER         44150           MASTER CYLINDER         46045 <td< td=""><td></td><td></td></td<>		
SWING ARM         35525           CLEVIS & PIN (HAND BRAKE)         36536           RETURN SPRING         36547           REAR CABLE ADJUSTER         36547           CALIPER YOKE         41025           HOLD DOWN PIN         41040           PNOT PIN         41041           ANTI-SQUEAK SPRING         41086           FRONT CALIPER         41110           CALIPER SEAL & PISTON         41120           FRONT BAFFLE PLATE         41151           FRONT BAFFLE PLATE         44010           BACK PLATE         44020           CALIPER BOOY         4025           HOLD DOWN PIN         44040           EXTENSION LINK         44075           ANTI-RATTLE PIN         44081           HAND BRAKE CONTROL LVR YOKE         44082           TOGGLE LEVER         44095           REAR WHEEL CYLINDER         44090           TOGGLE LEVER         44090           TOGGLE LEVER         44090           MASTER CYLINDER         44110           LEVER ASSY         44118           PISTON & SEAL         44120           REAR WHEEL CYLINDER         44150           MASTER CYLINDER         46045 <td< td=""><td>HANGER STRAP/SWING ARM</td><td>36525</td></td<>	HANGER STRAP/SWING ARM	36525
CLEVIS & PIN (HAND BRAKE)         36538           RETURN SPRING         36545           FEAR CABLE ADJUSTER         36547           CALIPER YOKE         41025           HOLD DOWN PIN         41040           MYOT PIN         41041           ANTI-SQUEAK SPRING         41083           CLIP         41086           FRONT CALIPER         41110           CALIPER SEAL & PISTON         41120           FRONT BAFFLE PLATE         41110           REAR CALIPER         44010           BACK PLATE         44020           CALIPER BODY         44025           HOLD DOWN PIN         44040           SATI-RATTLE PIN         44081           HAND BRAKE CONTROL LVR YOKE         44082           EVEN ASSY         4418           LAND BRAKE CONTROL LVR YOKE         44081           FEAR BRAKE RETURN SPRING         44080           TOGGLE LEVER         44095           REAR WHEEL CYLINDER         44100           MASTER CYLINDER         44118           PISTON & SEAL         44118           ANCHOR - PARKING BRAKE         44119           ADJUSTER ASSY         44201           MASTER CYLINDER         46040		
RETURN SPRING         38545           REAR CABLE ADJUSTER         36947           CALIPER YOKE         41025           HOLD DOWN PIN         41040           PYOT PIN         41040           ANTI-SQUEAK SPRING         41083           CLIP         41086           FRONT CALIPER         41100           FRONT BAFFLE PLATE         41110           FRONT BAFFLE PLATE         41151           REAR CALIPER         44010           BACK PLATE         44020           CALIPER BODY         44025           HOLD DOWN PIN         44040           EXTENSION LINK         44075           ANT.RATTLE PIN         44081           HAND BRAKE CONTROL LVR YOKE         44082           REAR BRAKE RETURN SPRING         44090           TOGGLE LEVER         44095           REAR WHEEL CYLINDER         44100           LEVER ASSY         44118           NOCHOR: PARKING BRAKE         441100           LEVER ASSY         44118           PISTON & SEAL         44110           REAR BAFFLE PLATE         46010           OIL RESERVOIR CAP         46020           MASTER CYLINDER         46010           OIL RE		
REAR CABLE ADJUSTER         36547           CALIPER YOKE         41025           HOLD DOWN PIN         41040           PIVOT PIN         41041           ANTI-SQUEAK SPRING         41083           CLIP         41086           FRONT CALIPER         41110           CALIPER SEAL & PISTON         41120           FRONT BAFFLE PLATE         41151           REAR CALIPER         44010           BACK PLATE         44020           CALIPER BODY         44025           HOLD DOWN PIN         44040           EXTENSION LINK         44075           ANTI-RATTLE PIN         44081           HAND BRAKE CONTROL LVR YOKE         44082           REAR BRAKE RETURN SPRING         44090           TOGGIE LEVER         44095           REAR WHEEL CYLINDER         44100           LEVER ASSY         44118           PISTON & SEAL         44120           MASTER CYLINDER         46019           MASTER CYLINDER         46019           MASTER CYLINDER         46010           MISTON ASSY         44200           MASTER CYLINDER         46010           RESERVOIR SEAL         46014           LEVEL INDI		
CALIPER YOKE 41025 HOLD DOWN PIN 41040 PIVOT PIN 41041 ANTI-SQUEAK SPRING 41083 CLIP 41086 CLIP 41086 FRONT CALIPER 41110 CALIPER SEAL & PISTON 41120 FRONT BAFFLE PLATE 41151 REAR CALIPER 44020 ALIPER BODY 44025 HOLD DOWN PIN 440425 HOLD DOWN PIN 44045 HOLD DOWN PIN 44075 ANTI-RATTLE PIN 44081 HAND BRAKE CONTROL LYR YOKE 44082 TOGGLE LEVER 44080 TOGGLE 44080		
CALIPER YOKE 41025 HOLD DOWN PIN 41040 PIVOT PIN 41041 ANTI-SQUEAK SPRING 41083 CLIP 41086 CLIP 41086 FRONT CALIPER 41110 CALIPER 5EAL & PISTON 41120 FRONT BAFFLE PLATE 41151 REAR CALIPER 44020 CALIPER BEAL & PISTON 44025 HOLD DOWN PIN 44045 HOLD DOWN PIN 44045 HAND BRAKE CONTROL LVR YOKE 44081 HAND BRAKE CONTROL LVR YOKE 44081 FROR BARKE RETURN SPRING 44080 TOGGLE LEVER 4559 TOGGLE LEVER 44080 TOGGLE 44080 TOGG	REAR CABLE ADJUSTER	36547
HOLD DOWN PIN 41040 PIVOT PIN 41041 ANTI-SQUEAK SPRING 41083 CLIP 41086 FRONT CALIPER 411086 FRONT CALIPER 41110 FRONT BAFFLE PLATE 41151 REAR CALIPER 44010 BACK PLATE 44020 CALIPER BODY 44025 HOLD DOWN PIN 44040 EXTENSION LINK 44075 ANTI-RATTLE PIN 44081 HAND BRAKE CONTROL LVR YOKE 44082 TOGGLE LEVER 44090 TOGGLE A4090 TOGGLE LEVER 44090 TOGGLE A4090 TOGGLE LEVER 44090 TOGGLE A4090 TOGGLE LEVER 44090 TOGGLE A4090 TOGGLE A4090 TOGGLE A4090 TOGGLE		
PIVOT PIN	HOLD DOWN DIN	
ANTI-SQUEAK SPRING 41083 CLIP 41086 CLIP 41086 CLIP 41086 CLIP 41086 FRONT CALIPER 41110 CALIPER SEAL & PISTON 41120 FRONT BAFFLE PLATE 41151 EAR CALIPER 44010 BACK PLATE 44020 CALIPER BODY 44025 HOLD DOWN PIN 44040 EXTENSION LINK 44075 ANTI-RATTLE PIN 44081 HAND BRAKE CONTROL LVR YOKE 44081 HAND BRAKE CONTROL LVR YOKE 44081 FEAR BRAKE RETURN SPRING 44090 TOGGLE LEVER 44090 TOGGLE LEVER 44090 TOGGLE LEVER 44100 TOGGLE 44000 TOGGLE 440		
CLIP         41086           FRONT CALIPER         411086           FRONT CALIPER         41110           CALIPER SEAL & PISTON         41120           FRONT BAFFLE PLATE         41151           REAR CALIPER         44012           BACK PLATE         44020           CALIPER BODY         44025           HOLD DOWN PIN         44062           EXTENSION LINK         44075           ANT-RATTLE PIN         44081           HAND BRAKE CONTROL LVR YOKE         44082           REAR BRAKE RETURN SPRING         44098           COGGLE LEVER         44095           REAR WHEEL CYLINDER         44100           LEVER ASSY         44118           PISTON & SEAL         44120           REAR BAFFLE PLATE         44110           RESTON & SEAL         44120           REAR BAFFLE PLATE         44110		
FRONT CALIPER	ANTI-SQUEAK SPRING	41083
FRONT CALIPER 41110 CALIPER SEAL & PISTON 41120 FRONT BAFFLE PLATE 41010 BACK PLATE 44020 CALIPER BODY 44025 HOLD DOWN PIN 44040 EXTENSION LINK 44075 ANTI-RATTLE PIN 44081 HAND BRAKE CONTROL LIVR YOKE 44082 REAR BRAKE RETURN SPRING 44080 TOGGLE LEVER 44095 TOGGLE LEVER 44095 REAR BRAKE CONTROL LIVR YOKE 441100 LEVER ASSY 44118 PISTON & SEAL 41120 LEVER ASSY 44118 PISTON & SEAL 41120 REAR BAFFLE PLATE 44151 ANCHOR - PARKING BRAKE 441100 LEVER INDICATOR 46040 MASTER CYLINDER 46010 LEVEL INDICATOR 46040 RESERVOIR SEAL 46020 RESERVOIR SEAL 46045 LEVEL INDICATOR 46040 SNAP RING 46040 SNAP RING 46063 SNAP RING 46063 SNAP RING 46082 FLUID RESERVOIR 46091 FLUID STRAINER 46093 FLUID STRAINER 46093 FLUID STRAINER 46512 BRAKE PIPE 46284 CONNICTOR 46512 BRAKE PIPE 46580 BRAKE PEDAL BUSHING 46520 BRAKE FEDAL BUSHING 46520 BRAKE FEDAL BUSHING 46520 BRAKE FULCRUM SHAFT 46560 BRAKE FEDAL BUSHING 46520 BRAKE FULCRUM SHAFT 46560 BRAKE FEDAL BUSHING 46525 BRAKE FULCRUM SHAFT 46560 BRAKE FEDAL BUSHING 46525 BRAKE FULCRUM SHAFT 46560 BRAKE BOOSTER SPACER 47210	CLIP	41086
CALIPER SEAL & PISTON 41120 FRONT BAFFLE PLATE 41151 REAR CALIPER 44010 BACK PLATE 44020 CALIPER BODY 44025 CALIPER BODY 44025 HOLD DOWN PIN 44040 EXTENSION LINK 44015 ANTI-RATTLE PIN 44081 HAND BRAKE CONTROL LVR YOKE 44082 REAR BRAKE RETURN SPRING 44090 TOGGLE LEVER 44095 TOGGLE LEVER 44095 REAR WHEEL CYLINDER 44110 LEVER ASSY 44118 PISTON & SEAL 44120 REAR BAFFLE PLATE 44151 DISTON & SEAL 44120 REAR BAFFLE PLATE 44151 DISTON & SEAL 44150 DISTORMEN 44080 RESERVOIR SEAL 46045 LEVEL INDICATOR 46010 DIL RESERVOIR CAP 46020 RESERVOIR SEAL 46045 LEVEL INDICATOR 46080 PISTON ASSY 46063 SNAP RING 46092 FLUID STRAINER 46092 FLUID STRAINER 46093 FLUID STRAINER 46093 FLUID STRAINER 46093 FLUID STRAINER 46093 PLUID STRAINER 46093 PLUID STRAINER 46093 PLUID STRAINER 46093 BRAKE PIPE 46284 CONNECTOR 46513 BRAKE PIPE 46580 BRAKE PEDAL 805HING 46522 BRAKE PEDAL 805HING 46523 BRAKE FEDAL 805HING 46523 BRAKE FEDAL 805HING 46523 BRAKE FEDAL 805HING 46525 BRAKE FEDAL 805HING 46585 BRAKE FEDAL 805HING 46585 BRAKE FEDAL SPRING 46586 BRAKE BOOSTER SPACER 47210 BRAKE BOOSTER SPACER 47210 BRAKE BOOSTER SPACER 47210 BRAKE BOOSTER SPACER 47210 BRAKE BOOSTER SPACER 47215 BRAKE BOOSTER SPACER 47216		
FROMT BAFFLE PLATE  REAR CALIPER  REAR CALIPER  44010  CALIPER BODY  44025  HOLD DOWN PIN  44000  SETEMSION LINK  44075  ANTI-RATTLE PIN  44081  HAND BRAKE CONTROL LVR YOKE  44082  TOGGLE LEVER  44095  TOGGLE LEVER  44095  TOGGLE LEVER  44095  REAR WHEEL CYLINDER  44110  PISTON S SEAL  44120  REAR BRAKE RETURN SPRING  44080  TOGGLE LEVER  44095  REAR WHEEL CYLINDER  44100  TOGGLE LEVER  46010  TOGGLE LEVER  46010  TOGGLE LEVER  46010  TOGGLE LEVER  46040  TOGGLE LEVER  46040  TOGGLE LEVER  46080  FLUID STRAINER  46		
REAR CALIPER 44010 BACK PLATE 44020 CALIPER BODY 44025 HOLD DOWN PIN 44040 EXTENSION LINK 44075 ANT-RATTLE PIN 44081 HAND BRAKE CONTROL LVR YOKE 44082 REAR BBAKE RETURN SPRING 44095 TOGGLE LEVER 44095 REAR WHEEL CYLINDER 44110 LEVER ASSY 44118 PISTON & SEAL 41120 LEVER ASSY 44118 PISTON & SEAL 44120 ADJUSTER ASSY 44205 MASTER CYLINDER 44095 REAR BAFER PLATE 44151 ANCHOR - PARKING BRAKE 44180 ADJUSTER ASSY 4200 MASTER CYLINDER 46010 LEVEL INDICATOR 46020 RESERVOIR SEAL 46025 RESERVOIR SEAL 46025 SNAP RING 46025 SNAP RING 46025 SNAP RING 46032 SNAP RING 46032 SNAP RING 46032 CLEVIS PIN 46033 BRAKE PIPE 46284 CONNECTOR 46033 BRAKE PIPE 46284 CONNECTOR 46313 BRAKE PIPE 46284 CONNECTOR 46513 BRAKE PIPE 46284 BRAKE PIPE 46528 BRAKE PIPE 46529 BRAKE PEDAL BUSHING 46520 BRAKE PEDAL BUSHING 46520 BRAKE PEDAL SUSHING 46520 BRAKE FULCRUM SHAFT 46560 PEDAL SHIFT SLEEVE 46588 BRAKE BOOSTER SPACER 47210		
BACK PLATE  A4020 CALIPER BODY  44025 HOLD DOWN PIN  44040 EXTENSION LINK  44015 ANTHRATTLE PIN  44081 REAR BRAKE CONTROL LIVR YOKE  REAR BRAKE CONTROL LIVR YOKE  REAR BRAKE CONTROL LIVR YOKE  REAR BRAKE RETURN SPRING  44080 TOGGLE LEVER  44090 TOGGLE LEVER  44090 TOGGLE LEVER  44100 LEVER ASSY  44110 REVER ASSY  44110 REVER ASSY  44118 PISTON & SEAL  44120 REAR BAFFLE PLATE  44151 ANCHOR - PARKING BRAKE  44116 ADJUSTER ASSY  44200 MASTER CYLINDER  46010 LEVEL INDICATOR  46040 RESERVOIR CAP  46040 RESERVOIR SEAL  46045 LEVEL INDICATOR  46082 SNAP RING  46092 FLUID STRAINER  46093 FLUID STRAINER  46093 FLUID STRAINER  46093 FLUID STRAINER  46093 PLUID STRAINER  46093 PRING  46094 BRAKE PIPE  46284 CONNICTOR  46312 BRAKE PIPE  46580 BRAKE PEDAL BRAKE PEDAL BRAKE PEDAL BRAKE PEDAL BRAKE PEDAL BRAKE PEDAL BRAKE FUCRUM SHAFT  46580 BRAKE FULCRUM SHAFT  46580 BRAKE FULCRUM SHAFT  46580 BRAKE FULCRUM SHAFT  46580 BRAKE FEDAL BUSHING  46582 BRAKE FULCRUM SHAFT  465865 BRAKE FULCRUM SHAFT  465865 BRAKE FULCRUM SHAFT  465865 BRAKE FEDAL BUSHING  465865 BRAKE FEDAL SPRING BRAKE BOOSTER SPACER  47210 BRAKE BOOSTER SPACER  47210 BRAKE BOOSTER SPACER  47415		
BACK PLATE  A4020 CALIPER BODY  A4025 HOLD DOWN PIN  44040 EXTENSION LINK  AVTHERITE PIN  AVAILABLE CONTROL LVR YOKE REAR BRAKE RETURN SPRING  A4080 REAR BRAKE RETURN SPRING  44080 TOGGLE LEVER  44090 TOGGLE LEVER  44090 TOGGLE LEVER  44090 TOGGLE LEVER  44090 REAR WHEEL CYLINDER  44110 LEVER ASSY  44118 PISTON & SEAL  A43120 REAR BAFFLE PLATE  ANCHOR: PARKING BRAKE  44116 ADJUSTER ASSY  44200 MASTER CYLINDER  46010 LI RESERVOIR CAP  46040 RESERVOIR SEAL  46045 LEVEL INDICATOR  45040 RISTON ASSY  46063 SNAP RING  46092 FLUID STRAINER  46092 FLUID STRAINER  46093 FLUID STRAINER  46093 FLUID STRAINER  46093 PLUID STRAINER  46093 BRAKE PIPE  46284 CONNECTOR  46313 BRAKE PIPE  46520 BRAKE PEDAL BRAKE FUCRUM SHAFT  46560 BRAKE FEDAL BUSHING  46525 BRAKE FULCRUM SHAFT  46585 BRAKE FULCRUM SHAFT  46585 BRAKE FULCRUM SHAFT  46586 BRAKE PEDAL BUSHING  46585 BRAKE FEDAL SPRING  46585 BRAKE BOOSTER SPACER  47210 BRAKE BOOSTER SPACER  47210 BRAKE BOOSTER SPACER  47415	REAR CALIPER	44010
CALIPER BODY 44025 HOLD DOWN PIN 44040 STETENSION LINK 44075 ANTI-RATTLE PIN 44081 HAND BRAKE CONTROL LVR YOKE 44082 TOGGLE LEVER 44095 TOGGLE LEVER 44095 TOGGLE LEVER 44095 TOGGLE LEVER 44095 TOGGLE LEVER 44108 PISTON 8 SEAL 44118 PISTON 8 SEAL 44118 PISTON 8 SEAL 44119 ANCHOR - PARKING BRAKE 44119 ANCHOR - PARKING BRAKE 44119 ANCHOR - PARKING BRAKE 44110 ADJUSTER ASSY 46010 OL RESERVOIR CAP 46010 OL RESERVOIR CAP 46010 FULL TO THE ANGLE AND 46011 FULL TO THE ANGLE AND 46011 DISTRAINER 46090 FULL TO STRAINER 46090 FULL		
HOLD DOWN PIN	BACK PLATE	44020
EXTENSION LINK		
ANT-RATTLE PIN 44081  HAND BRAKE CONTROL LVR YOKE 44082  TOGGLE LEVER 44095  REAR WHEEL CYLINDER 44100  LEVER ASSY 44118  BISTON 8 SEAL 44120  REAR BAFFLE PLATE 44115  ANCHOR - PARKING BRAKE 44110  ADJUSTER ASSY 44200  MASTER CYLINDER 46010  OIL RESERVOIR CAP 46020  RESERVOIR CAP 46020  RESERVOIR CAP 46020  RESERVOIR CAP 46020  LEVEL INDICATOR 46048  PISTON ASSY 46063  LEVEL INDICATOR 46048  PISTON ASSY 46063  LEVEL INDICATOR 46048  PISTON ASSY 46063  LEVEL INDICATOR 46080  FLUID STRAIMER 46090  BRAKE PEDAL 80090  FLUID STRAIMER 46590  BRAKE PEDAL 80090  FLUID STRAIMER 46590  BRAKE PEDAL 80091  BRAKE PEDAL 80091  BRAKE FEDAL 80091  BRAKE BOOSTER 47210  BRAKE BOOSTER 47210  BRAKE BOOSTER 70091  BRACUM 10BE 47476	CALIPER BODY	44025
HAND BRAKE CONTROL LVR YOKE	CALIPER BODY HOLD DOWN PIN	44025 44040
REAR BRAKE RETURN SPRING 44080 TOGGLE LEVER 44095 TOGGLE LEVER 44109 TOGGLE LEVER 44100 LEVER ASSY 44118 PISTON & SEAL 41120 REAR BAFFLE PLATE 44151 ANCHOR - PARKING BRAKE 441180 ADJUSTER ASSY 44200 MASTER CYLINDER 46010 LRESERVOIR CAP 46020 RESERVOIR SEAL 46045 LEVEL INDICATOR 46045 SNAP RING 46082 SNAP RING 46082 SNAP RING 46082 SNAP RING 46082 CLEVIS PIN 46083 SNAP RING 46082 RESERVOIR SEAL 46093 CLEVIS PIN 46083 BRAKE PIPE 46284 COINDECTOR 46393 BRAKE PIPE 46284 COINDECTOR 46519 BRAKE MASTER CYLINDER BRACKET 46519 BRAKE PEDAL BUSHING 46529 BRAKE FEULCRUM SHAFT 46560 PEDAL SHIFT SLEEVE 46580 BRAKE FEDAL SUSHING 46585 BRAKE FEDAL SUSHING 46585 BRAKE BOOSTER SPACER 47210 BRAKE BOOSTER SPACER 47211 BRAKE BOOSTER CONNECTOR 47475 BRAKE BOOSTER CONNECTOR 47475 BRAKE BOOSTER CONNECTOR 47475 BRAKE BOOSTER CONNECTOR 47475	CALIPER BODY HOLD DOWN PIN EXTENSION LINK	44025 44040
REAR BRAKE RETURN SPRING 44080 TOGGLE LEVER 44095 TOGGLE LEVER 44109 TOGGLE LEVER 44100 LEVER ASSY 44118 PISTON & SEAL 41120 REAR BAFFLE PLATE 44151 ANCHOR - PARKING BRAKE 441180 ADJUSTER ASSY 44200 MASTER CYLINDER 46010 LRESERVOIR CAP 46020 RESERVOIR SEAL 46045 LEVEL INDICATOR 46045 SNAP RING 46082 SNAP RING 46082 SNAP RING 46082 SNAP RING 46082 CLEVIS PIN 46083 SNAP RING 46082 RESERVOIR SEAL 46093 CLEVIS PIN 46083 BRAKE PIPE 46284 COINDECTOR 46393 BRAKE PIPE 46284 COINDECTOR 46519 BRAKE MASTER CYLINDER BRACKET 46519 BRAKE PEDAL BUSHING 46529 BRAKE FEULCRUM SHAFT 46560 PEDAL SHIFT SLEEVE 46580 BRAKE FEDAL SUSHING 46585 BRAKE FEDAL SUSHING 46585 BRAKE BOOSTER SPACER 47210 BRAKE BOOSTER SPACER 47211 BRAKE BOOSTER CONNECTOR 47475 BRAKE BOOSTER CONNECTOR 47475 BRAKE BOOSTER CONNECTOR 47475 BRAKE BOOSTER CONNECTOR 47475	CALIPER BODY HOLD DOWN PIN EXTENSION LINK	44025 44040 44075
TOGGLE LEVER	CALIPER BODY HOLD DOWN PIN EXTENSION LINK ANTI-RATTLE PIN	44025 44040 44075 44081
REAR WHEEL CYLINDER 44100 LEVER ASSY 44118 PISTON & SEAL 44120 REAR BAFFLE PLATE 44151 ANCHOR: PARKING BRAKE 44100 ADJUSTER ASSY 44200 MASTER CYLINDER 46010 OIL RESERVOIR CAP 46020 MESSERVOIR CAP 46020 SESSERVOIR SEAL 46045 LEVEL INDICATOR 46048 PISTON ASSY 46063 SNAP RING 46082 FLUID RESERVOIR 46090 FLUID STRAINER 46090 F	CALIPER BODY HOLD DOWN PIN EXTENSION LINK ANTI-RATTLE PIN HAND BRAKE CONTROL LVR YOKE	44025 44040 44075 44081 44082
LEVER ASSY         44118           PISTON & SEAL         44120           PISTON & SEAL         44120           ANCHOR - PARKING BRAKE         44180           ADJUSTER ASSY         44200           MASTER CYLINDER         46010           OLI RESERVOIR CAP         46020           RESERVOIR SEAL         46045           LEVEL INDICATOR         46045           PISTON ASSY         46063           SNAP RING         46082           FLUID STRAINER         46093           CLEVIS PIN         46123           BRAKE PIPE         46284           CONNECTOR         46313           DPILOAD SENSING VALVE         46400           BRAKE MASTER CYLINDER BRACKET         46515           PEDAL STOPPER         46519           BRAKE PEDAL         46520           BRAKE PEDAL BUSHING         46520           BRAKE PEDAL BUSHING         46523           BRAKE FEUCRUM SHAFT         46560           PEDAL SHIFT SLEEVE         46560           BRAKE PEDAL SPRING         46585           BRAKE BOOSTER SPACER         47210           BRAKE BOOSTER SPACER         47210           BRAKE BOOSTER SPACER         47215	CALIPER BODY HOLD DOWN PIN EXTENSION LINK ANTI-RATTLE PIN HAND BRAKE CONTROL LVR YOKE REAR BRAKE RETURN SPRING	44025 44040 44075 44081 44082 44090
PISTON & SEAL	CALIPER BODY HOLD DOWN PIN EXTENSION LINK ANTI-RATTLE PIN HAND BRAKE CONTROL LVR YOKE REAR BRAKE RETURN SPRING TOGGLE LEVER	44025 44040 44075 44081 44082 44090 44095
PISTON & SEAL	CALIPER BODY HOLD DOWN PIN EXTENSION LINK ANTI-RATTLE PIN HAND BRAKE CONTROL LVR YOKE REAR BRAKE RETURN SPRING TOGGLE LEVER	44025 44040 44075 44081 44082 44090 44095
REAR BAFFLE PLATE 44151 ANCHOR - PARKING BRAKE 44180 ADJUSTER ASSY 44200 MASTER CYLINDER 46010 OIL RESERVOIR CAP 46020 RESERVOIR SEAL 46045 LEVEL INDICATOR 46048 PISTON ASSY 46063 SNAP RING 46092 FLUID STRAINER 46090 FLUID STRAINER 46090 FLUID STRAINER 46090 CLEVIS PIN 46123 BRAKE PIPE 46284 CONNECTOR 45313 DP/LOAD SENSING VALVE 46515 PEDAL STOPPER 46518 BRAKE PEDAL BUSHING 46525 BRAKE PEDAL 805116 BRAKE BOOSTER SPACER 47211 BRAKE BOOSTER PACER 47215 BRAKE BOOSTER PACER 47215 BRAKE BOOSTER SPACER 47215 BRAKE BOOSTER CONNECTOR 47475 VACUUM TUBE 47476	CALIPER BODY HOLD DOWN PIN EXTENSION LINK ANT-RATTLE PIN HAND BRAKE CONTROL LVR YOKE REAR BRAKE RETURN SPRING TOGGLE LEVER REAR WHEEL CYLINDER	44025 44040 44075 44081 44082 44090 44095 44100
ANCHOR PARKING BRAKE 44180 ADJUSTER ASSY 44200 ADJUSTER ASSY 44200 OIL RESERVOIR CAP 46010 OIL RESERVOIR CAP 46020 RESERVOIR SEAL 46045 EVEL INDICATOR 46048 PISTON ASSY 46063 SNAP RING 46082 FLUID RESERVOIR 46093 CLEVIS PIN 46123 BRAKE PIPE 46284 CONNECTOR 46313 DPILOAD SENSING VALVE 46400 BRAKE MASTER CYLINDER BRACKET 46515 PEDAL STOPPER 46519 BRAKE PEDAL BUSHING 46520 BRAKE PEDAL BUSHING 46520 BRAKE PEDAL BUSHING 46520 BRAKE PEDAL BUSHING 46520 BRAKE PEDAL SHAFT 46560 PEDAL SHIFT SLEEVE 46589 BRAKE PEDAL SPRING 46585 BRAKE BEDAL SPRING 46585 BRAKE BOOSTER 47210 BRAKE BOOSTER 47210 BRAKE BOOSTER 500NECTOR 47475 VACUUM TUBE 47476	CALIPER BODY HOLD DOWN PIN EXTENSION LINK ANTI-RATTLE PIN HAND BRAKE CONTROL LVR YOKE REAR BRAKE RETURN SPRING TOGGLE LEVER REAR WHEEL CYLINDER LEVER ASSY	44025 44040 44075 44081 44082 44090 44095 44100 44118
ADJUSTER ASSY 44200 MASTER CYLINDER 46010 LI RESERVOIR CAP 46020 RESERVOIR SEAL 46045 LEVEL INDICATOR 46088 SINAP RING 46082 SINAP RING 46082 SINAP RING 46082 FLUID RESERVOIR 46090 FLUID STRAINER 46093 FLUID STRAINER 46093 FLUID STRAINER 46093 BRAKE PIPE 46284 CONNICTOR 45313 BRAKE PIPE 46515 BRAKE PEDAL BUSHING 46515 PEDAL STOPPER 46518 BRAKE PEDAL BUSHING 46520 BRAKE FEDAL BUSHING 46525 BRAKE FULCRUM SHAFT 46560 PEDAL SHIFT SLEEVE 46580 BRAKE FEDAL BUSHING 46525 BRAKE FEDAL BUSHING 46525 BRAKE FEDAL BUSHING 46585 BRAKE FEDAL SHIPT 46586 BRAKE PEDAL BUSHING 46585 BRAKE FEDAL SPRING 46588 BRAKE BOOSTER SPACER 47210 BRAKE BOOSTER SPACER 47210 BRAKE BOOSTER SPACER 47215 BRAKE BOOSTER CONNECTOR 47475 VACUUM TUBE 47476	CALIPER BODY HOLD DOWN PIN EXTENSION LINK ANTI-RATTLE PIN HAND BRAKE CONTROL LVR YOKE REAR BRAKE RETURN SPRING TOGGLE LEVER REAR WHEEL CYLINDER LEVER ASSY PISTON & SEAL	44025 44040 44075 44081 44082 44090 44095 44100 44118 44120
MASTER CYLINDER	CALIPER BODY HOLD DOWN PIN EXTENSION LINK ANTI-RATTLE PIN HAND BRAKE CONTROL LVR YOKE REAR BRAKE RETURN SPRING TOGGLE LEVER REAR WHEEL CYLINDER LEVER ASSY PISTON & SEAL REAR BAFFLE PLATE	44025 44040 44075 44081 44082 44090 44095 44100 44118 44120 44151
ÖLL RESERVÖIR CAP         46020           RESERVÖIR SEAL         46045           LEVEL INDICATOR         46048           PISTON ASSY         46063           SNAP RING         46082           FLUID RESERVÖIR         46090           FLUID STRAINER         46092           CLEVIS PIN         46123           BRAKE PIPE         46284           CONNECTOR         46313           DP/LOAD SENSING VALVE         46400           BRAKE MASTER CYLINDER BRACKET         46519           PEDAL STOPPER         46519           BRAKE PEDAL         46520           BRAKE PEDAL BUSHING         46520           BRAKE PEDAL SHIFT SLEEVE         46580           BRAKE PEDAL SPRING         46580           BRAKE BOOSTER         47210           BRAKE BOOSTER SPACER         47210           BRAKE BOOSTER CONNECTOR         47475           VACUUM TUBE         41476	CALIPER BODY HOLD DOWN PIN EXTENSION LINK ANT-RATTLE PIN HAND BRAKE CONTROL LVR YOKE REAR BRAKE RETURN SPRING TOGGLE LEVER REAR WHEEL CYLINDER LEVER ASSY PISTON & SEAL REAR BAFFLE PLATE ANCHOR - PARKING BRAKE	44025 44040 44075 44081 44082 44090 44095 44100 44118 44120 44151 44180
ÖIL RESERVÖIR CAP         46020           RESERVÖIR SEAL         46045           LEVEL INDICATOR         46048           PISTON ASSY         46063           SNAP RING         46082           FLUID RESERVÖIR         46090           FLUID STRAIMER         46092           CLEVIS PIN         46123           BRAKE PIPE         46284           CONNECTOR         46313           DP/LOAD SENSING VALVE         46400           BRAKE MASTER CYLINDER BRACKET         46519           BRAKE MASTER CYLINDER BRACKET         46519           BRAKE PEDAL         46520           BRAKE PEDAL BUSHING         46520           BRAKE PEDAL BUSHING         46520           BRAKE PEDAL SHIFT SLEEVE         46580           BRAKE PEDAL SPRING         46580           BRAKE BOOSTER         47210           BRAKE BOOSTER SPAGER         47210           BRAKE BOOSTER CONNECTOR         47475           VACUUM TUBE         47476	CALIPER BODY HOLD DOWN PIN EXTENSION LINK ANTI-RATTLE PIN HAND BRAKE CONTROL LVR YOKE REAR BRAKE RETURN SPRING TOGGLE LEVER REAR WHEEL CYLINDER LEVER ASSY PISTON & SEAL REAR BAFFLE PLATE ANCHOR. PARKING BRAKE ADJUSTER ASSY	44025 44040 44075 44081 44082 44090 44095 44100 44118 44120 44151 44180
RESERVOIR SEAL  LEVEL INDICATOR  46042  FISTON ASSY  46063  SNAP RING  46082  FLUID RESERVOIR  46093  CLEVIS PIN  46093  CLEVIS PIN  46123  BRAKE PIPE  46284  CONNECTOR  46313  DPILOAD SENSING VALVE  46400  BRAKE MASTER CYLINDER BRACKET  46515  PEDAL STOPPER  46518  BRAKE PEDAL  BRAKE PEDAL  BRAKE FULCRUM SHAFT  46520  BRAKE FULCRUM SHAFT  46560  PEDAL SHIFT SLEVE  46580  BRAKE PEDAL SUSHING  46585  BRAKE BOOSTER SPACER  47210  BRAKE BOOSTER SPACER  47210  BRAKE BOOSTER SPACER  47415	CALIPER BODY HOLD DOWN PIN EXTENSION LINK ANTI-RATTLE PIN HAND BRAKE CONTROL LVR YOKE REAR BRAKE RETURN SPRING TOGGLE LEVER REAR WHEEL CYLINDER LEVER ASSY PISTON & SEAL REAR BAFFLE PLATE ANCHOR. PARKING BRAKE ADJUSTER ASSY	44025 44040 44075 44081 44082 44090 44095 44100 44118 44120 44151 44180 44200
LEVEL INDICATOR         46048           PISTON ASSY         46063           SNAP RING         46082           FLUID RESERVOIR         46090           FLUID STRAIMER         46092           CLEVIS PIN         46123           BRAKE PIPE         46284           CONNECTOR         45313           DP/LOAD SENSING VALVE         46400           BRAKE MASTER CYLINDER BRACKET         46519           PEDAL STOPPER         46518           BRAKE PEDAL         46520           BRAKE PEDAL BUSHING         46522           BRAKE FEDAL SHIFT SLEEVE         45580           BRAKE FEDAL SPRING         46588           BRAKE BOOSTER         47210           BRAKE BOOSTER SPACER         47211           BRAKE BOOSTER SPACER         47210           BRAKE BOOSTER CONNECTOR         47475           VACUUM TUBE         47476	CALIPER BODY HOLD DOWN PIN EXTENSION LINK ANTI-RATTLE PIN HAND BRAKE CONTROL LVR YOKE REAR BRAKE RETURN SPRING TOGGLE LEVER REAR WHEEL CYLINDER LEVER ASSY PISTON & SEAL REAR BAFFLE PLATE ANCHOR - PARKING BRAKE ADJUSTER ASSY MASTER CYLINDER	44025 44040 44075 44081 44082 44090 44090 44190 44118 44120 44151 44180 44200 46010
PISTON ASSY         46063           SNAP RING         46062           SNAP RING         46082           FLUID STRAINER         46093           CLEVIS PIN         46123           BRAKE PIPE         46284           CONNECTOR         46313           DP/LOAD SENSING VALVE         46400           BRAKE MASTER CYLINDER BRACKET         46519           PEDAL STOPPER         46519           BRAKE PEDAL         46520           BRAKE PEDAL BUSHING         46520           BRAKE PEDAL SHIFT SLEEVE         46580           BRAKE PEDAL SPRING         46580           BRAKE BOOSTER         47210           BRAKE BOOSTER SPACER         47210           BRAKE BOOSTER CONNECTOR         47475           VACUUM TUBE         41476	CALIPER BODY HOLD DOWN PIN EXTENSION LINK ANTI-RATTLE PIN HAND BRAKE CONTROL LVR YOKE REAR BRAKE RETURN SPRING TOGGLE LEVER REAR WHEEL CYLINDER LEVER ASSY PISTON & SEAL REAR BAFTLE PLATE ANCHOR - PARKING BRAKE ADJUSTER ASSY MASTER CYLINDER OIL RESERVOIR CAP	44025 44040 44075 44081 44082 44090 44095 44118 44120 44151 44180 44200 46010 46020
SNAP RING	CALIPER BODY HOLD DOWN PIN EXTENSION LINK ANTI-RATTLE PIN HAND BRAKE CONTROL LVR YOKE REAR BRAKE RETURN SPRING TOGGLE LEVER REAR WHEEL CYLINDER LEVER ASSY PISTON & SEAL REAR BAFFLE PLATE ANCHOR - PARKING BRAKE ADJUSTER ASSY MASTER CYLINDER UIL RESERVOIR CAP RESERVOIR CAP RESERVOIR SEAL	44025 44040 44075 44081 44082 44080 44095 44100 44118 44120 44151 44180 44200 46010 46020 46045
SNAP RING	CALIPER BODY HOLD DOWN PIN EXTENSION LINK ANTI-RATTLE PIN HAND BRAKE CONTROL LVR YOKE REAR BRAKE RETURN SPRING TOGGLE LEVER REAR WHEEL CYLINDER LEVER ASSY PISTON & SEAL REAR BAFFLE PLATE ANCHOR - PARKING BRAKE ADJUSTER ASSY MASTER CYLINDER OIL RESERVOIR CAP RESERVOIR CAP RESERVOIR SEAL LEVEL INDICATOR	44025 44040 44075 44081 44082 44090 44100 44118 44120 44151 44180 44200 46010 46020 46045 46048
FLUID RESERVOIR         46993           FLUID STRAINER         46993           CLEVIS PIN         46123           BRAKE PIPE         46284           CONNECTOR         45313           DPILOAD SENSING VALVE         46400           BRAKE MASTER CYLINDER BRACKET         46515           PEDAL STOPPER         46518           BRAKE PEDAL         46520           BRAKE PEDAL BUSHING         46520           BRAKE FEDAL SHIFT         46560           PEDAL SHIFT SLEEVE         46580           BRAKE PEDAL SPRING         46585           BRAKE BOOSTER SPACER         47210           BRAKE BOOSTER SPACER         47210           BRAKE BOOSTER CONNECTOR         47475           VACUUM TUBE         47476	CALIPER BODY HOLD DOWN PIN EXTENSION LINK ANTI-RATTLE PIN HAND BRAKE CONTROL LVR YOKE REAR BRAKE RETURN SPRING TOGGLE LEVER REAR WHEEL CYLINDER LEVER ASSY PISTON & SEAL REAR BAFFLE PLATE ANCHOR - PARKING BRAKE ADJUSTER ASSY MASTER CYLINDER OIL RESERVOIR CAP RESERVOIR CAP RESERVOIR SEAL LEVEL INDICATOR	44025 44040 44075 44081 44082 44090 44100 44118 44120 44151 44180 44200 46010 46020 46045 46048
FLUID STRAINER         46093           CLEVIS PIN         46123           BRAKE PIPE         46284           CONNICTOR         45313           DPILOAD SENSING VALVE         46400           BRAKE MASTER CYLINDER BRACKET         46518           PEDAL STOPPER         46518           BRAKE PEDAL         46520           BRAKE PEDAL BUSHING         46525           BRAKE PEDAL SHAFT         46560           BRAKE FULCRUM SHAFT         46580           BRAKE FULS SHING         46585           BRAKE BODASTER         47210           BRAKE BOOSTER SPACER         47210           BRAKE BOOSTER CONNECTOR         47475           VACUUM TUBE         47476	CALIPER BODY HOLD DOWN PIN EXTENSION LINK ANTI-RATTLE PIN HAND BRAKE CONTROL LVR YOKE REAR BRAKE RETURN SPRING TOGGLE LEVER REAR WHEEL CYLINDER LEVER ASSY PISTON & SEAL REAR BAFFLE PLATE ANCHOR . PARKING BRAKE ADJUSTER ASSY MASTER CYLINDER OIL RESERVOIR CAP RESERVOIR SEAL LEVEL INDICATOR PISTON & SEAL REAR BAFFLE PLATE ANCHOR . PARKING BRAKE ADJUSTER ASSY MASTER CYLINDER OIL RESERVOIR CAP RESERVOIR SEAL LEVEL INDICATOR PISTON ASSY	44025 44040 44075 44081 44082 44090 44095 44100 44118 44120 44151 44180 44200 46010 46040 46040 46048 46048 46063
CLEVIS PIN         46123           BRAKE PIPE         46284           CONNECTOR         46313           DPILOAD SENSING VALVE         46400           BRAKE MASTER CYLINDER BRACKET         46515           PEDAL STOPPER         46518           BRAKE PEDAL         46520           BRAKE PEDAL BUSHING         46525           BRAKE PEDAL SHAFT         46560           PEDAL SHIFT SLEEVE         46580           BRAKE PEDAL SPRING         46585           BRAKE BOOSTER         47210           BRAKE BOOSTER SPACER         47210           BRAKE BOOSTER CONNECTOR         47475           VACUUM TUBE         47476	CALIPER BODY HOLD DOWN PIN EXTENSION LINK ANT-RATTLE PIN HAND BRAKE CONTROL LVR YOKE REAR BRAKE RETURN SPRING TOGGLE LEVER REAR WHEEL CYLINDER LEVER ASSY PISTON & SEAL REAR BAFTLE PLATE ANCHOR - PARKING BRAKE ADJUSTER ASSY MASTER CYLINDER LEVEL INDICATOR RESERVOIR CAP RESERVOIR CAP RESERVOIR SEAL LEVEL INDICATOR PISTON ASSY SNAP RING	44025 44040 44075 44081 44082 44080 44095 44100 44118 44120 44151 44180 44200 46010 46045 46045 46063 46063
BRAKE PIPE         46284           CONNIECTOR         45313           DPILOAD SENSING VALVE         46400           BRAKE MASTER CYLINDER BRACKET         46515           PEDAL STOPPER         46518           BRAKE PEDAL         46520           BRAKE PEDAL BUSHING         46523           BRAKE FULCRUM SHAFT         46560           PEDAL SHIFT SLEEVE         46580           PEDAL SHIFT SLEEVE         46580           BRAKE BOOSTER         47210           BRAKE BOOSTER SPACER         47211           BRAKE BOOSTER SPACER         47211           BRAKE BOOSTER SPACER         47210           BRAKE BOOSTER SPACER         47210           BRAKE BOOSTER SPACER         47210           BRAKE BOOSTER CONNECTOR         47475           VACUUM TUBE         47476	CALIPER BODY HOLD DOWN PIN EXTENSION LINK ANTI-RATTLE PIN HAND BRAKE CONTROL LVR YOKE REAR BRAKE RETURN SPRING TOGGLE LEVER REAR WHEEL CYLINDER LEVER ASSY PISTON & SEAL REAR BAFFLE PLATE ANCHOR - PARKING BRAKE ADJUSTER ASSY MASTER CYLINDER OL RESERVOIR CAP RESERVOIR CAP RESERVOIR SEAL LEVEL INDICATOR PISTON ASSY SNAP RING SHAP RING FLUID RESERVOIR FLUID RESERVOIR FLUID RESERVOIR	44025 44040 44075 44081 44082 44090 44095 44118 44120 44151 44180 44160 46010 46020 46045 46048 46048 46062 46090
CONNECTOR         46313           DPILOAD SENSING VALVE         46400           BRAKE MASTER CYLINDER BRACKET         46515           PEDAL STOPPER         46518           BRAKE PEDAL         46520           BRAKE PEDAL BUSHING         46520           BRAKE FÜLCRUM SHAFT         46560           PEDAL SHIFT SLEEVE         46580           BRAKE PEDAL SPRING         46580           BRAKE BOOSTER         47210           BRAKE BOOSTER SPACER         47211           BRAKE BOOSTER CONNECTOR         47475           VACUUM TUBE         47476	CALIPER BODY HOLD DOWN PIN EXTENSION LINK ANTI-RATTLE PIN HAND BRAKE CONTROL LVR YOKE REAR BRAKE RETURN SPRING TOGGLE LEVER REAR WHEEL CYLINDER LEVER ASSY PISTON & SEAL REAR BAFFLE PLATE ANCHOR - PARKING BRAKE ADJUSTER ASSY MASTER CYLINDER OIL RESERVOIR CAP RESERVOIR SEAL LEVEL INDICATOR PISTON ASSY SNAP RING FILID RESERVOIR	44025 44040 44075 44081 44082 44082 44090 44190 44118 44120 44118 44120 44151 44180 44200 46010 46020 46048 46063 46082 46082 46093
CONNECTOR         46313           DPILOAD SENSING VALVE         46400           BRAKE MASTER CYLINDER BRACKET         46515           PEDAL STOPPER         46518           BRAKE PEDAL BUSHING         46520           BRAKE PEDAL BUSHING         46520           BRAKE FÜLCRUM SHAFT         46560           PEDAL SHIFT SLEEVE         46580           BRAKE PEDAL SPRING         46585           BRAKE BOOSTER         47210           BRAKE BOOSTER SPACER         47211           BRAKE BOOSTER CONNECTOR         47475           VACUUM TUBE         47476	CALIPER BODY HOLD DOWN PIN EXTENSION LINK ANTI-RATTLE PIN HAND BRAKE CONTROL LVR YOKE REAR BRAKE RETURN SPRING TOGGLE LEVER REAR WHEEL CYLINDER LEVER ASSY PISTON & SEAL REAR BAFTLE PLATE ANCHOR - PARKING BRAKE ADJUSTER ASSY OIL RESERVOIR CAP RESERVOIR SEAL LEVEL INDICATOR PISTON ASSY SNAP RING FLUID RESERVOIR FLUID STRAINER CLEVIS PIN	44025 44040 44075 44081 44082 44090 44095 44118 44118 44118 44120 44151 44180 44200 46010 46020 46048 46048 46063 46082 46090 46093 46093 46123
DP/LOAD SENSING VALVE         46400           BRAKE MASTER CYLINDER BRACKET         46518           PEDAL STOPPER         46518           BRAKE PEDAL         46520           BRAKE PEDAL BUSHING         46520           BRAKE PEDAL SHAFT         46560           BRAKE FULCRUM SHAFT         46580           BRAKE FEDAL SPRING         46580           BRAKE PEDAL SPRING         46585           BRAKE BOOSTER         47210           BRAKE BOOSTER SPACER         47210           BRAKE BOOSTER CONNECTOR         47475           VACUUM TUBE         47476	CALIPER BODY HOLD DOWN PIN EXTENSION LINK ANTI-RATTLE PIN HAND BRAKE CONTROL LVR YOKE REAR BRAKE RETURN SPRING TOGGLE LEVER REAR WHEEL CYLINDER LEVER ASSY PISTON & SEAL REAR BAFTLE PLATE ANCHOR - PARKING BRAKE ADJUSTER ASSY OIL RESERVOIR CAP RESERVOIR SEAL LEVEL INDICATOR PISTON ASSY SNAP RING FLUID RESERVOIR FLUID STRAINER CLEVIS PIN	44025 44040 44075 44081 44082 44090 44095 44118 44118 44119 44151 44151 44160 46010 46020 46010 46048 46063 46063 46082 46090 46000 46000 46000 46000 46000 46000 46000
BRAKE MASTER CYLINDER BRACKET         46519           PEDAL STOPPER         46519           BRAKE PEDAL         46520           BRAKE PEDAL BUSHING         46525           BRAKE FULCRUM SHAFT         46560           PEDAL SHIFT SLEEVE         46580           BRAKE PEDAL SPRING         46585           BRAKE BOOSTER         47210           BRAKE BOOSTER SPACER         47211           BRAKE BOOSTER SPACER         47210           BRAKE BOOSTER CONNECTOR         47475           VACUUM TUBE         47476	CALIPER BODY HOLD DOWN PIN EXTENSION LINK ANTI-RATTLE PIN HAND BRAKE CONTROL LVR YOKE REAR BRAKE RETURN SPRING TOGGLE LEVER REAR WHEEL CYLINDER LEVER ASSY PISTON & SEAL REAR BAFFLE PLATE ANCHOR - PARKING BRAKE ADJUSTER ASSY MASTER CYLINDER OIL RESERVOIR CAP RESERVOIR SEAL LEVEL INDICATOR PISTON ASSY SNAP RING FLUID STRAINER CLEVIS PIN ESTRAINER CLEVIS PIN BRAKE PIPE	44025 44040 44075 44080 44080 44080 44090 44190 44118 44120 44119 44120 44151 44151 44160 46010 46010 46045 46048 46062 46090 46093 46093 46083 46123 46284
PEDAL STOPPER         46518           BRAKE PEDAL         46520           BRAKE PEDAL BUSHING         46525           BRAKE FEDAL BUSHING         46560           PEDAL SHIFT SLEEVE         46580           BRAKE PEDAL SPRING         46585           BRAKE BOOSTER         47210           BRAKE BOOSTER SPACER         47211           BRAKE BOOSTER SPACER         47211           BRAKE BOOSTER SPACER         47210           BRAKE BOOSTER SPACER         47210           BRAKE BOOSTER SPACER         47210           WACUUM TUBE         47476	CALIPER BODY HOLD DOWN PIN EXTENSION LINK ANTI-RATTLE PIN HAND BRAKE CONTROL LVR YOKE REAR BRAKE RETURN SPRING TOGGLE LEVER REAR WHEEL CYLINDER LEVER ASSY PISTON & SEAL REAR BAFFLE PLATE ANCHOR - PARKING BRAKE ADJUSTER ASSY MASTER CYLINDER OIL RESERVOIR CAP RESERVOIR CAP RESERVOIR SEAL LEVEL INDICATOR PISTON ASSY SNAP RING FLUID RESERVOIR FLUID STRAINER CLEVIS PIN BRAKE PIPE CONNECTOR	44025 44040 44075 44082 44082 44082 44100 44118 44120 44116 44120 44151 44180 46010 46010 46020 46048 46063 46063 46082 46093 46093 46093 46123 46284 46333
BRAKE PEDAL         46520           BRAKE PEDAL BUSHING         45525           BRAKE FULCRUM SHAFT         46560           PEDAL SHIFT SLEEVE         46580           BRAKE PEDAL SPRING         46585           BRAKE BOOSTER         47210           BRAKE BOOSTER SPACER         47211           BRAKE BOOSTER CONNECTOR         47475           VACUUM TUBE         47476	CALIPER BODY HOLD DOWN PIN EXTENSION LINK ANTI-RATTLE PIN HAND BRAKE CONTROL LVR YOKE REAR BRAKE RETURN SPRING TOGGLE LEVER REAR WHEEL CYLINDER LEVER ASSY PISTON & SEAL REAR BAFFLE PLATE ANCHOR PARKING BRAKE ADJUSTER ASSY MASTER CYLINDER OIL RESERVOIR CAP RESERVOIR SEAL LEVEL INDICATOR PISTON ASSY SNAP RING FILIO RESERVOIR FILIO RESERVOIR FILIO STRAIMER CLEVIS PIN BRAKE PIPE CONNECTOR DP/LOAD SENSING VALVE	44025 44040 44075 44081 44082 44080 44080 44180 44118 44118 44120 44151 44180 44200 46045 46045 46063 46063 46082 46083 46084 46083 46083 46083 46083 46083 46084 46083 46083 46083 46083 46084
BRAKE PEDAL         46520           BRAKE PEDAL BUSHING         45525           BRAKE FULCRUM SHAFT         46560           PEDAL SHIFT SLEEVE         46580           BRAKE PEDAL SPRING         46585           BRAKE BOOSTER         47210           BRAKE BOOSTER SPACER         47211           BRAKE BOOSTER CONNECTOR         47475           VACUUM TUBE         47476	CALIPER BODY HOLD DOWN PIN EXTENSION LINK ANTI-RATTLE PIN HAND BRAKE CONTROL LVR YOKE REAR BRAKE RETURN SPRING TOGGLE LEVER REAR WHEEL CYLINDER LEVER ASSY PISTON & SEAL REAR BAFFLE PLATE ANCHOR. PARKING BRAKE ADJUSTER ASSY MASTER CYLINDER OIL RESERVOIR CAP RESERVOIR CAP RESTROIR SEAL LEVEL INDICATOR PISTON ASSY SNAP RING FLUID STRAINER CLEVIS PIN BRAKE PIPE CONNECTOR DPILOAD SENSING VALVE BRAKE MASTER CYLINDER BRACKET	44025 44040 44075 44081 44082 44095 44100 44100 44118 44118 44120 46010 46010 46045 46063 46063 46063 46093 46093 46123 46123 46284 46313 46284 46313 46284 46313
BRAKE PEDAL BUSHING         46525           BRAKE FULCRUM SHAFT         46560           BRAKE FULCRUM SHAFT         46580           BERAKE PEDAL SPRING         46585           BRAKE BOOSTER         47210           BRAKE BOOSTER SPACER         47211           BRAKE BOOSTER SPACER         47211           BRAKE BOOSTER CONNECTOR         47475           VACUUM TUBE         47476	CALIPER BODY HOLD DOWN PIN EXTENSION LINK ANTI-RATTLE PIN HAND BRAKE CONTROL LVR YOKE REAR BRAKE RETURN SPRING TOGGLE LEVER REAR WHEEL CYLINDER LEVER ASSY PISTON & SEAL REAR BAFFLE PLATE ANCHOR. PARKING BRAKE ADJUSTER ASSY MASTER CYLINDER OIL RESERVOIR CAP RESERVOIR CAP RESTROIR SEAL LEVEL INDICATOR PISTON ASSY SNAP RING FLUID STRAINER CLEVIS PIN BRAKE PIPE CONNECTOR DPILOAD SENSING VALVE BRAKE MASTER CYLINDER BRACKET	44025 44040 44075 44081 44082 44095 44100 44100 44118 44118 44120 46010 46010 46045 46063 46063 46063 46093 46093 46123 46123 46284 46313 46284 46313 46284 46313
BRAKE FULCRUM SHAFT         45500           PEDAL SHIFT SLEEVE         46580           BRAKE PEDAL SPRING         46585           BRAKE BOOSTER         47210           BRAKE BOOSTER SPACER         47211           BRAKE BOOSTER SPACER         47211           VACUUM TUBE         47475	CALIPER BODY HOLD DOWN PIN EXTENSION LINK ANTI-RATTLE PIN HAND BRAKE CONTROL LVR YOKE REAR BRAKE RETURN SPRING TOGGLE LEVER REAR WHEEL CYLINDER LEVER ASSY PISTON & SEAL REAR BAFFLE PLATE ANCHOR - PARKING BRAKE ADJUSTER ASSY MASTER CYLINDER OIL RESERVOIR CAP RESERVOIR SEAL LEVEL INDICATOR PISTON ASSY SNAP RING FLUID STRAINER CLEVIS PIN BRAKE RIPE CONNECTOR DPILODA SENSING VALVE BRAKE MASTER CYLINDER BRACKET PEDAL STOPPER	44025 44040 44075 44081 44082 44082 44109 44100 44110 44110 44151 44110 44100 46010 46020 46010 46040 46040 46083 46083 46083 46083 46184 46313 46400 46518
PEDAL SHIFT SLEEVE         46580           BRAKE PEDAL SPRING         46585           BRAKE BOOSTER         47210           BRAKE BOOSTER SPACER         47211           BRAKE BOOSTER CONNECTOR         47475           VACUUM TUBE         47476	CALIPER BODY HOLD DOWN PIN EXTENSION LINK ANTI-RATTLE PIN HAND BRAKE CONTROL LVR YOKE REAR BRAKE RETURN SPRING TOGGLE LEVER REAR WHEEL CYLINDER LEVER ASSY PISTON & SEAL REAR BAFFLE PLATE ANCHOR - PARKING BRAKE ADJUSTER ASSY MASTER CYLINDER OIL RESERVOIR CAP RESERVOIR CAP RESERVOIR SEAL LEVEL INDICATOR PISTON ASSY MASTER CYLINDER OIL RESERVOIR FLUID CATOR PISTON ASSY SNAP RING FLUID RESERVOIR FLUID STRAINER CLEVIS PIN BRAKE PIPE CONNECTOR DP/LOAD SENSING VALVE BRAKE MASTER CYLINDER BRACKET PEDAL STOPPER BRAKE PEDAL	44025 44040 44075 44081 44082 44095 44100 44118 44120 44151 44110 44151 44110 46010 46010 46045 46063 46063 46063 46063 46082 46093 46123 4623 46313 46400 46515 46516
BRAKE PEDAL SPRING         46585           BRAKE BOOSTER         47210           BRAKE BOOSTER SPACER         47211           BRAKE BOOSTER CONNECTOR         47475           VACUUM TUBE         47476	CALIPER BODY HOLD DOWN PIN EXTENSION LINK ANTI-RATTLE PIN HAND BRAKE CONTROL LVR YOKE REAR BRAKE RETURN SPRING TOGGLE LEVER REAR WHEEL CYLINDER LEVER ASSY PISTON & SEAL REAR BAFFLE PLATE ANCHOR PARKING BRAKE ADJUSTER ASSY MASTER CYLINDER LEVEL HOLDCATOR PISTON ASSY SNAP RING FLUID STRAINER FLUID STRAINER FLUID STRAINER CLEVIS PIN BRAKE PIPE CONNECTOR BRAKE MASTER CYLINDER BRACKET PEDAL STOPPER BRAKE MASTER CYLINDER BRACKET PEDAL STOPPER BRAKE MASTER CYLINDER BRACKET PEDAL BRAKE PED	44025 440405 44075 44081 44082 44095 44109 44110 44110 44110 44110 44110 44110 44110 44110 44110 44110 44110 46010 46010 46040 46040 46040 46040 46090 46093 46093 46123 46123 46123 46120 46120 46110
BRAKE BOOSTER         47210           BRAKE BOOSTER SPACER         47211           BRAKE BOOSTER CONNECTOR         47475           VACUUM TUBE         47476	CALIPER BODY HOLD DOWN PIN EXTENSION LINK ANTI-RATTLE PIN HAND BRAKE CONTROL LVR YOKE REAR BRAKE RETURN SPRING TOGGLE LEVER REAR WHEEL CYLINDER LEVER ASSY PISTON & SEAL REAR BAFFLE PLATE ANCHOR - PARKING BRAKE ADJUSTER ASSY MASTER CYLINDER OL RESERVOIR CAP RESERVOIR CAP RESERVOIR SEAL LEVEL INDICATOR PISTON ASSY MASTER CYLINDER CLEVIS PIN BRAKE PIPE CONNECTOR DP/LOAD SENSING VALVE BRAKE PIPE CONNECTOR DP/LOAD SENSING VALVE PEDAL STOPPER BRAKE PEDAL BRAKE PEDAL BRAKE FEDAL BRAKE FULCRUM SHAFT	44025 44040 44075 44081 44082 44089 44095 44100 44118 44120 44151 44180 46010 46020 46010 46020 46063
BRAKE BOOSTER         47210           BRAKE BOOSTER SPACER         47211           BRAKE BOOSTER CONNECTOR         47475           VACUUM TUBE         47476	CALIPER BODY HOLD DOWN PIN EXTENSION LINK ANTI-RATTLE PIN HAND BRAKE CONTROL LVR YOKE REAR BRAKE RETURN SPRING TOGGLE LEVER REAR WHEEL CYLINDER LEVER ASSY PISTON & SEAL REAR BAFFLE PLATE ANCHOR - PARKING BRAKE ADJUSTER ASSY MASTER CYLINDER OIL RESERVOIR CAP RESERVOIR SEAL LEVEL INDICATOR PISTON ASSY SNAP RING FLUID RESERVOIR FLUID STRAINER CLEVIS PIN BRAKE PIPE CONNECTOR DPILOAD SENSING VALVE BRAKE MASTER CYLINDER BRACKET PEDAL STOPPER BRAKE PIPE CONNECTOR DPILOAD SENSING VALVE BRAKE MASTER CYLINDER BRACKET PEDAL STOPPER BRAKE PEDAL BUSHING BRAKE PEDAL BUSHING BRAKE FULCRUM SHAFT PEDAL STOPPER BRAKE PEDAL BUSHING BRAKE FULCRUM SHAFT	44025 44040 44075 44081 44082 44080 44085 44100 441180 441180 441181 44180 44160 46010 46010 46020 46048 46063 46063 46082 46093 46123 46123 46123 46284 46313 46400 46518 46520 46520 46520 46580
BRAKE BOOSTER SPACER         47211           BRAKE BOOSTER CONNECTOR         47475           VACUUM TUBE         47476	CALIPER BODY HOLD DOWN PIN EXTENSION LINK ANTI-RATTLE PIN HAND BRAKE CONTROL LVR YOKE REAR BRAKE RETURN SPRING TOGGLE LEVER REAR WHEEL CYLINDER LEVER ASSY PISTON & SEAL REAR BAFFLE PLATE ANCHOR - PARKING BRAKE ADJUSTER ASSY MASTER CYLINDER OIL RESERVOIR CAP RESERVOIR SEAL LEVEL INDICATOR PISTON ASSY SNAP RING FLUID RESERVOIR FLUID STRAINER CLEVIS PIN BRAKE PIPE CONNECTOR DPILOAD SENSING VALVE BRAKE MASTER CYLINDER BRACKET PEDAL STOPPER BRAKE PIPE CONNECTOR DPILOAD SENSING VALVE BRAKE MASTER CYLINDER BRACKET PEDAL STOPPER BRAKE PEDAL BUSHING BRAKE PEDAL BUSHING BRAKE FULCRUM SHAFT PEDAL STOPPER BRAKE PEDAL BUSHING BRAKE FULCRUM SHAFT	44025 44040 44075 44081 44082 44080 44085 44100 441180 441180 441181 44180 44160 46010 46010 46020 46048 46063 46063 46082 46093 46123 46123 46123 46284 46313 46400 46518 46520 46520 46520 46580
BRAKE BOOSTER CONNECTOR 47475 VACUUM TUBE 47476	CALIPER BODY HOLD DOWN PIN EXTENSION LINK ANTI-RATTLE PIN HAND BRAKE CONTROL LVR YOKE REAR BRAKE RETURN SPRING TOGGLE LEVER REAR WHEEL CYLINDER LEVER ASSY PISTON & SEAL REAR BAFFLE PLATE ANCHOR. PARKING BRAKE ADJUSTER ASSY MASTER CYLINDER OIL RESERVOIR CAP RESERVOIR SEAL LEVEL INDICATOR PISTON ASSY SNAP RING FLUID STRAINER CLEVIS PIN BRAKE PIPE CONNECTOR DPLICAD SENSING VALVE BRAKE MASTER CYLINDER BRACKET PEDAL STOPPER BRAKE PEDAL BRAKE FULCRUM SHAFT PEDAL SHIFT SLEEVE BRAKE PEDAL SHIRG	44025 440405 44075 44081 44082 44095 44100 44195 44118 44118 44118 44119 44200 46020 46020 46020 46090
VACUUM TUBE 47476	CALIPER BODY HOLD DOWN PIN EXTENSION LINK ANTI-RATTLE PIN HAND BRAKE CONTROL LVR YOKE REAR BRAKE RETURN SPRING TOGGLE LEVER REAR WHEEL CYLINDER LEVER ASSY PISTON & SEAL REAR BAFFLE PLATE ANCHOR - PARKING BRAKE ADJUSTER ASSY MASTER CYLINDER OL RESERVOIR CAP RESERVOIR CAP RESERVOIR CAP RESERVOIR SEAL LEVEL INDICATOR PISTON ASSY SNAP RING FLUID RESERVOIR FLUID STRAINER CLEVIS PIN BRAKE PIPE CONNECTOR DP/LOAD SENSING VALVE BRAKE PEDAL BRAKE FULCRUM SHAFT PEDAL SHIFT SLEEVE BRAKE BLUCRUM SHAFT PEDAL SHIFT SLEEVE BRAKE PEDAL BUSHING BRAKE FULCRUM SHAFT PEDAL SHIFT SLEEVE BRAKE PEDAL BUSHING BRAKE FULCRUM SHAFT PEDAL SHIFT SLEEVE BRAKE PEDAL BUSHING BRAKE FULCRUM SHAFT PEDAL SPRING BRAKE PEDAL BUSHING BRAKE PEDAL SPRING	44025 44040 44075 44081 44082 44089 44095 44100 441180 44120 44151 44180 44200 46010 46020 46030 46063 46063 46093 46093 46093 46593 46515 46516 46520 46520 46580
	CALIPER BODY HOLD DOWN PIN EXTENSION LINK ANTI-RATTLE PIN HAND BRAKE CONTROL LVR YOKE REAR BRAKE RETURN SPRING TOGGLE LEVER REAR WHEEL CYLINDER LEVER ASSY PISTON & SEAL REAR BAFFLE PLATE ANCHOR - PARKING BRAKE ADJUSTER ASSY MASTER CYLINDER OIL RESERVOIR CAP RESERVOIR CAP RESERVOIR SEAL LEVEL INDICATOR PISTON ASSY SNAP RING FLUID RESERVOIR FLUID STRAINER CLEVIS PIN BRAKE PIPE CONNECTOR DPILOAD SENSING VALVE BRAKE MESTER CYLINDER BRACKET PEDAL STOPPER BRAKE PEDAL BRAKE PEDAL BRAKE PEDAL BRAKE PEDAL BRAKE PEDAL SHIFT SLEEVE BRAKE PEDAL SHING BRAKE PEDAL SHING BRAKE PEDAL SHING BRAKE PEDAL SHING BRAKE PEDAL SPRING	44025 44040 44075 44082 44082 44080 44082 44190 44119 44119 44119 44119 44119 44119 44119 46010 46020 46010 46020 46043 46083
	CALIPER BODY HOLD DOWN PIN EXTENSION LINK ANTI-RATTLE PIN HAND BRAKE CONTROL LVR YOKE REAR BRAKE RETURN SPRING TOGGLE LEVER REAR WHEEL CYLINDER LEVER ASSY PISTON & SEAL REAR BAFFLE PLATE ANCHOR - PARKING BRAKE ADJUSTER ASSY MASTER CYLINDER OIL RESERVOIR CAP RESERVOIR SEAL LEVEL INDICATOR PISTON ASSY SNAP RING FLUID RESERVOIR FLUID STRAINER CLEVIS PIN BRAKE PIPE CONNECTOR DP/LOAD SENSING VALVE BRAKE MASTER CYLINDER BRACKET PEDAL STOPPER BRAKE PEDAL BRAKE BOOSTER BRAKE BOOSTER BRAKE BRAKE BRAKE BRAKE BOOSTER BRAKE BRAKE BRAKE BRAKE BOOSTER BRAKE BOOSTER BRAKE BOOSTER BRAKE BOOSTER BRAKE BOOSTER BRAKE BOOSTER	44025 44040 44075 44081 44082 44082 44085 44100 44118 44120 44151 44120 44151 44180 46010 46020 46045 46063 46082 46082 46083
	CALIPER BODY HOLD DOWN PIN EXTENSION LINK ANTI-RATTLE PIN HAND BRAKE CONTROL LVR YOKE REAR BRAKE RETURN SPRING TOGGLE LEVER REAR WHEEL CYLINDER LEVER ASSY PISTON & SEAL REAR BAFFLE PLATE ANCHOR - PARKING BRAKE ADJUSTER ASSY MASTER CYLINDER OIL RESERVOIR CAP RESERVOIR SEAL LEVEL INDICATOR PISTON ASSY SNAP RING FLUID RESERVOIR FLUID STRAINER CLEVIS PIN BRAKE PIPE CONNECTOR DP/LOAD SENSING VALVE BRAKE MASTER CYLINDER BRACKET PEDAL STOPPER BRAKE PEDAL BRAKE BOOSTER BRAKE BOOSTER BRAKE BRAKE BRAKE BRAKE BOOSTER BRAKE BRAKE BRAKE BRAKE BOOSTER BRAKE BOOSTER BRAKE BOOSTER BRAKE BOOSTER BRAKE BOOSTER BRAKE BOOSTER	44025 44040 44075 44081 44082 44082 44085 44100 44118 44120 44151 44120 44151 44180 46010 46020 46045 46063 46082 46082 46083

COMPONENT	P.M.C
ACTIVATOR ASSY	47600
ABS ACTUATOR RELAY	47605
MODULE ASSY	47850
SENSOR ASSY (RR) ANTI-SKID	47900
SENSOR ASSY (FR) ANTI-SKID	47910
ANTI-SKID SPLASH GUARD	47935
ROTOR ASSY (RR) SENSOR	47950
FRONT SENSOR BRACKET	47960
ROTOR ASSY (FR) SENSOR	47970

# FEGRECAL

BODY CLUTTRICKS

ASCD O.D. CANCEL SWITCH	18930
MAIN HARNESS	24010
ENGINE HARNESS	24012
INSTRUMENT HARNESS	24013
BODY HARNESS	24014
TAIL HARNESS	24015
CHASSIS HARNESS	24016
CONSOLE HARNESS	24030
ENGINE SUB-HARNESS	24077
TAIL GATE HARNESS	24145
	24160
ROOM LAMP HARNESS	
FUSIBLE LINK	24161
AIR BAG HARNESS	24170
DOOR HARNESS	24239
REAR WINDOW DEFROSTER	24320
DEFROSTER WIRING	24328
CIRCUIT BREAKER	24330
VOLT METER	24822
DIGITAL TEMP METER ASSY	24835
GAUGE ASSEMBLY	24840
SPEEDOMETER	24850
TACHOMETER	24855
FUEL GAUGE	24860
OIL PRESSURE GAUGE	24870
ODOMETER/TRIP METER	24875
COOLANT TEMP GAUGE	24880
HEAD-UP DISPLAY UNIT	24941
SECURITY INDICATOR LAMP	25021
PRINTED CIRCUIT	25030
WARNING DISPLAY	25041
WARNING DISPLAT	
SPEEDOMETER CABLE	25050
WARNING DISPLAY AMPLIFIER	25065
TAIL GATE SWITCH	25141
LIGHTING/COMBO SWITCH	25160
RETRACTABLE HEADLAMP SWITCH	25195
RELAY-TAIL GATE RELEASE	25202
LICADI AMD DELAY	
HEADLAMP RELAY	25203
REAR DEFROST RELAY	25204
REAR DEFROST RELAY HORN RELAY	25204 25205
REAR DEFROST RELAY	25204
REAR DEFROST RELAY HORN RELAY INSTRUMENT PANEL SWITCH	25204 25205 25210
REAR DEFROST RELAY HORN RELAY INSTRUMENT PANEL SWITCH IGNITION RELAY	25204 25205 25210 25215
REAR DEFROST RELAY HORN RELAY INSTRUMENT PANEL SWITCH IGNITION RELAY INHIBITOR RELAY	25204 25205 25210 25215 25216
REAR DEFROST RELAY HORN RELAY INSTRUMENT PANEL SWITCH IGNITION RELAY INHIBITOR RELAY RELAY—AUTO LAMP	25204 25205 25210 25215 25216 25219
REAR DEFROST RELAY HORN RELAY INSTRUMENT PANEL SWITCH IGNITION RELAY INHIBITOR RELAY RELAY—AUTO LAMP HEADLAMP DIMMER RELAY	25204 25205 25210 25215 25216 25219 25228
REAR DEFROST RELAY HORN RELAY HORN RELAY INSTRUMENT PANEL SWITCH IGNITION RELAY INHIBITOR RELAY RELAY—AUTO LAMP HADALANP DIMMER RELAY RELAY—FOG LAMP	25204 25205 25210 25215 25216 25219 25228 25229
REAR DEFROST RELAY HORN RELAY INSTRUMENT PANEL SWITCH IGNITION RELAY INHIBITOR RELAY RELAY—AUTO LAMP HEADLAMP DIMMER RELAY	25204 25205 25210 25215 25216 25219 25228
REAR DEFROST RELAY HORN RELAY HORN RELAY INSTRUMENT PANEL SWITCH IGNITION RELAY INHIBITOR RELAY RELAY—AUTO LAMP HADALANP DIMMER RELAY RELAY—FOG LAMP	25204 25205 25210 25215 25216 25219 25228 25229
REAR DEFROST RELAY HORN RELAY INSTRUMENT PANEL SWITCH IGNITION RELAY INHIBITOR RELAY RELAY—AUTO LAMP HEADLAMP DIMMER RELAY RELAY—FOG LAMP RELAY—FOG LAMP RELAY—REAR WIPER	25204 25205 25210 25215 25216 25219 25228 25229 25234 25236
REAR DEFROST RELAY HORN RELAY HORN RELAY INSTRUMENT PANEL SWITCH IGNITION RELAY INHIBITOR RELAY RELAY—AUTO LAMP HEADLAMP DIMMER RELAY RELAY—FOG LAMP ASCD RELAY RELAY—REAR WIPER STARTER RELAY	25204 25205 25210 25215 25216 25219 25228 25229 25234 25236 25243
REAR DEFROST RELAY HORN RELAY HORN RELAY INSTRUMENT PANEL SWITCH IGNITION RELAY INHIBITOR RELAY RELAY—AUTO LAMP HEADLAMP DIMMER RELAY RELAY—FOG LAMP ASCD RELAY RELAY—REAR WIPER STARTER RELAY ASCD VACUUM PUMP RELAY	25204 25205 25210 25215 25216 25219 25228 25229 25234 25236 25243 25243
REAR DEFROST RELAY HORN RELAY INSTRUMENT PANEL SWITCH IGNITION RELAY INHIBITOR RELAY RELAY—AUTO LAMP HEADLAMP DIMMER RELAY RELAY—FOG LAMP ASCD RELAY RELAY—REAR WIPER STARTER RELAY ASCD VELAY RELAY—REAR WIPER STARTER RELAY INTERLOCK EMERGENCY RELAY INTERLOCK EMERGENCY RELAY	25204 25205 25210 25215 25216 25219 25228 25229 25234 25236 25243 25245 25250
REAR DEFROST RELAY HORN RELAY INSTRUMENT PANEL SWITCH IGNITION RELAY INHIBITOR RELAY RELAY—AUTO LAMP HEADLAMP DIMMER RELAY RELAY—FOG LAMP ASCD RELAY RELAY—FOG LAMP STANDER RELAY RELAY—REAR WIPER STARTER RELAY ASCD VACUUM PUMP RELAY INTERLOCK EMERGENCY RELAY POWER WINDOW RELAY	25204 25205 25210 25215 25216 25219 25228 25229 25234 25236 25243 25245 25250 25252
REAR DEFROST RELAY HORN RELAY HORN RELAY INSTRUMENT PANEL SWITCH IGNITION RELAY INHIBITOR RELAY RELAY—AUTO LAMP HEADLAMP DIMMER RELAY RELAY—FOG LAMP ASCD RELAY RELAY—REAR WIPER STARTER RELAY ASCD VACUUM PUMP RELAY INTERLOCK EMERGENCY RELAY POWER WINDOW RELAY CULTCH RELAY CULTCH RELAY	25204 25205 25210 25215 25216 25219 25228 25229 25234 25236 25243 25245 25250 25250 25252 25258
REAR DEFROST RELAY HORN RELAY INSTRUMENT PANEL SWITCH IGNITION RELAY INHIBITOR RELAY RELAY—AUTO LAMP HEADLAMP DIMMER RELAY RELAY—FOG LAMP ASCD RELAY RELAY—FOG LAMP STARTER RELAY RELAY—REAR WIPER STARTER RELAY ROSCO VACUUM PUMP RELAY INTERLOCK EMERGENCY RELAY POWER WINDOW RELAY	25204 25205 25210 25215 25216 25219 25228 25229 25234 25236 25243 25245 25250 25252
REAR DEFROST RELAY HORN RELAY HORN RELAY INHIBITOR RELAY INHIBITOR RELAY INHIBITOR RELAY RELAY—AUTO LAMP HEADLAMP DIMMER RELAY RELAY—FOG LAMP ASCD RELAY RELAY—REAR WIPER STARTER RELAY ASCD VACUUM PUMP RELAY INTERLOCK EMERGENCY RELAY POWER WINDOW RELAY CULTCH RELAY MULTI-REMOTE CONTROL RELAY	25204 25205 25210 25215 25216 25219 25228 25229 25234 25236 25243 25245 25250 25250 25252 25258 25258
REAR DEFROST RELAY HORN RELAY INSTRUMENT PANEL SWITCH IGNITION RELAY INHIBITOR RELAY RELAY—AUTO LAMP HEADLAMP DIMMER RELAY RELAY—FOG LAMP ASCD RELAY RELAY—FOG LAMP ASCD RELAY RELAY—FOG LAMP ASCD VACUUM PUMP RELAY INTERLOCK EMERGENCY RELAY POWER WINDOW RELAY CLUTCH RELAY SWITCH : SLIDE DOOR	25204 25205 25210 25215 25216 25219 25228 25229 25234 25234 25243 25245 25250 25252 25258 25259 25259
REAR DEFROST RELAY HORN RELAY HORN RELAY INSTRUMENT PANEL SWITCH IGNITION RELAY INHIBITOR RELAY RELAY—AUTO LAMP HEADLAMP DIMMER RELAY RELAY—FOG LAMP ASCD RELAY RELAY—FAR WIPER STARTER RELAY ASCD VACUUM PUMP RELAY INTERLOCK EMERGENCY RELAY POWER WINDOW RELAY CLUTCH RELAY MULTI-REMOTE CONTROL RELAY SWITCH - SLIDE DOOR HEADLAMP CLEANER SWITCH	25204 25205 25210 25215 25216 25219 25228 25229 25234 25234 25236 25243 25245 25250 25252 25258 25259 25259 25261
REAR DEFROST RELAY HORN RELAY HORN RELAY INSTRUMENT PANEL SWITCH IGNITION RELAY INHIBITOR RELAY RELAY—AUTO LAMP HEADLAMP DIMMER RELAY RELAY—FOG LAMP ASCD RELAY RELAY—REAR WIPER STARTER RELAY ASCD VACUUM PUMP RELAY INTERLOCK EMERGENCY RELAY POWER WINDOW RELAY OUTCH RELAY MULTI-REMOTE CONTROL RELAY SWITCH - SLIDE DOOR HEADLAMP CLEANER SWITCH REAR WIPER/WASHER SWITCH	25204 25205 25210 25215 25216 25219 25228 25229 25234 25236 25243 25245 25250 25252 25252 25259 25259 25259 25261 25261
REAR DEFROST RELAY HORN RELAY HORN RELAY INSTRUMENT PANEL SWITCH IGNITION RELAY INHIBITOR RELAY RELAY—AUTO LAMP HEADLAMP DIMMER RELAY RELAY—FOG LAMP ASCD RELAY RELAY—FOG LAMP STARTER RELAY ASCD VACUUM PUMP RELAY INTERLOCK EMERGENCY RELAY POWER WINDOW RELAY CLUTCH RELAY MULTI-REMOTE CONTROL RELAY SWITCH - SLIDE DOOR HEADLAMP CLEANER SWITCH ASCD HOLD RELAY	25204 25205 25210 25215 25216 25219 25228 25229 25234 25236 25243 25245 25250 25250 25252 25259 25259 25259 25261 25262
REAR DEFROST RELAY HORN RELAY HORN RELAY INSTRUMENT PANEL SWITCH IGNITION RELAY INHIBITOR RELAY RELAY—AUTO LAMP HEADLAMP DIMMER RELAY RELAY—FOG LAMP ASCD RELAY RELAY—FOR LAMP STARTER RELAY ASCD VACUUM PUMP RELAY INTERLOCK EMERGENCY RELAY POWER WINDOW RELAY CLUTCH RELAY MULTI-REMOTE CONTROL RELAY SWITCH SUDE DOOR HEADLAMP CLEANER SWITCH REAR WIPERWASHER SWITCH REACH MIPERWASHER SWITCH REAR WIPERWASHER SWITCH REACH MIPERWASHER SWITCH REACH MIPE	25204 25205 25210 25215 25216 25218 25228 25229 25234 25236 25245 25245 25250 25252 25258 25259 25259 25261 25262 25264 25264 25267
REAR DEFROST RELAY HORN RELAY HORN RELAY INSTRUMENT PANEL SWITCH IGNITION RELAY INHIBITOR RELAY RELAY—AUTO LAMP HEADLAMP DIMMER RELAY RELAY—FOG LAMP ASCD RELAY RELAY—REAR WIPER STANTER RELAY ASCD VACUUM PUMP RELAY INTERLOCK EMERGENCY RELAY POWER WINDOW RELAY OLUTCH RELAY MULTI-REMOTE CONTROL RELAY SWITCH - SLIDE DOOR HEADLAMP CLEANER SWITCH REAR WIPER/WASHER SWITCH ASCD HOLD RELAY SWITCH - SUDE DOOR REAR WIPER/WASHER SWITCH ASCD HOLD RELAY SWITCH - SUDE DOOR REAR WIPER/WASHER SWITCH ASCD HOLD RELAY SWITCH - SWITCH ASCD HOLD RELAY SWITCH - SWITCH BEADLAMP DAYTIME RELAY	25204 25205 25210 25215 25216 25219 25228 25229 25234 25236 25243 25245 25250 25250 25252 25259 25259 25259 25261 25262
REAR DEFROST RELAY HORN RELAY HORN RELAY INSTRUMENT PANEL SWITCH IGNITION RELAY INHIBITOR RELAY RELAY—AUTO LAMP HEADLAMP DIMMER RELAY RELAY—FOG LAMP ASCD RELAY RELAY—FOR LAMP STARTER RELAY ASCD VACUUM PUMP RELAY INTERLOCK EMERGENCY RELAY POWER WINDOW RELAY CLUTCH RELAY MULTI-REMOTE CONTROL RELAY SWITCH SUDE DOOR HEADLAMP CLEANER SWITCH REAR WIPERWASHER SWITCH REACH MIPERWASHER SWITCH REAR WIPERWASHER SWITCH REACH MIPERWASHER SWITCH REACH MIPE	25204 25205 25210 25215 25216 25218 25228 25229 25234 25236 25245 25245 25250 25252 25258 25259 25259 25261 25262 25264 25264 25267
REAR DEFROST RELAY HORN RELAY INSTRUMENT PANEL SWITCH IGNITION RELAY INHIBITOR RELAY RELAY—AUTO LAMP HEADLAMP DIMMER RELAY RELAY—FOG LAMP ASCD RELAY RELAY—FOG LAMP ASCD RELAY RELAY—REAR WIPER STARTER RELAY ASCD VACUUM PUMP RELAY INTERLOCK EMERGENCY RELAY POWER WINDOW RELAY CLUTCH RELAY MULTI-REMOTE CONTROL RELAY SWITCH - SLIDE DOOR HEADLAMP CLEANER SWITCH ASCD HOLD RELAY SWITCH HANDB HEADLAMP DAYTIME RELAY SWITCH KNOB HEADLAMP DAYTIME RELAY NAWI SPEAKER RELAY NAWI SPEAKER RELAY NAWI SPEAKER RELAY	25204 25205 25210 25215 25215 25218 25228 25228 25236 25236 25245 25245 25250
REAR DEFROST RELAY HORN RELAY INSTRUMENT PANEL SWITCH IGNITION RELAY INHIBITOR RELAY INHIBITOR RELAY RELAY—AUTO LAMP HEADLAMP DIMMER RELAY RELAY—FOG LAMP ASCD RELAY RELAY—FOG LAMP ASCD RELAY RELAY—REAR WIPER STARTER RELAY INTERLOCK EMERGENCY RELAY POWER WINDOW RELAY OLUTCH RELAY SWITCH SLIDE DOOR HEADLAMP CLEANER SWITCH REAR WIPER/MASHER SWITCH REAR WIPER/MASHER SWITCH REAR WIPER/MASHER SWITCH SSCD HOLD RELAY SWITCH SLIDE DOOR HEADLAMP CLEANER SWITCH SACOH HOLD RELAY SWITCH SLIDE DOOR HEADLAMP CLEANER SWITCH SACOH HOLD RELAY SWITCH KNOB HEADLAMP DAYTIME RELAY MAUS SPEAKER RELAY RELAY—NA P	25204 25205 25215 25216 25216 25228 25228 25228 25234 25236 25236 25236 25252 25250 25252 25258 25252 25258 25252 25258 25252 25258 25262
REAR DEFROST RELAY HORN RELAY HORN RELAY INSTRUMENT PANEL SWITCH IGNITION RELAY INHIBITOR RELAY RELAY—AUTO LAMP HEADLAMP DIMMER RELAY RELAY—FOG LAMP ASCD RELAY RELAY—FOG LAMP ASCD RELAY RELAY—FAR WIPER STARTER RELAY ASCD VACUUM PUMP RELAY INTERLOCK EMERGENCY RELAY POWER WINDOW RELAY CLUTCH RELAY MULTI-REMOTE CONTROL RELAY SWITCH - KUDE DOOR HEADLAMP CLEANER SWITCH REAR WIPERWASHER SWITCH REAR WIPERWASHER SWITCH ASCD HOLD RELAY SWITCH KNOB HEADLAMP DAYTIME RELAY NAVI SPEAKER RELAY RELAY—A & P LILUMINATION CONTROL	25204 25205 25215 25216 25218 25228 25229 25228 25234 25236 25236 25240 25245 25250 25250 25250 25250 25250 25250 25250 25261 25262 25264 25264 25264 25264 25264 25264 25264 25264 25264 25265 25264 25266 25264 25266 25267 25267 25267 25267 25267 2527 252
REAR DEFROST RELAY HORN RELAY HORN RELAY INSTRUMENT PANEL SWITCH IGNITION RELAY INHIBITOR RELAY RELAY—AUTO LAMP HEADLAMP DIMMER RELAY RELAY—FOG LAMP ASCD RELAY RELAY—REAR WIPER STARTER RELAY ASCD VACUUM PUMP RELAY INTERLOCK EMERGENCY RELAY POWER WINDOW RELAY OLUTCH RELAY MULTI-REMOTE CONTROL RELAY SWITCH - SLIDE DOOR HEADLAMP CLEANER SWITCH ASCD HOLD RELAY SWITCH KNOB HEADLAMP DAYTIME RELAY NAVI SPEAKER RELAY NAVI SPEAKER RELAY NAVI SPEAKER RELAY NAVI SPEAKER RELAY RELAY—N & P LILLUMINATION CONTROL SWITCH - VALTO DOOR ON/OFF	25204 25205 25210 25215 25216 25228 25228 25228 25234 25236 25245 25250 25270
REAR DEFROST RELAY HORN RELAY HORN RELAY INSTRUMENT PANEL SWITCH IGNITION RELAY INHIBITOR RELAY RELAY—AUTO LAMP HEADLAMP DIMMER RELAY RELAY—FOG LAMP ASCD RELAY RELAY—FOG LAMP ASCD RELAY RELAY—FOG LAMP ASCD WACUUM PUMP RELAY INTERLOCK EMERGENCY RELAY POWER WINDOW RELAY CLUTCH RELAY MULTI-REMOTE CONTROL RELAY SWITCH - SLIDE DOOR HEADLAMP CLEANER SWITCH ASSCD HOLD RELAY SWITCH SUDE DOOR HEADLAMP CLEANER SWITCH ASSCD HOLD RELAY SWITCH SUDE DOOR HEADLAMP CLEANER SWITCH REAR WIPPER/WASHER SWITCH ASSCD HOLD RELAY SWITCH SUDE DOOR HEADLAMP DAYTIME RELAY NAWI SPEAKER RELAY RELAY—N & P LLUMINATION CONTROL SWITCH - AUTO DOOR ON/OFF SWITCH - AUTO DOOR ON/OFF	25204 25205 25210 25215 25216 25228 25228 25228 25234 25235 25245 25252
REAR DEFROST RELAY HORN RELAY HORN RELAY INSTRUMENT PANEL SWITCH IGNITION RELAY INHIBITOR RELAY RELAY—AUTO LAMP HEADLAMP DIMMER RELAY RELAY—FOG LAMP ASCD RELAY RELAY—REAR WIPER STARTER RELAY ASCD VACUUM PUMP RELAY INTERLOCK EMERGENCY RELAY POWER WINDOW RELAY OLUTCH RELAY MULTI-REMOTE CONTROL RELAY SWITCH - SLIDE DOOR HEADLAMP CLEANER SWITCH ASCD HOLD RELAY SWITCH KNOB HEADLAMP DAYTIME RELAY NAVI SPEAKER RELAY NAVI SPEAKER RELAY NAVI SPEAKER RELAY NAVI SPEAKER RELAY RELAY—N & P LILLUMINATION CONTROL SWITCH - VALTO DOOR ON/OFF	25204 25205 25210 252116 25212 25218 25228 25228 25228 25234 25236 25245 25245 25259 25259 25259 25262
REAR DEFROST RELAY HORN RELAY HORN RELAY INSTRUMENT PANEL SWITCH IGNITION RELAY INHIBITOR RELAY RELAY—AUTO LAMP HEADLAMP DIMMER RELAY RELAY—FOG LAMP ASCD RELAY RELAY—FOG LAMP ASCD RELAY RELAY—FOG LAMP ASCD WACUUM PUMP RELAY INTERLOCK EMERGENCY RELAY POWER WINDOW RELAY CLUTCH RELAY MULTI-REMOTE CONTROL RELAY SWITCH - SLIDE DOOR HEADLAMP CLEANER SWITCH ASSCD HOLD RELAY SWITCH SUDE DOOR HEADLAMP CLEANER SWITCH ASSCD HOLD RELAY SWITCH SUDE DOOR HEADLAMP CLEANER SWITCH REAR WIPPER/WASHER SWITCH ASSCD HOLD RELAY SWITCH SUDE DOOR HEADLAMP DAYTIME RELAY NAWI SPEAKER RELAY RELAY—N & P LLUMINATION CONTROL SWITCH - AUTO DOOR ON/OFF SWITCH - AUTO DOOR ON/OFF	25204 25205 25210 25215 25216 25228 25228 25228 25234 25235 25245 25252
REAR DEFROST RELAY HORN RELAY INSTRUMENT PANEL SWITCH IGNITION RELAY INHIBITOR RELAY INHIBITOR RELAY RELAY—HOLD LAMP HEADLAMP DIMMER RELAY RELAY—FOG LAMP ASCD RELAY RELAY—FOG LAMP ASCD RELAY RELAY—REAR WIPER STARTER RELAY ASCD VACUUM PUMP RELAY INTERLOCK EMERGENCY RELAY POWER WINDOW RELAY CLUTCH RELAY MULTI-REMOTE CONTROL RELAY SWITCH - SLIDE DOOR HEADLAMP CLEANER SWITCH ASCD HOLD RELAY SWITCH KNOB HEADLAMP DAYTIME RELAY NAVI SPEAKER RELAY NAVI SPEAKER RELAY RELAY—N & P LULUMINATION CONTROL SWITCH - BACK DOOR ASCD CLUTCH SWITCH ASCD LUTCH SWITCH ASCD LUTCH SWITCH ASCD STOP SWITCH ASCD CLUTCH SWITCH ASCD CLUTCH SWITCH ASCD STOP SWITCH	25204 25205 25210 25215 25216 25219 25228 25229 25234 25245 25250 25252
REAR DEFROST RELAY HORN RELAY HORN RELAY INSTRUMENT PANEL SWITCH IGNITION RELAY INHIBITOR RELAY RELAY—HOLD LAMP HEADLAMP DIMMER RELAY RELAY—FOG LAMP ASCD RELAY RELAY—FOG LAMP ASCD RELAY RELAY—FOG LAMP ASCD RELAY RELAY—FOG LAMP ASCD RELAY RELAY—RAR WIPER STARTER RELAY ASCD VACUUM PUMP RELAY INTERLOCK EMERGENCY RELAY POWER WINDOW RELAY CULTCH RELAY MULTI-REMOTE CONTROL RELAY SWITCH - SLIDE DOOR HEADLAMP CLEANER SWITCH REAR WIPER-WASHER SWITCH ASCD HOLD RELAY SWITCH KNOB HEADLAMP DAYTIME RELAY NAVI SPEAKER RELAY	5204 25205 25216 25216 25218 25218 25228 25234 25234 25245 25245 25252 252
REAR DEFROST RELAY HORN RELAY HORN RELAY INSTRUMENT PANEL SWITCH IGNITION RELAY INHIBITOR RELAY RELAY—AUTO LAMP HEADLAMP DIMMER RELAY RELAY—FOG LAMP ASCD RELAY RELAY—FOG LAMP ASCD RELAY RELAY—FOG LAMP ASCD WACIUM PUMP RELAY INTERLOCK EMERGENCY RELAY POWER WINDOW RELAY CLUTCH RELAY MULTI-REMOTE CONTROL RELAY SWITCH - SLIDE DOOR HEADLAMP CLEANER SWITCH REAR WIPERWASHER SWITCH ASCD HOLD RELAY SWITCH SUDE DOOR HEADLAMP CLEANER SWITCH REAR WIPERWASHER SWITCH ASCD HOLD RELAY SWITCH SUDE DOOR HEADLAMP DAYTIME RELAY NAVI SPEAKER RELAY RELAY—AU F LLUMINATION CONTROL SWITCH - AUTO DOOR ON/OFF SWITCH - BACK DOOR ASCD CLUTCH SWITCH ASCD STOP SWITCH CGARRETE LIGHTER REAR DEFROST SWITCH CGARRETE LIGHTER	5204 52505 5210 25215 5216 5228 5228 5228 5224 5224 5224 5225 5257 5257
REAR DEFROST RELAY HORN RELAY INSTRUMENT PANEL SWITCH IGNITION RELAY INHIBITOR RELAY INHIBITOR RELAY RELAY—HOLD LAMP HEADLAMP DIMMER RELAY RELAY—FOG LAMP ASCD RELAY RELAY—REAR WIPER STARTER RELAY ASCD VACUUM PUMP RELAY INTERLOCK EMERGENCY RELAY POWER WINDOW RELAY CLUTCH RELAY MULTI-REMOTE CONTROL RELAY SWITCH - SLIDE DOOR HEADLAMP CLEANER SWITCH REAR WIPERWASHER SWITCH SWITCH KNOB HEADLAMP DAYTIME RELAY NAVI SPEAKER RELAY RELAY—M & P LLUMINATION CONTROL SWITCH - BACK DOOR ASCD CLUTCH SWITCH ASCD TOOR SWITCH SWITCH - BACK DOOR SWITCH - BACK DOOR ASCD CLUTCH SWITCH ASCD STOP SWITCH CIGARETTE LIGHTER REAR PERFANTS HER REAR DEFROST SWITCH DOOR SWITCH DOOR SWITCH	25204 25205 25210 25215 25216 25219 25229 25234 25243 25245 25250 25252 25252 25252 25252 25252 25252 25252 25252 25252 25252 25252 25252 25252 25261 25262 25261 25262 2527 25262 2527 25280 2529 2529 2529 2529 2529 2529 2529 252
REAR DEFROST RELAY HORN RELAY HORN RELAY INSTRUMENT PANEL SWITCH IGNITION RELAY INHIBITOR RELAY RELAY—AUTO LAMP HEADLAMP DIMMER RELAY RELAY—FOG LAMP ASCD RELAY RELAY—FOG LAMP ASCD RELAY RELAY—FOG LAMP ASCD RELAY RELAY—FOG LAMP ASCD RELAY RELAY—RAR WIPER STARTER RELAY ASCD VACUUM PUMP RELAY INTERLOCK EMERGENCY RELAY POWER WINDOW RELAY CULTCH RELAY MULTI-REMOTE CONTROL RELAY SWITCH - SLIDE DOOR HEADLAMP CLEANER SWITCH ASCD HOLD RELAY SWITCH HAND SWITCH KNOB HEADLAMP DAYTIME RELAY NANI SPEAKER RELAY SWITCH - BACK DOOR ASCD CULTCH SWITCH ASCD COUNTROL SWITCH - BACK DOOR ASCD CULTCH SWITCH CIGARETTE LIGHTER REAR DEFROST SWITCH DOOR SWITCH DOOR SWITCH DOOR SWITCH DOOR SWITCH DOOR SWITCH	5204 5210 25215 5216 5218 5228 5228 5228 5228 5228 5223 5224 5224 5224 5225 5225 5225 5225 5225 5225 5225 5225 5225 5225 5225 5225 5225 5225 5226 5226 5226 5227 5226 5226 5226 5227 5226 5226 5227 5226 5227 5226 5227 5226 5227 5227 5228 5229 5232 5232 5232 5232 5232 5232 5233 5234 5233 5233 5233 5233 5234 5235 5236 5236 5236 5236 5236 5236 5236 5237 5238
REAR DEFROST RELAY HORN RELAY HORN RELAY INSTRUMENT PANEL SWITCH IGNITION RELAY INHIBITOR RELAY RELAY—AUTO LAMP HEADLAMP DIMMER RELAY RELAY—FOG LAMP ASCD RELAY RELAY—FOG LAMP ASCD RELAY RELAY—FOG LAMP ASCD WACIUM PUMP RELAY INTERLOCK EMERGENCY RELAY POWER WINDOW RELAY CLUTCH RELAY MULTI-REMOTE CONTROL RELAY SWITCH - SLIDE DOOR HEADLAMP CLEANER SWITCH REAR WIPERWASHER SWITCH ASCD HOLD RELAY SWITCH SUDE DOOR HEADLAMP CLEANER SWITCH REAR WIPERWASHER SWITCH ASCD HOLD RELAY SWITCH SUDE DOOR HEADLAMP DAYTIME RELAY NAVI SPEAKER RELAY RELAY—AU F LLUMINATION CONTROL SWITCH - AUTO DOOR ON/OFF SWITCH - BACK DOOR ASCD CLUTCH SWITCH ASCD STOP SWITCH CGARRETE LIGHTER REAR DEFROST SWITCH CGARRETE LIGHTER	25204 25205 25210 25215 25216 25219 25229 25234 25243 25245 25250 25252 25252 25252 25252 25252 25252 25252 25252 25252 25252 25252 25252 25252 25261 25262 25261 25262 2527 25262 2527 25280 2529 2529 2529 2529 2529 2529 2529 252
REAR DEFROST RELAY HORN RELAY HORN RELAY INSTRUMENT PANEL SWITCH IGNITION RELAY INHIBITOR RELAY RELAY—AUTO LAMP HEADLAMP DIMMER RELAY RELAY—FOG LAMP ASCD RELAY RELAY—FOG LAMP ASCD RELAY RELAY—FOG LAMP ASCD RELAY RELAY—FOG LAMP ASCD RELAY RELAY—RAR WIPER STARTER RELAY ASCD VACUUM PUMP RELAY INTERLOCK EMERGENCY RELAY POWER WINDOW RELAY CULTCH RELAY MULTI-REMOTE CONTROL RELAY SWITCH - SLIDE DOOR HEADLAMP CLEANER SWITCH ASCD HOLD RELAY SWITCH HAND SWITCH KNOB HEADLAMP DAYTIME RELAY NANI SPEAKER RELAY SWITCH - BACK DOOR ASCD CULTCH SWITCH ASCD COUNTROL SWITCH - BACK DOOR ASCD CULTCH SWITCH CIGARETTE LIGHTER REAR DEFROST SWITCH DOOR SWITCH DOOR SWITCH DOOR SWITCH DOOR SWITCH DOOR SWITCH	5204 5210 25215 5216 5218 5228 5228 5228 5228 5228 5223 5224 5224 5224 5225 5225 5225 5225 5225 5225 5225 5225 5225 5225 5225 5225 5225 5225 5226 5226 5226 5227 5226 5226 5226 5227 5226 5226 5227 5226 5227 5226 5227 5226 5227 5227 5228 5229 5232 5232 5232 5232 5232 5232 5233 5234 5233 5233 5233 5233 5234 5235 5236 5236 5236 5236 5236 5236 5236 5237 5238

SWITCH ASSY—FOG LAMP	P.N.C.
	25370
TRUNK LID OPENER SWITCH	25384
FUEL FILLER OPENER SWITCH	25394 25400
DOOR LOCK SWITCH INTERLOCK EMERGENCY SWITCH	25400
CLUTCH INTERLOCK SWITCH	25402
FUSE BLOCK	25410
FUSIBLE LINK HOLDER	25411
HEADLAMP SENSOR UNIT	25505
TAIL & STOP LAMP SENSOR	25506
FLASHER ASSY COMBINATION	25520
FLASHER UNIT & RELAY METER POWER UNIT	25521 25522
SEAT BELT WARNING TIMER	25529
HEADLAMP/TURN SIGNAL SWITCH	25540
BRUSH ASSEMBLY	25542
REAR WIPER/WASHER SWITCH	25560
HEAT MIRROR SWITCH	25580
VOICE WARNING SWITCH	25591
TRANSMITTER	25695
RECEIVER	25696
GLOVE BOX SWITCH POWER WINDOW MAIN SWITCH	25720 25750
POWER WINDOW SUB SWITCH	25752
HAZARD SWITCH	25880
SPEED SENSOR	25911
VOICE WARNING UNIT	25925
DISPLAY UNIT	25930
CONTROL UNIT	25931
POWER UNIT	25936
NAVI GPS ANTENNA ASSY	25957
DRIVE COMPUTER DISPLAY CONTROL UNIT - BACK DOOR	25987
RETRACTABLE HEADLAMP MOTOR	25990 26010
HEADLAMP ASSY	26023
FRONT COMBO LAMP ASSY	26120
SIDE MARKER LAMP ASSY	26160
SIDE CLEARANCE LAMP	26162
HORN	26310
WARNING CHIME/BUZZER	26350
KEYLESS ENTRY BUZZER	26352
WIPER ARM	26380
REAR WIPER ARM	26390 26410
ROOM/LUGGAGE LAMP SPOT LAMP (SWITCH)	26416
STEP (FOOTWELL) LAMP	26420
SWITCH-REAR SIDE WINDOW	
	20430
	26430 26440
FOOT LAMP ASSY VANITY MIRROR LAMP	
FOOT LAMP ASSY VANITY MIRROR LAMP LICENSE LAMP ASSY	26440 26450 26510
FOOT LAMP ASSY VANITY MIRROR LAMP LICENSE LAMP ASSY REVERSE LAMP	26440 26450 26510 26540
FOOT LAMP ASSY VANITY MIRROR LAMP LICENSE LAMP ASSY REVERSE LAMP REAR COMBO LAMP ASSY	26440 26450 26510 26540 26550
FOOT LAMP ASSY VANITY MIRROR LAMP LICENSE LAMP ASSY REVERSE LAMP REAR COMBO LAMP ASSY REAR COMBO LAMP HARNESS	26440 26450 26510 26540 26550 26551
FOOT LAMP ASSY VANITY MIRROR LAMP LICENSE LAMP ASSY REVERSE LAMP REAR COMBO LAMP ASSY REAR COMB LAMP HARNESS REAR COMB LAMP GASKET	26440 26450 26510 26540 26550 26551 26553
FOOT LAMP ASSY VANITY MIRROR LAMP LICENSE LAMP ASSY REVERSE LAMP ASSY REAR COMBO LAMP ASSY REAR COMBO LAMP ARRIESS REAR COMBO LAMP HARNESS REAR COMBO LAMP GASKET HIGH MOUNT STOP LAMP	26440 26450 26510 26540 26550 26551 26553 26591
FOOT LAMP ASSY VANITY MIRROR LAMP LICENSE LAMP ASSY REVERSE LAMP REAR COMBO LAMP ASSY REAR COMBO LAMP ARNESS REAR COMBO LAMP HARNESS REAR COMBO LAMP HARNESS REAR COMBO LAMP HARNESS REAR COMBO LAMP COCOCA COMBO LAMP COCOCA COMBO LAMP COCOCA COCOCA COMBO LAMP COCOCA COC	26440 26450 26510 26540 26550 26551 26553 26591 27380
FOOT LAMP ASSY VANITY MIRROR LAMP LICENSE LAMP ASSY REVERSE LAMP ASSY REAR COMBO LAMP ASSY REAR COMBO LAMP ARRIESS REAR COMBO LAMP HARNESS REAR COMBO LAMP GASKET HIGH MOUNT STOP LAMP	26440 26450 26510 26540 26550 26551 26553 26591
FOOT LAMP ASSY VANITY MIRROR LAMP LICENSE LAMP ASSY REVERSE LAMP ASSY REAR COMBO LAMP ASSY REAR COMB. LAMP HARNESS REAR COMB. LAMP HARNESS REAR COMB. LAMP HARNESS REAR COMB. LAMP GASKET HIGH MOUNT STOP LAMP CLOCK TEE TUBE WASHER ROZZLE REAR WASHER NOZZLE	26440 26450 26510 26540 26550 26551 26553 26591 27380 27416 27440 27450
FOOT LAMP ASSY VANITY MIRROR LAMP LICENSE LAMP ASSY REVERSE LAMP REAR COMBO LAMP ASSY REAR COMB LAMP HARNESS REAR COMB LAMP HARNESS REAR COMB LAMP GASKET HIGH MOUNT STOP LAMP CLOCK LEE TUBE WASHER NOZZLE REAR WASHER NOZZLE WASHER TUBE	26440 26450 26510 26540 26550 26551 26553 26591 27380 27416 27440 27450 27460
FOOT LAMP ASSY VANITY MIRROR LAMP LICENSE LAMP ASSY REVERSE LAMP REAR COMBO LAMP ASSY REAR COMBO LAMP ASSY REAR COMB LAMP HARNESS REAR COMB LAMP GASKET HIGH MOUNT STOP LAMP CLOCK TEE TUBE WASHER NOZZLE WASHER NOZZLE WASHER TUBE REAR WASHER TUBE	26440 26450 26510 26540 26550 26551 26553 26591 27380 27416 27440 27450
FOOT LAMP ASSY VANITY MIRROR LAMP LICENSE LAMP ASSY REVERSE LAMP REAR COMB LAMP ASSY REAR COMB LAMP ASSY REAR COMB LAMP HARNESS REAR COMB LAMP HARNESS REAR COMB LAMP GASKET HIGH MOUNT STOP LAMP CLOCK TEE TUBE WASHER NOZZLE REAR WASHER NOZZLE RASHER TUBE REAR WASHER TUBE WIPPER WASHER TUBE WIPPER WASHER TUBE	26440 26450 26510 26540 26550 26551 26553 26591 27380 27416 27440 27450 27470 27480
FOOT LAMP ASSY VANITY MIRROR LAMP LICENSE LAMP ASSY REVERSE LAMP REAR COMBO LAMP ASSY REAR COMBO LAMP ARNESS REAR COMBO LAMP HARNESS REAR COMBO LAMP GASKET HIGH MOUNT STOP LAMP CLOCK LEE TUBE WASHER NOZZLE REAR WASHER NOZZLE WASHER TUBE REAR WASHER TUBE WHER WASHER TUBE WHER WASHER TANK REAR WASHER TANK	26440 26450 26510 26540 26550 26551 26553 26591 27380 27416 27440 27450 27460 27470 27480 27490
FOOT LAMP ASSY VANITY MIRROR LAMP LICENSE LAMP ASSY REVERSE LAMP REAR COMBO LAMP ASSY REAR COMBO LAMP ASSY REAR COMB. LAMP HARNESS REAR COMB. LAMP GASKET HIGH MOUNT STOP LAMP CCLOCK TEE TUBE WASHER NOZZLE WASHER NOZZLE WASHER TUBE REAR WASHER TUBE REAR WASHER TANK	26440 26450 26510 26540 26550 26551 26553 26591 27380 27416 27440 27450 27470 27480 27490 27491
FOOT LAMP ASSY VANITY MIRROR LAMP LICENSE LAMP REVERSE LAMP REAR COMBO LAMP ASSY REAR COMBO LAMP ASSY REAR COMBO LAMP ASSY REAR COMBO LAMP ASSY REAR COMBO LAMP GASKET HIGH MOUNT STOP LAMP CLOCK TEE TUBE WASHER NOZZLE WASHER NOZZLE WASHER TUBE WIPER WASHER TUBE WIPER WASHER TANK REAR WASHER TANK WASHER TAN	26440 26450 26510 26540 26550 26551 26553 26591 27380 27416 27450 27450 27470 27490 27490 27491 27522
FOOT LAMP ASSY VANITY MIRROR LAMP LICENSE LAMP ASSY REVERSE LAMP ASSY REVERSE LAMP ASSY REAR COMB. LAMP ASSY REAR COMB. LAMP HARNESS REAR COMB. LAMP HARNESS REAR COMB. LAMP GASKET HIGH MOUNT STOP LAMP CLOCK TEE TUBE WASHER NOZZLE WASHER NOZZLE WASHER TUBE REAR WASHER TUBE WIPER WASHER TUBE REAR WASHER TANK	26440 26450 26510 26540 26550 26551 26553 26591 27380 27416 27440 27450 27470 27480 27490 27491
FOOT LAMP ASSY VANITY MIRROR LAMP LICENSE LAMP REVERSE LAMP REAR COMBO LAMP ASSY REAR COMBO LAMP ASSY REAR COMBO LAMP ASSY REAR COMBO LAMP ASSY REAR COMBO LAMP GASKET HIGH MOUNT STOP LAMP CLOCK TEE TUBE WASHER NOZZLE WASHER NOZZLE WASHER TUBE WIPER WASHER TUBE WIPER WASHER TANK REAR WASHER TANK WASHER TAN	26440 26450 26510 26540 26550 26551 26553 26553 26591 27380 27416 27450 27450 27470 27490 27490 27491 27522 27528
FOOT LAMP ASSY VANITY MIRROR LAMP LICENSE LAMP ASSY REVERSE LAMP ASSY REVERSE LAMP ASSY REAR COMB. LAMP ASSY REAR COMB. LAMP HARNESS REAR COMB. LAMP HARNESS REAR COMB. LAMP GASKET HIGH MOUNT STOP LAMP CLOCK TEE TUBE WASHER NOZZLE REAR WASHER NOZZLE WASHER TUBE REAR WASHER TUBE WIPER WASHER TUBE WIPER WASHER TANK REAR WASHER TANK LEVEL SENSOR READLAMP CLEANER PUMP HEADLAMP CLEANER TVALVE HEADLAMP CLEANER TANK HEADLAMP CLEANER TANK HEADLAMP CLEANER NOZZLE RANTENNA SWITCH	26440 26450 26550 26550 26550 26553 26553 26551 27380 27416 27440 27450 27460 27470 27490 27490 27490 27491 27522 27528 27538 27538 27538 27538 27538
FOOT LAMP ASSY VANITY MIRROR LAMP LICENSE LAMP ASSY REVERSE LAMP REAR COMBO LAMP ASSY REAR COMBO LAMP ASSY REAR COMBO LAMP ASSY REAR COMBO LAMP ASSY REAR COMBO LAMP GASKET HIGH MOUNT STOP LAMP CLOCK TEE TUBE WASHER NOZZLE WASHER NOZZLE WASHER NOZZLE WASHER NOZZLE WASHER TUBE REAR WASHER TUBE WIPER WASHER TANK REAR WASHER TANK READLAMP CLEANER TVALVE HEADLAMP CLEANER TVALVE HEADLAMP CLEANER TNAK READLAMP CLEANER TANK READLAMP CLEANER TOALVE HEADLAMP CLEANER TOALVE	26440 26450 26510 26550 26551 26553 26551 26553 26591 27380 27416 27450 27460 27470 27480 27490 27491 27522 27528 27538 27922 27960
FOOT LAMP ASSY VANITY MIRROR LAMP LICENSE LAMP ASSY REVERSE LAMP ASSY REVERSE LAMP ASSY REAR COMB. LAMP HARNESS REAR COMB. LAMP HARNESS REAR COMB. LAMP GASKET HIGH MOUNT STOP LAMP CLOCK TEE TUBE WASHER NOZZLE REAR WASHER NOZZLE WASHER NOZZLE WASHER TANE REAR WASHER TANE READLAMP CLEARER TANE REA	26440 26450 26510 26550 26555 26555 26551 27538 27416 27450 27450 27480 27490 27490 27490 27490 27490 27522 27522 27522 27524 27522 27524 27528 27534 27534 27534 27534 27534 27536
FOOT LAMP ASSY VAINTY MIRROR LAMP LICENSE LAMP REVERSE LAMP REVERSE LAMP REAR COMBO LAMP ASSY REAR COMBO LAMP ASSY REAR COMBO LAMP ASSY REAR COMBO LAMP ASSY REAR COMBO LAMP GASKET HIGH MOUNT STOP LAMP CLOCK TEE TUBE WASHER NOZZLE REAR WASHER NOZZLE WASHER TUBE WIPER WASHER TUBE WIPER WASHER TANK REAR WASHER TAN	26440 26450 26510 26550 26550 26551 26551 26551 27380 27416 27440 27440 27490 27491 27491 27522 27528 27528 27538 27538 27538
FOOT LAMP ASSY VANITY MIRROR LAMP LICENSE LAMP ASSY REVERSE LAMP REAR COMBO LAMP ASSY REAR COMBO LAMP ASSY REAR COMBO LAMP ARNESS REAR COMBO LAMP ARNESS REAR COMBO LAMP GASKET HIGH MOUNT STOP LAMP CLOCK LEE TUBE WASHER NOZZLE REAR WASHER NOZZLE WASHER TUBE REAR WASHER NOZZLE WASHER TUBE WASHER TANK REAR WASHER TANK REAR WASHER TANK REAR WASHER TANK REAR WASHER TANK WASHER TANK LEVEL SENSOR HEADLAMP CLEANER TWALVE HEADLAMP CLEANER TANK HEADLAMP COR TANK HEADLAMP CLEANER TANK HEADLAMP COR OR NAVI DISPLAY ASSY REMOTE CONTROL RADIO SWITCH REMOTE CONTROL RADIO SWITCH REAR AUDIO PANEL	26440 26450 26510 26550 26550 26551 26551 27380 27446 27440 27450 27490 27491 27522 27528 27528 27534
FOOT LAMP ASSY VANITY MIRROR LAMP LICENSE LAMP ASSY REVERSE LAMP REAR COMBO LAMP ASSY REVERSE LAMP HARNESS REAR COMB. LAMP HARNESS REAR COMB. LAMP GASKET HIGH MOUNT STOP LAMP CCLOCK TEE TUBE WASHER NOZZLE WASHER NOZZLE WASHER NOZZLE WASHER TOZZLE REAR WASHER TUBE WIPER WASHER TIME REAR WASHER TAMK READLAMP CLEANER TVALVE HEADLAMP CLEANER TVALVE HEADLAMP CLEANER TVALVE HEADLAMP CLEANER TVALVE HEADLAMP CLEANER TVALVE REAR WASHER TAMK READLAMP CLEANER TVALVE READLAMP CLEANER TVALVE READLAMP CLEANER TOXALVE READLAMP CLEANER	26440 26450 26510 26550 26550 26551 26551 27380 27416 27450 27450 27490
FOOT LAMP ASSY VAINTY MIRROR LAMP LICENSE LAMP REVERSE LAMP REVERSE LAMP REAR COMBO LAMP ASSY REAR COMBO LAMP ASSY REAR COMBO LAMP ASSY REAR COMBO LAMP ASSY REAR COMBO LAMP GASKET HIGH MOUNT STOP LAMP CLOCK TEE TUBE WASHER NOZZLE WASHER NOZZLE WASHER NOZZLE WASHER TUBE WIPER WASHER TUBE WIPER WASHER TIBE WIPER WASHER TANK REAR WASHER TANK REAR WASHER TANK REAR WASHER TANK REAR WASHER TANK WASHER TAN	26440 26450 26550 26550 26551 26553 26551 27380 27440 27450 27440 27450 27490 27490 27522 27528
FOOT LAMP ASSY VANITY MIRROR LAMP LICENSE LAMP ASSY REVERSE LAMP REAR COMBO LAMP ASSY REAR COMBO LAMP ASSY REAR COMBO LAMP ARNESS REAR COMBO LAMP ARNESS REAR COMBO LAMP GASKET HIGH MOUNT STOP LAMP CLOCK LEE TUBE WASHER NOZZLE REAR WASHER NOZZLE WASHER NOZZLE WASHER TOZZLE REAR WASHER NOZZLE WASHER TUBE REAR WASHER TUBE WASHER TANK WASHER WASHER TANK WASHER	26440 26450 26550 26550 26551 26553 26551 27380 27450
FOOT LAMP ASSY VANITY MIRROR LAMP LICENSE LAMP ASSY REVERSE LAMP REAR COMBO LAMP ASSY REAR COMBO LAMP ASSY REAR COMBO LAMP ASSY REAR COMBO LAMP ASSY REAR COMBO LAMP GASKET HIGH MOUNT STOP LAMP CLOCK TEE TUBE WASHER NOZZLE WASHER NOZZLE WASHER NOZZLE WASHER NOZZLE WASHER TUBE REAR WASHER TUBE REAR WASHER TUBE REAR WASHER TANK READLAMP CLEANER TVALVE HEADLAMP CLEANER TVALVE HEADLAMP CLEANER TOALVE REAR WASHER TOALVE REAR MOTOR OF NAVI DISPLAY ASSY REMOTE CONTROL RADIO SWITCH REAR AUDIO PANEL REAR AUDIO PANEL REAR DEFOGGER CONDENSOR ASCO SERVO VALVE RSCO SCRUCY VALVE RESCO SERVO VALVE RSCO SCRUCY VALVE	26440 26450 26550 26550 26550 26551 26553 26551 27380 27416 27450 27470 27480 27490 27491 27528 27534
FOOT LAMP ASSY VANITY MIRROR LAMP LICENSE LAMP ASSY REVERSE LAMP REAR COMBO LAMP ASSY REAR COMBO LAMP GASKET HIGH MOUNT STOP LAMP CLICOCK TEE TUBE WASHER NOZZLE REAR WASHER NOZZLE WASHER NOZZLE REAR WASHER NOZZLE REAR WASHER TANK REAR WASHER TAN	26440 26450 26550 26550 26551 26553 26551 27380 27450
FOOT LAMP ASSY VANITY MIRROR LAMP LICENSE LAMP ASSY REVERSE LAMP REAR COMBO LAMP ASSY REAR COMBO LAMP ASSY REAR COMBO LAMP ASSY REAR COMBO LAMP ASSY REAR COMBO LAMP GASKET HIGH MOUNT STOP LAMP CLOCK TEE TUBE WASHER NOZZLE WASHER NOZZLE WASHER NOZZLE WASHER NOZZLE WASHER TUBE REAR WASHER TUBE REAR WASHER TUBE REAR WASHER TANK READLAMP CLEANER TVALVE HEADLAMP CLEANER TVALVE HEADLAMP CLEANER TOALVE REAR WASHER TOALVE REAR MOTOR OF NAVI DISPLAY ASSY REMOTE CONTROL RADIO SWITCH REAR AUDIO PANEL REAR AUDIO PANEL REAR DEFOGGER CONDENSOR ASCO SERVO VALVE RSCO SCRUCY VALVE RESCO SERVO VALVE RSCO SCRUCY VALVE	26440 26450 26550 26550 26551 26553 26551 27380 27440 27450 27440 27450 27470 27480 27490 27490 27532 27538 27538 27538 27538 27538 28269 28269 28269 28400 28400 28400 28400
FOOT LAMP ASSY VANITY MIRROR LAMP LICENSE LAMP ASSY REVERSE LAMP REAR COMBO LAMP ASSY REAR COMBO LAMP GASKET HIGH MOUNT STOP LAMP CLICOCK TEE TUBE WASHER NOZZLE REAR WASHER NOZZLE WASHER NOZZLE REAR WASHER NOZZLE REAR WASHER TANK REAR DEFOGGER CONDENSOR RECORD REAR DEFOGGER CONDENSOR REAR DEFOGGER CONDENSOR RECORD REVOLUCE REAR DEFOGGER CONDENSOR RECORD REVOLUCE REAR DEFOGGER CONDENSOR RECORD REVOLUCE RESCO CABLE RECORD WALVE RESCO CABLE RESCO CABLE RETRACTABLE HEADLAMP TIMER RETRACTABLE HEADLAMP TIMER RETRACTABLE HEADLAMP TIMER	26440 26450 26550 26550 26551 26553 26551 27380 27450 27450 27480 27480 27490 27480 27490 27490 27490 27532
FOOT LAMP ASSY VANITY MIRROR LAMP LICENSE LAMP ASSY REVERSE LAMP ASSY REVERSE LAMP ASSY REAR COMB LAMP ARNESS REAR COMB LAMP HARNESS REAR COMB LAMP GASKET HIGH MOUNT STOP LAMP CLOCK TEE TUBE WASHER NOZZLE REAR WASHER NOZZLE WASHER NOZZLE WASHER TOZZLE WASHER TANK REAR WASHER TUBE REAR WASHER TUBE REAR WASHER TANK WASHER	26440 26450 26550 26550 26551 26553 26553 26553 27440 27450 27440 27450 27490 27490 27522 27528
FOOT LAMP ASSY VANITY MIRROR LAMP LICENSE LAMP ASSY REVERSE LAMP REAR COMBO LAMP ASSY REAR COMBO LAMP ASSY REAR COMBO LAMP ASSY REAR COMBO LAMP ASSY REAR COMBO LAMP GASKET HIGH MOUNT STOP LAMP CLOCK TEE TUBE WASHER NOZZLE REAR WASHER NOZZLE WASHER TUBE REAR WASHER TANK REAR LEVEL SENSOR READLAMP CLEANER TANK READLAMP TANK R	26440 26450 26550 26550 26550 26551 26551 26551 27446 27450 27450 27450 27470 27480 27490 27490 27491 27528
FOOT LAMP ASSY VANITY MIRROR LAMP LICENSE LAMP ASSY REVERSE LAMP ASSY REVERSE LAMP ASSY REVERSE LAMP HARNESS REAR COMB. LAMP HARNESS REAR COMB. LAMP GASKET HIGH MOUNT STOP LAMP CCLOCK TEE TUBE WASHER NOZZLE WASHER NOZZLE WASHER NOZZLE WASHER NOZZLE REAR WASHER NOZZLE WASHER TUBE REAR WASHER TUBE WIPER WASHER TANK REAR WASHER TANK REAR WASHER TANK REAR WASHER TANK WASHER TANK LEVEL SENSOR HEADLAMP CLEANER TVALVE HEADLAMP CLEANER TVALVE HEADLAMP CLEANER NOZZLE ANTENNA SWITCH ANTENNA WASHER TANK LEVEL SENSOR HEADLAMP CLEANER TVALVE HEADLAMP CLEANER TVALVE HEADLAMP CLEANER TVALVE HEADLAMP CLEANER TOALVE	26440 26450 26550 26550 26551 26553 26553 26553 27440 27450 27440 27450 27490 27490 27522 27528

# ELECTRICAL/BODY & INTERIOR CONTROL

COMPONER	PACC.
INTERIOR LAMP TIMER	28460
ANTENNA TIMER	28490
BODY CONTROL LAN MODULE	28492
P/S CONTROL UNIT	28500
WIPER RELAY	28510
POWER WINDOW AMPLIFIER	28515
CONTROL UNIT - SLIDE DOOR	28543
TIME CONTROL UNIT	28550
LIGHTING CONTROL	28575
LIGHTING SENSOR	28578
THEFT WARNING CONTROL UNIT	28591
THEFT WARNING SUB-CONTROL	28592
THEFT WARNING RELAY	28593
SMART ENTRANCE CONTROL UNIT	28594
KEYLESS ENTRY CONTROL UNIT	28595
REAR WIPER MOTOR	28710
WASHER MOTOR	28765
REAR WASHER MOTOR	28766
WIPER MOTOR	28810
INTERMITTANT WIPER AMP	28820
WIPER MOTOR ARM	28840
WIPER CONNECTING ROD	28860
PIVOT ASSY	28870
ASCD SPEED SENSOR	28940_
DECELERATION SENSOR ASSY	47930
IGNITION KEY LAMP ASSY	48476
IGNITION SWITCH	48750
HOOD SWITCH	65630
DOOR LOCK ACTUATOR	80550
KEYBOARD	80604
FRONT REGULATOR MOTOR	80730
REAR REGULATOR MOTOR	82730
REAR SIDE WINDOW MOTOR	83500
	90605
ASCD VACUUM PUMP	92270

HELDER - COLORIGION	AHMR-
---------------------	-------

COMPRESSOR BRACKET	11910
IDLER PULLEY	11925
IDLER PULLEY BRACKET	11926
REAR HEATER CONTROL	25207
BLOWER MOTOR RELAY	25208
HEATER RELAY	25214
A/C RELAY	25218
F.I.C.D. RELAY (Fast Idle Control Device)	25224
REAR A/C RELAY	25225
FAN MOTOR RELAY	25246
MAX COLD DOOR RELAY	25257
REAR HEATER RELAY	25274
HEATER UNIT	27000
REAR HEATER CORE	27013
REAR HEATER MOTOR	27014
HEATER & A/C CONTROL	27030
VACUUM SELECTOR VALVE	27031
ATC CONTROL	27032
REAR HEATER	27035
A/C HARNESS	27038
A/C SWITCH	27041
BLOWER CASE/HOUSING	27065
BLOWER MOTOR & FAN	27070
HEATER CONNECTOR	27071
HEATER SWITCH RESISTOR	27077
VACUUM ACTUATOR	27080
VACUUM TANK	27084
VACUUM WATER COCK	27090
VACUUM CHECK VALVE	27096
HEATER CORE	27115
HEATER COCK	27116
CONTROL CABLE	27134
MODE ACTUATOR ASSY	27141
BLOWER CONTROL AMPLIFIER	27150
CENTER DEFROST DUCT	27151
SIDE DEFROST DUCT	27152
FLOOR NOZZLE	27167
REAR COOLING CASE	27172
HEATER DUCT	27173
DUCT AIR OUTLET	27175
REAR HEATER RESISTOR	27178
THERMISTOR	27322
THERMO CONTROL UNIT	27330
REAR BLOWER MOTOR	27375
FAN IMPELLER	27383
REAR EVAPORATOR	27410
REAR A/C HIGH TUBE ASSY.	27413
REAR A/C LOW TUBE ASSY.	27414

COMPONENT	P.N.C.
CASE ASSEMBLY	27415
COOLER BOX & TUBING REFRIGERATOR ASSY	27430
	27430
REAR COOLER HARNESS	27582
EVAPORATOR	27621
SWITCH-HIGH PRESSURE	27623
EXPANSION VALVE	27625
COMPRESSOR ASSY	27630
RADIATOR FAN CONTROL AMP	27631
RECEIVER DRIER	27640
LOW PRESSURE SWITCH	27648
CONDENSOR	27650
CONDENSOR FAN & MOTOR	27651
FAST IDLE DIAPHRAGM	27655
SOLENOID VALVE	27659
SUCTION THROTTLE VALVE	27660
SWITCH-REAR A/C	27665
SIDE VENT DUCT	27670
ACCELERATION CUT SWITCH	27671
THERMO CONTROL AMPLIFIER	27675
COOLER PIPE	27677
JOINT CONNECTOR	27680
VACUUM LOCK-OUT SWITCH	27685
FLOOR DUCT SENSOR	27700 27701
VENTILATOR DUCT SENSOR	27702
DEFROSTER NOZZLE SENSOR ROOF IN-CAR SENSOR	27703
FOOT IN-CAR SENSOR	27704
FOOT IN-CAR SENSOR SUNLOAD SENSOR	27705
SENSOR GRILLE	27706
FAN CONTROL AMPLIFIER	27717
INTAKE SENSOR	27723
IN-VEHICLE SENSOR	27727
COMPRESSOR SHAFT SEAL	27730
WATER TEMP SENSOR	27732
BI-LEVEL MOTOR ACTUATOR	27736
FEEDBACK RESISTOR (PBR)	27738
AIR MIX DOOR ACTUATOR	27740
DOUBLE SOLENOID VACUUM VALVE	27741
MAGNETIC CLUTCH	27742
SNAP RING	27744
ACTUATOR - DEFROSTER DOOR	27747
ACTUATOR - DRIVER SIDE, AIR MIX DOOR	27748
ACTUATOR - DRIVER SIDE, INTAKE DOOR	27749
ASPIRATOR FAN	27752
AMBIENT SENSOR	27755
SUNLOAD SENSOR AMPLIFIER	27764
SHIFT ACTUATOR VALVE	27765
SOLENOID VALVE SET	27770
CENTER VENT DUCT	27860
REAR HEATER GRILLE	27913
HEATER REAR DUCT	27950
AUTO AIR CONTROL AMPLIFIER	28520
MAGNETIC CLUTCH AMPLIFIER	28525
CONTROL KNOB	68725
VALVE—EXPANSION	92200 92310
SUPER HEAT SWITCH	
THERMAL PROTECTOR	92316
ACCELERATION CUT TIMER	92330
SUPER HEAT TIMER	92331 92420
REAR HEATER HOSE REAR HEATER TUBE	92420
REAR COOLER PIPE	92463
FLEXIBLE HOSE-LOW PRESSURE	92480
FLEXIBLE HOSE-HIGH PRESSURE	92490
PIPE - REAR HIGH/LOW COOLER	92741
COMPRESSOR RPM SENSOR	92855

# BODY & INTERIOR COMPONENTS

BOSA

18110
18121
24162
25191
25192
25200
25380
25570

COMPONENT	£4,50,0
MIRROR HEAT SWITCH	25580
AIR GUIDE	41182
HOOD HINGE HOOD STAY	65400 65470
HOOD LOCK	65601
HOOD LOCK CABLE	65620
SUNROOF RAIL ASSY	73662
SUN ROOF MOTOR GUIDE BRACKET SUN ROOF LIMIT SWITCH	73670 73678
SUN ROOF MOTOR	73685
SUN ROOF STRIKER	73812
FEMALE LOCK	73820
ROOF PANEL HINGE SUNSHADE - SKYROOF	73860 73960
SEAT BELT/ANCHOR STAY	74830
REAR SEAT BACK CENTER SUPPORT	76730
REAR SIDE WINDOW HINGE	76829
REAR SIDE WINDOW HANDLE UPPER RAIL GUIDE	76870
REAR RAIL GUIDE	77796
FUELING STOPPER ASSY	78402
TRUNK LID SWITCH	78526
FUEL FILLER LID OPENER	78826
FRONT DOOR HINGE DOOR STOPPER LINK	80400 80430
FRONT LOCK	80502
LOCK KNOB ROD	80510
REMOTE CONTROL ROD	80512
KNOB ROD PROTECTOR  LOCK STRIKER	80519 80570
LOCK KNOB	80595
LOCK CYLINDER	80600
FRONT OUTSIDE HANDLE	80605
HANDLE ROD FRONT INSIDE HANDLE	80608
FRONT WINDOW REGULATOR	80700
REAR DOOR HINGE	8240C
UPPER STOPPER	82440
LOWER STOPPER	82442
UPPER MALE DOVETAIL UPPER FEMALE DOVETAIL	82470 82472
LOWER MALE DOVETAIL	82474
LOWER FEMALE DOVETAIL	82476
REAR LOCK ASSY LOCK KNOB ROD	82502
REMOTE CONTROL ROD	82510 82512
MOTOR · CLOSING	82530
AUTO DOOR LOCK ACTUATOR	82550
MOTOR - SLIDE DOOR LOCK STRIKER	82560 82570
MOTOR - BACK DOOR OPEN/CLOSE	82580
LOCK KNOB	82595
REAR OUTSIDE HANDLE	82605
HANDLE ROD REAR INSIDE HANDLE	82608 82670
REAR WINDOW REGULATOR	82700
REGULATOR HANDLE	82760
WELT - REAR WINDOW	83331
SLIDE DOOR LOCK ASSY REAR SIDE WINDOW REGULATOR	83502 83506
REMOTE CONTROL ROD	83512
OUTSIDE HANDLE	83605
INSIDE HANDLE	83670
REGULATOR WIRE	83752
SLIDE DOOR ROLLER SLIDE DOOR LINK	83810 83840
DECK LID LOCK STRIKER	84420
LID OPENER LEVER	84440
LID OPENER CABLE	84450
DECK LID LOCK TRUNK OPENER SOLENOID	84460 84471
	84510
DECK LID HINGE	84532
DECK LID HINGE DECK LID TORSION BAR	04032
DECK LID HINGE DECK LID TORSION BAR RR BUMPER SHOCK ABS JSTAY	85210
DECK LID HINGE DECK LID TORSION BAR RR BUMPER SHOCK ABS/STAY SPECIAL BOLT	85210 87408
DECK LID HINGE DECK LID TORSION BAR RR BUMPER SHOCK ABS /STAY SPECIAL BOLT BACK DOOR LOCK & HANDLE	85210 87408 90502
DECK LID HINGE DECK LID TORSION BAR RR BUMPER SHOCK ABS./STAY SPECIAL BOLT BACK DOOR LOCK & HANDLE TAILGATE STOPPER	85210 87408
DECK LID HINGE DECK LID TORSION BAR RR BUMPER SHOCK ABS /STAY SPECIAL BOUT BACK DOOR LOCK & HANDLE TAILGATE STOPPER STRIP. PINCH, BACK DOOR GLASS HATCH OPENER ACTUATOR	85210 87408 90502 90510 90523 90550
DECK LID HINGE DECK LID TORSION BAR RR BUMPER SHOCK ABS /STAY SPECIAL BOLT BACK DOOR LOCK & HANDLE TAIL GATE STOPPER STIPP - PINCH, BACK DOOR GLASS HATCH OPENER ACTUATOR TAILGATE WEDGE/DOVETAIL	85210 87408 90502 90510 90523 90550 90623
DECK LID HINGE DECK LID TORSION BAR RR BUMPER SHOCK ABS./STAY SPECIAL BOLT BACK DOOR LOCK & HANDLE TAILGARE STOPPER STRIP - PINCH, BACK DOOR GLASS HATCH OPENER ACTUATOR TAILGARE STOPE.	85210 87408 90502 90510 90523 90550 90623 90940
DECK LID HINGE DECK LID TORSION BAR RR BUMPER SHOCK ABS./STAY SPECIAL BOLT BACK DOOR LOCK & HANDLE TAILGATE STOPPER STRIP. PINCH, BACK DOOR GLASS HATCH OPENER ACTUATOR TAILGATE WEDGE/DOVETAIL TAILGATE HANDLE ELECTRIC DOOR MIRROR	85210 87408 90502 90510 90523 90550 90623 90940 96302
DECK LID HINGE DECK LID TORSION BAR RR BUMPER SHOCK ABS./STAY SPECIAL BOLT BACK DOOR LOCK & HANDLE TAILGATE STOPPER STRIP - PINCH, BACK DOOR GLASS HATCH OPENER ACTUATOR TAILGATE STRIP WEDGE/DOVETAIL TAILGATE HANDLE	85210 87408 90502 90510 90523 90550 90623 90940

# BODY & INTERIOR/ACCESSORIES Gold Plan.

DETERMINE

COMPONEN	P.N.C.
BODY SONIC HARNESS	28378
SENS & DIAG (PLANS PRIOR TO 1/1/99)	28558
SEAT BELT CONTROL UNIT	28570
SIDE VENT NOZZLE	66550
DEFROSTER GRILLE	68742
SIDE DEFROSTER GRILLE	68745
CENTER VENT NOZZLE	68790
SUN ROOF LOCK	73520
MOTOR - STORAGE LID OPENER	84472
RECLINING SWITCH	86401
SENSOR - PRESSURE DETECTION	86509
PASSIVE BUCKLE ASSY	86878
SEAT BELT POWER UNIT	86910
SEAT BELT SLIDE ASSY	86920
SEAT BELT LIMIT SWITCH	86970
SEAT BELT LIMIT SWITCH	86980
SWITCH-SEAT SLIDE	86982
SIDE AIRBAG HARNESS	87020
BACK VIBRATOR PLATE	87060
CUSHION VIBRATOR PLATE	87080
SLIDE, LIFT SWITCH (PWR/SEAT)	87352
FRT. SEAT LIMIT SWITCH	87504
AIR PUMP	87652
SLIDE ASSY (PWR/SEAT)	87653
LIFT ASSY (PWR/SEAT)	87654
SEAT SWIVEL ASSY	88201
2ND SEAT BACK HINGE	88350
REAR RECLINING DEVICE ASSY	88451
2ND SEAT SLIDE	88501
SLIDE ASSY,3RD SEAT	88505
REAR SEAT BACK LOCK	88603
REAR SEAT BACK STRIKER	88604
3RD SEAT HINGE ASSY	89303
SEAT LOCK ASSY	89341
LOCK ASSY-2ND SEAT	89342
RECLINING DEVICE ASSY	89401
RAIL ASSY—3RD SEAT	89552
A/T RANGE INDICATOR	96940
ASSIST AIRBAG MODULE	98515
AIRBAG MODULE	98520
SENSOR (PLANS SOLD PRIOR TO 1/1/99)	98581
SIDE AIRBAG MODULE ASSY	98830
AIRBAG ON/OFF SWITCH	98840
AIRBAG ON/OFF SWITCH HARNESS	98841
MODULE ASSY - AIR BAG PRES. DETECTION	98850

ACCY SINGRA

V.S.S ELECTRONIC MODULE	AA600
V.S.S. STATUS PANEL	AA601
V.S.S. HARNESSS	AA602
V.S.S. PIN SWITCH	AA603
V.S.S. ELECTRONIC MODULE	AA700


2019 X Constitute day

BOW ASSY #1	K1951
BOW ASSY #4	K2032
BOW ASSY #2	K2038
BOW ASSY #3	K2050
FRT. DOOR GUIDE LOCATOR/RECEIVER	K2252
REAR VIEW MIRROR	K2573
TOP STACK CONTROL SWITCH	K3086
DECK LID GAS STRUT	K3185
TOP LOGIC RELAY/JUMPER	K3353
TOP MECHANISM CLAMP ASSY	K3658
REAR SIDE WINDOW SWITCH/BEZEL FRT. DOOR GUIDE	K4412
PIN/SECONDARY PIN	K5204
DECK LID HINGE ASSY	K6658

3603 13507 s ...swertible Top

HYDRAULIC MOTOR/PUMP ASSY	K8048
HYDRAULIC CYLINDER ASSY	K8049
HOSE/BYPASS VALVE ASSY	K8097
SIDE WINDOW REGULATOR ASSY	K8098
RELAY, STORAGE OPENER	25209
RELAY, STORAGE OPEN CANCEL	25211
RELAY, TOP STK RR LOCK OPENER	25212
RELAY, TOP INTERLOCK	25213
RELAY, TRUNK LID OPENER	25221
RELAY, TRUNK LID OPEN CANCEL	25222
UNIT - FOLDING ROOF CONTROL	25313
SWITCH - LIMIT, ROOF FRONT	25365
SWITCH - LIMIT, REAR HATCH	25366
SWITCH - LIMIT, ROOF REAR	25367
STORAGE OPENER SWITCH	25383
SWITCH - TRUNK OPENER CANCEL	25385

COMPONENT	P.N.C.
SWITCH - ROOF OPENER	25465 68542
THEFT WARNING PIN SWITCH COVER - REAR FLOOR	73908
SIDE WTHRSTRP RETAINER ASSY	76871
HEADER WTHRSTRP RETAINER ASSY	76874
FINISHER - ROOF FRONT LATCH	76880
FUEL LID ACTUATOR	78852
RR PARCEL SHELF BRACKET ASSY	79926
GUIDE PIN	80520
PIN RECEIVER	80524
MOTOR - STORAGE LID OPENER	84472
SWITCH - STORAGE LID STOP	84480
TRUNK LID OPENER ACTUATOR	84680
HINGE - 3RD SEAT LOWER	89130
MOTOR - REAR HATCH CLOSURE	90552
FRAME ASSY - FOLDING ROOF	97004
NO.1 BOW ASSY	97012
NO. 2 BOW ASSY	97020
NO. 3 BOW ASSY	97040
REAR FRAME	97061
RECEIVER, PULL-DOWN LATCH	97082
PULL-DOWN CLAMP ASSY	97087
LATCH - ROOF FRPNT	97088
STAY - REAR HATCH	97089
LOCK ASSY, REAR	97090
REAR LOCK STRIKER PIN -	97092
MOTOR - FOLDING ROOF	97093
TOP FOLDING HOOK ASSY	97094
REHOOK ASSY, TOP STACK	97097
RAIL ASSY, FRONT	97100
RAIL ASSY, CENTER	97106
RAIL ASSY, REAR	97112
LINK ASSY, BALANCE	97120
MOTOR/RAIL - REAR HATCH	97125 97132
LINK, CONTROL TOP STACK FOLDING BRACKET	97142
BRACKET - FOLDING ROOF FRNT. MOUNTING	97143
BRACKET - FOLDING ROOF REAR MOUNTING	97145
BALANCE SPRING	97146
COVER RETAINER, FRONT	97155
HEADLINER RETAINER, NO. 1 BOW	97164
HEADLINER RETAINER, NO. 3 BOW	97167
PLATE - FOLDING ROOF	97173
WELT - FOLDING ROOF	97177
FRONT RAIL SHIM	97178
SHIM - FOLDING ROOF	97179
FRONT WITHRSTRP RETAINER ASSY	97180
REAR WITHRSTRP RETAINER ASSY	97184
CENTER RAIL SHIM	97188
HINGE ASSY, STORAGE LID	97240
BAR, STORAGE LID	97242
SHIM - STORAGE LID HINGE DOVETAIL ASSY, STORAGE LID	97243 97244
RECEIVER, DOVETAIL	97246
SPRING, STORAGE LID LOWER	97252
ROLLER ASSY, STORAGE LID	97254
GUIDE RAIL ASSY	97256
DOVETAIL BOLT ASSY	97259
LOCK ASSY, STORAGE LID	97260
STRIKER, STORAGE LID	97262
ACTUATOR ASSY, STORAGE OPENER	97264
FRONT STORAGE LID BUMPER	97266
CABLE ASSY, TOP STORAGE OPENER	97270
CABLE ASSY, TOP OPENER	97273
CENTER STORAGE LID BUMPER	97274
ACTUATOR ASSY, TOP OPENER	97278
FINISHER - OVERHEAD	97283
SCREEN - REAR	97530





## **NISSAN SECURITY+PLUS**




### DISCLAIMER:

THIS BROCHURE IS NOT A CONTRACT. THE BROCHURE CONTENT IS LIMITED BY SIZE. THE ENTIRE CONTRACT IS INCLUDED IN THE NISSAN SECURITY+PLUS SERVICE AGREEMENT. BE SURE TO READ YOUR SECURITY+PLUS SERVICE AGREEMENT AS ALL BENEFITS ARE SUBJECT TO THE LIMITATIONS, EXCLUSIONS, TERMS AND CONDITIONS OF THE SERVICE AGREEMENT.

### NOTICE:

In compliance with federal laws, the contents of this brochure should be interpreted and understood within the meaning of a "Service Contract" as defined in Federal Law. (See 15 USCS Sec. 2301 (8).)

Nissan, the Nissan Logo and Nissan Model Names are Nissan Trademarks.
© 2004 Nissan North America, Inc.
(800) NISSAN-1
NissanUSA.com



Component Coverage Guide





## **NISSAN SECURITY+PLUS**

## THE BEST PROTECTION FOR YOUR NISSAN

Nissan's Security+Plus Vehicle Protection Plan provides you with quality long-term mechanical protection and extra peace of mind.

It covers the most important components of your Nissan vehicle: Engine, Transmission, Steering, Drive Axle Assembly, Electrical, and many more. Repairs to these parts can run as high as \$4,000 or more. But with Security+Plus, if a covered part fails, Nissan pays...not you.

This guide lists the covered components for the Gold Preferred Security+Plus Plan, by major category, in Nissan part number code (PNC) numeric sequence. For complete information regarding other coverage features, and those excluded from coverage, contact your Nissan Dealer.

Unlike other\_service agreements, Security+Plus is exclusively for Nissan owners, and **backed by Nissan North America, Inc.**:

### NISSAN SECURITY+PLUS: THE SMART CHOICE

Nissan's Security+Plus Vehicle Protection Plan is designed for new and previously-owned Nissan vehicles—by Nissan—and offers Nissan owners:

**Cost-effective coverage** up to 7 years, or 100,000 miles, to protect your investment. Guards against loss from the escalating cost of major repairs (including parts and labor).

**Nationwide Nissan repair** at Authorized Nissan dealerships by Nissantrained technicians. No payment hassles because the dealer is paid directly by Nissan.

**Customer Assistance** available throughout the United States. Just contact your nearest Nissan dealer, or call us at 1-800-NISSAN-1.

**Optional terms of coverage** (years and miles) to fit your driving needs, and an optional zero or \$50 deductible for each eligible component repair.

Transfer Security+Plus to a new owner if you sell your Nissan before coverage expires.\*\*

**Convenient and economical coverage**, costing only pennies a day. Your Nissan dealer will be happy to explain the various financing options available to you.

The cost of **Genuine Nissan replacement parts** is included for covered repairs—not inferior substitutes.

<sup>\*</sup> In Florida, Security+Plus is backed by Nissan Extended Service Corporation, Inc., P.O. Box 191, Gardena, California 90248-0191. License #60062.

<sup>\*\*</sup> A nominal transfer fee may apply. For details, please refer to the Security+Plus Service Agreement or contact your local Nissan dealer.

# CONTENTS

ENGINE
ENGINE & INTERNAL PARTS
LUBRICATION & COOLING
FUEL SYSTEM
MANIFOLDS & TURBOCHARGER
ENGINE ELECTRICAL
FUEL INJECTION
EMISSION CONTROLS
POWER TRAIN.
PROPELLER SHAFTS & DIFFERENTIAL
CLUTCH, TRANSMISSION, TRANSAXLE & TRANSFER CASE
దారా కార్మార్ కార్మ్ మార్జ్ br>మార్జ్ కార్జ్ మార్జ్ మార్జ
STEERING, SUPENSION, BRAKES
STEERING SYSTEM
AXLES & SUSPENSION
BRAKES
ELECTRICAL
BODY ELECTRICAL
HEATER & AIR CONDITIONING
BODY & INTERIOR COMPONENTS
BODY
INTERIOR
ACCESSORIES
240SX CONVERTIBLE TOP
350Z/300ZX CONVERTIBLE TOP
AUDIO/VIDEO COMPONENTS
MOBILE ENTERTAINMENT SYSTEM
and the second material and the second of the transfer of the second of

# ENGINE Gold Preferred Plan

INTERNAL PARTS  COMPONENTS  CYLINDER BLOCK  CYLINDER BLOCK   11001  CYLINDER BLOCK   11002  CYLINDER BLOCK   11004  CYLINDER BLOCK WELSH PLUG   11001  CYLINDER HEAD COVER   11004  CYLINDER HEAD GASKET   11004  CYLINDER HEAD WELSH PLUG   11051  CYLINDER HEAD WELSH PLUG   11056  INTAKE VALVE SEAT   11098  EXHAUST VALVE SEAT   11098  EXHAUST VALVE SEAT   11098  EXHAUST VALVE SEAT   11109  CIL PAN DRAIN PLUG   11112  CIL PAN DRAIN PLUG   11112  CIL PAN DRAIN PLUG   11114  FRONT ENGINE MOUNT   11220  MOUNT TRANSMISSION LOWER   11221  CENTER MEMBER   11240  ENGINE DAMPER ASSY   11246  ENGINE DAMPER ASSY   11246  ENGINE MOUNT DAMPER   11293  CENTER MEMBER   11290  ENGINE MOUNT ACTUATOR ASSY   11273  ENGINE MOUNT DAMPER   11290  REAR ENGINE MOUNT   11325  REAR MOUNT BRACKET   11340  BUFFER   11390  CONNECTING MOUNT BRACKET   11340  BUFFER   11390  CONVE BELT   11720  TIMING BELT   11720  MOUNT SPANCKET   11291  PISTON & PIN SET   12010  CONNECTING ROD & CAP SET   12010  CONNECTING ROD BEARINGS   12013  PULLEY BOUT   12309  BALANCER UNIT   12209  BALANCER UNIT   12209  BALANCER UNIT   12209  TOANSHAFT SUSHING (OHV)   13002  IDLER GEAR   13014  CAMSHAFT   13041  COVER GASKET   13042  CAMSHAFT   13041  COVER GASKET   1	ENGINE &	MOLLINE SUPP
COMPONEN P. P.N.C CYLINDER BLOCK 11010 CYLINDER BLOCK WELSH PLUG 11021 CYLINDER HEAD 11041 CYLINDER HEAD GASKET 11044 CYLINDER HEAD GASKET 11044 CYLINDER HEAD GASKET 11056 CYLINDER HEAD WELSH PLUG 11051 CYLINDER HEAD WELSH PLUG 11051 CYLINDER HEAD WELSH PLUG 11051 CYLINDER HEAD WELSH PLUG 11056 INTAKE VALVE SEAT 11098 EXHAUST VALVE SEAT 11098 EXHAUST VALVE SEAT 11098 CYLINDER HEAD BOLT 11056 INTAKE VALVE SEAT 11098 CYLINDER HEAD BOLT 11056 INTAKE VALVE SEAT 11098 CYLINDER HEAD BOLT 11100 CIL PAN GASKET 11121 CIL PAN DRAIN PLUG 111128 DIPSTICK 11140 FRONT ENGINE MOUNT 111220 MOUNT -TRANSMISSION LOWER 11221 FRONT MOUNT BRACKET 11232 CENTER MEMBER 11240 ENGINE DAMPER ASSY 11246 COUSSET 11262 ENGINE MOUNT ACTUATOR ASSY 11273 ENGINE MOUNT DAMPER 11290 REAR ENGINE MOUNT 11325 REAR MOUNT BRACKET 11330 CROLL DAMPER ENGINE MOUNT 11325 REAR MOUNT BRACKET 11330 CROLL DAMPER ENGINE MOUNT 11325 TERAR MOUNT BRACKET 11390 CRIVE BELT 11720 TIMING BELT SENDINER BRACKET 11390 DRIVE BELT 11720 TIMING BELT 11720 TIMING BELT 11720 TIMING BELT 11720 TIMING BELT 11720 DISTON RINGS 12031 FORDING BRACKET 11390 PUSTON RINGS 12031 POSTON RINGS		
CYLINDER BLOCK WELSH PLUG         11021           CYLINDER HEAD         11041           CYLINDER HEAD COVER         11046           CYLINDER HEAD COVER         11046           CYLINDER HEAD COVER         11046           CYLINDER HEAD COVER         11046           CYLINDER HEAD BOLT         11056           INTAKE VALVE SEAT         11098           EXHAUST VALVE SEAT         11098           CIL PAN         11112           OIL PAN GASKET         11112           OIL PAN DRAIN PLUG         11128           DIPSTICK         11140           FRONT ENGINE MOUNT         11220           MOUNT - TRANSMISSION LOWER         11221           FRONT MOUNT BRACKET         11232           CENTER MEMBER         11240           GUSSET         11266           GUSSET         11266           GUSSET         11273           REAR ENGINE MOUNT         11325           REAR ENGINE MOUNT         11325           REAR ENGINE MOUNT BRACKET         11340           BUFFER         11390           DRIVE BELT         11720           SERPENTINE BELT TENSIONER BASSY         11750           SERPENTINE BELT TENSIONER BRACKET <t< td=""><td></td><td>P.N.C</td></t<>		P.N.C
CYLINDER HEAD CYLINDER HEAD GASKET 11044 CYLINDER HEAD GOVER 111046 CYLINDER HEAD WELSH PLUG 11051 CYLINDER HEAD WELSH PLUG 11051 CYLINDER HEAD BOLT 111058 EXHAUST VALVE SEAT 11099 OIL PAN 11110 OIL PAN 11110 OIL PAN GASKET 11121 OIL PAN DRAIN PLUG 11128 DIPSTICK 11126 FRONT ENGINE MOUNT 11120 FRONT ENGINE MOUNT 11121 FRONT MOUNT BRACKET 11221 FRONT MOUNT BRACKET 11232 CENTER MEMBER 11240 GUSSET 11262 ENGINE MOUNT ACTUATOR ASSY 11273 FROMINE MOUNT 11326 ENGINE MOUNT ACTUATOR ASSY 11273 RIGHNE MOUNT DAMPER 11280 REAR ENGINE MOUNT 11320 ROLL DAMPER ENGINE 11320 ROLL DAMPER EN		
CYLINDER HEAD GASKET 11044 CYLINDER HEAD COVER 11056 CYLINDER HEAD WELSH PLUG 11051 CYLINDER HEAD WELSH PLUG 11056 INTAKE VALVE SEAT 11098 EXHAUST VALVE SEAT 11098 CIL PAN 11110 OIL PAN AN 11110 OIL PAN GASKET 111121 OIL PAN GASKET 111121 OIL PAN DRAIN PLUG 111126 DISTICK 11140 FRONT ENGINE MOUNT 11220 MOUNT TRANSMISSION LOWER 11221 FRONT MOUNT BRACKET 11232 CENTER MEMBER 11240 ENGINE DAMPER ASSY 11246 ENGINE DAMPER ASSY 11246 ENGINE MOUNT ACTUATOR ASSY 11273 ENGINE MOUNT ACTUATOR ASSY 11273 ENGINE MOUNT DAMPER 11280 REAR ENGINE MOUNT 11325 REAR MOUNT BRACKET 11340 BUFFER 11390 DRIVE BELT 11720 TIMING BELT SENSIONER BRACKET 11390 ENFER BELT TENSIONER ASSY 11720 TIMING BELT 11720 CONNECTING ROD & CAP SET 12010 CONNECTING ROD BEARINGS 12013 PULLEY BOLT 1220 MAIN BEARINGS 12013 PULLEY BOLT 1220 MAIN BEARINGS 12207 REAR MAIN SEAL 12278 ROAMSHAFT BUSHING (OHV) 13002 FULLEY BOLT 12309 BALANCER UNIT 13309 CRANKSHAFT GEAR 13001 CAMSHAFT 13001 CAMSH		
CYLINDER HEAD BOLT 11051 CYLINDER HEAD BOLT 11056 INTIAKE VALVE SEAT 11098 EXHAUST VALVE SEAT 11099 OIL PAN ASKET 11110 OIL PAN DARAN PLUG 111128 DIPSTICK 111140 FRONT ENGINE MOUNT 11128 DIPSTICK 111140 FRONT ENGINE MOUNT 11220 MOUNT TRANSMISSION LOWER 11221 FRONT MOUNT BRACKET 11232 CENTER MEMBER 11240 GUSSET 11262 ENGINE MOUNT ACTUATOR ASSY 11273 RIGHIE MOUNT DAMPER 11280 REAR ENGINE MOUNT 11320 ROLL DAMPER ENGINE MOUNT 11320 ROLL DAMPER ENGINE MOUNT 11320 ROLL DAMPER SHORT 11340 BUFFER 11390 DRIVE BELT 11720 SERPENTINE BELT TENSIONER ASSY 11770 SERPENTINE BELT TENSIONER BRACKET 11927 PISTON RINGS 11033 CONNECTING ROD BEARINGS 12117 PISTON RINGS 12033 CONNECTING ROD BEARINGS 12111 PISTON COLL ET 12121 CRANKSHAFT 12200 MAIN BEARINGS 12207 PULLEY BOLT 12209 BALLANCER UNIT 12210 CAMSHAFT BUSHING (OHV) 13002 CAMSHAFT BUSHING (OHV) 13002 CAMSHAFT SPROCKET 13024 SPROCKET ASSY—VTC 13025 CRANKSHAFT GEAR 13021 CAMSHAFT GEAR 13021 CAMSHAFT FRONT OIL SEAL 13044 VAPER FRONT COVER 13035 COVER GASKET 13024 CAMSHAFT GEAR 13021 CAMSHAFT FRONT OIL SEAL 13043 VALVE DIFFER GEAR 13021 CAMSHAFT FRONT OIL SEAL 13043 VALVE SPRING SEAT 13020 VALVE SPRING SEAT 13	CYLINDER HEAD GASKET	11044
CYLINDER HEAD BOLT INTAKE WALVE SEAT I1098  OIL PAN OIL PAN OIL PAN OIL PAN GASKET OIL PAN BASKET OIL PAN BASKE		
INTAKE VALVE SEAT   11098     EXHAUST VALVE SEAT   11098     COLPAN   11110     OIL PAN SASKET   11121     OIL PAN GASKET   11121     OIL PAN GASKET   11121     OIL PAN DRAIN PLUG   11128     IPSTICK   11140     FRONT ENGINE MOUNT   11220     MOUNT - TRANSMISSION LOWER   11221     FRONT MOUNT BRACKET   11232     CENTER MEMBER   11240     ENGINE MOUNT ACTUATOR ASSY   11266     GUSSET   11262     ENGINE MOUNT ACTUATOR ASSY   11273     ENGINE MOUNT ACTUATOR ASSY   11273     ENGINE MOUNT ACTUATOR ASSY   11290     REAR ENGINE MOUNT   11325     ENGINE MOUNT DAMPER   11290     REAR ENGINE MOUNT   11325     REAR MOUNT BRACKET   11340     BUFFER   11390     CRIVE BELT   11720     TIMING BELT   11720     PISTON RINGS   12033     CONNECTING ROD & CAP SET   12010     PISTON RINGS   12033     CONNECTING ROD BEARINGS   12111     PISTON OIL JET   12121     CRANKSHAFT   12200     MAIN BEARINGS   12207     REAR MAIN SEAL   12279     CRANKSHAFT PULLEY   12303     PULLEY BOLT   12309     PULL		
DIL PAN   11110	INTAKE VALVE SEAT	11098
DIL PAN GASKET		
DIPSTICK         11140           FRONT ENGINE MOUNT         11220           RONT ENGINE MOUNT         11220           MOUNT TRANSMISSION LOWER         11221           FRONT MOUNT BRACKET         11221           ENGINE MOUNT BRACKET         11232           CENTER MEMBER         11246           GUSSET         11262           ENGINE MOUNT ACTUATOR ASSY         11273           REAR ENGINE MOUNT         11320           REAR ENGINE MOUNT         11320           REAR ENGINE MOUNT         11320           REAR MOUNT BRACKET         11340           BUFFER         11390           DRIVE BELT         11720           TIMING BELT         11720           TIMING BELT         11720           TIMING BELT         11720           SERPENTINE BELT TENSIONER BRACKET         11927           PISTON RINGS         12033           CONNECTING ROD & CAP SET         12010           CONNECTING ROD & CAP SET         12100           CONNECTING ROD BEARINGS         12211           DISTON RING         12033           CONNECTING ROD BEARINGS         12211           CRANKHAFT PULLEY         12209           MAIN BEARINGS         <		
PRONT ENGINE MOUNT   11220		
MOUNT - TRANSMISSION LOWER   11221   FRONT MOUNT BRACKET   11230   ENGINE MOUNT BRACKET   11240   ENGINE MOUNT ACTUATOR ASSY   11246   GUSSET   11260   ENGINE MOUNT ACTUATOR ASSY   11273   ENGINE MOUNT ACTUATOR ASSY   11273   ENGINE MOUNT DAMPER   11290   REAR ENGINE MOUNT   11325   REAR MOUNT BRACKET   11340   BUFFER   11390   DRIVE BELT   11720   SERPENTINE BELT TENSIONER MOUNT   11325   SERPENTINE BELT TENSIONER BRACKET   11271   SERPENTINE BELT TENSIONER BRACKET   11271   SERPENTINE BELT TENSIONER BRACKET   11270   PISTON & PIN SET   12010   PISTON RINGS   12033   CONNECTING ROD & CAP SET   12000   CONNECTING ROD & CAP SET   12100   MAIN BEARINGS   12211   PISTON & DIE   12121   CRANKSHAFT   12200   MAIN BEARINGS   12207   REAR MAIN SEAL   12278   CRANKSHAFT PULLEY   12303   PULLEY BOLT   12309   PULLEY BOLT   13001		
CENTER MEMBER 11240 ENGINE DAMPER ASSY 11246 ENGINE DAMPER ASSY 11262 ENGINE MOUNT ACTUATOR ASSY 11273 ENGINE MOUNT ACTUATOR ASSY 11273 ENGINE MOUNT ACTUATOR ASSY 11273 ENGINE MOUNT 11320 RCALL DAMPER ENGINE MOUNT 11320 RCALL DAMPER ENGINE MOUNT 11320 REAR ENGINE MOUNT 11325 ERAR MOUNT BRACKET 11340 BUFFER 11380 DEFYER 11380 DEFYER 11390 ENFERD 11720 TIMING BELT 11720 TIMING BELT 11720 TIMING BELT 11720 SERPENTINE BELT TENSIONER BRACKET 11927 PISTON & PIN SET 12010 PISTON RINGS 12031 CONNECTING ROD & CAP SET 12010 CONNECTING ROD & CAP SET 12100 CONNECTING ROD BEARINGS 12011 PISTON OIL JET 12121 CRANKSHAFT 121200 MAIN BEARINGS 12207 REAR MAIN SEAL 12278 RCARNKSHAFT PULLEY 12303 PULLEY BOLT 12309 BALANCER UNIT 12309 BALANCER UNIT 12416 CAMSHAFT 13001 CAMSHAFT 13001 CAMSHAFT BUSHING (OHV) 13002 IDLER GEAR 13014 CAMSHAFT GEAR 13014 CAMSHAFT GEAR 13021 CAMSHAFT SPROCKET 13024 SPROCKET ASSY—VTC 13025 TIMING CHAIN 13025 TIMING CHAIN 13025 TIMING CHAIN 13026 CRANKSHAFT FRONT OIL SEAL 13043 COVER GASKET 13044 VAPER NILET 13049 LIFTER GUIDE 13051 CHAIN TENSIONER SIDE GUIDE 13081 CHAIN TENSIONER SIDE GUIDE 13081 JACK SHAFT GEAR 13104 VANER NILET 13049 JACK SHAFT GEAR 13107 VALVE SPRING SEAT 13206 VALVE OIL SEAL 13303 VALVE SPRING SEAT 13206 VALVE GUIDE 13212 VALVE LIFTER 13224 VALVE CUSTER SAKET 13204 VALVE SPRING SEAT 13206 UNITER SPRING SEAT 13207 VALVE SPRING SEAT 13206 UNITER SPRING SEAT 13207 VALVE SPRING SEAT 13206 UNITER SPRING SEAT 13206 UNITER SPRING SEAT 13207 VALVE SPRING SEAT 13206 UNITER S	MOUNT - TRANSMISSION LOWER	11221
ENGINE DAMPER ASSY 11246 GUSSET 11262 GUSSET 11262 ENGINE MOUNT ACTUATOR ASSY 11273 ENGINE MOUNT ACTUATOR ASSY 11273 ENGINE MOUNT DAMPER 11290 REAR ENGINE MOUNT 11325 REAR MOUNT BRACKET 11340 BUFFER 11390 DRIVE BELT 11390 DRIVE BELT 11390 BUFFER 11390 DRIVE BELT 11390 ENERPENTINE BELT TENSIONER ASSY 11750 SERPENTINE BELT TENSIONER BRACKET 11927 PISTON & PIN SET 12010 PISTON RINGS 12033 CONNECTING ROD & CAP SET 12010 CONNECTING ROD & CAP SET 12100 CONNECTING ROD BEARINGS 12111 PISTON OIL JET 12121 CRANKSHAFT 12200 MAIN BEARINGS 12207 MAIN BEARINGS 12207 REAR MAIN SEAL 12278 CRANKSHAFT PULLEY 12033 PULLEY BOLT 12309 BALANCER UNIT 12416 CAMSHAFT BUSHING (OHV) 13002 CAMSHAFT GEAR 13021 CAMSHAFT GEAR 13021 FUEL PUMP CAM 13015 CRANKSHAFT GEAR 13021 CAMSHAFT GEAR 13024 CAMSHAFT SPROCKET 33026 FRONT COVER DATE 13049 FRONT CHAPT OF THE STAN SHAPE 13049 LIFTER GUIDE 13035 CRANKSHAFT FORD OIL SEAL 13042 CAMSHAFT OIL SEAL 13042 CAMSHAFT OIL SEAL 13042 CAMSHAFT GEAR 13021 CAMSHAFT GEAR 13024 CAMSHAFT OIL SEAL 13042 CAMSHAFT GEAR 13024 CAMSHAFT OIL SEAL 13042 CAMSHAFT OIL SEAL 13042 CAMSHAFT OIL SEAL 13042 CAMSHAFT OIL SEAL 13044 WATER INLET 13049 LIFTER GUIDE 13081 JACK SHAFT GEAR 13170 INING CHAIN OIL JET 13081 JACK SHAFT GEAR 13170 INING CHAIN OIL JET 13081 JACK SHAFT GEAR 13170 INING CHAIN OIL JET 13081 JACK SHAFT GEAR 13170 INING CHAIN OIL JET 13081 JACK SHAFT GEAR 13170 INING CHAIN OIL JET 13081 JACK SHAFT GEAR 13170 INING CHAIN OIL JET 13081 JACK SHAFT GEAR 13170 INING CHAIN OIL JET 13081 VALVE SPRING SEAT 13260 VALVE ROCKER COVER 13260 VALVE ROCKER SHAFT SPRING 13255 VALVE ROCKER SHAFT SPRING 13256 VALVE ROCKER SHAFT SPRING 13256 VALVE ROCKER SHAFT SPRING 13256 VALVE ROCKER SHAFT SPRING		
ENGINE MOUNT ACTUATOR ASSY ENGINE MOUNT DAMPER 11290 REAR ENGINE MOUNT 11320 ROLL DAMPER ENGINE MOUNT 11325 REAR MOUNT BRACKET 11340 BUFFER 11390 DRIVE BELT 11720 TIMING BELT 11720 TIMING BELT 11720 TIMING BELT 11720 SERPENTINE BELT TENSIONER ASSY 11927 PISTON & PIN SET 12010 SERPENTINE BELT TENSIONER BRACKET 11927 PISTON RINGS 12033 CONNECTING ROD & CAP SET 12010 CONNECTING ROD BEARINGS 12111 PISTON CILL JET 12200 MAIN BEARINGS 12207 REAR MAIN SEAL 12279 CRANKSHAFT 12200 MAIN BEARINGS 12207 REAR MAIN SEAL 12279 CRANKSHAFT PULLEY 12303 PULLEY BOLT 12303 PULLEY BOLT 12303 PULLEY BOLT 12304 BALANCER UNIT 12416 CAMSHAFT BUSHING (OHV) 13002 LOLER GEAR 13014 CAMSHAFT GEAR 13014 CAMSHAFT GEAR 13021 CAMSHAFT GEAR 13024 CAMSHAFT GEAR 13025 CRANKSHAFT FONT OIL SEAL 13025 TIMING CHAIN 13025 CRANKSHAFT FONT OIL SEAL 13042 CAMSHAFT SEAL 13043 COVER GASKET 13044 CAMSHAFT GEAR 13041 CAMSHAFT GEAR 13042 CAMSHAFT GEAR 13043 COVER GASKET 13044 CAMSHAFT GEAR 13045 LIFTER GUIDE 13051 CHAIN TENSIONER 13064 JACK SHAFT GEAR 13161 JACK SHAFT GEAR 13170 VALVE SPRING SEAT 13205 VALVE SPRING SEAT 13207 VALVE SPRING SEAT 13207 VALVE SPRING SEAT 13207 VALVE SPRING SEAT 13208 VALVE SPRING SEAT 13209 VALVE SPRING SEAT 13209 VALVE SPRING SEAT 13209 VALVE SPRING SEAT 13207 VALVE SPRING SEAT 13207 VALVE SPRING SEAT 13208 VALVE SPRING SEAT 13207 VALVE SPRING SEAT 13208 VALVE PRING SEAT 13209 VALVE SPRING SEAT 13209 VALVE GUIDE 13212 VALVE LIFTER 13260 USER PASSAGE 13201 VALVE PRING SEAT 13202 VALVE SPRING SEAT 13203 VALVE PRING SEAT 13206 DISTRAINS SEAT 13206 DISTRAINS SEAT 13207 VALVE SPRING SEAT 13207 VALVE SPRING SEAT 13208 VALVE PRING SEAT 13209 VALVE GUIDE 13217 VALVE SPRING SEAT 13209 VALVE SPRING SEAT 13209 VALVE GUIDE 13217 VALVE LIFTER 13209 VALVE GUIDE 13217 VALVE LIFTER 13209 VALVE SPRING SEAT 13201 VALVE SPRING SEAT 13203 VALVE SPRING SEAT 13206 DISTRAINS SEAT 13206 DISTRAINS SEAT 13206 DISTRAINS SEAT 13206 DISTRAI		
ENGINE MOUNT DAMPER 11290 REAR ENGINE MOUNT 11320 REAR MOUNT BRACKET 11340 BUFFER 11390 ROLL DAMPER ENGINE MOUNT 11325 REAR MOUNT BRACKET 11340 BUFFER 11390 ROLL DAMPER ENGINE MOUNT 11325 REAR MOUNT BRACKET 11390 SURVE BELT 11720 TIMING BELT 11720 TIMING BELT 11720 TIMING BELT 11720 SERPENTINE BELT TENSIONER ASSY 11750 SERPENTINE BELT TENSIONER BRACKET 11927 PISTON & PIN SET 12010 PISTON RINGS 12033 CONNECTING ROD & CAP SET 12010 PISTON OIL JET 12121 CRANKSHAFT 12200 CONNECTING ROD BEARINGS 12111 PISTON OIL JET 12121 CRANKSHAFT 12207 REAR MAIN SEAL 12279 CRANKSHAFT PULLEY 12303 BALANCER UNIT 12416 CAMSHAFT BUSHING (OHV) 13002 DIELR GEAR 13001 CAMSHAFT BUSHING (OHV) 13002 DIELR GEAR 13001 CAMSHAFT GEAR 13001 CRANKSHAFT GEAR 13021 CRANKSHAFT GEAR 13024 CAMSHAFT SPROCKET 13024 SPROCKET ASSY—VTC 13025 FRONT COVER 13025 FRONT COVER 13035 CRANKSHAFT FONT OIL SEAL 13042 CAMSHAFT OIL SEAL 13042 CAMSHAFT OIL SEAL 13043 COVER CASKET 13044 WATER INLET 13049 UIFTER GUIDE 13051 CHAIN TENSIONER 13070 TIMING CHAIN 0IL JET 13081 JACK SHAFT GEAR 13070 TIMING CHAIN OIL JET 13081 JACK SHAFT GEAR 13070 TIMING CHAIN OIL JET 13081 JACK SHAFT GEAR 13070 TIMING CHAIN OIL JET 13081 JACK SHAFT GEAR 13070 TIMING CHAIN OIL JET 13081 JACK SHAFT GEAR 13070 TIMING CHAIN OIL JET 13081 JACK SHAFT GEAR 13070 TIMING CHAIN OIL JET 13081 JACK SHAFT GEAR 13070 TIMING CHAIN OIL JET 13081 JACK SHAFT GEAR 13070 TIMING CHAIN OIL JET 13081 JACK SHAFT GEAR 13070 TIMING CHAIN OIL JET 13081 JACK SHAFT GEAR 13070 TIMING CHAIN OIL JET 13081 JACK SHAFT GEAR 13070 TIMING CHAIN OIL JET 13081 JACK SHAFT GEAR 13070 TIMING CHAIN FERSIONER 13200 VALVE SPRING SEAT 13200 VALVE SPRING CETAR TO THE TOTOL SEAL 13201 VALVE PROVOT (L'ENGINE) 13265 VALVE ROCKER COVER 13360 DI STRAINER 150500 DIPSTICK TUBE 1555 OIL FILLER CAP 15255 OIL FILLER CAP 15255 OIL FILLE		
REAR ENGINE MOUNT 11325 ROLL DAMPER ENGINE MOUNT 11325 REAR MOUNT BRACKET 11340 BUFFER 11390 DRIVE BELT 11720 TIMING BELT 11720 SERPENTINE BELT TENSIONER ASSY 11750 SERPENTINE BELT TENSIONER BRACKET 11927 PISTON & PIN SET 12010 CONNECTING ROD & CAP SET 12100 CONNECTING ROD & CAP SET 12100 CONNECTING ROD BEARINGS 12111 PISTON OIL JET 12121 CRANKSHAFT 12200 MAIN BEARINGS 12207 CRANKSHAFT PULLEY 12303 PULLEY BOLT 12309 BALLANCER UNIT 12416 CAMSHAFT BUSHING (OHV) 13002 CAMSHAFT BUSHING (OHV) 13001 CAMSHAFT BUSHING (OHV) 13001 CAMSHAFT GEAR 13021 CAMSHAFT GEAR 13021 CAMSHAFT GEAR 13021 CAMSHAFT SPROCKET 13024 SPROCKET ASSY—VIC 13025 TIMING CHAIN 13025 TIMING CHAIN 13025 CRANKSHAFT FORDAT OIL SEAL 13041 CAMSHAFT T GEAR 13024 CAMSHAFT SPROCKET 13024 CAMSHAFT T GEAR 13021 CAMSHAFT SPROCKET 13025 TIMING CHAIN 13025 CRANKSHAFT FORDAT OIL SEAL 13042 CAMSHAFT FORDAT OIL SEAL 13042 CAMSHAFT GEAR 13021 CAMSHAFT GEAR 13025 CRANKSHAFT FORDAT OIL SEAL 13042 CAMSHAFT GEAR 13025 CRANKSHAFT FORDAT OIL SEAL 13042 CAMSHAFT GEAR 13025 CRANKSHAFT FORDAT OIL SEAL 13042 CAMSHAFT GEAR 13024 CAMSHAFT GEAR 13025 CRANKSHAFT FORDAT OIL SEAL 13042 CAMSHAFT GEAR 13025 CRANKSHAFT GEAR 13025 CRANKSHAFT GEAR 13024 CAMSHAFT GIL SEAL 13043 CAMSHAFT GIL SEAL 13043 VALVE SPRING CHAIN OIL JET 13081 CHAIN TENSIONER 13069 CHAIN TENSIONER SIDE GUIDE 13085 CHAIN TENSIONER SIDE GUIDE 13081 CHAIN TENSIONER 13201 VALVE SPRING SEAT 13201 VALVE SPRING SEAT 13201 VALVE SPRING SEAT 13201 VALVE SPRING SEAT 13205 COVER GASKET 13200 VALVE SPRING SEAT 13205 COVER GASKET 13200 COVER GASKE		
REAR MOUNT BRACKET 11340 BUFFER 11390 DUFFER 11391 TIMING BELT 113720 TIMING BELT 11720 TIMING BELT 11720 TIMING BELT 11720 SERPENTINE BELT TENSIONER ASSY 11750 SERPENTINE BELT TENSIONER BRACKET 11927 PISTON & PIN SET 12010 PISTON RINGS 12033 CONNECTING ROD & CAP SET 12010 CONNECTING ROD & CAP SET 12100 CONNECTING ROD & CAP SET 12110 PISTON OIL JET 12121 CRANKSHAFT 12200 REAR MAIN SEAL 12279 CRANKSHAFT PULLEY 12033 BALANCER UNIT 12416 CAMSHAFT PULLEY 12030 BALANCER UNIT 12416 CAMSHAFT BUSHING (OHV) 13002 DILER GEAR 13014 FUEL PUMP CAM 13015 CRANKSHAFT GEAR 13021 CAMSHAFT GEAR 13024 CAMSHAFT GEAR 13024 CAMSHAFT GEAR 13024 CAMSHAFT GEAR 13024 CAMSHAFT SPROCKET 13024 SPROCKET ASSY—VTC 13025 FRONT COVER 13035 CRANKSHAFT FRONT OIL SEAL 13043 COVER GASKET 13044 WATER INLET 13049 LIFTER GUIDE 13095 CHAIN TENSIONER SIDE GUIDE 13095 LIFTER GUIDE 13091 CHAIN TENSIONER SIDE GUIDE 13095 LIFTER GUIDE 13091 CHAIN TENSIONER SIDE GUIDE 13095 LOKES SHAFT GEAR 13107 TIMING CHAIN OIL JET 13081 JACK SHAFT GEAR 13107 TIMING CHAIN OIL JET 13081 JACK SHAFT GEAR 13170 CHAIN TENSIONER SIDE GUIDE 13095 LOKES SHAFT GEAR 13170 TIMING CHAIN OIL JET 13081 JACK SHAFT GEAR 13170 TIMING CHAIN OIL JET 13081 JACK SHAFT GEAR 13170 TIMING CHAIN OIL JET 13081 JACK SHAFT GEAR 13170 TIMING CHAIN OIL JET 13081 JACK SHAFT GEAR 13170 TIMING CHAIN OIL JET 13081 JACK SHAFT GEAR 13170 TIMING CHAIN OIL JET 13081 JACK SHAFT GEAR 13170 TIMING CHAIN OIL JET 13081 JACK SHAFT GEAR 13170 TIMING CHAIN OIL JET 13081 JACK SHAFT GEAR 13170 TIMING CHAIN OIL JET 13081 JACK SHAFT GEAR 13170 TIMING CHAIN OIL JET 13081 JACK SHAFT GEAR 13170 TIMING CHAIN OIL JET 13081 JACK SHAFT GEAR 13170 TIMING CHAIN FEAR COVER 13260 VALVE OIL SEAL 13201 VALVE SPRING SEAT 13200 VAL	REAR ENGINE MOUNT	11320
BUFFER		
TIMING BELT  SERPENTINE BELT TENSIONER ASSY  11750  SERPENTINE BELT TENSIONER BRACKET  11927  PISTON & PIN SET  12010  PISTON & PIN SET  12010  PISTON RINGS  12033  CONNECTING ROD & CAP SET  12100  CONNECTING ROD BEARINGS  12111  PISTON OIL JET  CRANKSHAFT  12207  REAR MAIN SEAL  12279  CRANKSHAFT PULLEY  12308  BALANCER UNIT  12416  CAMSHAFT PULLEY  12309  BALANCER UNIT  12416  CAMSHAFT  13001  FUEL PUMP CAM  13015  CRANKSHAFT GEAR  13014  FUEL PUMP CAM  13015  CRANKSHAFT GEAR  13024  CAMSHAFT GEAR  13024  CAMSHAFT GEAR  13024  CAMSHAFT GEAR  13025  CRANKSHAFT FONT OIL SEAL  13025  FRONT COVER  FRONT COVER  13044  WATER INLET  13043  COVER GASKET  13044  WATER INLET  13049  LIFTER GUIDE  13041  CHAIN TENSIONER SIDE GUIDE  13057  CHAIN TENSIONER SIDE GUIDE  13068  JACK SHAFT GEAR  13107  TIMING CHAIN OIL JET  13081  JACK SHAFT GEAR  13107  TIMING CHAIN OIL JET  13081  JACK SHAFT GEAR  13170  TIMING CHAIN OIL JET  13081  JACK SHAFT GEAR  13170  LHAIN TENSIONER SIDE GUIDE  13061  JACK SHAFT GEAR  13161  JACK SHAFT GEAR  13207  VALVE SPRING SEAL  13208  VALVE SPRING SEAL  13207  VALVE SPRING SEAL  13208  VALVE SPRING SEAL  13207  VALVE SPRING SEAT  13207  VALVE SPRING SEAT  13207  VALVE SPRING SEAT  13208  VALVE ROCKER SHAFT  13209  VALVE ROCKER COVER  13264  VALVE ROCKER SHAFT  13225  VALVE ROCKER SHAFT  13225  VALVE ROCKER SHAFT  13226  VALVE ROCKER COVER  13260  VALVE ROCKER COVER  13260  VALVE ROCKER COVER  13260  VALVE ROCKER COVER  13260  VALVE ROCKER SHAFT  13225  VALVE ROCKER SHAFT  13225  VALVE ROCKER SHAFT  13260  DISTRAINER  13260  DISTRAINER  13260  DISTRAINER  15050  DIPSTICK TUBE  01. STRAINER  15050  DIPSTICK TUBE		
SERPENTINE BELT TENSIONER BRACKET         11750           SERPENTINE BELT TENSIONER BRACKET         11927           PISTON & PIN SET         12010           PISTON RINGS         12013           CONNECTING ROD & CAP SET         12100           CONNECTING ROD & CAP SET         12101           PISTON OIL JET         12111           PISTON OIL JET         12121           CRANKSHAFT         12200           MAIN BEARINGS         12207           CRANKSHAFT PULLEY         12030           BALLANCER UNIT         12416           CAMSHAFT PULLEY         13031           PULLEY BOLT         13001           CAMSHAFT DUT         13001           CAMSHAFT BOLH (DIV)         13002           CAMSHAFT GEAR         13011           FUEL PUMP CAM         13015           CRANKSHAFT GEAR         13024           CAMSHAFT GEAR         13024           CAMSHAFT SPROCKET         13024           SPROCKET ASSY—VIC         13025           TIMING CHAIN         13028           FRONT COVER         13035           CRANKSHAFT FORD OIL SEAL         13042           CAMSHAFT OIL SEAL         13042           CAMSHAFT OIL SEAL		
SERPENTINE BELT TENSIONER BRACKET   11927     PISTON IN SET   12010     PISTON RINGS   12033     CONNECTING ROD & CAP SET   12100     CONNECTING ROD BEARINGS   12111     PISTON CILL BET   12121     CRANKSHAFT   12200     MAIN BEARINGS   12207     REAR MAIN SEAL   12279     CRANKSHAFT PULLEY   12303     PULLEY BOLT   12309     BALANCER UNIT   12416     CAMSHAFT BUSHING (OHV)   13002     DLER GEAR   13014     FUEL PUMP CAM   13015     CRANKSHAFT GEAR   13021     CAMSHAFT GEAR   13024     CAMSHAFT SEAR   13024     CAMSHAFT SPROCKET   13024     SPROCKET ASSY—VTC   13025     TIMING CHAIN   13002     CRANKSHAFT FRONT OIL SEAL   13042     CAMSHAFT OIL SEAL   13043     CRANKSHAFT FRONT OIL SEAL   13042     CAMSHAFT OIL SEAL   13043     CAMSHAFT GEAR   13044     VAIER INLET   13049     LIFTER GUIDE   13051     CHAIN TENSIONER   13061     CHAIN TENSIONER   13070     CHAIN TENSIONER   13070     CHAIN TENSIONER SIDE GUIDE   13081     JACK SHAFT GEAR   13202     VALVE SPRING SEAT   13202     VALVE SPRING SEAT   13203     VALVE SPRING SEAT   13203     VALVE SPRING SEAT   13203     VALVE SPRING SEAT   13204     VALVE SPRING SEAT   13205     VALVE SPRING SEAT   13207     VALVE SPRING SEAT   13208     VALVE SPRING SEAT   13207     VALVE SPRING SEAT   13208     VALVE SPRING SEAT   13208     VALVE OLISEAL   13207     VALVE SPRING SEAT   13208     VALVE OLISEAL   13207     VALVE SPRING SEAT   13208     VALVE SPRING SEAT   13208     VALVE OLISEAL   13207     VALVE SPRING SEAT   13208     VALVE OLISEAL   13208     VALVE OLISEAL   13207     VALVE OLISEAL   13208     VALVE OLISEAL   13209     VALVE OLISEAL   13206     VALVE OLISEAL   13207     VALVE OLISEAL   13208     VALVE OLISEAL   13208     VALVE OLISEAL   13209     VALVE OLISEAL   13209     VALVE OLISEAL   13209     VALVE OLISEAL   13209     VALVE OLISEAL   13200     VALVE		
PISTON RINGS 12033 CONNECTING ROD & CAP SET 12100 CONNECTING ROD BEARINGS 12111 PISTON OIL JET 12121 CRANKSHAFT 12200 MAIN BEARINGS 12207 REAR MAIN SEAL 12273 CRANKSHAFT PULLEY 12303 PULLEY BOLT 12309 BALANCER UNIT 12416 CAMSHAFT BUSHING (OHV) 13002 COMBERT BUSHING (OHV) 13002 COMBRET BUSHING (OHV) 13001 COMBRET BUSHING (OHV) 13015 CRANKSHAFT GEAR 13011 FUEL PUMP CAM 13015 CRANKSHAFT GEAR 13021 CAMSHAFT GEAR 13024 CAMSHAFT OIL SEAL 13024 CAMSHAFT OIL SEAL 13024 CAMSHAFT OIL SEAL 13042 CAMSHAFT OIL SEAL 13043 CRANKSHAFT GEAR 13024 CAMSHAFT OIL SEAL 13044 UFIER GUIDE 13051 CRANKSHAFT GEAR 13064 UFIER GUIDE 13051 CHAIN TENSIONER 13070 TIMING CHAIN 0IL JET 13081 CHAIN TENSIONER 13070 TIMING CHAIN OIL JET 13081 JACK SHAFT GEAR 13170 JACK SHAFT GEAR 13170 JACK SHAFT GEAR 13170 JACK SPRING CHAIN 13202 VALVE SPRING SEAL 13201 VALVE SPRING SEAL 13202 VALVE SPRING SEAT 13202 VALVE SPRING SEAT 13202 VALVE SPRING SEAT 13202 VALVE SPRING SEAT 13203 VALVE SPRING SEAT 13205 VALVE ROCKER SHAFT 13265 VALVE ROCKER COVER 13264 VALVE ROCKER COVER 13266 VALVE ROCKER COVER 13260 UNIT COVER GASKET 13200 DUST	SERPENTINE BELT TENSIONER BRACKET	11927
CONNECTING ROD & CAP SET 12100 CONNECTING ROD BEARINGS 12111 PISTON OIL BET 12121 CRANKSHAFT 12200 MAIN BEARINGS 12207 MAIN BEARINGS 12207 REAR MAIN SEAL 12279 CRANKSHAFT PULLEY 12303 PULLEY BOLT 12309 BALANCER UNIT 12416 CAMSHAFT BUSHING (OHV) 13002 CAMSHAFT BUSHING (OHV) 13002 CAMSHAFT BUSHING (OHV) 13001 CAMSHAFT GEAR 13011 FUEL PUMP CAM 13015 CRANKSHAFT GEAR 13021 CAMSHAFT GEAR 13021 CAMSHAFT SPROCKET 13024 SPROCKET ASSY—VTC 13025 TIMING CHAIN 13002 CRANKSHAFT GEAR 13021 CAMSHAFT GEAR 13021 CAMSHAFT GEAR 13024 CAMSHAFT SPROCKET 13024 SPROCKET ASSY—VTC 13025 TIMING CHAIN 13002 CRANKSHAFT FRONT OIL SEAL 13043 CAMSHAFT OIL SEAL 13043 CAMSHAFT GEAR 13044 WATER INLET 13044 WATER INLET 13049 LIFTER GUIDE 13051 CHAIN TENSIONER 13070 TIMING CHAIN OIL JET 13081 CHAIN TENSIONER 13070 TIMING CHAIN OIL JET 13081 JACK SHAFT GEAR 13170 NITAKE VALVE 13202 VALVE SPRING SEAL 13203 VALVE SPRING SEAT 13205 VALVE SPRING SEAT 13207 VALVE SPRING SEAT 13205 VALVE SPRING SEAT 13207 VALVE SPRING SEAT 13205 VALVE OIL SEAL 13207 VALVE SPRING SEAT 13205 VALVE PRING SEAT 13205 VALVE SPRING SEAT 13205 VALVE PRING SEAT		
PISTON CIL JET 12121 CRANKSHAFT 12200 REAR MAIN SEAL 12279 CRANKSHAFT 12207 REAR MAIN SEAL 12279 CRANKSHAFT PULLEY 12303 BALANCER UNIT 12416 CAMSHAFT PULLEY 12309 BALANCER UNIT 12416 CAMSHAFT USHING (OHV) 13002 IDLER GEAR 13014 FUEL PUMP CAM 13015 CRANKSHAFT GEAR 13021 CRANKSHAFT GEAR 13024 CAMSHAFT GEAR 13024 CAMSHAFT GEAR 13024 CAMSHAFT TORAN 13025 REAN 13024 CAMSHAFT SPROCKET 13024 SPROCKET ASSY—VTC 13025 FRONT COVER 13035 CRANKSHAFT FRONT OIL SEAL 13043 COVER GASKET 13044 WATER INLET 13049 LIFTER GUIDE 13041 WATER INLET 13049 LIFTER GUIDE 13051 CHAIN TENSIONER SIDE GUIDE 13061 LACK SHAFT GEAR 13170 INTIAKE WALVE 13201 KALVE SPRING SEAT 13202 VALVE SPRING SEAT 13202 VALVE SPRING SEAT 13203 VALVE SPRING SEAT 13204 VALVE GUIDE 13221 VALVE PIVOT (L'ENGINE) 13225 VALVE ROCKER COVER 13260 VALVE ROCKER COV		
CRANKSHAFT         12200           MAIN BEARINGS         12207           CRANKSHAFT PULLEY         12303           PULLEY BOLT         12303           PULLEY BOLT         12303           BALLANCER UNIT         12416           CAMSHAFT         13001           CAMSHAFT BUSHING (OHV)         13002           CAMSHAFT BUSHING (OHV)         13001           CAMSHAFT GEAR         13014           FUEL PUMP CAM         13015           CRANKSHAFT GEAR         13024           CAMSHAFT GEAR         13024           CAMSHAFT SPROCKET         13024           SPROCKET ASSY—VTC         13025           TIMING CHAIN         13028           RERONT COVER         13035           CRANKSHAFT FRONT OIL SEAL         13042           CAMSHAFT I SEAL         13043           LIFTER GUIDE         13051           CHAIN TENSIONER 13064         13049           LIFTER GUIDE         13061           CHAIN TENSIONER 13070         13081           CHAIN TENSIONER 13070         13081           CHAIN TENSIONER 13161         13161           JACK SHAFT GEAR         13170           VALVE SPRING         13201		
MAIN BEARINGS 12207 REAR MAIN SEAL 12279 CRAMSHAFT PULLEY 12303 PULLEY BOLT 12309 PULLEY BOLT 12309 PULLEY BOLT 12309 PULLEY BOLT 12309 PULLEY BOLT 13001 CAMSHAFT 13001 CAMSHAFT BUSHING (OHV) 13002 IDLER GEAR 13001 CRANSHAFT GEAR 13014 CRANSHAFT GEAR 13015 CRANKSHAFT GEAR 13021 CAMSHAFT GEAR 13022 CAMSHAFT GEAR 13024 SPROCKET ASSY—VTC 13025 SPROCKET ASSY—VTC 13025 STIMING CHAIN 13028 CRANKSHAFT FRONT OIL SEAL 13043 COVER GASKET 13044 CAMSHAFT OIL SEAL 13043 COVER GASKET 13044 CAMSHAFT OIL SEAL 13043 COVER GASKET 13044 WATER INLET 13049 LIFTER GUIDE 13051 CHAIN TENSIONER 13070 TIMING CHAIN OIL JET 13081 JACK SHAFT JESEAL 13168 JACK SHAFT GEAR 13170 NITAKE VALVE 13201 CHAIN TENSIONER SIDE GUIDE 13085 JACK SHAFT GEAR 13170 NITAKE VALVE 13201 VALVE SPRING SEAT 13202 VALVE SPRING SEAT 13203 VALVE SPRING SEAT 13203 VALVE SPRING SEAT 13203 VALVE SPRING SEAT 13205 VALVE GUIDE 13212 VALVE LIFTER 13231 VALVE PROCKER SAKET 13205 FRONT COVER GASKET 13205 FRONT COVER GASKET 13205 FRONT COVER GASKET 13205 FRONT COVER GASKET 13205 VALVE ROCKER SHAFT SPRING 13256 VALVE ROCKER SHAFT SPRING 13256 VALVE ROCKER COVER 13360 INSTRAINER 15050 DIPSTICK TUBE 15155 OIL FILLER CAP 15255 OIL FILLER CAP 15255 OIL FILLER CAP 15255 OIL FILLER CAP 15255 OIL FILLER CAP 15555 OIL FILLER CAP 15555 OIL FILLER CAP 15605		
CRANKSHAFT PULLEY   12303	MAIN BEARINGS	12207
PULLEY BOLT 12309 BALANCER UNIT 12416 CAMSHAFT 13001 CAMSHAFT BUSHING (OHV) 13002 IDLER GEAR 13014 PULL PUIMP CAM 13015 CRANKSHAFT GEAR 13014 CRANKSHAFT GEAR 13021 CAMSHAFT GEAR 13022 CAMSHAFT GEAR 13024 SPROCKET ASSY—VTC 13025 SPROCKET ASSY—VTC 13025 SPROCKET ASSY—VTC 13025 STIMING CHAIN 13028 CRANKSHAFT FERONT OIL SEAL 13042 CAMSHAFT OIL SEAL 13043 COVER GASKET 13044 WATER INLET 13049 LIFTER GUIDE 13051 CHAIN TENSIONER 13070 TIMING CHAIN OIL JET 13081 JACK SHAFT GEAR 13168 JACK SHAFT GEAR 13168 JACK SHAFT GEAR 13170 NITAKE VALVE 13201 VALVE SPRING SEAT 13202 VALVE SPRING SEAT 13203 VALVE SPRING SEAT 13205 VALVE GUIDE 13212 VALVE LIFTER 13231 VALVE PROCKER SHAFT SPRING 13237 VALVE SPRING SEAT 13205 VALVE GUIDE 13212 VALVE LIFTER 13231 VALVE PROCKER SHAFT SPRING 13256 VALVE ROCKER COVER 13260 ROCKER COVER 13260 UNITAK OF THE WATER SHAFT SPRING 13256 VALVE ROCKER COVER 13260 UNITAK OF THE WATER SHAFT SPRING 13256 VALVE ROCKER COVER 13360 DIPSTICK TUBE 15155 OIL FILLER CAP 15255 OIL FILLER CAP 15605		
CAMSHAFT   13001	PULLEY BOLT	
CAMSHAFT BUSHING (OHV)   13002		
DLER GEAR		
CRANKSHAFT GEAR         13021           CAMSHAFT GEAR         13024           CAMSHAFT SPROCKET         13024           SPROCKET ASSY—VTC         13025           TIMING CHAIN         13028           FRONT COVER         13035           CRANKSHAFT FRONT OIL SEAL         13042           CAMSHAFT OIL SEAL         13042           CAMSHAFT OIL SEAL         13042           CAMSHAFT OIL SEAL         13049           LIFTER GUIDE         13051           CHAIN TENSIONER         13070           THIMING CHAIN OIL JET         13081           CHAIN TENSIONER SIDE GUIDE         13085           JACK SHAFT         13161           JACK SHAFT GEAR         13176           JACK SHAFT GEAR         13176           NALVE SPRING         13201           VALVE SPRING         13202           VALVE SPRING SEAT         13202           VALVE SPRING SEAT         13203           VALVE SPRING SEAT         13203           VALVE SPRING SEAT         13209           VALVE SPRING SEAT         13209           VALVE SPRING SEAT         13209           VALVE SPRING SEAT         13220           VALVE SPRING SEAT         13220		
CAMSHAFT GEAR 13024 CAMSHAFT SPROCKET 13024 CAMSHAFT SPROCKET 13025 TIMING CHAIN 13028 FRONT COVER 13025 FRONT COVER 13035 CRANKSHAFT FRONT OIL SEAL 13042 CAMSHAFT OIL SEAL 13043 COVER GASKET 13044 WATER INLET 13049 LIFTER GUIDE 13051 CHAIN TENSIONER 13070 TIMING CHAIN OIL JET 13081 JACK SHAFT OIL SEAL 13161 VALVE SPRING GEAR 13370 VALVE SPRING SEAL 13201 VALVE SPRING SEAL 13201 VALVE SPRING SEAT 13201 VALVE OIL SEAL 13202 VALVE SPRING SEAT 13205 VALVE CIL SEAL 13207 VALVE CIL SEAL 13205 VALVE OIL SEAL 13207 VALVE CIL SEAL 13207 VALVE COLKERSHAFT SPRING 13203 VALVE COLK SPRING SEAT 13205 VALVE COLK SPRING SEAT 13205 VALVE COLK SPRING SEAT 13205 VALVE COLK SPRING SEAT 13207 VALVE COCKER SHAFT SPRING 13256 VALVE ROCKER SHAFT SPRING 13256 VALVE ROCKER COVER 13260 VALVE ROCKER COVER 13260 VALVE ROCKER SHAFT SPRING 13266 VALVE ROCKER SHAFT SPRING		
SPROCKET ASSY—VTC   13025	CAMSHAFT GEAR	13024
TIMING CHAIN 13028 FRONT COVER 13035 CRANKSHAFT FRONT OIL SEAL 13042 CAMSHAFT OIL SEAL 13043 COVER GASKET 13044 WATER INLET 13049 LIFTER GUIDE 13051 CHAIN TENSIONER 13070 LIFTER GUIDE 13051 CHAIN TENSIONER 13070 LIMING CHAIN OIL JET 13081 CHAIN TENSIONER SIDE GUIDE 13085 JACK SHAFT 13161 JACK SHAFT OIL SEAL 13168 JACK SHAFT GEAR 13170 INTAKE VALVE 13201 VALVE SPRING 13202 VALVE SPRING SEAT 13203 VALVE SPRING SEAT 13203 VALVE SPRING SEAT 13204 VALVE GUIDE 13229 VALVE GUIDE 13212 VALVE LIFTER 13231 VALVE PROCKER SHAFT SPRING 13234 ROCKER SHAFT 13256 VALVE COLLETER 13231 VALVE PROCKER SHAFT SPRING 13256 VALVE COLLETER 13231 VALVE PROCKER SHAFT SPRING 13256 VALVE ROCKER SHAFT SPRING 13256 VALVE ROCKER COVER 13264 ROCKER COVER 13260 LITEMON COVER GASKET 13250 UNIT COVER GASKET 13250 LITEMON COVER GASKET 13500 LITEMON COVER GASKET 13500 LITEMON COVER GASKET 13500 LITEMON COVER GASKET 15050 DIPSTICK TUBE 15155 OIL FILLER CAP 15255 OIL FILLER CAP 15255 OIL FILLER CAP 15255 OIL FILLER CAP 15505 OIL FILLER CAP 15505 OIL FILLER CAP 15505 OIL FILLER CAP 15605	CAMSHAFT SPROCKET	
CRANKSHAFT FRONT OIL SEAL         13042           CAMSHAFT OIL SEAL         13043           COVER GASKET         13044           WATER INLET         13049           LIFTER GUIDE         13051           CHAIN TENSIONER         13070           TIMING CHAIN OIL JET         13081           CHAIN TENSIONER SIDE GUIDE         13085           JACK SHAFT         13161           JACK SHAFT GEAR         13170           INTAKE WALVE         13201           WALVE SPRING         13203           VALVE SPRING SEAT         13203           VALVE SPRING SEAT         13203           VALVE SPRING RETAINER         13209           VALVE SPRING RETAINER         13209           VALVE GUIDE         13212           VALVE PIVOT (L'ENGINE)         13234           VOEVER SHAFT         13233           VALVE PIVOT (L'ENGINE)         13234           VOEVER CEKER SAKET         13250           VALVE ROCKER COVER         13266	TIMING CHAIN	
CAMSHAFT OIL SEAL         13043           COVER GASKET         13044           WATER INLET         13049           LIFTER GUIDE         13051           CHAIN TENSIONER         13070           TIMING CHAIN OIL JET         13081           CHAIN TENSIONER SIDE GUIDE         13085           JACK SHAFT         13161           JACK SHAFT OIL SEAL         13160           JACK SHAFT GEAR         13170           INTAKE VALVE         13201           EXHAUST VALVE         13202           VALVE SPRING         13203           VALVE SPRING SEAT         13205           VALVE OIL SEAL         13207           VALVE OIL SEAL         13207           VALVE SPRING RETAINER         13209           VALVE GUIDE         13212           VALVE LIFTER         13231           VALVE PIVOT (L'ENGINE)         13232           VALVE ROCKER SHAFT         13252           VALVE ROCKER SHAFT         13255           VALVE ROCKER SHAFT SPRING         13256           VALVE ROCKER COVER GASKET         13270           TIMING CHAIN REAR COVER         13260           TIMING CHAIN REAR COVER         13500           TRONT COVER GASKET		
WATER INLET   13049     UFTER GUIDE   13051     CHAIN TENSIONER   13070     TIMING CHAIN OIL JET   13081     CHAIN TENSIONER SIDE GUIDE   13085     CHAIN TENSIONER SIDE GUIDE   13085     JACK SHAFT   13161     JACK SHAFT OIL SEAL   13168     JACK SHAFT GEAR   13170     JACK SHAFT GEAR   13170     JACK SHAFT GEAR   13201     WALVE SPRING SEAT   13202     WALVE SPRING   13203     WALVE SPRING SEAT   13207     WALVE SPRING SEAT   13209     WALVE GUIDE   13212     WALVE GUIDE   13212     WALVE PIVOT (L'ENGINE)   13231     WALVE PIVOT (L'ENGINE)   13234     WALVE PIVOT (L'ENGINE)   13235     WALVE ROCKER SHAFT SPRING   13256     WALVE ROCKER SHAFT SPRING   13256     WALVE ROCKER SHAFT SPRING   13256     WALVE ROCKER COVER   13260     WALVE ROCKER COVER   13560     WALVE ROCKER ROW     WALVE ROCKE		
LIFTER GUIDE 13051 CHAIN TENSIONER 13070 CHAIN TENSIONER SIDE GUIDE 13085 CHAIN TENSIONER SIDE GUIDE 13085 JACK SHAFT 13161 JACK SHAFT OIL SEAL 13168 JACK SHAFT GEAR 13370 INTAKE VALVE 13201 EXHAUST VALVE 13202 VALVE SPRING 13203 VALVE SPRING 13203 VALVE SPRING 13203 VALVE SPRING 13205 VALVE UIL SEAL 13207 VALVE SPRING 13205 VALVE COIL SEAL 13207 VALVE SPRING RETAINER 13209 VALVE GUIDE 13212 VALVE LIFTER 13231 VALVE LIFTER 13231 VALVE LIFTER 13231 VALVE COKER/SHAFT SPRING 13256 VALVE COCKER SAFT 13250 VALVE ROCKER COVER 13264 COCKER SAFT 13270 TIMING CHAIN REAR COVER 13560 EGR PASSAGE 14711 FRONT COVER GASKET 13520 DIST COVER 13560 CIL PUMP DRIVE GEAR 15053 DIL STRAINER 15050 DIPSTICK TUBE 15155 OIL FILLER CAP 15255 OLI FILLER CAP 15265		
CHAIN TENSIONER   13070		
CHAIN TENSIONER SIDE GUIDE	CHAIN TENSIONER	13070
JACK SHAFT		
JACK SHAFT GEAR 13170 INTAKE VALVE 13201 EXHAUST VALVE 13202 VALVE SPRING 13203 VALVE SPRING 13203 VALVE SPRING SEAT 13205 VALVE SPRING SEAT 13209 VALVE SPRING RETAINER 13209 VALVE GUIDE 13212 VALVE HITER 13209 VALVE PRIVOT (L-ENGINE) 13212 VALVE PRIVOT (L-ENGINE) 13231 VALVE PRIVOT (L-ENGINE) 13234 ROCKER SHAFT 13265 VALVE ROCKER SHAFT SPRING 13256 VALVE ROCKER SHAFT SPRING 13266 VALVE ROCKER SHAFT SPRING 13266 VALVE ROCKER SHAFT SPRING 13260 VALVE ROCKER SHAFT SPRING 1326	JACK SHAFT	
NTAKE VALVE	JACK SHAFT OIL SEAL	
EXHAUST VALVE         13202           VALVE SPRING         13203           VALVE SPRING SEAT         13205           VALVE OIL SEAL         13207           VALVE OIL SEAL         13207           VALVE GUIDE         13212           VALVE GUIDE         13212           VALVE LIFTER         13231           VALVE PIVOT (IENGINE)         13234           ROCKER SHAFT         13252           VALVE ROCKER/SHAFT SPRING         13266           VALVE ROCKER COVER         13260           VALVE ROCKER SASKET         13270           TIMING CHAIN REAR COVER         13500           FRONT COVER GASKET         13500           TRONT COVER GASKET         13500           TOUST COVER         13560           EGR PASSAGE         14711           FRONT COVER O-RING         15066           OIL PUMP DRIVE GEAR         1504           OIL STRAINER         15050           DIPSTICK TUBE         15155           OIL FILLER CAP         15255           COVER PLATE/GASKET         16420           BELT TENSIONER         16805		
VALVE SPRING SEAT         13205           VALVE OIL SEAL         13207           VALVE OIL SEAL         13209           VALVE GUIDE         13212           VALVE GUIDE         13212           VALVE GUIDE         13231           VALVE LIFTER         13231           VALVE PIVOT (L'ENGINE)         13234           VOCKER SHAFT         13252           VALVE ROCKER/SHAFT SPRING         13256           VALVE ROCKER COWER         13264           ROCKER COVER         13264           ROCKER COVER GASKET         13500           FRONT COVER GASKET         13500           FRONT COVER GASKET         13560           EGR PASSAGE         14711           FRONT COVER O-RING         15060           OIL PUMP DRIVE GEAR         15043           OIL STRAINER         15050           DIPSTICK TUBE         15155           OIL FILLER CAP         15255           OIL FILLER CAP         15260           BELT TENSIONER         16805	EXHAUST VALVE	13202
VALVE OIL SEAL   13207		
VALVE GUIDE         13212           VALVE LIFTER         13231           VALVE LIFTER         13231           VALVE PIVOT (L'ENGINE)         13234           ROCKER SHAFT         13252           VALVE ROCKER SHAFT         13256           VALVE ROCKER ARM         13256           VALVE ROCKER COVER         13264           ROCKER COVER         13264           ROCKER COVER GASKET         13520           DUST COVER GASKET         13520           DUST COVER         13560           EGR PASSAGE         14711           FRONT COVER O-RING         15063           OIL PUMP DRIVE GEAR         15043           OIL STRAINER         15050           DIPSTICK TUBE         15155           OIL FILLER CAP         15255           OLVER PLATE/GASKET         16420           BELT TENSIONER         16805	VALVE OIL SEAL	
VALVE LIFTER         13231           VALVE PIVOT (L'ENGINE)         13234           VALVE PROCKER SHAFT         13256           VALVE ROCKER/SHAFT SPRING         13256           VALVE ROCKER ARM         13257           VALVE ROCKER COVER         13264           ROCKER COVER GASKET         13270           TIMING CHAIN REAR COVER         13500           FRONT COVER GASKET         13520           DUST COVER         13560           EGR PASSAGE         14711           FRONT COVER O-RING         15066           OIL PUMP DRIVE GEAR         15043           OIL STRAINER         15050           DIPSTICK TUBE         15155           OIL FILLER CAP         15255           COVER PLATE/GASKET         16420           BELT TENSIONER         16805		
VALVE PIVOT (L-ENGINE)   13234		
VALVE ROCKER/SHAFT SPRING         13256           VALVE ROCKER ARM         13257           VALVE ROCKER COVER         13264           ROCKER COVER         13270           TIMING CHAIN REAR COVER         13520           FRONT COVER GASKET         13520           DUST COVER         13560           EGR PASSAGE         14711           FRONT COVER O-RING         15060           OIL PUMP DRIVE GEAR         15043           OIL STRAINER         15050           DIPSTICK TUBE         15155           OIL FILLER CAP         15255           COVER PLATE/GASKET         16420           BELT TENSIONER         16805	VALVE PIVOT (L-ENGINE)	13234
VALVE ROCKER ARM         13257           VALVE ROCKER COVER         13264           NOCKER COVER         13260           ROCKER COVER         13270           TIMING CHAIN REAR COVER         13500           FRONT COVER GASKET         13500           DUST COVER         13560           EGR PASSAGE         14711           FRONT COVER O-RING         15066           OIL PUMP DRIVE GEAR         15030           OIL STRAINER         15050           DIPSTICK TUBE         15755           OIL FILLER CAP         15255           COVER PLATE/GASKET         16420           BELT TENSIONER         16805		
VALVE ROCKER COVÉR   13264	VALVE ROCKER ARM	13257
TIMMIG CHAIN REAR COVER         13500           FRONT COVER GASKET         13520           DUST COVER         13560           EGR PASSAGE         14711           FRONT COVER O-RING         15066           OIL PUMP DRIVE GEAR         15043           OIL STRAINER         15050           DIPSTICK TUBE         15155           OIL FILLER CAP         15255           COVER PLATE/GASKET         16420           BELT TENSIONER         16805	VALVE ROCKER COVER	
RODIT COVER GASKET   13520		
EGR PASSAGE         14711           FRONT COVER O-RING         15066           OIL PUMP DRIVE GEAR         15043           OIL STRAINER         15050           DIPSTICK TUBE         15155           OIL FILLER CAP         15255           COVER PLATE/GASKET         16420           BELT TENSIONER         16805	FRONT COVER GASKET	13520
FRONT COVER O-RING   15066     OIL PUMP DRIVE GEAR   15043     OIL STRAINER   15050     DIPSTICK TUBE   15155     OIL FILLER CAP   15255     COVER PLATE/GASKET   16420     BELT TENSIONER   15805		
OIL STRAINER         15050           DIPSTICK TUBE         15155           OIL FILLER CAP         15255           COVER PLATE/GASKET         16420           BELT TENSIONER         16805	FRONT COVER O-RING	15066
DIPSTICK TUBE         15155           OIL FILLER CAP         15255           COVER PLATE/GASKET         16420           BELT TENSIONER         16805		
OIL FILLER CAP         15255           COVER PLATE/GASKET         16420           BELT TENSIONER         16805		
BELT TENSIONER 16805	OIL FILLER CAP	15255

# LUBRICATION & COOLING

COOLING	
COMPONEN:	P.N.
WATER OUTLET	11060
THERMOSTAT HOUSING	11061
WATER OUTLET GASKET	11062
CYLINDER BLOCK WATER OUTLET	11063
THERMOSTAT HOUSING GASKET	11072
A/T AIR GUIDE	11338
DRIVE BELT	11720
WATER CONNECTOR	14054
WATER BY-PASS HOSE	14055
OIL PUMP	15010
OIL PUMP GASKET	15025
OIL PUMP DRIVE SPINDLE	15040
OIL PUMP REGULATOR VALVE	15132
OIL FILTER BRACKET	15238
FILTER BRACKET GASKET	15239
OIL FILTER RELIEF VALVE	15241
OIL FILTER REGULATOR VALVE	15300
WATER PUMP	21010
WATER PUMP HOUSING AND GASKET	21012
WATER PUMP GASKET	21014
WATER PUMP/FAN PULLEY	21051
FAN BLADE	21060
FAN COUPLING ASSY	21082
THERMOSTAT	21200
OIL COOLER PIPE	21302
OIL COOLER-FIN TYPE	21305
OIL COOLER RADIATOR TYPE	21306
OIL COOLER PROTECTOR	21307
OIL COOLER GASKET	21310
PT—OIL COOLER HOSE	21355
RADIATOR	21400
RADIATOR CAP	21430
RADIATOR SHROUD	21475
RADIATOR DRAIN COCK	21480
INJECTOR BLOWER MOTOR	21490
BLOWER MOTOR INLET	21496
BLOWER MOTOR BRACKET	21497
BLOWER MOTOR CLAMP	21498
BLOWER MOTOR AIR DUCT	21499
UPPER RADIATOR HOSE	21501
LOWER RADIATOR HOSE	21503
RESERVOIR TANK	21510
RESERVOIR TANK BRACKET	21511
RESERVOIR TANK HOSE	21515
THERMO SWITCH	21595
RADIATOR FAN MOTOR	21597
A/T OIL COOLER ASSY	21606
OIL COOLER HOSE	21631
OIL COOLER PIPING	21636
COOLANT TEMP. SENSOR	25080
RADIATOR FAN RELAY	25217
OIL PRESSURE SENDING UNIT	25240
OIL PRESSURE SWITCH	25244
BLOWER MOTOR TIMER	28912
FUEL SYSTEM	

### FUEL SYSTEM

BOOST CONTROL VALVE	14920
PURGE CONTROL VALVE ASSY	14930
VALVE-EVAP.CAN.PURGE VOL.SOL.	14931
RESONATOR - EVAP PURGE	14934
VAPOR CANISTER ASSY	14949
CARBON CANISTER	14950
EPC VALVE	14953
CARBURETOR	16010
CHOKE CHAMBER	16011
JET/AIR BLEEDS	16033
ALTITUDE COMPENSATOR	16044
POWER VALVE	16059
FLOAT	16061
NEEDLE VALVE	16101
AIR FUEL RATIO SOLENOID	16102
ENRICHMENT SOLENOID	16103
FUEL CONNECTOR	16111
THROTTLE CHAMBER	16118
CARBURETOR LINKAGE	16134
ACCELERATOR PUMP	16150
THROTTLE RETURN SPRING	16160
MIXTURE HEATER/INSULATOR	16174
DASH POT	16182
THROTTLE POSITIONER	16183
IDLE SPEED CONTROL	16260
SERVO DIAPHRAGM	16262
DIAPHRAGM CHAMBER	16313
THROTTLE CONTROL DIAPHRAGM	16313
IDLE COMPENSATOR	16331
ACCELERATOR TERMINAL	16361

4.24.7	
COMPONER	Patri
FLOAT CHAMBER GASKET	16455
AIR CLEANER ASSY VACUUM MOTOR ASSY	16500 16510
IDLE COMPENSATOR TUBE	16520
AIR CLEANER INSULATOR	16523
HOT AIR DUCT	16530
AIR DUCT ASSY	16577
AIR TEMP SENSOR	16580
RESONATOR	16585
EXHAUST MANIFOLD COVER	16590
FUEL PUMP CONTROL UNIT	17001
FUEL PUMP	17010
ELECTRIC FUEL PUMP	17012
FUEL PUMP CHECK VALVE	17014
FUEL PUMP GASKET	17099
FUEL CONNECTOR	17103
FUEL TANK	17201
TUBE ASSY FILLER	17220
FUEL FILLER NECK	17222
FUEL FILLER CAP	17251
FUEL HOSE PROTECTOR	17271
FUEL TANK PROTECTOR	17285
FUEL TANK DRAIN PLUG	17310
EC-BREATHER HOSE	17325
FUEL CHECK VALVE	17330
EC-VENTILATION HOSE	17333
EC-VAPOR VENT HOSE	17337
O-RING	17342
BREATHER VALVE	17368
EVAPORATOR SHUT-OFF VALVE	17371
VACUUM CUT VALVE	17372
FUEL OUTLET TUBE	17501
VAPOR VENT LINE	17508
FUEL RETURN TUBE	17510
FRONT FUEL TUBE	17520
ACCELERATOR ARM	18010
ACCELERATOR BRACKET	18021 18050
PEDAL STOPPER BRACKET ACCELERATOR WIRE	18150
RETURN SPRING	18215
TORSION SHAFT ASSY	18300
SHAFT SUPPORT	18314
EC-TUBE & HOSE	18721
M/H WATER TEMP SWITCH	22121
MIXTURE HEATING RELAY	22122
WATER TEMP SENSOR	22630
FUEL DAMPER	22675
ECC MAIN RELAY	22696
DROPPING RESISTOR	22698
ECC CONTROL UNIT	23710
CRANKSHAFT POS. SENSOR (OBD POS)	23731
CRANKSHAFT POS. SENSOR (REF)	23732
VACUUM CONTROL MODULATOR	23771
FUEL TANK SENSOR	25060
VACUUM SENSOR	25085
FUEL CUT OFF SWITCH	25146
AUTO-CHOKE RELAY	25235
FRESH AIR DUCT	62860
	~ ** **

#### MANIFOLDS & TURBOCHARGER

INTAKE MANIFOLD	14001
EXHAUST MANIFOLD	14004
CAP BOLT/STUD	14006
LOWER MANIFOLD COLLECTOR	14011
MANIFOLD TUBE	14012
MANIFOLD COLLECTOR	14013
INTAKE MANIFOLD SUPPORT	14018
LOWER COLLECTOR GASKET	14033
MANIFOLD GASKET	14035
EC-WATER HOSE	14052
WATER INLET PIPE	14053
COLLECTOR GASKET	14080
EXHAUST MANIFOLD COVER	14091
HEAT SHROUD	14096
TURBOCHARGER	14411
TURBOCHARGER GASKET	14415
EXHAUST OUTLET	14440
EXHAUST OUTLET COVER	14441
GASKET	14445
HEAT INSULATOR	14450
INLET TUBE	14460
AIR INLET HOSE	14463
INLET TUBE GASKET	14465
EMERGENCY RELIEF VALVE	14466
RE-CIRCULATION VALVE	14483
VACUUM CONTROL HOSE	14484

COMPONENT	PAG
INTERCOOLER ASSY	14496
WATERPIPE, OUTLET	14498
WATER PIPE, INLET	14499
MANIFOLD CONNECTOR	14875
OIL INLET TUBE	15192
CONNECTOR & GASKET	15194
OIL OUTLET TUBE	15197
FRONT EXHAUST GASKET	20711
CONVERTER GASKET	20712
INTAKE MANIFOLD CONNECTOR & O-RING	21049
BOOST SENSOR	22364
EXHAUST GAS SENSOR	22690
OIL TEMP SENSOR	25075
FLOOR INSULATOR	74661

#### ENGINE ELECTRICAL

ALTERNATOR BRACKET	11710
ALTERNATOR ADJUSTING BAR	11715
THERMO ELEMENT KIT	16391
TRANSISTOR IGNITION UNIT	22020
TRANSISTOR (TRIG) UNIT	22022
DISTRIBUTOR	22100
SHAFT	22108
RELUCTOR	22115
GOVERNOR WEIGHT	22127
DISTRIBUTOR PINION	22129
DISTRIBUTOR CAM	22132
ROTOR HEAD	22157
MAGNET	22158
HARNESS	22159
DISTRIBUTOR CAP	22162
STATOR	22163
DISTRIBUTOR PROTECTOR	22172
VACUUM CONTROL	22301
IGNITION COIL/PWR TRANSISTOR	22433
HIGH TENSION CABLE	22450
RESISTOR	22460
IGNITION COIL PROTECTOR	22465
AIR CUT VALVE	22622
ALTERNATOR	23100
ALTERNATOR ROTOR	23108
ALTERNATOR BEARING	23120
ALTERNATOR BRUSH & HOLDER	23133
ALTERNATOR PULLEY	23150
IC VOLTAGE REGULATOR	23215
DIODE SET	23230
STARTER MOTOR ASSY	23300
FIELD COIL	23306
ARMATURE	23310
CLUTCH PINION	23312
REDUCTION GEAR	23313
STARTER SOLENOID	23343
BRUSH	23380
BATTERY CABLE	24110
BATTERY FRAME/TRAY/ROD	24428

#### FUEL INJECTION

POWER VALVE ASSY	14510
POWER VALVE SOLENOID VALVE ASSY	14517
POWER VALVE SOLENOID	14952
E.P.C. VALVE	14953
PRESSURE REG. CONTROL	14960
ELECTRO INJECTION UNIT	16012
VENTURI CHAMBER	16017
ALTITUDE SWITCH	16044
THROTTLE CHAMBER	16118
THROTTLE LINKAGE	16135
MIXTURE HEATER	16175
DASH POT	16182
F.I.C.D SOLENOID VALVE	16197
I.A.S. UNIT	16250
WAX HOLDER	16394
COLD START VALVE	16601
FUEL INJECTOR	16603
INJECTOR	16604
FUEL PUMP CONTROL MODULE	17001
THROTTLE CHAMBER	17118
B.C.D.D. ASSY	17484
DETONATION SENSOR	22060
VACUUM TANK	22327
VACUUM SWITCH	22361
CONTROL UNIT (ECU)	22604
CONTROL UNIT - EFI	22611
THROTTLE VALVE SWITCH	22620
WATER TEMP SENSOR	22630
AIR TEMPERATURE SENSOR	22631

COMPOWENT	EMU
CYLINDER HEAD TEMP SENSOR	22632
THERMOTIME SWITCH	22635
AIR REGULATOR	22660
I.S.C. VALVE	22664
PRESSURE REGULATOR	22670
PRESSURÉ REG. CONTROL MODULE	22671
PRESSURE PUMP	22674
AIR FLOW METER	22680
AIR FLOW METER BRACKET	22682
VACUUM CONTROL VALVE	22686
MAIN RELAY	22694
DROPPING RESISTOR	22695

#### EMISSION CONTROLS

EFI RELAY	22696
MAIN & FUEL PUMP RELAY	22697
CRANK ANGLE SENSOR	23730
A.A.C. VALVE	23781
EFI HARNESS	24011
MIXTURE HEATER RELAY	25231
PCV VALVE	11810
EGR TUBE	14120
EGR CONTROL VALVE	14710
EGR PASSAGE	14711
EC-EGR VACUUM HOSE	14729
EXHAUST TEMP SENSOR	14730
BPT VALVE	14741
A.I.V. UNIT CASE	14810
A.I.V. TUBE	14821
AIR INJECTION PIPE	14823
AIR CONTROL VALVE	14832
A.B. VALVE	14835
SERVICE PORT-EVAP.	14939
AIR INJECTION VALVE	14854
EC-HOSE	14860
A.I.V. BOX	14880
THERMAL VACUUM VALVE	14890
SCV SOLENOID VALVE	14951
EPC VALVE	14953
EGR SOLENOID VALVE	14954
VACUUM CUT SOLENOID	14955
A.I.V. SOLENOID VALVE	14956
EGR MIXTURE SOLENOID	14956
SPARK DELAY VALVE	14958
FUEL CUT SOLENOID	16196
ENGINE REVOLUTION SWITCH	16767
DETONATION SENSOR	22060
DETONATION CONTROL UNIT	22061
EGR WATER TEMP SENSOR	22120
CK SWITCH—CANISTER VAC CNTRL	22360
EGR VACUUM CONTROL VALVE	22363
EGR VACUUM CONTROL VALVE	22365
THROTTLE VALVE SWITCH	22620
02 SENSOR	22690
REAR OXYGEN 02 SENSOR	22691
CRANK POSITION SENSOR—RING GEAR	23733
EGR CONTROL UNIT	25024
FUEL SHUT OFF CLUTCH SWITCH	25322
EGR RESERVOIR TANK	27085

# POWER TRAIN

#### PROPELLER SHAFTS & DIFFERENTIAL

DRAIN PLUG 4WD	32104
PROPELLER SHAFT	37000
FRONT PROPELLER SHAFT	37010
JOURNAL ASSY	37125
CENTER BEARING BRACKET	37511
CENTER BEARING	37521
CENTER BEARING INSULATOR	37522
RING & PINION SET	38100
DRIVE GEAR BOLT	38102
REAR PINION BEARING	38120
FRONT PINION BEARING	38140
PINION BEARING SPACER	38165
PILOT BEARING SPACER	38169
DRIVE PINION OIL SEAL	38189
COMPANION FLANGE	38210
SIDE FLANGE	38220
SIDE FLANGE 4WD	38221
DIFFERENTIAL CARRIER (HOUSING)	38310
DIFFERENTIAL CARRIER-4WD	38311
REAR COVER GASKET	38320
FRONT PILOT BEARING	38335
4WD SIDE BEARING RETAINER	38341

COMPONENT	P.M.
DIFFERENTIAL SIDE OIL SEAL	38342
DIFFERENTIAL SIDE OIL SEAL 4WD	38344
SIDE RETAINER O-RING 4WD	38345
REAR COVER	38351
BREATHER	38352
BREATHER 4WD	38353
BREATHER HOSE	38354
DRAIN PLUG	38355
LTD SLIP DIFFERENTIAL ASSY	38420
DIFFERENTIAL CASE	38421
SIDE GEAR	38423
SIDE GEAR THRUST WASHER	38424
PINION MATE	38425
PINION MATE THRUST WASHER	38426
PINION MATE SHAFT	38427
PINION SHAFT LOCK PIN	38428
PINION SHAFT LOCK PIN 4WD	38429
THRUST BLOCK	38430
LSD PRESSURE RING	38431
LSD FRICTION PLATE	38432
LSD FRICTION DISC	38433
SIDE BEARING	38440
DRIVE FLANGE	38512
RING & PINION 4WD	38540
FRONT PINION BEARING 4WD	38541
RING & PINION BEARING 4WD	38542
PINION BEARING SPACER-4WD	38543
DRIVE PINION OIL SEAL 4WD	38544
COMPANION FLANGE 4WD	38545
DIFFERENTIAL CASE 4WD	38546
SIDE GEAR 4WD	38547
SIDE GEAR THRUST WASHER	38548
PINION MATE 4WD	38549
PINION MATE THRUST WASHER	38550
PINION MATE SHAFT 4WD	38551
SIDE BEARING 4WD	38552
DRIVE GEAR BOLT 4WD	38553
REAR COVER 4WD	40513
REAR COVER GASKET 4WD	40515
RONT DIFFRNTL MOUNTING INSULATOR	54710
RONT DIFFRNTL MOUNTING MEMBER	54720
RONT DIFFRATL MOUNTING STOPPER	54751
RONT DIFF MOUNTING STOPPR BRACKET	54752

#### CLUTCH, TRANSMISSION, TRANSAXLE & TRANSFER CASE

REAR MAIN SEAL	12279
FLYWHEEL ASSY	12310
FLYWHEEL RING GEAR	12312
FIXING BOLT	12315
DRIVE PLATE ASSY	12331
A/T COOLER BYPASS VALVE	21607
OIL COOLER TUBE	21621
DIFFERENTIAL OIL COOLER	21652
DIFFERENTIAL OIL PUMP	21660
THERMAL SWITCH	21669
DIFFERENTIAL OIL COOLER PIPE	21682
DROPPING RESISTOR	22693
CIRCUIT BREAKER	24330
O.D. CANCEL/POWER SWITCH	25130
SHIFT PATTERN SELECT SWITCH	25131
SHIFT LOCK RELAY	25206
TRANSFER RELAY	25249
KICKDOWN SWITCH	25390
INTERLOCK CONTROL UNIT	28491
TRANSFER CONTROL UNIT	28495
CLUTCH HOUSING	30400
CLUTCH RELEASE SLEEVE	30501
CLUTCH RELEASE BEARING	30502
CLUTCH WITHDRAWAL LEVER	30531
WITHDRAWAL LEVER PIN	30537
DUST COVER	30542
CLUTCH DAMPER	30600
CLUTCH MASTER CYLINDER	30610
CLUTCH OPERATING CYLINDER	30620
BLEEDER (CLUTCH)	30621
PUSH ROD	30628
CLUTCH BOOSTER	30630
PUSH ROD	30631
CHECK VALVE ASSY	30639
CLUTCH TUBE & HOSE	30650
CLUTCH VACUUM HOSE	30664
CLUTCH OPERATING CABLE	30670
CONVERTER BOLT	31009
A/T CONTROL UNIT	31036
O.D. INDICATOR SWITCH	31041

# FOWER TRAIN Gold Preferred Plan

CLUTCH, TRANSMISSION, TRANSAXLE &

TRANSAXLE &	
TRANSFER CASE	
continued	
COMPONER:	PALC.
VACUUM MODULATOR	31050
THROTTLE CABLE VACUUM TUBE	31051
OIL LEVEL GAUGE	31061 31080
TORQUE CONVERTER	31100
CVT STEEL BELT	312A0
CONVERTER HOUSING	31301
CONVERTER HOUSING GASKET	31309
TRANSMISSION CASE O.D. CASE (4 SP)	31310
REAR EXTENSION (ADAPTOR)	31322
CONTROL CYLINDER	31331
REAR EXTENSION GASKET	31335
REAR EXTENSION OIL SEAL	31336
OIL PUMP	31340
FRONT OIL SEAL OIL PUMP HOUSING SEAL	31343 31344
OIL PUMP ROTOR SET	31345
O-RING (AUTO TRANS SECTION)	31362
OIL PUMP GASKET	31366
BEARING RETAINER (3 SP)	31370
BREATHER	31381
DRUM SUPPORT (4 SP)	31385
OIL PAN/VALVE COVER SIDE COVER	31390 31391
GASKET	31397
INPUT SHAFT	31411
INTERMEDIATE SHAFT (4 SP)	31416
FRONT PLANETARY CARRIER	31420
NEEDLE BEARING	31428
REAR PLANETARY CARRIER CONNECTING DRUM	31440 31471
ONE-WAY CLUTCH	31473
FORWARD CLUTCH HUB	31475
OUTPUT SHAFT	31480
PARKING GEAR/OIL DISTRIBUTOR	31486
OUTPUT & IDLER GEAR SET	31493
DIRECT CLUTCH (4 SP) LOW CLUTCH (4 SP)	31505 31505
FRONT CLUTCH ASSY	31510
FRONT/REV. CLUTCH ASSY	31510
REVERSE CLUTCH DRUM	31512
REVERSE CLUTCH ASSY	31515
REAR CLUTCH ASSY REAR/HIGH CLUTCH	31540
HIGH CLUTCH DRUM	31540 31541
HIGH CLUTCH ASSY	31545
HIGH CLUTCH HUB	31550
FORWARD CLUTCH ASSY	31570
FORWARD CLUTCH DRUM	31571
O.D. PLANETARY CARRIER-4 SP OVERRUN CLUTCH HUB	31580 31591
OVERRUN CLUTCH ASSY	31595
BAND SERVO	31615
BRAKE BAND	31630
LOW & REVERSE BRAKE	31645
LOW & REVERSE BRAKE	31650
ACCUMULATOR PISTON	31671
ACCUMULATOR (4 SP) SPEEDOMETER PINION ASSY	31671 31703
CONTROL VALVE ASSY	31705
OIL STRAINER	31728
GOVERNOR	31860
GOVERNOR SEAL RING CAP	31877
SPEEDOMETER CASE & GEAR RANGE SELECT LEVER	31883 31913
GASKET & O-RING	31916
INHIBITOR SWITCH	31918
MANUAL SHAFT	31921
MANUAL PLATE ASSY	31924
VACUUM DIAPHRAGM	31931
O-RING SEAL REVOLUTION SENSOR	31933
TURBINE REVOLUTION SENSOR	31935
DOWNSHIFT SOLENOID	31941
LOCK-UP SOLENOID	31942
SHIFT SOLENOID A	31943
SHIFT SOLENOID B	31944
O.D. CANCEL SOLENOID	31945
LINE PRESSURE SOLENOID  OVERRUN, CLUTCH SOLENOID	31946
LOW TEMP SENSOR	31947
PARKING ROD ASSY	31970
PARKING PAWL	31986
REVERSE LAMP SWITCH	32005

COMPORENI	P.M.C
TOP/NEUTRAL SWITCH	32006
NEUTRAL SWITCH-4WD	32007 32008
TRANSMISSION CASE	32100
DRAIN PLUG	32103
DRAIN PLUG	32104
DRAIN PLUG (4WD)	32104
OIL GUIDE/GUTTER	32107
TRANSMISSION FRONT COVER	32110
FRONT COVER GASKET FRONT COVER/OIL INPUT SEAL	32112
CASE COVER	32113 32129
REAR EXTENSION ASSY	32130
BREATHER	32131
REAR EXTENSION OIL SEAL	32136
MAIN DRIVE GEAR	32200
OUTPUT SHAFT	32200
PILOT BEARING DRIVE GEAR BEARING	32202 32203
ROLLER BEARING	32203
SNAP RING	32204
COUNTERSHAFT	32211
COUNTER GEAR	32213
INPUT SHAFT	32213
COUNTERSHAFT BEARING	32219
INPUT SHAFT BEARING	32219
ROLLER BEARING	32219
REVERSE COUNTER GEAR GEAR, 1ST SPEED	32220 32230
MAIN GEAR (1ST)	32230
COUNTERSHAFT NUT	32236
MAINSHAFT	32241
MAINSHAFT LOCK NUT	32243
REVERSE GEAR	32245
REVERSE MAIN GEAR	32245
GEAR, 2ND SPEED MAIN GEAR (2ND)	32250 32250
GEAR, 3RD SPEED	32260
MAIN GEAR (3RD)	32260
3RD GEAR INPUT SHAFT	32261
NEEDLE BEARING -	32264
MAIN GEAR (4TH)	32270
4TH GEAR INPUT SHAFT	32271
NEEDLE ROLLERS	32272
PILOT BEARING	32272
MAINSHAFT BEARING ROLLER BEARING	32273 32273
REVERSE IDLER SHAFT	32281
REVERSE IDLER GEAR	32282
REVERSE IDLER BEARING	32283
RETAINING PIN	32293
COUNTERSHAFT GEAR (5TH)	32310
INPUT GEAR (5TH)	32310
OVERDRIVE COUNTER GEAR	32310
MAIN GEAR (5TH) MAINSHAFT GEAR (5TH) BW-T5	32340 32340
O.D. (5TH) MAIN GEAR	32340
C RING HOLDER	32351
SYNCHRO ASSY	32601
SYNCHRONIZER HUB	32601
SYNCHRO SLEEVE	32601
SPREAD RING	32602
INSERT SPRING	32603
SPREAD RING BAULK RING	32603
COUPLING SLEEVE	32604 32606
INSERT	32609
SHIFTING INSERT	32609
REVERSE BAULK RING	32617
BAULK RING	32680
BAULK RING (1ST)	32680
BLOCKER RING	32680
BAULK RING (2ND) BLOCKER RING	32681 32681
BAULK RING (3RD)	32682
BLOCKER RING	32682
BAULK RING (4TH)	32683
BLOCKER RING	32683
BAULK RING (5TH)	32684
BLOCKER RING	32684
SYNCHRO RING SET (5TH)	32689
SPEEDMASTER DRIVE GEAR	32701
SPEEDOMETER PINION	32703
	32721
CHECK BALL & SPRING	
CHECK BALL & SPRING SHIFT ROD FORK ROD	32801 32801

CHECK BALL & SPRING CONTROL LEVER CONTROL LEVER BOOT (RWD)	
	3282
	3284 3284
O-RING	3284
OIL CONTROL SEAL	3285
CONTROL LEVER SOCKET (RWD)	3286
CONTROL LEVER BOOT (RWD)	3286
SHIFT KNOB	3286
STRIKING ROD	3289
CONTROL SELECTOR ARM	3289
STRIKING LEVER	32898
STRIKING ROD PIN	3291
TRANSFER FRONT CASE	3310
TRANSFER REAR CASE TRANSFER CENTER CASE	33103
FRONT CASE OIL SEAL	33112
MAIN GEAR	33113
DRIVESHAFT OIL SEAL	33114
RING GEAR	33115
BALL BEARING	33116
BALL BEARING (MAIN GEAR)	33116
END COVER	33119
COUNTERSHAFT COUNTER GEAR	33120
NEEDLE BEARING	33121 33122
HYPOID GEAR	33123
COUNTER GEAR BEARING	33124
TRANSFER DRIVE SHAFT	33131
TRANSFER MAIN SHAFT	33131
LOW SPEED GEAR	33132
FRONT DRIVE SPROCKET DRIVE SHAFT BEARING	33134 33135
REAR CASE OIL SEAL	33142
REAR COVER OIL SEAL	33142
PINION SLEEVE	33143
COUPLING SLEEVE HUB	33144
FRONT COVER OIL SEAL TRANSFER FRONT CASE	33147 33150
TRANSFER FRONT COVER	33150
FRONT DRIVE SHAFT	33151
NEEDLE BEARING	33152
COUPLING SLEEVE	33154
COMPANION FLANGE HYPOID PINION	33156 33158
	33159
DRIVE CHAIN SHIFT ROD	33161
SHIFT FORK	33162
FRONT SHIFT BRACKET	33164
FRONT SHIFT BRACKET SHIFT FORK SPRING	33169
FRONT SHIFT BRACKET SHIFT FORK SPRING SHIFT SHAFT	33169 33180
FRONT SHIFT BRACKET SHIFT FORK SPRING	33169
FRONT SHIFT BRACKET SHIFT FORK SPRING SHIFT SHAFT SHIFT SHAFT OIL SEAL TRANSFER CONTROL LEVER CENTER CASE OIL SEAL	33169 33180 33185 33210 33216
FRONT SHIFT BRACKET SHIFT FORK SPRING SHIFT SHAFT SHIFT SHAFT SHIFT SHAFT OIL SEAL TRANSFER CONTROL LEVER CENTER CASE OIL SEAL TRANSFER SHIFT KNOB	33169 33180 33185 33210 33216 33219
FRONT SHIFT BRACKET SHIFT FORK SPRING SHIFT SHAFT SHIFT SHAFT OIL SEAL TRANSFER CONTROL LEVER CENTER CASE OIL SEAL TRANSFER SHIFT KNOB CROSS SHAFT	33169 33180 33185 33210 33216 33219 33822
FRONT SHIFT BRACKET SHIFT FORK SPRING SHIFT SHAFT SHIFT SHAFT OIL SEAL TRANSFER CONTROL LEVER CENTER CASE OIL SEAL TRANSFER SHIFT KNOB CROSS SHAFT TRANSFER PROTECTOR	33169 33180 33185 33210 33216 33219 33822 33940
FRONT SHIFT BRACKET SHIFT FORK SPRING SHIFT SHAFT SHIFT SHAFT SHIFT SHAFT OIL SEAL TRANSFER CONTROL LEVER CENTER CASE OIL SEAL TRANSFER SHIFT KNOB CROSS SHAFT TRANSFER PROTECTOR CONTROL ROD	33169 33180 33185 33210 33216 33219 33822
FRONT SHIFT BRACKET SHIFT FORK SPRING SHIFT SHAFT SHIFT SHAFT OIL SEAL TRANSFER CONTROL LEVER CENTER CASE OIL SEAL TRANSFER SHIFT KNOB CROSS SHAFT TRANSFER SHIFT KNOB CROSS SHAFT TRANSFER PROTECTOR CONTROL ROD CONTROL ROD (FWD) ACTUATOR ASSY	33169 33180 33185 33210 33216 33219 33822 33940 34103 34103 34310
FRONT SHIFT BRACKET SHIFT FORK SPRING SHIFT SHAFT SHIFT SHAFT SHIFT SHAFT SHIFT SHAFT OIL SEAL TRANSFER CONTROL LEVER CENTER CASE OIL SEAL TRANSFER SHIFT KNOB CROSS SHAFT TRANSFER PROTECTOR CONTROL ROD CONTROL ROD CONTROL ROD CONTROL ROD CONTROL ROD (WED) ACTUATOR ASSY CONTROL ROD LOWER BRACKET	33169 33180 33185 33210 33216 33219 33822 33940 34103 34103 34310 34400
FRONT SHIFT BRACKET SHIFT FORK SPRING SHIFT SHAFT SHIFT SHAFT SHIFT SHAFT SHIFT SHAFT OIL SEAL TRANSFER CONTROL LEVER CENTER CASE OIL SEAL TRANSFER SHIFT KNOB CROSS SHAFT TRANSFER PROTECTOR CONTROL ROD CONTROL ROD CONTROL ROD (FWD) ACTUATOR ASSY CONTROL ROD LOWER BRACKET SHIFT ROD TRUNNION	33169 33180 33185 33210 33216 33219 33822 33940 34103 34310 34400 34410
FRONT SHIFT BRACKET SHIFT FORK SPRING SHIFT SHAFT SHIFT SHAFT OIL SEAL TRANSFER CONTROL LEVER CENTER CASE OIL SEAL TRANSFER SHIFT KNOB CROSS SHAFT TRANSFER PROTECTOR CONTROL ROD CONTROL ROD CONTROL ROD (FWD) ACTUATOR ASSY COMTROL ROD LOWER BRACKET SHIFT ROD TRUNNION SELECT LEVER ASSY (RWD)	33169 33180 33185 33210 33216 33219 33822 33940 34103 34310 34400 34410 34415
FRONT SHIFT BRACKET SHIFT FORK SPRING SHIFT SHAFT SHIFT SHAFT OIL SEAL TRANSFER CONTROL LEVER CENTER CASE OIL SEAL TRANSFER SHIFT KNOB CROSS SHAFT TRANSFER PROTECTOR CONTROL ROD CONTROL ROD CONTROL ROD ((WD) ACTUATOR ASSY CONTROL ROD LOWER BRACKET SHIFT ROD TRUNNION SELECT LEVER ASSY (RWD) CROSS SHAFT LEVER	33169 33180 33185 33210 33216 33219 33822 33940 34103 34310 34400 34410
FRONT SHIFT BRACKET SHIFT FORK SPRING SHIFT SHAFT SHIFT SHAFT OIL SEAL TRANSFER CONTROL LEVER CENTER CASE OIL SEAL TRANSFER SHIFT KNOB CROSS SHAFT TRANSFER PROTECTOR CONTROL ROD CONTROL ROD CONTROL ROD CONTROL ROD (FWD) ACTUATOR ASSY CONTROL ROD LOWER BRACKET SHIFT ROD TRUMNION SELECT LEVER ASSY (RWD) CROSS SHAFT LEVER LOWER CONTROL ROD CONTROL COD CONTROL COD CONTROL COD CONTROL CABLE (RWD)	33169 33180 33185 33210 33216 33219 33822 33940 34103 34103 34400 34415 34430 34441 34445
FRONT SHIFT BRACKET SHIFT FORK SPRING SHIFT SHAFT SHIFT SHAFT OIL SEAL TRANSFER CONTROL LEVER CENTER CASE OIL SEAL TRANSFER SHIFT KNOB CROSS SHAFT TRANSFER PROTECTOR CONTROL ROD CONTROL ROD CONTROL ROD (EWD) ACTUATOR ASSY CONTROL ROD LOWER BRACKET SHIFT ROD TRUNNION SELECT LEVER ASSY (RWD) CROSS SHAFT LEVER LOWER CONTROL ROD CONTROL ROD CONTROL ROD TRUNNION SELECT LEVER ASSY (RWD) CROSS SHAFT LEVER LOWER CONTROL ROD CONTROL CABLE (RWD) SUB TRANSMISSION ROD	33169 33180 33185 33210 33216 33219 33822 33940 34103 34103 34400 34410 34415 34430 34441 34445
FRONT SHIFT BRACKET SHIFT FORK SPRING SHIFT SHAFT SHIFT SHAFT SHIFT SHAFT OIL SEAL TRANSFER CONTROL LEVER CENTER CASE OIL SEAL TRANSFER SHIFT KNOB CROSS SHAFT TRANSFER PROTECTOR CONTROL ROD CONTROL ROD CONTROL ROD (FWD) ACTUATOR ASSY CONTROL ROD LOWER BRACKET SHIFT ROD TRUNNION SELECT LEVER ASSY (RWD) CROSS SHAFT LEVER LOWER CONTROL ROD CONTROL ROD LOWER BRACKET SHIFT ROD TRUNNION SELECT LEVER ASSY (RWD) CROSS SHAFT LEVER LOWER CONTROL ROD CONTROL ROD CONTROL ROD CONTROL ROD SUB TRANSMISSION ROD	33169 33180 33185 33210 33216 33219 33822 33940 34103 34103 34410 34415 34430 34441 34445 34451 34451
FRONT SHIFT BRACKET SHIFT FORK SPRING SHIFT SHAFT SHIFT SHAFT OIL SEAL TRANSFER CONTROL LEVER CENTER CASE OIL SEAL TRANSFER SHIFT KNOB CROSS SHAFT TRANSFER PROTECTOR CONTROL ROD CONTROL ROD CONTROL ROD (FWD) ACTUATOR ASSY CONTROL ROD LOWER BRACKET SHIFT ROD TRUMNION SELECT LEVER ASSY (RWD) CROSS SHAFT LEVER LOWER CONTROL ROD CONTROL ROD CONTROL ROD TRUMNION SELECT LEVER ASSY (RWD) CROSS SHAFT LEVER LOWER CONTROL ROD CONTROL CABLE (RWD) SUB TRANSMISSION ROD SUB TRANSMISSION ROD SUB TRANSMISSION ROD	33169 33180 33185 33210 33216 33212 33940 34103 34103 34310 34400 34415 34430 34445 34445 34451 34452
FRONT SHIFT BRACKET SHIFT FORK SPRING SHIFT SHAFT SHIFT SHAFT OIL SEAL TRANSFER CONTROL LEVER CENTER CASE OIL SEAL TRANSFER SHIFT KNOB CROSS SHAFT TRANSFER PROTECTOR CONTROL ROD CONTROL ROD CONTROL ROD (FWD) ACTUATOR ASSY CONTROL ROD LOWER BRACKET SHIFT ROD TRUNNION SELECT LEVER ASSY (RWD) CROSS SHAFT LEVER LOWER CONTROL ROD CONTROL CABLE (RWD) SUB TRANSMISSION ROD SUB TRANSMISSION ROD SUB TRANSMISSION ROD DUST COVER HOLDER	33169 33180 33210 33210 33210 33219 33219 33219 33922 33940 34103 34410 34410 34415 34430 34431 34431 34431 34431 34431 34431 34451 34452 34504
FRONT SHIFT BRACKET SHIFT FORK SPRING SHIFT SHAFT SHIFT SHAFT SHIFT SHAFT OIL SEAL TRANSFER CONTROL LEVER CENTER CASE OIL SEAL TRANSFER SHIFT KNOB CROSS SHAFT TRANSFER PROTECTOR CONTROL ROD CONTROL ROD CONTROL ROD (FWD) ACTUATOR ASSY CONTROL ROD LOWER BRACKET SHIFT ROD TRUNNION SELECT LEVER ASSY (RWD) CROSS SHAFT LEVER LOWER CONTROL ROD CONTROL ROD CONTROL ROD CONTROL ROD CONTROL ROD CONTROL CABLE (RWD) SUB TRANSMISSION ROD SUB TRANSMISSION ROD DUST COVER HOLDER DUST COVER (FWD) CROSS COVER (FWD) CROSS COVER (FWD)	33169 33180 33180 33210 33210 33210 33219 33940 34103 34103 34410 34450 34450 34450 34450 34506 34507
FRONT SHIFT BRACKET SHIFT FORK SPRING SHIFT SHAFT SHIFT SHAFT SHIFT SHAFT SHIFT SHAFT SHIFT SHAFT OIL SEAL TRANSFER CONTROL LEVER CENTER CASE OIL SEAL TRANSFER SHIFT KNOB CROSS SHAFT TRANSFER PROTECTOR CONTROL ROO CONTROL ROO CONTROL ROO CONTROL ROO (FWD) ACTUATOR ASSY CONTROL ROD LOWER BRACKET SHIFT ROD TRUNNION SELECT LEVER ASSY (RWD) CROSS SHAFT LEVER LOWER CONTROL ROD CONTROL CABLE (RWD) SUB TRANSMISSION ROD SUB TRANSMISSION ROD DUST COVER (FWD) CROSS SHAFT LEVER CROSS SHAFT ASSY	33169 33180 33210 33210 33210 33219 33219 33219 33922 33940 34103 34410 34410 34415 34430 34431 34431 34431 34431 34431 34431 34451 34452 34504
FRONT SHIFT BRACKET SHIFT FORK SPRING SHIFT SHAFT SHIFT SHAFT SHIFT SHAFT SHIFT SHAFT OIL SEAL TRANSFER CONTROL LEVER CENTER CASE OIL SEAL TRANSFER SHIFT KNOB CROSS SHAFT CONTROL ROD CONTROL ROD CONTROL ROD CONTROL ROD CONTROL ROD LOWER BRACKET SHIFT ROD TRUNNION SELECT LEVER ASSY (RWD) CONTROL ROD LOWER BRACKET SHIFT ROD TRUNNION SELECT LEVER ASSY (RWD) CONTROL CABLE (RWD) SUB TRANSMISSION ROD DUST COVER HOLDER DUST COVER HOLDER DUST COVER (FWD) CROSS SHAFT LEVER CROSS SHAFT LEVER CROSS SHAFT LEVER COVER (FWD) SUB TRANSMISSION ROD SUB TRANSMISSION ROD SUB TRANSMISSION ROD SUBSTANSMISSION ROD SUBSTA	33169 33180 33180 33210 33210 33210 33210 33210 33403 34103 34400 34410 34430 34430 34430 34452 34520 34520 34520 34559 34559
FRONT SHIFT BRACKET SHIFT FORK SPRING SHIFT SHAFT SHIFT SHAFT SHIFT SHAFT SHIFT SHAFT OIL SEAL TRANSFER CONTROL LEVER CENTER CASE OIL SEAL TRANSFER SHIFT KNOB CROSS SHAFT TRANSFER PROTECTOR CONTROL ROD CONTROL ROD CONTROL ROD (CWD) ACTUATOR ASSY CONTROL ROD LOWER BRACKET SHIFT ROD TRUNNION SELECT LEVER ASSY (RWD) CROSS SHAFT LEVER LOWER CONTROL ROD CONTROL CABLE (RWD) SUB TRANSMISSION ROD SUB TRANSMISSION ROD DUST COVER HOLDER DUST COVER (FWD) CROSS SHAFT LEVER	33169 33180 33180 33210 33210 33210 33210 33220 33940 34103 34103 34410 34450 34451 34451 34451 34506 34507 34506 34507 34506
FRONT SHIFT BRACKET SHIFT FORK SPRING SHIFT SHAFT SHIFT SHAFT SHIFT SHAFT SHIFT SHAFT OIL SEAL TRANSFER CONTROL LEVER CENTER CASE OIL SEAL TRANSFER SHIFT KNOB CROSS SHAFT TRANSFER PROTECTOR CONTROL ROD CONTROL ROD CONTROL ROD (FWD) ACTUATOR ASSY CONTROL ROD LOWER BRACKET SHIFT ROD TRUMNION SELECT LEVER ASSY (RWD) CROSS SHAFT LEVER LOWER CONTROL ROD CONTROL CABLE (RWD) SUB TRANSMISSION ROD SUB TRANSMISSION ROD DUST COVER (FWD) CROSS SHAFT LEVER CROSS SHAFT LEVER CROSS SHAFT ASSY SUPPORT ROD (FWD) SUPPORT ROD (FWD) SUPPORT ROD BRACKET SUPPORT ROD DAMPER CROSS OVER SHAFT	33169 33180 33185 33210 33216 33219 33822 34103 34103 34310 34410 34415 34430 34415 34452 34452 34520 34566 34566 34566 34569
FRONT SHIFT BRACKET SHIFT FORK SPRING SHIFT SHAFT SHIFT SHAFT SHIFT SHAFT SHIFT SHAFT OIL SEAL TRANSFER CONTROL LEVER CENTER CASE OIL SEAL TRANSFER SHIFT KNOB CROSS SHAFT TRANSFER PROTECTOR CONTROL ROD CONTROL ROD (EWD) ACTUATOR ASSY CONTROL ROD LOWER BRACKET SHIFT ROD TRUNNION SELECT LEVER ASSY (RWD) CROSS SHAFT LEVER LOWER CONTROL ROD CONTROL CABLE (RWD) SUB TRANSMISSION ROD SUB TRANSMISSION ROD SUB TRANSMISSION ROD DUST COVER HOLDER DUST COVER HOLDER DUST COVER (EWD) CROSS SHAFT LEVER CROSS SHAFT LEVER CROSS SHAFT LEVER SUPPORT ROD EWD) SUPPORT ROD DAMPER CROSS SHAFT LEVER CROSS OVER SHAFT ACT CONTROL DEVICE	33169 33180 33185 33210 33210 33210 33219 3329 33940 34103 34410 34410 34410 3443 34450 3450 3450 3450 3450 3450 34
FRONT SHIFT BRACKET SHIFT FORK SPRING SHIFT SHAFT SHIFT SHAFT SHIFT SHAFT OIL SEAL TRANSFER CONTROL LEVER CENTER CASE OIL SEAL TRANSFER SHIFT KNOB CROSS SHAFT TRANSFER PROTECTOR CONTROL ROD CONTROL ROD CONTROL ROD (FWD) ACTUATOR ASSY CONTROL ROD LOWER BRACKET SHIFT ROD TRUNNION SELECT LEVER ASSY (RWD) CROSS SHAFT LEVER LOWER CONTROL ROD CONTROL CABLE (RWD) SUB TRANSMISSION ROD SUB TRANSMISSION ROD SUB TRANSMISSION ROD DUST COVER (FWD) CROSS SHAFT LEVER CROSS SHAFT LEVER CROSS SHAFT RSSY SUBPORT ROD [FWD] SUPPORT ROD FROD SUB TRANSMISSION ROD SUB TRANSMISMISMISMISMISMISMISMISMISMISMISMISMIS	33169 33180 33185 33210 33216 33219 33822 34103 34103 34310 34410 34415 34430 34415 34452 34452 34520 34566 34566 34566 34569
FRONT SHIFT BRACKET SHIFT FORK SPRING SHIFT SHAFT SHIFT SHAFT SHIFT SHAFT SHIFT SHAFT OIL SEAL TRANSFER CONTROL LEVER CENTER CASE OIL SEAL TRANSFER SHIFT KNOB CROSS SHAFT TRANSFER PROTECTOR CONTROL ROD CONTROL ROD (EWD) ACTUATOR ASSY CONTROL ROD LOWER BRACKET SHIFT ROD TRUNNION SELECT LEVER ASSY (RWD) CROSS SHAFT LEVER LOWER CONTROL ROD CONTROL CABLE (RWD) SUB TRANSMISSION ROD SUB TRANSMISSION ROD SUB TRANSMISSION ROD DUST COVER HOLDER DUST COVER HOLDER DUST COVER (EWD) CROSS SHAFT LEVER CROSS OF SHAFT ASSY SUPPORT ROD DAMPER CROSS OF SHAFT AT CONTROL DEVICE KEY INTERCOCK CABLE ASSY COMPRESSION ROD LEVER SHAFT	33169 33180 33185 33210 33216 33219 33216 33219 33940 34103 34400 34410 34415 34451 34451 34451 34506 34506 34507 34506 34507 34508 34509
FRONT SHIFT BRACKET SHIFT FORK SPRING SHIFT SHAFT SHIFT SHAFT SHIFT SHAFT SHIFT SHAFT OIL SEAL TRANSFER CONTROL LEVER CENTER CASE OIL SEAL TRANSFER SHIFT KNOB CROSS SHAFT CONTROL ROD CONTROL ROD CONTROL ROD CONTROL ROD CONTROL ROD LOWER BRACKET SHIFT ROD TRUNNION SELECT LEVER ASSY (RWD) CONTROL ROD LOWER BRACKET SHIFT ROD TRUNNION SELECT LEVER ASSY (RWD) CONTROL CABLE (RWD) SUB TRANSMISSION ROD DUST COVER HOLDER DUST COVER (FWD) SUB TRANSMISSION ROD SUB TRANSMISSION	33169 33180 33210 33216 33216 33219 33212 33940 34103 34310 34430 34430 34451 34452 34452 34452 34452 34452 34506 34507 34506 34507 34508 34507 34508
FRONT SHIFT BRACKET SHIFT FORK SPRING SHIFT SHAFT SHIFT SHAFT OIL SEAL TRANSFER CONTROL LEVER CENTER CASE OIL SEAL TRANSFER SHIFT KNOB CROSS SHAFT TRANSFER PROTECTOR CONTROL ROD CONTROL ROD CONTROL ROD (CWD) ACTUATOR ASSY CONTROL ROD (CWD) CONTROL CABLE (RWD) SUB TRANSMISSION ROD SUB TRANSMISSION ROD SUB TRANSMISSION ROD DUST COVER (FWD) COSS SHAFT LEVER CROSS SHAFT LEVER	33169 33180 33180 33210 33216 33219 33219 33822 33940 34103 34103 34410 34410 34410 34451 34450 34504
FRONT SHIFT BRACKET SHIFT FORK SPRING SHIFT SHAFT SHIFT SHAFT SHIFT SHAFT SHIFT SHAFT SHIFT SHAFT OIL SEAL TRANSFER CONTROL LEVER CENTER CASE OIL SEAL TRANSFER SHIFT KNOB GROSS SHAFT TRANSFER PROTECTOR CONTROL ROD CONTROL ROD CONTROL ROD (FWD) ACTUATOR ASSY CONTROL ROD LOWER BRACKET SHIFT ROD TRUMNION SELECT LEVER ASSY (RWD) CROSS SHAFT LEVER LOWER CONTROL ROD CONTROL CABLE (RWD) SUB TRANSMISSION ROD SUB TRANSMISSION ROD DUST COVER (FWD) CONTROL CABLE (RWD) SUB TRANSMISSION ROD SUB TRANSMISSION ROD SUB TRANSMISSION ROD SUB TROME (FWD) SUB TROME (FWD) SUB TROME (FWD) CROSS SHAFT LEVER CROSS SHAFT LEVER CROSS SHAFT ASSY SUPPORT ROD DAMPER CROSS OVER SHAFT AST CONTROL DEVICE KEY INTERLOCK CABLE ASSY COMPRESSION ROD LEVER SHAFT OOSTION PLATE PIN CONTROL LEVER RETURN SPRING	33169 33180 33180 33210 33216 33213 33219 33219 33219 33219 33219 33400 34403 34415 34415 34415 34451 34451 34451 34506 34506 34506 34509
FRONT SHIFT BRACKET SHIFT FORK SPRING SHIFT SHAFT SHIFT SHAFT SHIFT SHAFT OIL SEAL TRANSFER CONTROL LEVER CENTER CASE OIL SEAL TRANSFER SHIFT KNOB CROSS SHAFT TRANSFER PROTECTOR CONTROL ROD CONTROL ROD CONTROL ROD (FWD) ACTUATOR ASSY CONTROL ROD LOWER BRACKET SHIFT ROD TRUNNION SELECT LEVER ASSY (RWD) CONTROL ROD LOWER BRACKET SHIFT ROD TRUNNION SELECT LEVER ASSY (RWD) CONTROL CABLE (RWD) SUB TRANSMISSION ROD DUST COVER HOLDER DUST COVER HOLDER DUST COVER (FWD) SUPPORT ROD FWD) SUPPORT ROD BRACKET SUPPORT ROD BRACKET SUPPORT ROD DAMPER CROSS SHAFT LEVER CROSS SHAFT LEVER CROSS SHAFT ASSY SUPPORT ROD DAMPER CROSS SHAFT ROS (FWD) CROSS SHAFT ROD BRACKET SUPPORT ROD DAMPER CROSS SHAFT ROD BRACKET FOR TOD DAMPER CROSS OVER SHAFT CONTROL DEVICE KEY INTERLOCK CABLE ASSY COMPRESSION ROD LEVER SHAFT POSITION PLATE PIN CONTROL LEVER RETURN SPRING SELLECTOR ROD/CONTROL CABLE	33169 33180 33210 33216 33213 33219 33213 33219 33212 33940 34103 34400 34415 34430 34430 34451 34451 34451 34504
FRONT SHIFT BRACKET SHIFT FORK SPRING SHIFT SHAFT OIL SEAL TRANSFER CONTROL LEVER CENTER CASE OIL SEAL TRANSFER SHIFT KNOB CROSS SHAFT TRANSFER PROTECTOR CONTROL ROD CONTROL ROD (EWD) ACTUATOR ASSY CONTROL ROD LOWER BRACKET SHIFT ROD TRUNNION SELECT LEVER ASSY (RWD) CROSS SHAFT LEVER LOWER CONTROL ROD CONTROL CABLE (RWD) SUB TRANSMISSION ROD DUST COVER HOLDER DUST COVER (EWD) CROSS SHAFT LEVER CROSS SHAFT LEVER CROSS SHAFT ASSY SUPPORT ROD DAMPER CROSS SHAFT LEVER CROSS SHAFT ASSY SUPPORT ROD DAMPER CROSS OF SHAFT AFT CONTROL DEVICE KEY INTERLOCK CABLE ASSY COMPRESSION ROD LEVER SHAFT AFT CONTROL DEVICE KEY INTERLOCK CABLE ASSY COMPRESSION ROD LEVER SHAFT POSITION PLATE PIN CONTROL LEVER RETURN SPRING SELECTOR ROD/CONTROL CABLE ANT CABLE MITERLOCK SOLENOID	33169 33180 33180 33210 33216 33213 33219 33219 33219 33219 33219 33400 34403 34415 34415 34415 34451 34451 34451 34506 34506 34506 34509
FRONT SHIFT BRACKET SHIFT FORK SPRING SHIFT SHAFT SHIFT SHAFT OIL SEAL TRANSFER CONTROL LEVER CENTER CASE OIL SEAL TRANSFER SHIFT KNOB CROSS SHAFT TRANSFER PROTECTOR CONTROL ROD CONTROL ROD CONTROL ROD (FWD) ACTUATOR ASSY CONTROL ROD LOWER BRACKET SHIFT ROD TRUNNION SELECT LEVER ASSY (RWD) CCONTROL GOD, COWER BRACKET SHIFT ROD TRUNNION SELECT LEVER ASSY (RWD) CONTROL CABLE (RWD) SUB TRANSMISSION ROD SUB TRANSMISSION ROD SUB TRANSMISSION ROD DUST COVER (FWD) CROSS SHAFT LEVER CROSS SHAFT	33169 33180 33180 33180 33210 33210 33213 33210 33219 33822 33940 34103 34410 34415 34445 34506 34506 34500

COMPONER

# STEERING, SUSPENSION, BRAKES Gold Preferred Plan

COMPONENT	PALC.
FINAL GEAR	38106
PINION BEARING	38121
HYPOID PINION	38158
COMPANION FLANGE	38212
TRANSFER BREATHER	38323
DIFFERENTIAL SIDE OIL SEAL	38342
DIFFERENTIAL CASE	38410
SIDE GEAR	38413
SIDE GEAR	38414
PINION MATE	38415
PINION MATE	38416
PINION MATE SHAFT	38417
PINION MATE SHAFT	38418
COUNTERSHAFT BEARING	38441
SIDE BEARING	38444
SIDE BEARING	38446
DIFFERENTIAL CASE	38720
PINION MATE SHAFT	38727
VISCOUS COUPLING	38760
CLEVIŞ PIN	46123
CLUTCH PEDAL BUSHING	46526
CLUTCH PEDAL	46540
CLUTCH PEDAL RET. SPRING	46586
VACUUM TANK -	47100
VACUUM TANK ASSY	47110
A/T CONTROL INDICATOR	48475
A/T SHIFTLOCK SYSTEM	48712

# Steering, Suspension,

# BRAKES

STEERING SYSTEM

IDLER PULLEY	11925
IDLER PULLEY BRACKET	11935
POWER STEERING PUMP BRACKET	11940
ADJUSTING BAR	11945
LAMP - HICAS WARNING	25020
HICAS RELAY	25247
SLIP RING	25694
HEAD AMPLIFIER	25697
STEERING SENSOR ASSY	28475
HICAS CONTROL UNIT	28505
RACK & PINION ASSY	48001
STEERING GEAR ASSY	48010
STEERING GEAR HOUSING	48011
STEERING GEAR PINION	48023
PINION GEAR BEARING	48025
PINION OIL SEAL	48025
WORM GEAR BEARING	48025
FILLER PLUG	48060
STEERING LOWER JOINT	48080
STEERING RACK	48100
SECTOR SHAFT	48103
WORM OIL SEAL	48125
SECTOR SHAFT BEARING	48127
SECTOR SHAFT ADJUST SCREWINUT	48135
SECTOR SHAFT OIL SEAL	48137
STEERING WORM ASSY	48150
SECTOR SHAFT COVER	48201
STEERING GEAR BOOT	48203
SECTOR SHAFT COVER GASKET	48204
REAR HOUSING	48210
REAR HOUSING CAP	48212
REAR HOUSING OIL SEAL	48214
ADJUSTER	48231
RACK MOUNT CLAMP	48353
RACK MOUNT INSULATOR	48376
STEERING WHEEL	48400
LOCK NUT	48401
HORN BUTTON ASSY	48420
STEERING GEAR ARM	48502
STEERING GEAR LOCK NUT	48503
SIDE ROD ASSY	48510
SIDE ROD BAR	48512
LOCK NUT	48514
OUTER SOCKET	48520
INNER SOCKET	48521
DUST COVER	48522
SLOTTED NUT	48523
STEERING IDLER ARM	48530
STEERING IDLER FIXING BOLT	48534

COMPONENT	em.
STEERING IDLER LOCK NUT	48535
CROSS ROD	48560
SIDE ROD CLIP	48562
STEERING DAMPER	48611
STEERING LOCK	48700
TRANSFER GEAR ASSY	48760
STEERING COLUMN ASSY	48805
STEERING COLUMN SHAFT	48820
UPPER COLUMN SHAFT	48821
JACKET TUBE	48860
UPPER JACKET TUBE	48861
STEERING COLUMN CLAMP	48960
JOINT COVER	48967
TILT LEVER	48970
POWER STEERING GEAR ASSEMBLY	49001
POWER STEERING PUMP	49110
PUMP RESERVOIR TANK	49115
PUMP CAP	49181
POWER STEERING GEAR ASSEMBLY	49200
O-RING	49203
PINION OIL SEAL	49226
RACK PACKING	49297
STUB SHAFT SEAL	49365
RACK BUSHING	49522
O-RING	49525
CYLINDER TUBE	49541
HOSE/TUBE PUMP TO GEAR	49710
PRESSURE TUBE ASSY	49716
HOSE/TUBE-GEAR TO PUMP	49720
P/S TUBE HOSE	49722
POWER STEERING RETURN HOSE	49725
BREATHER TUBE	49731
POWER STEERING OIL SWITCH	49761
FLOW CONTROL VALVE	49810
PRESSURE CONTROL VALVE ASSY	49836
REAR AXLE BALL JOINT ASSY	55154
ELECTRIC CYLINDER ASSY	55705
HICAS POWER CYLINDER ASSY	55710
HICAS MOTOR ASSEMBLY	55740
POSITION SENSOR ASSY - MAIN	55741
POSITION SENSOR ASSY - SUB	55742
PRESSURE REAR TUBE/HOSE SET	55750
CUT OFF VALVE ASSY	55780
AXLES & SUSPENSION	

#### AXLES & SUSPENSION

SELECT SWITCH	25140
SUSPENSION CONTROL UNIT	25963
SONAR ROAD SENSOR	25965
STEERING ANGLE SENSOR	28476
CENTER BEARING BRACKET	37519
CENTER DRIVE BEARING	37520
AXLE SHAFT	38162
REAR AXLE SHAFT	38162
REAR AXLE SHAFT NUT	38163
BREATHER	38352
DRAIN PLUG	38355
FRONT DRIVE SHAFT 4WD	38519
FRONT DRIVE SHAFT	39100
DRIVE SHAFT	39600
SPIDER ASSY	39625
DRIVE SHAFT BOOT	39655
SLIDE JOINT HOUSING	39714
SLIDE JOINT SPIDER	39720
KNUCKLE SPINDLE (FWD)	40014
KNUCKLE SPINDLE (REAR)	40014
KING PIN	40022
KING PIN BEARING	40030
STEERING STOPPER BOLT	40038
STOPPER BOLT CAP	40039
KNUCKLE ARM	40052
DUST COVER (CV BOOT)	40088
DRIVE SHAFT BOOT	40088
UPPER BALL JOINT	40110
LOWER BALL JOINT	40160
LOWER BALL JOINT SEAT	40173
FRONT WHEEL HUB	40202
DRIVE SHAFT BEARING 4WD	40213
FRONT WHEEL BEARING	40215
FRONT HUB BOLT	40222
GREASE SEAL	40232
FREE RUNNING HUB 4WD	40250
DRIVE CLUTCH GEAR, 4WD	40252
LOCK NUT	40262
BEAM—REAR AXLE	43011
HOUSING-RR AXLE	43018
BUSHING ASSY-AXLE HOUSING	43052

COMPLECE.	5,65
REAR WHEEL HUB	43204
REAR AXLE COMPANION FLANGE REAR AXLE BEARING	43213 43215
REAR HUB BOLT	43222
SEAL, GREASE, RR HUB	43232
REAR AXLE OIL SEAL LOCK NUT	43252 43262
FRONT COIL SPRING (STRUT)	54010
FRONT LEAF SPRING	54010
FRONT TORSION BAR SPRING SEAT	54010 54036
BOUND BUMPER	54050
REBOUND BUMPER	54053
STRUT DUST COVER STRUT DUST SEAL	54055
TORQUE ARM	54059 54080
ANCHOR ARM	54210
ANCHOR ADJ. BOLT & NUT	54216
STRUT ASSY GLAND PACKING	54302 54308
STRUT INSULATOR	54320
STRUT BEARING	54325
REBUND STOPPER ADJ. SHOCK SUB-HARNESS	54342 54390
FRONT SUSPENSION MEMBER	54401
SUPRT BRACKET - FRNT, SUSPENSION MBR.	54402
LINK SPINDLE LOWER LINK SPINDLE	54419 54419
TENSION ROD	54470
TENSION/COMPRESSION ROD	54473
BUSHING TENSION ROD BUSHING	54476 54476
TENSION ROD BRACKET	54480
TRANSVERSE LINK GUSSETT	54499
BUSHING UPPER LINK BUSHING	54504 54507
UPPER LINK ASSY	54524
UPPER LINK BRACKET	54527
LOWERLINK	54529
TRANSVERSE LINK UPPER LINK	54529 54533
BUSHING	54535
UPPER LINK SPINDLE	54536
STEERING KNUCKLE EXTENSION FRONT STABILIZER	54590 54611
BRACKET & BUSHING	54614
CONNECTING ROD BUSHING	54618
ROC-RR STAB. LAUNCHING BRACKET	54619 55015
LOWER LINK ASSY	55019
LOWER LINK (IRS-4WD)	55019
REAR COIL SPRING (IRS) REAL COIL SPRING (STRUT)	55020 55020
REAR COIL SPRING-LINK TYPE	55020
REAR SPRING (LEAF)	55020
TORSION BAR UPPER LINK	55020 55023
PARALLEL ROD	55024
REAR SPRING SEAT (IRS)	55036
REAR SPRING SEAT (STRUT) SPRING SEAT (LINK TYPE)	55036 55036
INNER BUSHING	55042
OUTER BUSHING	55043
SPRING MOUNT BUSHING SUSPENSION ARM BUSHING	55044 55045
SHACKLE BUSHING	55046
LOWER LINK BUSHING	55047
UPPER LINK BUSHING	55048
LOCATION PLATE REAR SUSPENSION LOWER LINK ASSY	55054 55100
LINK ASSYRR SUSPENSION UPPER FR	55121
PANHARD ROD BUSHING	55135
CONTROL ROD PANHARD ROD	55122 55130
LINK ASSYRR SUSPENSION UPPER RR	55131
RADIUS ROD AND BOLT	55140
RADIUS ROD BUSHING SPRING MOUNT	55142 55202
SPRING SHACKLE	55220
REAR SPRING PIN	55225
SUSPENSION ARM BOLT SPRING LOCK PLATE	55226 55227
BOUND BUMPER (IRS)	55240
BOUND BUMPER-LEAF SPRING	55240
BOUND BUMPER-LINK TYPE	55240
STRUT BOUND BUMPER	55241

# ELECTRICAL Gold Preferred Plan

# AXLES & SUSPENSION

consinued

COMPONENT	FALC
SPRING PAD (LEAF)	55243
SPRING CLIP	55247
LOWER LINK BRACELET	55252
SPRING SEAT (LEAF)	55262
UPPER LINK BRACKET	55270
REAR STRUT ASSY	55302
GLAND PACKING	55308
MOUNTING INSULATOR	55320
REAR SUSPENSION MEMBER	55401
TORQUE ARRESTER	55425
STAY-RR SUSPENSION MEMBER	55451
REAR SUSPENSION MOUNT	55466
DIFFERENTIAL MOUNTING MEMBER	55470
DIFFERENTIAL MOUNTING BRACKET	55471
PARALLEL ROD BUSHING	55480
SUSPENSION BAR (MULTI-LINK)	55495
TORSION BEAM — REAR AXLE	55500
SUSPENSION ARM ASSY	55501
REAR ARM ASSY	55502
ANCHOR ARM	55520
PARALLEL ROD BOLT	55524
ANCHOR ARM SLEEVE	55525
REAR ARM BRACKET	55530
TORSION BAR STOPPER	55539
SPRING SEAT STAY	55545
BUSHING	55743
LINK DAMPER	56220
REAR STABILIZER	56230
CONNECT ROD BUSHING	56231
BRACKET-RR STABILIZER	56233
MOUNTING BRACKET BUSHING	56243

#### BRAKES

ABS MOTOR RELAY	25187
STOP LAMP SWITCH	25320
HAND BRAKE CONTROL	36010
PARKING BRAKE SWITCH	36011
RATCHET NAIL	36320
HAND BRAKE STEM	36326
PARKING BRAKE RELEASE ROD	36327
HAND BRAKE BRACKET	36328
HAND BRAKE GUIDE	36335
HAND BRAKE SPRING	36337
HAND BRAKE CONTROL LEVER YOKE	36339
HAND BRAKE LEVER	36372
CLEVIS PIN (HAND BRAKE)	36381
FRONT CABLE	36402
CENTER LEVER BRACKET	36421
ADJUSTER NUT	36437
REAR CABLE	36450
CROSS CABLE	36451
REAR CABLE/ROD	36452
CENTER LEVER	36510
EQUALIZER	36518
	36525
HANGER STRAP/SWING ARM	
SWING ARM	36525
CLEVIS & PIN (HAND BRAKE)	36538
RETURN SPRING	36545
REAR CABLE ADJUSTER	36547
CALIPER YOKE	41025
HOLD DOWN PIN	41040
PIVOT PIN	41041
ANTI-SQUEAK SPRING	41083
CLIP	41086
FRONT CALIPER	41110
CALIPER SEAL & PISTON	41120
FRONT BAFFLE PLATE	41151
REAR CALIPER	44010
BACK PLATE	44020
CALIPER BODY	44025
HOLD DOWN PIN	44040
EXTENSION LINK	44075
ANTI-RATTLE PIN	44081
HAND BRAKE CONTROL LVR YOKE	44082
REAR BRAKE RETURN SPRING	44090
TOGGLE LEVER	44095
REAR WHEEL CYLINDER	44100
LEVER ASSY	44118
PISTON & SEAL	44120
REAR BAFFLE PLATE	44151
ANCHOR - PARKING BRAKE	44180
ADJUSTER ASSY	44200
MASTER CYLINDER	46010
OIL RESERVOIR CAP	46020
RESERVOIR SEAL	46045
LEVEL INDICATOR	46048
PISTON ASSY	46063

COMPOSER	PNC
SNAP RING	46082
FLUID RESERVOIR	46090
FLUID STRAINER	46093
RESERVOIR HOSE	46113
CLEVIS PIN	46123
BRAKE PIPE	46284
CONNECTOR	46313
DP/LOAD SENSING VALVE	46400
BRAKE MASTER CYLINDER BRACKET	46515
PEDAL STOPPER	46518
BRAKE PEDAL	46520
BRAKE PEDAL BUSHING	46525
BRAKE FULCRUM SHAFT	46560
PEDAL SHIFT SLEEVE	46580
BRAKE PEDAL SPRING	46585
BRAKE BOOSTER	47210
BRAKE BOOSTER SPACER	47211
BRAKE BOOSTER CONNECTOR	47475
VACUUM TUBE	47476
CHECK VALVE	47478
ACTIVATOR ASSY	47600
ABS ACTUATOR RELAY	47605
MODULE ASSY	47850
SENSOR ASSY (RR) ANTI-SKID	47900
SENSOR ASSY (FR) ANTI-SKID	47910
ANTI-SKID SPLASH GUARD	47935
ROTOR ASSY (RR) SENSOR	47950
FRONT SENSOR BRACKET	47960
ROTOR ASSY (FR) SENSOR	47970

# E LECTRICAL

#### BODY ELECTRICAL

ASCD O.D. CANCEL SWITCH	18930
MAIN HARNESS	24010
ENGINE HARNESS	24012
INSTRUMENT HARNESS	24013
BODY HARNESS	24014
TAIL HARNESS	24015
CHASSIS HARNESS	24016
CONSOLE HARNESS	24030
ENGINE SUB-HARNESS	24077
TAIL GATE HARNESS	24145
ROOM LAMP HARNESS	24160
FUSIBLE LINK	24161
AIR BAG HARNESS	24170
DOOR HARNESS	24239
REAR WINDOW DEFROSTER	24320
DEFROSTER WIRING	24328
CIRCUIT BREAKER	24330
VOLT METER	24822
DIGITAL TEMP METER ASSY	24835
GAUGE ASSEMBLY	24840
SPEEDOMETER	24850
TACHOMETER	24855
FUEL GAUGE	24860
OIL PRESSURE GAUGE	24870
ODOMETER/TRIP METER	24875
COOLANT TEMP GAUGE	24880
HEAD-UP DISPLAY UNIT	24941
SECURITY INDICATOR LAMP	25021
PRINTED CIRCUIT	25030
WARNING DISPLAY	25041
SPEEDOMETER CABLE	25050
WARNING DISPLAY AMPLIFIER	25065
TAIL GATE SWITCH	25141
LIGHTING/COMBO SWITCH	25160
RETRACTABLE HEADLAMP SWITCH	25195
RELAY—TAIL GATE RELEASE	25202
HEADLAMP RELAY	25203
REAR DEFROST RELAY	25204
HORN RELAY	25205
NSTRUMENT PANEL SWITCH	25210
GNITION RELAY	25215
NHIBITOR RELAY	25216
RELAY-AUTO LAMP	25219
HEADLAMP DIMMER RELAY	25228
RELAY—FOG LAMP	25229
ASCD RELAY	25234
RELAYREAR WIPER	25236
STARTER RELAY	25243
ASCD VACUUM PUMP RELAY	25245
NTERLOCK EMERGENCY RELAY	25250
POWER WINDOW RELAY	25252
CLUTCH RELAY	25258
MULTI-REMOTE CONTROL RELAY	25259
SWITCH - SLIDE DOOR	25259

HEADLAMP CLEANER SWITCH	2526
REAR WIPER/WASHER SWITCH	2526
ASCD HOLD RELAY	2526
SWITCH KNOB	2526
HEADLAMP DAYTIME RELAY NAVI SPEAKER RELAY	2526 2527
RELAY—N & P	2527
ILLUMINATION CONTROL	2528
SWITCH - AUTO DOOR ON/OFF	2529
SWITCH - BACK DOOR	2529
ASCD CLUTCH SWITCH	2532
ASCD STOP SWITCH CIGARETTE LIGHTER	2532
REAR DEFROST SWITCH	2534
DOOR SWITCH	2536
DOOR LOCK SWITCH	2536
BACK DOOR SWITCH	2536
BACK DOOR UNLOCK SWITCH SWITCH ASSY—FOG LAMP	2536 25370
TRUNK LID OPENER SWITCH	2538
FUEL FILLER OPENER SWITCH	2539
DOOR LOCK SWITCH	25400
INTERLOCK EMERGENCY SWITCH	2540
CLUTCH INTERLOCK SWITCH	2540
FUSE BLOCK FUSIBLE LINK HOLDER	25410 2541
HEADLAMP SENSOR UNIT	2550
TAIL & STOP LAMP SENSOR	25500
FLASHER ASSY:COMBINATION	25520
FLASHER UNIT & RELAY	25521
METER POWER UNIT	25522
SEAT BELT WARNING TIMER HEADLAMP/TURN SIGNAL SWITCH	25529 25540
BRUSH ASSEMBLY	25542
REAR WIPER/WASHER SWITCH	25560
HEAT MIRROR SWITCH	25580
VOICE WARNING SWITCH	25591
TRANSMITTÉR RECEIVER	25695 25696
GLOVE BOX SWITCH	25720
POWER WINDOW MAIN SWITCH	25750
POWER WINDOW SUB SWITCH	25752
HAZARD SWITCH	25880
SPEED SENSOR	25911
VOICE WARNING UNIT DISPLAY UNIT	25925 25930
CONTROL UNIT	25931
POWER UNIT	25936
NAVI GPS ANTENNA ASSY	25957
DRIVE COMPUTER DISPLAY CONTROL UNIT - BACK DOOR	25987 25990
RETRACTABLE HEADLAMP MOTOR	26010
HEADLAMP ASSY	26023
FRONT COMBO LAMP ASSY	26120
SIDE MARKER LAMP ASSY	26160
SIDE CLEARANCE LAMP	26162
HORN Warning Chime/Buzzer	26310 26350
KEYLESS ENTRY BUZZER	26352
WIPER ARM	26380
REAR WIPER ARM	26390
ROOM/LUGGAGE LAMP	26410 26416
SPOT LAMP (SWITCH) STEP (FOOTWELL) LAMP	26420
SWITCH—REAR SIDE WINDOW	26430
OOT LAMP ASSY	26440
VANITY MIRROR LAMP	26450
JICENSE LAMP ASSY	26510 26540
REVERSE LAMP REAR COMBO LAMP ASSY	26550
REAR COMB. LAMP HARNESS	26551
REAR COMB. LAMP GASKET	26553
HIGH MOUNT STOP LAMP	26591
CLOCK	27380
TEE TUBE WASHER NOZZLE	27416
REAR WASHER NOZZLE	27450
WASHER TUBE	27460
REAR WASHER TUBE	27470
WIPER WASHER TANK	27480
REAR WASHER TANK	27490
WASHER TANK LEVEL SENSOR HEADLAMP CLEANER PUMP	27491
HEADLAMP CLEANER T-VALVE	27528
HEADLAMP CLEANER TANK	27534
HEADLAMP CLEANER NOZZLE - ANTENNA SWITCH -	27538

# BODY & INTERIOR COMPONENTS Gold Preferred Plan

COMPONENT	P.M.s.
ANTENNA	27960
VIDEO OR NAVI DISPLAY ASSY	28090
REMOTE CONTROL RADIO SWITCH	28268
REAR AUDIO PANEL	28269
REAR DEFOGGER CONDENSOR	28357
ASCD ACTUATOR	28400
ASCD SERVO VALVE	28401
ASCD CONTROLLER	28402
ASCD CABLE	28403
ASCD MAIN SWITCH	28404
RETRACTABLE HEADLAMP TIMER	28412
ASCD SOLENOID VALVE	28415
CORNERING LAMP UNIT	28421
TIMEROIL LEVEL	28432
DOOR LOCK TIMER	28450
REAR DEFROST TIMER	28455
INTERIOR LAMP TIMER	28460
ANTENNA TIMER	28490
BODY CONTROL LAN MODULE	28492
P/S CONTROL UNIT	28500
WIPER RELAY	28510
POWER WINDOW AMPLIFIER	28515
CONTROL UNIT - SLIDE DOOR	28543
TIME CONTROL UNIT	28550
LIGHTING CONTROL	28575
LIGHTING SENSOR	28578
THEFT WARNING CONTROL UNIT	28591
THEFT WARNING SUB-CONTROL	28592
THEFT WARNING RELAY	28593
SMART ENTRANCE CONTROL UNIT	28594
KEYLESS ENTRY CONTROL UNIT	28595
REAR WIPER MOTOR	28710
WASHER MOTOR	28765
REAR WASHER MOTOR	28766
WIPER MOTOR	28810
INTERMITTANT WIPER AMP	28820
WIPER MOTOR ARM	28840
WIPER CONNECTING ROD	28860
PIVOT ASSY	28870
ASCD SPEED SENSOR	28940
DECELERATION SENSOR ASSY	47930
IGNITION KEY LAMP ASSY	48476
IGNITION SWITCH	48750
HOOD SWITCH	65630
DOOR LOCK ACTUATOR	80550
KEYBOARD	80604
FRONT REGULATOR MOTOR	80730
REAR REGULATOR MOTOR	82730
REAR SIDE WINDOW MOTOR	83500
INTELLIGENT KEY SWITCH - TRUNK/BACK DOOR	
ASCD VACUUM PUMP	92270

## HEATER & AIR CONDITIONING

COMPRESSOR BRACKET	11910
IDLER PULLEY	11925
IDLER PULLEY BRACKET	11926
REAR HEATER CONTROL	25207
BLOWER MOTOR RELAY	25208
HEATER RELAY	25214
A/C RELAY	25218
F.I.C.D. RELAY (Fast Idle Control Device)	25224
REAR A/C RELAY	25225
FAN MOTOR RELAY.	25246
MAX COLD DOOR RELAY	25257
REAR HEATER RELAY	25274
HEATER UNIT	27000
REAR HEATER CORE	27013
REAR HEATER MOTOR	27014
HEATER & A/C CONTROL	27030
VACUUM SELECTOR VALVE	27031
ATC CONTROL	27032
REAR HEATER	27035
A/C HARNESS	27038
A/C SWITCH	27041
BLOWER CASE/HOUSING	27065
BLOWER MOTOR & FAN	27070
HEATER CONNECTOR	27071
HEATER SWITCH RESISTOR	27077
VACUUM ACTUATOR	27080
VACUUM TANK	27084
VACUUM WATER COCK	27090
VACUUM CHECK VALVE	27096
HEATER CORE	27115
HEATER COCK	27116
CONTROL CABLE	27134
MODE ACTUATOR ASSY	27141
BLOWER CONTROL AMPLIFIER	27150

COMPONENT	P.N.C.
CENTER DEFROST DUCT	27151
SIDE DEFROST DUCT	27152
FLOOR NOZZLE REAR COOLING CASE	27167 27172
HEATER DUCT	27173
DUCT AIR OUTLET	27175
REAR HEATER RESISTOR	27178
HEATER HOSE THERMISTOR	27181 27322
THERMO CONTROL UNIT	27330
REAR BLOWER MOTOR	27375
FAN IMPELLER REAR EVAPORATOR	27383 27410
REAR A/C HIGH TUBE ASSY.	27413
REAR A/C LOW TUBE ASSY.	27414
CASE ASSEMBLY	27415
COOLER BOX & TUBING REFRIGERATOR ASSY	27430 27430
REAR COOLER HARNESS	27582
DRAIN HOSE	27619
EVAPORATOR SWITCH—HIGH PRESSURE	27621 27623
EXPANSION VALVE	27625
COMPRESSOR ASSY	27630
RADIATOR FAN CONTROL AMP	27631
RECEIVER DRIER — LOW PRESSURE SWITCH	27640 27648
CONDENSOR	27650
CONDENSOR FAN & MOTOR	27651
FAST IDLE DIAPHRAGM SOLENOID VALVE	27655 27659
SUCTION THROTTLE VALVE	27660
SWITCHREAR A/C	27665
SIDE VENT DUCT	27670
ACCELERATION CUT SWITCH THERMO CONTROL AMPLIFIER	27671
COOLER PIPE	27677
JOINT CONNECTOR	27680
VACUUM LOCK-OUT SWITCH FLOOR DUCT SENSOR	27685 27700
VENTILATOR DUCT SENSOR	27701
DEFROSTER NOZZLE SENSOR	27702
ROOF IN-CAR SENSOR FOOT IN-CAR SENSOR	27703 27704
SUNLOAD SENSOR	27705
SENSOR GRILLE	27706
VACUUM HOSE FAN CONTROL AMPLIFIER	27711 27717
INTAKE SENSOR	27723
IN-VEHICLE SENSOR	27727
COMPRESSOR SHAFT SEAL WATER TEMP SENSOR	27730
BI-LEVEL MOTOR ACTUATOR	27732 27736
FEEDBACK RESISTOR (PBR)	27738
AIR MIX DOOR ACTUATOR	27740
DOUBLE SOLENOID VACUUM VALVE MAGNETIC CLUTCH	27741
SNAP RING	27744
ACTUATOR - DEFROSTER DOOR	27747
ACTUATOR - DRIVER SIDE, AIR MIX DOOR	27748
ASPIRATOR FAN	27752
AMBIENT SENSOR	27755
SUNLOAD SENSOR AMPLIFIER	27764 27765
SHIFT ACTUATOR VALVE SOLENOID VALVE SET	27770
CENTER VENT DUCT	27860
REAR HEATER GRILLE	27913
HEATER REAR DUCT AUTO AIR CONTROL AMPLIFIER	27950 28520
MAGNETIC CLUTCH AMPLIFIER	28525
CONTROL KNOB	68725
VALVE—EXPANSION SUPER HEAT SWITCH	92200 92310
THERMAL PROTECTOR	92316
ACCELERATION CUT TIMER	92330
SUPER HEAT TIMER	92331
REAR HEATER HOSE REAR HEATER TUBE	92420 92433
REAR COOLER PIPE	92463
FLEXIBLE HOSE-LOW PRESSURE	92480
FLEXIBLE HOSE-HIGH PRESSURE PIPE - REAR HIGH/LOW COOLER	92490 92741
COMPRESSOR RPM SENSOR	92855

# BODY & INTERIOR COMPONENTS

COMPONE	
BODY	. 10 105 .
COMPONENT	PAR
ACCELERATOR PEDAL BELL CRANK ASSY	18110
SUN ROOF HARNESS	24162
SUN ROOF SLIDE SWITCH	25191
SUN ROOF RELAY	25192
MIRROR HEAT RELAY	25200
BACK DOOR HATCH OPENER SWITCH REMOTE MIRROR SWITCH	25380 25570
MIRROR HEAT SWITCH	25580
AIR GUIDE	41182
HOOD HINGE	65400
HOOD STAY	65470 65601
HOOD LOCK CABLE	65620
SUNROOF RAIL ASSY	73662
SUN ROOF MOTOR GUIDE BRACKET	73670
SUN ROOF LIMIT SWITCH	73678
SUN ROOF MOTOR SUN ROOF STRIKER	73685 73812
FEMALE LOCK	73820
ROOF PANEL HINGE	73860
DRAIN HOSE (SUNROOF)	73876
SUNSHADE - SKYROOF SEAT BELT/ANCHOR STAY	73960 74830
ENGINE UNDER COVER	75891
REAR SEAT BACK CENTER SUPPORT	76730
REAR SIDE WINDOW HINGE	76829
REAR SIDE WINDOW HANDLE	76870
UPPER RAIL GUIDE	77790 77796
REAR RAIL GUIDE FUELING STOPPER ASSY	78402
TRUNK LID SWITCH	78526
FUEL FILLER LID OPENER	78826
FRONT DOOR HINGE	80400
DOOR STOPPER LINK FRONT LOCK	80430 80502
LOCK KNOB ROD	80510
REMOTE CONTROL ROD	80512
KNOB ROD PROTECTOR	80519
LOCK STRIKER LOCK KNOB	80570 80595
LOCK CYLINDER	80600
FRONT OUTSIDE HANDLE	80605
HANDLE ROD	80608
FRONT INSIDE HANDLE	80670
FRONT WINDOW REGULATOR REAR DOOR HINGE	80700 82400
UPPER STOPPER	82440
LOWER STOPPER	82442
UPPER MALE DOVETAIL	82470
UPPER FEMALE DOVETAIL LOWER MALE DOVETAIL	82472 82474
LOWER FEMALE DOVETAIL	82476
REAR LOCK ASSY	82502
LOCK KNOB ROD	82510
MOTOR - CLOSING	82512 82530
AUTO DOOR LOCK ACTUATOR	82550
MOTOR · SLIDE DOOR	82560
LOCK STRIKER	82570
MOTOR - BACK DOOR OPEN/CLOSE	82580
LOCK KNOB REAR OUTSIDE HANDLE	82595 82605
HANDLE ROD	82608
REAR INSIDE HANDLE	82670
REAR WINDOW REGULATOR	82700
REGULATOR HANDLE	82760
WELT - REAR WINDOW SLIDE DOOR LOCK ASSY	83331 83502
REAR SIDE WINDOW REGULATOR	83506
REMOTE CONTROL ROD	83512
OUTSIDE HANDLE	83605
INSIDE HANDLE	83670
REGULATOR WIRE SLIDE DOOR ROLLER	83752 83810
SLIDE DOOR LINK	83840
DECK LID LOCK STRIKER	84420

# AUDIO COMPONENTS Gold Preferred Plan

BODY	
------	--

#### continued

D. C. A. L. C. A. C.	
COMPONENT	P,N,C.
LID OPENER LEVER	84440
LID OPENER CABLE	84450
DECK LID LOCK	84460
TRUNK OPENER SOLENOID	84471
DECK LID HINGE	84510
DECK LID TORSION BAR	84532
RR BUMPER SHOCK ABS./STAY	85210
SPECIAL BOLT	87408
BACK DOOR LOCK & HANDLE	90502
TAILGATE STOPPER	90510
STRIP - PINCH, BACK DOOR	90523
GLASS HATCH OPENER ACTUATOR	90550
TAILGATE WEDGE/DOVETAIL	90623
TAILGATE HANDLE	90940
ELECTRIC DOOR MIRROR	96302

#### INTERIOR

BODY SONIC RELAY	25248
SPIRAL CABLE	25554
AIRBAG CONTROL UNIT	25555
BODY SONIC HARNESS	28378
SENS & DIAG (PLANS PRIOR TO 1/1/99)	28558
SEAT BELT CONTROL UNIT	28570
SIDE VENT NOZZLE	66550
DEFROSTER GRILLE	68742
SIDE DEFROSTER GRILLE	68745
CENTER VENT NOZZLE	68790
SUN ROOF LOCK	73520
MOTOR - STORAGE LID OPENER	84472
RECLINING SWITCH	86401
SENSOR - PRESSURE DETECTION	86509
PASSIVE BUCKLE ASSY	86878
SEAT BELT POWER UNIT	86910
SEAT BELT SLIDE ASSY	86920
SEAT BELT LIMIT SWITCH	86970
SEAT BELT LIMIT SWITCH	86980
SWITCH-SEAT SLIDE	86982
SIDE AIRBAG HARNESS	B7020
BACK VIBRATOR PLATE	87060
CUSHION VIBRATOR PLATE	87080
SLIDE, LIFT SWITCH (PWR/SEAT)	87352
FRT, SEAT LIMIT SWITCH	87504
AIR PUMP	87652
SLIDE ASSY (PWR/SEAT)	87653
LIFT ASSY (PWR/SEAT)	87654
SEAT SWIVEL ASSY	88201
2ND SEAT BACK HINGE	B8350
REAR RECLINING DEVICE ASSY	88451
2ND SEAT SLIDE	88501
SLIDE ASSY3RD SEAT	88505
REAR SEAT BACK LOCK	88603
REAR SEAT BACK STRIKER	88604
3RD SEAT HINGE ASSY	89303
SEAT LOCK ASSY	89341
LOCK ASSY—2ND SEAT	89342
RECLINING DEVICE ASSY	89401
RAIL ASSY—3RD SEAT	B9552
A/T RANGE INDICATOR	96940
ASSIST AIRBAG MODULE	98515
AIRBAG MODULE	98520
SENSOR (PLANS SOLD PRIOR TO 1/1/99)	98581
SIDE AIRBAG MODULE ASSY	98930
AIRBAG ON/OFF SWITCH	98840
AIRBAG ON/OFF SWITCH HARNESS	98841
MODULE ASSY - AIR BAG PRES. DETECTION	98850

#### ACCESSORIES

V.S.S. ELECTRONIC MODULE	AA600
V.S.S. STATUS PANEL	AA601
V.S.S. HARNESSS	AA602
V.S.S. PIN SWITCH	AA603
V.S.S. ELECTRONIC MODULE	AA700

#### 240SX Convertible Top

BOW ASSY #1	K1951
BOW ASSY #4	K2032
BOW ASSY #2	K2038
BOW ASSY #3	K2050
FRT. DOOR GUIDE LOCATOR/RECEIVER	K2252
REAR VIEW MIRROR	K2573
TOP STACK CONTROL SWITCH	K3086
DECK LID GAS STRUT	K3185
TOP LOGIC RELAY/JUMPER	K3353
TOP MECHANISM CLAMP ASSY	K3658
REAR SIDE WINDOW SWITCH/BEZEL FRT. DOOR GUIDE	K4412

K5204
K6658

# 350Z/300ZX Convertible Top

HYDRAULIC MOTOR/PUMP ASSY	K8048
HYDRAULIC CYLINDER ASSY	K8049
HOSE/BYPASS VALVE ASSY	K8097
SIDE WINDOW REGULATOR ASSY	K8098
RELAY, STORAGE OPENER	25209
RELAY, STORAGE OPEN CANCEL	25211
RELAY, TOP STK RR LOCK OPENER	25212
RELAY, TOP INTERLOCK	25213
RELAY, TRUNK LID OPENER	25221
RELAY, TRUNK LID OPEN CANCEL	25222
UNIT - FOLDING ROOF CONTROL	25313
SWITCH - LIMIT, ROOF FRONT	25365
	25366
SWITCH - LIMIT, REAR HATCH	
SWITCH - LIMIT, ROOF REAR	25367
STORAGE OPENER SWITCH	25383
SWITCH - TRUNK OPENER CANCEL	25385
SWITCH - ROOF OPENER	25465
THEFT WARNING PIN SWITCH	68542
COVER - REAR FLOOR	73908
SIDE WITHRSTRP RETAINER ASSY	76871
HEADER WTHRSTRP RETAINER ASSY	76874
FINISHER - ROOF FRONT LATCH	76880
FUEL LID ACTUATOR	78852
RR PARCEL SHELF BRACKET ASSY	79926
GUIDE PIN	80520
PIN RECEIVER	80524
MOTOR - STORAGE LID OPENER	84472
SWITCH - STORAGE LID STOP	84480
TRUNK LID OPENER ACTUATOR	84680
HINGE - 3RD SEAT LOWER	89130
MOTOR - REAR HATCH CLOSURE	90552
FRAME ASSY - FOLDING ROOF	97004
NO.1 BOW ASSY	97012
NO. 2 BOW ASSY	97020
NO. 3 BOW ASSY	97040
REAR FRAME	97061
RECEIVER, PULL-DOWN LATCH	97082
PULL-DOWN CLAMP ASSY	97087
LATCH - ROOF FRPNT	97088
STAY - REAR HATCH	97089
LOCK ASSY, REAR	97090
REAR LOCK STRIKER PIN	97092
MOTOR - FOLDING ROOF	97093
TOP FOLDING HOOK ASSY	97094
REHOOK ASSY, TOP STACK	97097
RAIL ASSY, FRONT	97100
RAIL ASSY, CENTER	97106
	97112
RAIL ASSY, REAR	97120
LINK ASSY, BALANCE	
MOTOR/RAIL - REAR HATCH	97125
LINK, CONTROL	97132
TOP STACK FOLDING BRACKET	97142
BRACKET - FOLDING ROOF FRNT, MOUNTING	97143
BRACKET - FOLDING ROOF REAR MOUNTING	97145
BALANCE SPRING	97146
COVER RETAINER, FRONT	97155
COVER RETAINER, FRONT HEADLINER RETAINER, NO. 1 BOW	97164
COVER RETAINER, FRONT HEADLINER RETAINER, NO. 1 BOW HEADLINER RETAINER, NO. 3 BOW	97164 97167
COVER RETAINER, FRONT HEADLINER RETAINER, NO. 1 BOW HEADLINER RETAINER, NO. 3 BOW PLATE - FOLDING ROOF	97164 97167 97173
COVER RETAINER, FRONT HEADLINER RETAINER, NO. 1 BOW HEADLINER RETAINER, NO. 3 BOW PLATE : FOLDING ROOF WELT - FOLDING ROOF	97164 97167 97173 97177
COVER RETAINER, FRONT HEADLINER RETAINER, NO. 1 BOW HEADLINER RETAINER, NO. 3 BOW PLATE - FOLDING ROOF WELT - FOLDING ROOF FRONT RAIL SHIM	97164 97167 97173 97177 97178
COVER RETAINER, FRONT HEADLINER RETAINER, NO. 1 BOW HEADLINER RETAINER, NO. 3 BOW PLATE - FOLDING ROOF WELT - FOLDING ROOF FRONT RAIL SHIM SHIM - FOLDING ROOF	97164 97167 97173 97177 97178 97179
COVER RETAINER, FRONT HEADLINER RETAINER, NO. 1 BOW HEADLINER RETAINER, NO. 3 BOW PLATE - FOLDING ROOF WELT - FOLDING ROOF FRONT RAIL SHIM SHIM - FOLDING ROOF FRONT WITHRISTRY RETAINER ASSY	97164 97167 97173 97177 97178 97179 97180
COVER RETAINER, FRONT HEADLINER RETAINER, NO. 1 BOW HEADLINER RETAINER, NO. 3 BOW PLATE - FOLDING ROOF WELT - FOLDING ROOF FRONT RAIL, SHIM SHIM - FOLDING ROOF FRONT WITHESTER RETAINER ASSY REAR WITHESTER PETAINER ASSY	97164 97167 97173 97177 97178 97179 97180 97184
COVER RETAINER, FRONT HEADLINER RETAINER, NO. 1 BOW HEADLINER RETAINER, NO. 3 BOW PLATE - FOLDING ROOF WELT - FOLDING ROOF FRONT RAIL SHIM SHIM - FOLDING ROOF FRONT WITHESTEP RETAINER ASSY REAR WITHESTEP RETAINER ASSY CENTER RAIL SHIM	97164 97167 97173 97177 97178 97179 97180 97184 97188
COVER RETAINER, FRONT HEADLINER RETAINER, NO. 1 BOW HEADLINER RETAINER, NO. 3 BOW PLATE - FOLDING ROOF WELT - FOLDING ROOF FRONT RAIL, SHIM SHIM - FOLDING ROOF FRONT WITHESTER RETAINER ASSY REAR WITHESTER PETAINER ASSY	97164 97167 97173 97177 97178 97179 97180 97184
COVER RETAINER, FRONT HEADLINER RETAINER, NO. 1 BOW HEADLINER RETAINER, NO. 3 BOW PLATE - FOLDING ROOF WELT - FOLDING ROOF FRONT RAIL, SHIM SHIM - FOLDING ROOF FRONT WHISTIRP RETAINER ASSY REAR WITHESTEP RETAINER ASSY CENTER RAIL, SHIM HINGE ASSY, STORAGE LID BAR, STORAGE LID	97164 97167 97173 97177 97178 97179 97180 97184 97188
COVER RETAINER, FRONT HEADLINER RETAINER, NO. 1 BOW HEADLINER RETAINER, NO. 3 BOW PLATE - FOLDING ROOF WELT - FOLDING ROOF FRONT RAIL SHIM SHIM - FOLDING ROOF FRONT WHIRSTER RETAINER ASSY REAR WHIRSTER PETAINER ASSY CENTER RAIL SHIM HINGE ASSY, STORAGE LID BAR, STORAGE LID SHIM - STORAGE LID SHIM - STORAGE LID SHIM - STORAGE LID	97164 97167 97173 97177 97178 97179 97180 97184 97188 97240
COVER RETAINER, FRONT HEADLINER RETAINER, NO. 1 BOW HEADLINER RETAINER, NO. 3 BOW PLATE - FOLDING ROOF WELT - FOLDING ROOF FRONT RAIL SHIM SHIM - FOLDING ROOF FRONT WITHESTEP RETAINER ASSY REAR WITHRSTEP RETAINER ASSY CENTER RAIL SHIM HINGE ASSY, STORAGE LID BAR, STORAGE LID SHIM - STORAGE LID SHIM - STORAGE LID DOVETAIL ASSY, STORAGE LID	97164 97167 97173 97177 97178 97179 97180 97184 97188 97240 97242
COVER RETAINER, FRONT HEADLINER RETAINER, NO. 1 BOW HEADLINER RETAINER, NO. 3 BOW PLATE - FOLDING ROOF WELT - FOLDING ROOF FRONT RAIL SHIM SHIM - FOLDING ROOF FRONT WITHESTEP RETAINER ASSY REAR WITHRSTEP RETAINER ASSY CENTER RAIL SHIM HINGE ASSY, STORAGE LID BAR, STORAGE LID SHIM - STORAGE LID SHIM - STORAGE LID DOVETAIL ASSY, STORAGE LID	97164 97167 97173 97177 97178 97179 97180 97184 97188 97240 97242 97243
COVER RETAINER, FRONT HEADLINER RETAINER, NO. 1 BOW HEADLINER RETAINER, NO. 3 BOW PLATE FOLDING ROOF WELT FOLDING ROOF FRONT RAIL SHIM SHIM FOLDING ROOF FRONT WTHESTER RETAINER ASSY REAR WTHESTER PETAINER ASSY CENTER RAIL SHIM HINGE ASSY, STORAGE LID BAR. STORAGE LID SHIM STORAGE LID SHIM STORAGE LID RECEIVER, DOVETAIL RECEIVER, DOVETAIL SPRING, STORAGE LID	97164 97167 97173 97177 97178 97179 97180 97184 97188 97240 97242 97243 97244
COVER RETAINER, FRONT HEADLINER RETAINER, NO. 1 BOW HEADLINER RETAINER, NO. 3 BOW PLATE FOLDING ROOF WELT FOLDING ROOF FRONT RAIL SHIM SHIM FOLDING ROOF FRONT WTHESTER RETAINER ASSY REAR WTHESTER PETAINER ASSY CENTER RAIL SHIM HINGE ASSY, STORAGE LID BAR. STORAGE LID SHIM STORAGE LID SHIM STORAGE LID RECEIVER, DOVETAIL RECEIVER, DOVETAIL SPRING, STORAGE LID	97164 97167 97173 97177 97178 97179 97180 97184 97188 97240 97242 97243 97244 97246
COVER RETAINER, FRONT HEADLINER RETAINER, NO. 1 BOW HEADLINER RETAINER, NO. 3 BOW PLATE - FOLDING ROOF WELT - FOLDING ROOF FRONT RAIL SHIM SHIM - FOLDING ROOF FRONT WITHESTER RELAINER ASSY REAR WITHRSTER PETAINER ASSY REAR WITHRSTER PETAINER ASSY OENTER RAIL SHIM HINGE ASSY, STORAGE LID BAR. STORAGE LID STIM - STORAGE LID RECEIVER, DOVETAIL SPRING, STORAGE LID RECEIVER, DOVETAIL SPRING, STORAGE LID DOVETAIL ASSY, STORAGE LID RECEIVER, DOVETAIL SPRING, STORAGE LID LOWER ROLLER ASSY, STORAGE LID	97164 97167 97173 97177 97178 97179 97180 97184 97188 97240 97242 97243 97244 97246 97252
COVER RETAINER, FRONT HEADLINER RETAINER, NO. 1 BOW HEADLINER RETAINER, NO. 3 BOW PLATE - FOLDING ROOF WELT - FOLDING ROOF FRONT RAIL, SHIM SHIM - FOLDING ROOF FRONT WTHESTER RETAINER ASSY REAR WTHESTER RETAINER ASSY CENTER RAIL SHIM HINGE ASSY, STORAGE LID BAR. STORAGE LID SHIM - STORAGE LID BAR. STORAGE LID RECEIVER, DOVETAIL SPRING, STORAGE LID RECEIVER, DOVETAIL SPRING, STORAGE LID DERGLER ASSY, STORAGE LID GUIDE RAIL ASSY STORAGE LID LOWER ROLLER ASSY, STORAGE LID COVETAIL ASSY, STORAGE LID GUIDE RAIL ASSY	97164 97167 97173 97177 97178 97179 97180 97184 97240 97242 97243 97244 97246 97256
COVER RETAINER, FRONT HEADLINER RETAINER, NO. 1 BOW HEADLINER RETAINER, NO. 3 BOW PLATE - FOLDING ROOF WELT - FOLDING ROOF FRONT RAIL, SHIM SHIM - FOLDING ROOF FRONT WTHESTER RETAINER ASSY REAR WTHESTER RETAINER ASSY CENTER RAIL SHIM HINGE ASSY, STORAGE LID BAR. STORAGE LID SHIM - STORAGE LID BAR. STORAGE LID RECEIVER, DOVETAIL SPRING, STORAGE LID RECEIVER, DOVETAIL SPRING, STORAGE LID DERGLER ASSY, STORAGE LID GUIDE RAIL ASSY STORAGE LID LOWER ROLLER ASSY, STORAGE LID COVETAIL ASSY, STORAGE LID GUIDE RAIL ASSY	97164 97167 97173 97177 97178 97179 97180 97184 97240 97242 97243 97244 97244 97246 97252 97255 97259
COVER RETAINER, FRONT HEADLINER RETAINER, NO. 1 BOW HEADLINER RETAINER, NO. 3 BOW PLATE - FOLDING ROOF WELT - FOLDING ROOF FRONT WILL SHIM SHIM - FOLDING ROOF FRONT WITHESTER RETAINER ASSY REAR WITHESTER PETAINER ASSY CENTER RAIL SHIM HINGE ASSY, STORAGE LID BAR. STORAGE LID BAR. STORAGE LID SHIM - STORAGE LID RECEIVER, DOVETAIL SPRING, STORAGE LID COVETAIL ASSY, STORAGE LID GUIDE RAIL ASSY DOVETAIL BOLT ASSY LOCK ASSY, STORAGE LID	97164 97167 97173 97177 97178 97179 97180 97184 97188 97240 97242 97243 97244 97245 97256 97256 97256 97250
COVER RETAINER, FRONT HEADLINER RETAINER, NO. 1 BOW HEADLINER RETAINER, NO. 3 BOW PLATE - FOLDING ROOF WELT - FOLDING ROOF FRONT RAIL, SHIM SHIM - FOLDING ROOF FRONT WTHESTEP RETAINER ASSY REAR WTHRSTRP RETAINER ASSY REAR WTHRSTRP RETAINER ASSY STORAGE LID BAR, STORAGE LID BAR, STORAGE LID SHIM - STORAGE LID HINGE DOVETAIL, ASSY, STORAGE LID RECEIVER, DOVETAIL SPRING, STORAGE LID LOWER ROLLER ASSY, STORAGE LID GUIDE RAIL ASSY DOVETAIL BOLT ASSY	97164 97167 97173 97177 971778 97178 97178 97180 97184 97188 97240 97243 97244 97246 97252 97254 97259 97259 97260 97262
COVER RETAINER, FRONT HEADLINER RETAINER, NO. 1 BOW HEADLINER RETAINER, NO. 3 BOW PLATE - FOLDING ROOF WELT - FOLDING ROOF FRONT RAIL, SHIM SHIM - FOLDING ROOF FRONT WITHSTRP RETAINER ASSY REAR WITHESTRP RETAINER ASSY CENTER RAIL, SHIM HINGE ASSY, STORAGE LID BAR. STORAGE LID BAR. STORAGE LID HINGE DOVETAIL, ASSY, STORAGE LID RECEIVER, DOVETAIL SPRING, STORAGE LID LOWER ROLLER ASSY, STORAGE LID GUIDE RAIL, ASSY DOVETAIL BOLT ASSY LOCK ASSY, STORAGE LID STRIKER, STORAGE DEPERR	97164 97167 97173 97177 97178 97178 97178 97180 97184 97188 97240 97242 97242 97244 97246 97252 97254 97256 97259 97259 97259 97259 97259 97259
COVER RETAINER, FRONT HEADLINER RETAINER, NO. 1 BOW HEADLINER RETAINER, NO. 3 BOW PLATE - FOLDING ROOF WELT - FOLDING ROOF FRONT WILL SHIM SHIM - FOLDING ROOF FRONT WITHESTER RETAINER ASSY REAR WITHESTER RETAINER ASSY CENTER RAIL SHIM HINGE ASSY, STORAGE LID BAR. STORAGE LID BAR. STORAGE LID SHIM - STORAGE LID BAR. STORAGE LID SPRING, STORAGE LID RECEIVER, DOVETAIL SPRING, STORAGE LID GUIDE RAIL ASSY LOCK ASSY, STORAGE LID STRIKER, STORAGE DENER FRONT STORAGE LID STRIKER, STORAGE OPENER FRONT STORAGE LID BUMPER	97164 97167 97173 97177 97178 97179 97180 97184 97240 97242 97243 97244 97246 97255 97259 97260 97260 97264 97264 97264
COVER RETAINER, FRONT HEADLINER RETAINER, NO. 1 BOW HEADLINER RETAINER, NO. 3 BOW PLATE - FOLDING ROOF WELT - FOLDING ROOF FRONT RAIL, SHIM SHIM - FOLDING ROOF FRONT WITHESTER RELAINER ASSY REAR WITHRSTER PETAINER ASSY CENTER RAIL, SHIM HINGE ASSY, STORAGE LID BAR, STORAGE LID SHIM - STORAGE LID HINGE DOVETAIL ASSY, STORAGE LID RECEIVER, DOVETAIL SPRING, STORAGE LID LOWER ROLLER ASSY, STORAGE LID GUIDE RAIL, ASSY DOVETAIL BOLT ASSY DOVETAIL BOLT ASSY DOVETAIL STORAGE LID STRIKER, STORAGE LID BUMPER CABLE ASSY, TORAGE OPENER FRONT STORAGE UD BUMPER CABLE ASSY, TOP STORAGE OPENER	97164 97167 97177 97178 97179 97180 97180 97180 97180 97242 97242 97243 97244 97243 97245 97252 97252 97252 97252 97252 97252 97252 97252 97252 97252 97252 97252 97253 97260 97260 97260 97260 97260
COVER RETAINER, FRONT HEADLINER RETAINER, NO. 1 BOW HEADLINER RETAINER, NO. 3 BOW PLATE - FOLDING ROOF WELT - FOLDING ROOF FRONT WILL SHIM SHIM - FOLDING ROOF FRONT WITHESTER RETAINER ASSY REAR WITHESTER RETAINER ASSY CENTER RAIL SHIM HINGE ASSY, STORAGE LID BAR. STORAGE LID BAR. STORAGE LID SHIM - STORAGE LID BAR. STORAGE LID SPRING, STORAGE LID RECEIVER, DOVETAIL SPRING, STORAGE LID GUIDE RAIL ASSY LOCK ASSY, STORAGE LID STRIKER, STORAGE DENER FRONT STORAGE LID STRIKER, STORAGE OPENER FRONT STORAGE LID BUMPER	97164 97167 97173 97177 97178 97179 97180 97184 97240 97242 97243 97244 97246 97255 97259 97260 97260 97264 97264 97264

COMPONEN:	P.N.C
ACTUATOR ASSY, TOP OPENER	97278
FINISHER - OVERHEAD	97283
SCREEN - REAR	97530


## AUDIO/VIDEO COMPONENTS

CD CHANGER CARTRIDGE	B8118
CLARION AUDIO/COMBO UNIT	2790A
PANASONIC AUDIO/COMBO UNIT	2790C
SPEAKER	27933
BOSE SPEAKER	2793A
RADIO FINISHER	28041
SONY CD PLAYER	2818D
ANTENNA ROD/MAST	28215
REMOTE RADIO SWITCH	28268
REAR AMPLIFIER	28063
PANASONIC CD PLAYER	2818C
PANASONIC CASSETTE DECK	2920C
CLARION SPEAKER AMP	2806C
BONDING (GROUNDING) WIRE	28360
PRE-AMP SPEAKER AMP	28060
REAR WINDOW ANTENNA AMP	25190
POWER SUPPLY BOX	28089
SPEAKER - WOOFER	27934
SPEAKER - WOOFER	2806H
DVD UNIT	28119

#### Mobile Entertinment System

MES Auxiliary Switch	AA018
MES Overhead Monitor	AA018
MES VCR/DVD Unit	AA018
MES Interface Box	AA018
MES Remote Switch	B10AA
MES Headphones	AA018
FES Video Monitor	28091
FES Video Cassette Planer	28706

\*Covered Audio Components listed.herein are applicable to Preferred Plans sold on or after April 1, 2004.





## **NISSAN SECURITY+PLUS**

# THE BEST PROTECTION FOR YOUR NISSAN



#### DISCLAIMER:

THIS BROCHURE IS NOT A CONTRACT. THE BROCHURE CONTENT IS LIMITED BY SIZE. THE ENTIRE CONTRACT IS INCLUDED IN THE NISSAN SECURITY+PLUS SERVICE AGREEMENT. BE SURE TO READ YOUR SECURITY+PLUS SERVICE AGREEMENT AS ALL BENEFITS ARE SUBJECT TO THE LIMITATIONS, EXCLUSIONS, TERMS AND CONDITIONS OF THE SERVICE AGREEMENT.

#### NOTICE

In compliance with federal laws, the contents of this brochure should be interpreted and understood within the meaning of a "Service Contract" as defined in Federal Law. (See 15 USCS Sec. 2301 (8).)

Nissan, the Nissan Logo and Nissan Model Names are Nissan Trademarks. © 2004 Nissan North America, Inc. (800) NISSAN-1 NissanUSA.com

# ATTACHMENT E

**Technical Service Bulletins** 

# **Technical Bulletin**



SERVICE	BULLETIN	
Classification:	Reference:	Date:
WT92-003a	NTB92-123a	August 30, 2006

# AFTERMARKET RECHROMING OF NISSAN ALLOY WHEELS

**APPLIED VEHICLE(S):** 

All Models

#### SERVICE INFORMATION

Nissan Original Equipment or Genuine Accessory Alloy wheels, along with their finish coating (clear, chrome, titanium, etc.), are specifically developed to achieve Nissan design and performance standards. These Original Equipment or Genuine Accessory wheels are also subjected to rigorous testing procedures to ensure they meet Nissan's standards. Nissan cannot ensure that Original Equipment Alloy or Genuine Accessory wheels subjected to aftermarket chroming are not damaged in some way, and that they continue to meet these standards. Therefore, Nissan does not recommend aftermarket chroming of Nissan original equipment Genuine Accessory Alloy wheels or their use.

Nor does Nissan in any way whatsoever warrant or guarantee such wheels or their performance. To the contrary, aftermarket chroming of Nissan original equipment Genuine Accessory Alloy wheels will likely result in denial of any warranty claim.

If Nissan Original Equipment or Genuine Accessory Alloy wheels are subjected to aftermarket chroming, problems may occur as a result of the chroming process, including:

- 1. The chroming process generally removes the original finish by "burning" or "chemical" methods, both of which my cause the heat treatment of the alloy to be changed. The application of chrome plating has to be controlled correctly, as the alloy can be harmed by a poorly controlled process.
- 2. Aftermarket chroming may degrade the durability, long term appearance, and may affect safety and performance of the wheels.

Accordingly, Nissan strongly recommends that Original Equipment or Genuine Accessory Alloy wheels not be modified by processes such as aftermarket chrome plating.

Please consult the Nissan Warranty Policies and Procedures Manual pertaining to the Dealer's responsibility when altering or modifying vehicles.

Models	All models
Section	Wheel & Tire
Classification	WT92-003
Bulletin No.	NTB92-123
Date	December 22, 1992

# AFTERMARKET CHROMING OF NISSAN ALLOY WHEELS

## SERVICE INFORMATION

The Original Equipment Alloy Wheels on Nissan vehicles are specifically developed in order to achieve the Nissan design and performance standards. These Original Equipment wheels are also subject to rigorous testing procedure's to ensure they meet Nissan's standards.

Nissan cannot ensure that Original Equipment Alloy Wheels which are subjected to aftermarket chroming meet these same standards, and therefore Nissan does not recommend the use of such wheels, nor does Nissan make any representations concerning their performance.

Indeed, if these Original Equipment Alloy Wheels are subjected to aftermarket chroming, there are serious potential problems which may occur as a result of the chroming process:

- 1. The chroming process removes the original paint coating by "burning" or "chemical" methods, both of which cause the alloy surface to be changed. The application of chrome plating has to be controlled correctly, as the alloy can be harmed by a poorly controlled process.
- 2. Overall aftermarket chroming may degrade the durability, long term appearance, and may affect safety and performance of the wheels.

Accordingly, Nissan recommends that Original Equipment Wheels NOT be chrome plated.

Please consult the Nissan Warranty Policies and Procedures Manual pertaining to the Dealer's responsibility when altering or modifying vehicles.

# WARRANTY INFORMATION

Note that damage to Nissan Alloy road wheels due to any non-factory-authorized process, such as chroming, is the responsibility of the customer, and is not covered by the Nissan Warranty, please consult the "Nissan Warranty Information Booklet" for specific details.