

Emer™ PRD Replacement for Gillig CNG Fuel Systems with Type 4 Cylinders and Manual Cylinder Valves ENP-735 REV B May 28, 2020



1. Introduction

Agility Fuel Solutions LLC (Agility®) has determined that pressure relief devices (PRDs) manufactured by Emer™ may fail to operate as designed. This issue has been reported to the National Highway Traffic and Safety Administration (NHSTSA Recall No. 20E-019). Impacted parts include Emer™ p/n PRD2302T-004 (Agility® p/n 10306997) used in Agility® compressed natural gas (CNG) fuel systems produced from October 6, 2016, to April 1, 2020.

PRDs are essential for safe vehicle operation and must be replaced if non-compliant. Agility[®] personnel have identified fuel system top level part numbers supplied for Gillig buses containing recalled Emer™ PRDs as original equipment manufacturer (OEM) equipment.

Agility® has engineered two retrofit kits for fuel systems equipped with Type 4 cylinders and manual cylinder valves to replace recalled Emer™ PRDs. The two retrofit kits replace 85-in. and 120-in. fuel system plumbing with PRDs manufactured by VTI and new PRD supply and vent tubes.

Agility[®] created this instructional document to guide trained CNG fuel system service technicians in the removal, replacement, and reporting of affected Emer™ PRDs.

1.1. Warning Messages and Symbols used in this document

▲ DANGER

Will cause death or severe injuries if procedures are not followed.

MARNING

Could cause death or severe injuries if procedures are not followed.

ACAUTION

Could cause minor or moderate injuries if procedures are not followed.



Practices not related to physical injury. Includes procedures to prevent vehicle damage as well as hints to help an operation or procedure go smoothly.



Critical Characteristic

Procedure directly affects safety of vehicle users, people nearby and maintenance personnel, or regulatory compliance.



Manufacturing Characteristic

- A product feature solely used to improve manufacturability or maintain process control .
- A process parameter or step that has a significant effect on achieving a Critical Characteristic or Significant Characteristic, or maintaining material identification/traceability.



2. Affected Units

Agility® top level system part numbers as follows:

25518000 - Roof Mount, 156 DGE, 2084 L, 8 Tanks, Gillig, Type 4

25520000 - Roof Mount, 185 DGE, 2474 L, 8 Tanks, Gillig, Type 4

25522000 - Roof Mount, 126 DGE, 1692 L, 8 Tanks, Type 4, Gillig

3. Tools and Supplies Required

Fall protection equipment	Safety glasses	
Safety ladder	Defueling hose with nozzle**	
NGV1 fuel receptacle adapter*	Shop towels	
Swagelok® preswage tool	Combination wrenches	
Socket wrenches	Swagelok® Snoop leak detection solution	
Permanent marker	Agility® reporting form FT.0320	
Torque seal marker	Agility go-nogo gauge, p/n TD 400394	
Camera / phone camera	Zip lock bag (NOTE: supplied by Agility with bulk replacement PRD shipment—use for PRD return)	
Flashlight		

^{*}may be required for defueling on some FMMs

3.1. PRD retrofit kits



Before beginning work, verify proper quantity of the appropriate Agility® PRD retrofit kit is on hand.

Agility® fuel system part numbers and corresponding retrofit kit part numbers are as follows:

Fuel system p/n	QTY required Kit, Retrofit, Gillig, 120" tanks PRD Retrofit, p/n 25519031	QTY required Kit, Retrofit, Gillig, 85" tanks PRD Retrofit, p/n 25519030
25518000	1	1
25519000	1	1
25520000	2	n/a
25521000	2	n/a
25522000	n/a	2

Verify proper part composition and quantity for each kit according to the following content lists and drawings:

^{**}If not provided at CNG fueling facility



00065 00208 00238 00563	Description Fitting, Tube, Connector, 1/2-in. Tube OD, 9/16-18 Male SAE, SS Fitting, Tube, Tee, 1/2-in. Tube OD, 1/2-in. Tube OD, 1/2-in. Tube OD, SS Fitting, Tube, Adapter, 1/2-in. Tube OD, 9/16-18 Male SAE, SS Fitting, Tube, Staright, 2 Male, UC, 4/2 20 Male, SAE, Staring	2 2 2
00208	Fitting, Tube, Tee, 1/2-in. Tube OD, 1/2-in. Tube OD, 1/2-in. Tube OD, SS Fitting, Tube, Adapter, 1/2-in. Tube OD, 9/16-18 Male SAE, SS	2
00238	Fitting, Tube, Adapter, 1/2-in. Tube OD, 9/16-18 Male SAE, SS	-
00563		2
	Fitting IIC Consider C Male IIC 4/0 00 Male CAF Const	_
<u> </u>	Fitting, JIC, Straight, -8 Male JIC, 1/2-20 Male SAE, Steel	4
00010	T-PRD, VTI, Remote, PRD 1	4
)2157	Decal, System, Danger Live High Pressure PRD Line	4
)2442	Decal, PRD Vent Line, Caution	8
00370	Dual Clamp Tie, 19.20-in Long, .025-in. Stud Dia.	2
01508	Tube Clamp Kit, 1/2-in., Double Mounting Hole, -40F to 212F	6
02022	P-Clip, 3/8-in., Rubber Clamp (10mm)	2
)2147	P-Clip, 1/2-in., Rubber Clamp	2
00436	Spacer, 0.100 in., Tube Clamp, Twin, 1/2-in., Single Mounting Hole	6
19028	Tube Subassembly, 25519420, PRD to Vent	1
19029	Tube Subassembly, 25519421, PRD To Vent	1
19037	Tube Subassembly, 25519429, PRD to Vent	1
19038	Tube Subassembly, 25519430, PRD To Vent	1
19039	Hardware, Retrofit Kit	1
19123	Bracket, tube clamp	2
19416	Tube, Formed, HP Fuel, 1/2-in. X .049-in., Tee to PRD	2
1903 1912	39 23	Hardware, Retrofit Kit Bracket, tube clamp




Figure 1. Kit, Retrofit, Gillig, 120" tanks PRD Retrofit, p/n 25519031.



	Kit contents: Kit, Retrofit, Gillig, 85" tanks PRD Retrofit, p/n 25519030. <i>Figure 2</i>				
Item	p/n	Description	QTY		
1	10200065	Fitting, Tube, Connector, 1/2-in. Tube OD, 9/16-18 Male SAE, SS	2		
2	10200208	Fitting, Tube, Tee, 1/2-in. Tube OD, 1/2-in. Tube OD, 1/2-in. Tube OD, SS	2		
3	10200238	Fitting, Tube, Adapter, 1/2-in. Tube OD, 9/16-18 Male SAE, SS	2		
4	10200563	Fitting, JIC, Straight, -8 Male JIC, 1/2-20 Male SAE, Steel	4		
5	10300513	T-PRD, VTI, Remote, PRD 1	4		
6	10602157	Decal, System, Danger Live High Pressure PRD Line	4		
7	10602442	Decal, PRD Vent Line, Caution	8		
8	10700370	Dual Clamp Tie, 19.20-in Long, .025-in. Stud Dia.	2		
9	10701508	Tube Clamp Kit, 1/2-in., Double Mounting Hole, -40F to 212F	6		
10	10702022	P-Clip, 3/8-in., Rubber Clamp (10mm)	2		
11	10702147	P-Clip, 1/2-in., Rubber Clamp	2		
12	20100436	Spacer, 0.100 in., Tube Clamp, Twin, 1/2-in., Single Mounting Hole	6		
13	25519026	Tube Subassembly, 25519414, PRD to Vent	1		
14	25519027	Tube Subassembly, 25519415, PRD To Vent	1		
15	25519037	Tube Subassembly, 25519429, PRD to Vent	1		
16	25519038	Tube Subassembly, 25519430, PRD To Vent	1		
17*	25519039	Hardware, Retrofit Kit	1		
18	25519123	Bracket, tube clamp	2		
19	25519417	Tube, Formed, HP Fuel, 1/2-in. X .049-in., Tee to PRD	2		

^{*}Not shown




Figure 2. Kit, Retrofit, Gillig, 85" tanks PRD Retrofit, p/n 25519030



4. Parts Location Identification

Refer to the appropriate fuel system illustration to locate the affected Emer™ PRDs in fuel system plumbing for 85-in. and 120-in. cylinders. *Figures 3 and 4*




Figure 3.

Locations of Emer™ PRDs (1) in 85-in. cylinder fuel system plumbing. NOTE: PRD bracket (2) elevated for clarity.




Figure 4.

Locations of Emer™ PRDs (1) in 120-in. cylinder fuel system plumbing. NOTE: PRD bracket (2) elevated for clarity



5. Corrective Action / Procedure

5.1. Preliminary Safety Preparation

1 TAHW	Set parking brake and secure vehicle with wheel chocks (not shown).	WHAT N	Attach a lock and tag (not shown) to block vehicle ignition.	
WHY	Worker safety.	WHY	Prevent vehicle start during repair procedure.	
3	Secure a safety ladder in either of the following locations:			
WHAT	A. Inside bus hatch opening B. Rear of bus exterior			
×H×	OSHA compliance.			



4 1. Open fuel system roof pod doors (d).

△WARNING

2. Secure fall protection equipment (not shown) to fall restraint lanyard attachment points (2).

△WARNING

3. Secure doors open with door retention strap (e). Refer to vehicle OEM instructions.


△WARNING

4. Always reattach fall PPE when resuming work on the roof mount portion of the fuel system.

WH≺


WHAT

OSHA compliance.





5.2. Prior to defueling





TVT/W	Defuel bus according to local facility regulations and procedure. If required: use defuel hose kit.	4 TAHW	Relieve any remaining system pressure by slowly opening the FMM (4) bleed valve (b).	4
> 1	PRD supply tubes to be removed are pressurized "live" lines.	XHX		



5.3. Remove Emer PRDs

- 1.Use two wrenches to loosen nut fittings (a) on each Emer™ PRD (d).
 - 2.Use wrenches to remove fasteners securing the following items:
 - A. P-clip (7)
 - B. Dual tube clamp (8)
 - C. Plate (6)

•

WHAT


Retain all clips, clamps, plates and fasteners for reuse.

NOTICE

- Support PRD and PRD vent assembly while removing clips and clamps.
- Use caution to avoid contact with cylinders.
- 3. Carefully remove PRD plumbing from each PRD bracket (9) as an assembly including Emer™ PRDs (d).
- Repeat for all plug end cylinders on all foof mount pods.

ΛHΥ

Protect cylinders from damage.






Use a pair of wrenches to Place all removed Emer™ remove all Emer™ PRDs PRDs in zip lock bag (d) from PRD vent tubes provided with bulk retrofit kit (5a) and (5b). shipment. 5a Dispose of PRD vent Place only PRDs from one WHAT tubes (5a) and (5b) vehicle in each zip lock according to facility bag. guidelines. Bag must be labeled with the following: 1. Fleet 2. VIN 3. Fuel system s/n PRD vent tubes will not be 1. Bag helps prevent PRD contamination. reused. 2. Agility is collecting all WHY WHY PRDs removed; return material authorization (RMA) instructions appear below.



5.4. Install PRD retrofit kits

5.4.1. Kit, Retrofit, Gillig, 85" tanks PRD Retrofit, p/n 25519030, installation instructions






2 1. Install tee fitting (12), p/n 13 15 10200208, on PRD 85-in. cylinder pod tube, (13), p/n 12 25519417. Tighten fitting finger tight; fittings will be tightened at a later step. 2. Install two tube clamp kits (15), p/n 10701508, on PRD tube, (13), p/n 25519417. 3. Secure tube clamps (15) to two locations (circled) 2X 2.50 on PRD bracket (9) WHAT using clamp kit **INSET A** 2.5-in HEX CAP SCREW FACES TOWARD PRD BRACKET fasteners as shown in (9) TO SECURE CLAMP (15) TO PRD BRACKET. INSET A. To ease component installation, do not tighten fasteners completely; fasteners will be torqued at a later step. 1.5-in HEX CAP SCREW FACES AWAY FROM Support PRD vent lines. PRD BRACKET (9) TO CAPTURE CLAMP (15).




Always use a backing wrench on the main fitting while using a wrench to install another fitting. 1. Install tube adapter fitting (17), p/n 85-in. cylinder pod 10200238 on VTI PRD (16b), p/n 10300513. Torque fitting (17) to 26 ft-lbs (35.25Nm) 2. Install straight fitting (18), p/n 10200563, on WHAT VTI PRD (16a), p/n 10300513. 3. Install straight fitting (18), p/n 10200563, on VTI PRD (16a), p/n 10300513. Torque fittings (18) to 18.5 ft-lbs (25Nm). 4. Install tube fitting (14), p/n 10200065, on VTI PRD (16a), p/n 10300513. **Torque fitting (14)** to 45 ft-lbs (61Nm). WHY











6a 1. Install PRD vent tube (26), p/n 25519026, on PRD (16a) fitting (a). Tighten nut fitting finger tight; fittings will be tightened at a later step. 85-in. cylinder pod 2. Slip dual tube clamp (8), on PRD vent tube (26), and on PRD vent tube (5a). 3. Use dual tube clamp (8) 16a fasteners (not visible) to WHAT secure plate (6) and PRD vent tube (26), to PRD bracket (9) at hole (circled). 4. Slide P-clip on PRD vent tube (26) and use existing fastener to secure P-clip (7) to Pclip bracket (b). 26 5с Tighten fasteners finger tight; fasteners will be torqued at a later step.

MH



6b 1. Install PRD vent tube (37), p/n 25519037, on PRD (16b) fitting (a).


Tighten nut fitting (b) finger tight; fitting will be tightened at a later step.


- 2. Slip tube clamp kit (15), on PRD vent tube (37).
- 3. Insert one 1.5-in. hex cap screw, p/n 10760200-0150, and one 2.5-in. hex cap screw, p/n 10760200-0120, into each tube clamp kit (15), as shown in INSET A.
- 4. Install one flat washer. p/n 10761000, and one flange top nut, p/n 10763000 (not shown) on each hex cap screw inserted in previous sub step.
- 5. Secure PRD vent tube (37) to PRD bracket (9) at hole.

Tighten fasteners finger tight; fasteners will be torqued at a later step.

MH≺

WHAT





2.5-in. HEX CAP SCREW FACES TOWARD PRD BRACKET (9) TO SECURE CLAMP (15) TO PRD BRACKET.

1.5-in. HEX CAP SCREW FACES AWAY FROM PRD BRACKET TO CAPTURE CLAMP (15).



- 1. Install tube clamp bracket (23), p/n 25519123 and one* spacer, p/n 20100436, on existing double tube clamp (8) using the double tube clamp fasteners and spacer (26), p/n 20100436.
- 2. Install P-clip (7), p/n 10702147, on PRD vent tube (37), p/n 25519037, and secure to bracket (23), p/n 25519123 using one hex cap screw, p/n 10760200-0100, one flat washer, p/n 10761000, and one flange top nut, p/n 10761300.


WHAT

*Additional spacers are provided in the retrofit kit if required.


NOTICE

Tighten fasteners finger tight; fasteners will be tightened at a later step.

System specification.










Tighten clamp fasteners at all clamp locations (circled). 85-in. cylinder pod WHAT Tighten fasteners to 8 ftlbs (11Nm). System specification. MH10 1. Verify clearance between PRD vent 85-in. cylinder pod tubes (a) and live high pressure PRD vent tubes (b) is 3/8-in. minimum. (b) **PLUG END** 2. Verify clearance between all system WHAT plumbing and cylinders (c) is 3/8-in. minimum. If required: Adjust tube (a) clips and clamps as required and repeat Step 10. **VALVE END** Prevent fuel line damage. ×HΑ









Always use a backing wrench on the main fitting while using a wrench to install another fitting. 5. Install tube adapter fitting (17), p/n 10200238 on VTI PRD 85-in. cylinder pod (16b), p/n 10300513. **Torque fitting (17)** to 26 ft-lbs (35.25Nm) 6. Install straight fitting (18), p/n 10200563, on VTI PRD (16a), p/n 10300513. 7. Install straight fitting (18), p/n 10200563, on VTI PRD (16a), p/n 18 16b 10300513. Torque fittings (18) to 18.5 ft-lbs (25Nm). 8. Install tube fitting (14), p/n 10200065, on VTI PRD (16a), p/n 10300513. **Torque fitting (14)** to 45 ft-lbs (61Nm). WHY











15 1. Install PRD supply tube (5b) on PRD supply tube 85-in. cylinder pod (13) at tee fitting (12). 12 Tighten fitting finger tight; 15 fitting will be tightened at a later step. 2. Install tube clamp kit (15), p/n 10701508, on PRD supply tube, (5b). 3. Insert one 1.5-in. hex cap screw, p/n 10760200-0150, and one 2.5-in. hex cap screw, p/n **INSET A** 10760200-0120, into WHAT 2.5-in HEX CAP SCREW FACES TOWARD PRD BRACKET each tube clamp kit (15), (9) TO SECURE CLAMP (15) TO PRD BRACKET. as shown in INSET A. 4. Install one flat washer. p/n 10761000, and one flange top nut, p/n 10763000 (not shown) on each hex cap screw inserted previously. 5. Secure PRD supply tube 15 (5b) to PRD bracket (9). Tighten fasteners finger tight. 1.5-in HEX CAP SCREW FACES AWAY FROM PRD BRACKET (9) TO CAPTURE CLAMP (15). MHY



16 1. Install PRD vent tube (27), p/n 25519027, on PRD (16a) fitting (a).


Tighten fittings finger tight; fittings will be torqued at a later step.

- 2. Use dual tube clamp, (8) and plate (6), to secure PRD supply tube (5d) to PRD vent tube (27).
- 3. Slip P-clip (7) on PRD vent tube (27).
- 4. Attach P-clip (7) to Pclip bracket (b) using existing fasteners (not visible).

Tighten fasteners finger tight; fasteners will be torqued at a later step.

MH

9 16a 85-in. cylinder pod





		idel sciolicias
17 a	Use two wrenches to tighten 1/2-in. Swagelok fittings at four	85-in. cylinder pod
	locations (circled).	65-III. Cyllilaci pod
WHAT	Tighten 1/2-in. Swagelok fittings per Appendix B WI.0441.	
WHY	System specification.	
17 b	Use two wrenches to tighten SAE/JIC	
	fittings at two locations (circled).	85-in. cylinder pod
WHAT	Tighten SAE/JIC fittings to 45 ft-lbs (61Nm).	
M	to 40 It-lb3 (OTMIII).	
WHY	System specification.	
>		



18 1. Install tube clamp bracket (23), p/n 25519123, and one* spacer, p/n 20100436, on existing double tube clamp (7) using double tube clamp fasteners (not shown).

- Install P-clip (8), p/n 10702147 on PRD vent tube (37), p/n 25519037.
- 3. Install P-clip (8) on tube clamp bracket (23) using one hex cap screw, p/n 10760200-0100, one flat washer, p/n 10761000, and one flange top nut, p/n 10761300.

WHAT

*Additional spacers are provided in the retrofit kit if required.


NOTICE

Tighten fasteners finger tight; fasteners will be tightened at a later step.


PRD vent tubes may need to be adjusted for clearance.

85-in. cylinder pod **VIEW A VIEW A**













5.4.2. Kit, Retrofit, Gillig, 120" tanks PRD Retrofit, p/n 25519031, installation instructions









- 1. Install two tube clamp kits (15), p/n 10701508, from retrofit kit on PRD tube, (13), p/n 25519417.
 2. Insert one 1.5-in. hex cap screw (a), p/n 10760200-0150, and
 - 2. Insert one 1.5-in. hex cap screw (a), p/n 10760200-0150, and one 2.5-in. hex cap screw (b), p/n 10760200-0120, into each tube clamp kit (15), as shown in INSET A.
 - 3. Install one flat washer, p/n 10761000, and one flange top nut, p/n 10763000 (not shown) on each hex cap screw inserted in previous sub step.
 - 4. Secure PRD vent tube (13) to PRD bracket (9) at holes *(circled)*.


NOTICE

To ease component installation, do not tighten fasteners completely; fasteners will be tightened at a later step.

MHY

WHAT


Support PRD vent lines.





Always use a backing wrench on the main fitting while using a wrench to install another fitting. 1. Install tube adapter fitting (17), p/n 10200238 on VTI PRD 120-in. cylinder pod (16b), p/n 10300513. **Torque fitting (17)** to 26 ft-lbs (35.25Nm) 2. Install straight fitting (18), p/n 10200563, on VTI PRD (16a), p/n WHAT 10300513. 3. Install straight fitting (18), p/n 10200563, on 16b VTI PRD (16a), p/n 16a 10300513. Torque fittings (18) to 18.5 ft-lbs (25Nm). 4. Install tube fitting (14), p/n 10200065, on VTI PRD (16a), p/n 10300513. **Torque fitting (14)** to 45 ft-lbs (61Nm). MHY







1. Install PRD vent supply tube (5d) on tee fitting (12).

NOTICE

Tighten fittings finger tight; fittings will be tightened at a later step.

- 2. Reinstall tube clamp kit (15) on PRD vent supply tube (5d).
- 3. Use tube clamp kit fasteners (not visible) from to secure clamp to PRD bracket (9).

NOTICE

Tighten fasteners finger tight; fasteners will be tightened at a later step.

×Hγ

WHAT

9 120-in. cylinder pod



1. Install PRD vent tube 1. Slip P-clip (8) removed 120-in. cylinder pod earlier on PRD vent tube 120-in. cylinder pod (28), p/n 25519028, on (28), p/n 25519028. tee fitting (12). 2. Secure P-clip (8) to P-clip bracket (b) using existing Tighten fittings finger hardware. tight; fittings will be tightened at a later step. 2. Install two Tube Clamp Tighten fasteners finger 28 Kits, 1/2-in., Double tight; fasteners will be Mounting Hole (7), p/n tightened at a later step. 10701508, from retrofit kit on PRD vent tube (28), and PRD supply WHAT WHAT tube (5c). 3. Use dual tube clamp (7) fasteners (not visible) from to secure clamps to PRD bracket (9). Tighten fasteners finger b tight; fasteners will be tightened at a later step. MHYWHY



7 1. Install nut fitting of PRD vent tube (37) on VTI PRD (16a) outlet fitting (a).

NOTICE

Tighten fitting finger tight; fitting will be tightened at a later step.

2. Install tube clamp kit (15), p/n 10701508, on PRD vent tube (37).

3. Use tube clamp kit (15) fasteners (not visible) from to secure clamp to PRD bracket (9).


NOTICE

Tighten fasteners finger tight; fasteners will be tightened at a later step. 9 16a 15 37 120-in. cylinder pod

×H×

WHAT







- 9 1. Install tube clamp bracket (23), p/n 25519123, and one* spacer, p/n 20100436, existing double tube clamp (7).
 - 2. Slip P-clip (8), p/n 10702147, on PRD vent tube (37), p/n 25519037.
 - 3. Install P-clip (8) on tube clamp bracket (23), p/n 25519123, using one hex cap screw, p/n 10760200-0100, one flat washer, p/n 10761000, and one flange top nut, p/n 10761300.

WHAT


MHY

*Additional spacers are provided in the retrofit kit if required.


NOTICE

Tighten fasteners finger tight; fasteners will be tightened at a later step.


System specification.













- 1. Install two tube clamp kits (15), p/n 10701508, from retrofit kit on PRD tube, (13), p/n 25519417.
 - 2. Insert one 1.5-in. hex cap screw (a), p/n 10760200-0150, and one 2.5-in. hex cap screw (b), p/n 10760200-0120, into each tube clamp kit (15), as shown in INSET A.
 - 3. Install one flat washer, p/n 10761000, and one flange top nut, p/n 10763000 (not shown) on each hex cap screw inserted in previous sub step.

WHAT


MHY

4. Secure PRD vent tube (13) to PRD bracket (9) at holes *(circled)*.

NOTICE

To ease component installation, do not tighten fasteners completely; fasteners will be torqued at a later step.


Support PRD vent lines.





Always use a 120-in. cylinder pod backing wrench on the main fitting while using a wrench to install another fitting. 1. Install tube adapter fitting (17), p/n 10200238 on VTI PRD (16b), p/n 10300513. Torque fitting (17) to 26 ft-lbs (35.25Nm) 2. Install straight fitting (18), p/n 10200563, on VTI PRD (16a), p/n WHAT 10300513. 3. Install straight fitting (18), p/n 10200563, on VTI PRD (16a), p/n 10300513. Torque fittings (18) to 18.5 ft-lbs (25Nm). 4. Install tube fitting (14), p/n 10200065, on VTI PRD (16a), p/n 10300513. **Torque fitting (14)** to 45 ft-lbs (61Nm). MHY







1. Install PRD vent supply 120-in. cylinder pod tube (5d) on tee fitting а (12). 15 Tighten fittings finger tight; fittings will be tightened at a later step. 2. Reinstall tube clamp kit (15) on PRD vent supply tube (5d). 3. Use tube clamp kit fasteners (not visible) from to secure clamp to PRD bracket (9). Tighten fasteners finger tight; fasteners will be tightened at a later step. WHY



16 b

WHAT

1. Install PRD vent tube (29), p/n 25519027, on VTI PRD (16b) fitting (a).

NOTICE

Tighten nut fitting finger tight; fittings will be tightened at a later step.


2. Slip two dual tube clamps (8) and two spacers, p/;n (not shown) on PRD vent tube (29), and on PRD supply tube (5d).

- 3. Use dual tube clamp (8) fasteners (not visible) to secure two clamps (8) and two plates (6), to PRD bracket (9) at hole (circled).
- 4. Slide P-clip (7) on PRD vent tube (29) and use existing fastener to secure P-clip (7) to P-clip bracket (b).

NOTICE

Tighten fasteners finger tight; fasteners will be torqued at a later step.

×H×





17 1. Install nut fitting of PRD vent tube (38) on VTI PRD (16a) outlet fitting (a).

NOTICE

Tighten fitting finger tight; fitting will be tightened at a later step.

- 2. Install tube clamp kit (15), p/n 10701508, on PRD vent tube (38).
- 3. Use tube clamp kit (15) fasteners (not visible) from to secure clamp to PRD bracket (9).

NOTICE


Tighten fasteners finger tight; fasteners will be tightened at a later step.

WHAT

9 15 a 16a 38

120-in. cylinder pod







20 1. Install tube clamp bracket (23), p/n 25519123, on existing double tube clamp (7) and one* spacer, p/n 20100436 (not shown).

- 2. Slip P-clip (8), p/n 10702147, on PRD vent tube (38), p/n 25519038.
- 3. Install P-clip (8) on tube clamp bracket (23), p/n 25519123 using one hex cap screw, p/n 10760200-0100, one flat washer, p/n 10761000, and one flange top nut, p/n 10761300.

*Additional spacers are provided in the retrofit kit if required.


NOTICE

Tighten fasteners finger tight; fasteners will be tightened at a later step.

WHY

WHAT

System specification.




120-in. cylinder pod



Tighten clamp fasteners at all clip 120-in. cylinder pod and clamp locations (circled). Tighten fasteners to 8 ftlbs (11Nm). System specification. ×H× 22 1. Verify clearance between PRD vent 120-in. cylinder pod tubes (a) and live high pressure PRD supply tubes (b) is 3/8-in. minimum. **PLUG END VALVE END** 2. Verify clearance between all system plumbing and cylinders (c) is 3/8-in. minimum. If required: Adjust clamps as required and repeat Step 23. (b) Prevent fuel line and cylinder damage.







5.4.3. Check PRD vent tube outlet clearance

1	1. Gently close one	OLISHIT LAND SALIVI LITTES ON LEG COLISHIT ON CHITCHS	2	Repeat Step 1 for each roof	
	fuel system roof	ATTINDON, CARS MACE DR. ATTINDON, CARS MACE DR.		pod door.	
	pod door.				
	2. Visually verify proper				
	clearance between plug end PRD vent tube cap				
	(f) and door opening				
	(circled).				
	3. Visually verify proper				
	clearance between valve end PRD vent	(f)			
	tube caps (f) and door		_		
WHAT	opening (circled).		WHAT		
≥	△WARNING		\geqslant		
	PRD vent tubes cannot				
	protrude above the top of				
	the pod door.				
	If PRD vent tube caps protrude above the pod				
	door opening, fuel system				
	plumbing must be adjusted	(*			
	to achieve proper clearance.	AFTEN: 4-CluS Vent Location			
		UV PROTECTIVE STATE			
≥	Verify proper PRD vent	PREVENT WATER FROM EIDELING	≥	Verify proper PRD vent tube	
WHY	tube position.	IF UV CAPS ARE MISSING CONSULT OPERATION MANUAL	WHY	position.	



5.5. System Leak Check Procedure

1 1. Turn 1/4-turn manual shut off valve (3) on the FMM (2) to the OPEN position.

MARNING

- Select the appropriate CNG fuel nozzle and/or adaptor for the FMM (2) fuel fill receptacle (not visible).
- 3. Remove fuel fill receptacle dust cap (f).
- 4. Begin fueling the vehicle with CNG using a regulated fuel supply.

WHAT




Open nozzle valve slowly and regulate gas delivery to prevent connector from icing and reducing or blocking fuel flow.

△WARNING

Follow all local and facility fueling regulations and procedures.



Test fuel system integrity.





Monitor FMM (2) high 3 pressure gauge (b) to Leak test all fuel and verify when system PRD tubes and fitting pressure reaches 500 connections using Swagelok psi to 510 psi (3.45MPa Snoop® leak detection solution to 3.52MPa) and stop or equivalent. pressurization. **△WARNING** 1. If a hissing sound is WHAT WHAT heard coming from fuel system fittings during filling, stop the fill immediately. 2. Try to isolate the sound and spray Swagelok Snoop® on the suspected location to check for bubble formation. Subjects fuel system to Approved leak detection solution for visual inspection partial operating of system leaks. pressure.



4 LAHW	 Begin at one end the of the fuel system and work methodically to spray all fuel line fittings with Swagelok Snoop® or equivalent. Allow at least 10 minutes to elapse before checking the integrity of fitting connections. 	10 min	WHAT 5	If a leak is audible or icing, condensation, foam, or bubbles appear at a fitting connection the fitting connection must be inspected. **TWARNING** Fuel system must be defueled prior to investigating any leak. Refer to OEM procedure to defuel system.	
×H×			×H∧		
6	Re-tighten leaking		7	Repeat Steps 1 and 2 to	
WHAT	fitting(s) discovered during Step 5. 1. For JIC fittings, refer to p/n specific tightening instructions. 2. For compression fittings, tighten fitting according to Appendix B.	M	WHAT	repressurize the system.	
×ΗΜ			WHY		



8	Spray leaking fitting		9		
WHAT	again with Swagelok Snoop® or equivalent and allow at least 10 minutes to elapse before checking for bubble formation.	10	WHAT	If leaking fitting is fixed, proceed to test any remaining fitting connections.	
WHY			WHY		
WHAT	If leak is not fixed, the fuel system must be defueled to replace the fitting. Perform OEM defuel procedure.		11 MHAT	Inspect tubing, fittings, ferrules, and nuts at the site of the leak for perforations, cracks, assembly defects, or other damage. Any damaged components must be replaced.	
WHY			WHY		
12	Replace any related		13	Repressurize fuel system by	
WHAT	components at the fitting junction as required. Follow fitting installation directions in Appendix 2.		WHAT	repeating Step 1 and Step 2.	
WHY			MHY		



14		15	Turn FMM 1/4-turn manual	
WHAT	Spray new fitting junction with Swagelok Snoop® or equivalent to retest for leaks.	WHAT	shut off valve (3) counterclockwise to the OPEN position.	
λHM		ДНМ	Allow fuel into system.	
16	C	17	C	
WHAT	Repeat pressure test procedure stopping the fill when fuel system pressure reaches 2000 psi to 2100 psi (13.79MPa to 14.48MPa).	WHAT	Repeat pressure test procedure stopping the fill when fuel system pressure reaches 3600 psi to 3700 psi (24.8MPa to 25.5MPa) and repeat leak checking all connections until the entire fuel system is confirmed leak free.	3000 3000 5000 5000 5000 5000 5000 5000 5000
WHY	Subjects fuel system to partial operating pressure.	WHY	Subjects fuel system to full operating pressure.	///Agility
18 WHAT	If fuel system is leak free or if defueling is required, close flow valve on CNG dispense nozzle (not shown) and carefully disconnect fill nozzle (not shown) from FMM (2) fuel fill receptacle (a).	19 TAHW	Replace dust cap (f) on FMM (2) fuel fill receptacle (a).	
ΛΗΛ		WHY	Vehicle will not start if dust cap is not in place.	



Z0 LAHW	If not open, turn FMM (2) 1/4-turn manual shut off valve (3) counterclockwise to the OPEN position.	2	21	Clean Swagelok Snoop® or equivalent from the fuel system.	
WHY	Allow gas to flow throughout fuel system.		WHY	Customer satisfaction.	
22 TAHW	When the pressure test is completed successfully, use form FT.0313 (c) to record the result and the date on which the fuel system passed the 3600 psi test.	Recall Custo Sheet, FT.0313 RGV 2.0 Incall Custo Sheet, FT.0313 RGV 2.0 Incall Custo Sheet, FT.0313 RGV 2.0 Incal Custo Sheet, FT.0313 RGV	23	Apply Torque Seal to all fitting junctions.	
WHY	Verify safe and proper fuel system pressure specification.	FTWENTY CJ. 4/2000		System quality specification.	



5.6. Reporting and Return Procedure

1. Use form FT.0313
(c) to record the serial number (a) and the location of each VTI replacement PRD (16), p/n 10300513,within the fuel system.


2. Inspect fuel system repairs per the quality assurance criteria specified in FT.0313.

NOTICE

Use a flashlight to aid serial number identification in low light.

- 3. Use a camera or camera phone to take a photo of completed form FT.0313 (c).
- 4. Submit photo of completed form FT.0313 (c) to the email address indicated on the form to receive a Return Material Authorization (RMA) shipping label.

Required for retrofit kit component and repair tracking and, if applicable, installer reimbursement.





2	Dancet Castion F		2		
	Repeat Section 5.		3		
	Corrective Action /			. •	
	Procedure for all vehicles			1. Pack all removed PRDs	
	subject to the Emer™ PRD			(still bagged by VIN), in one	
	recall on hand until all			box. If the quantity of PRDs	
	repairs are complete.			is too large for a single box,	
				use additional boxes but	
				ship them all using the	
				same RMA.	
WHAT			WHAT	If possible: reuse the box in	
\			 	which the replacement	
_			_	PRDs were shipped.	
				2. Apply RMA label obtained	
				from Agility® to the box.	
				• •	
				3. Use a permanent marker to	
				write RMA number on	
				exterior of each shipping	
				box.	
		 		Required for repair return	
\			≻ │	tracking and, if applicable,	
WHY			MH≺	installer reimbursement.	
			_	motanor rombarsoment.	



Appendix A. WI.0197 Manual Swaging of Swagelok Fittings



Manual Swaging of Swagelok Fittings

Standard Work Instruction

Scope: Manual swaging of Swagelok fittings onto:

- 1/4", 3/8" and 1/2" OD tubing (Steps 1-10)
- Swagelok port connectors and port adaptors (Steps 4-10 only)

WHAT	Place tube end fully into depth marking tool (DMT). Mark the tube with a fine-tipped Sharpie.		WHAT	Use magnification to verify that nut and ferrules have Swagelok markings (NOT Parker).	SWAGELOK"
WHY	The DMT line corresponds to the nut's location after swaging in step 8.		WHY	Swagelok fittings and ferrules may NOT be interchangeable with other manufacturers. They may not swage or seal properly.	"P"
WHAT	Install nut and ferrules onto the tube. Verify that they are in the proper order and orientation.		4 MHAT	At the beginning of the shift, use magnified ring light and fingertip to inspect swaging die for damage, pitting and debris. If damaged, replace the die. If dirty, clean by hand with a nylon brush and cloth.	Swaging surface Threads
WHY	This is critical for proper swage strength and leak-tightness.	front back nut ferrule ferrule	WHY	A damaged or dirty swaging die could lead to damage to the ferrule or nut.	
5	Insert tube into swaging die. Verify		6	While holding tube in place within	
WHAT	that tube is bottomed out. DMT line should NOT be visible.		WHAT	the pre-swaging tool, hand tighten the nut. The nut should turn freely. If the nut does not turn freely, the die (or nut) must be cleaned or replaced.	
WHY	If tube is not fully seated, ferrules will be swaged in incorrect location on tube.		WHY	The tube must be held in place to prevent it from backing out during pre-swaging. If the nut does not turn freely the swaging die is likely damage or worn, which could prevent the tube from being swaged properly.	C

WI.0197, rev. 1.1

Printed copy is uncontrolled. - Agility Fuel Solutions proprietary.

Page 1 of 4





Manual Swaging of Swagelok Fittings

Scope: Manual swaging of Swagelok fittings onto:

- 1/4", 3/8" and 1/2" OD tubing (Steps 1-10)
- Swagelok port connectors and port adaptors (Steps 4-10 only)

Standard Work Instruction

WHAT 7	Mark the nut and die with a fine- tipped sharpie at the 6 o'clock position.	WHAT [∞]	While holding tube against the die, tighten the nut 1-1/4 turns (to the 9 o'clock position).	
WHY	These black marks are needed to control step 8.	WHY	Less than 1-1/4 turns can cause a leak.	
WHAT 6	Verify DMT line on tube is fully exposed above nut. If the DMT line is not exposed, turn up to 1/8 turn more and recheck. If line is still not visible, then scrap the tube.	WHAT 10	Remove the tube from the swaging die by gently moving tube side to side. If excessive force is needed to remove the tube, the swaging die should be replaced.	
WHY	If DMT line is not "high enough", either tube is not seated enough in DMT, OR not swaged far enough (due to hand tightening variation).	WHY	Excessive force to remove the tube may indicate that the swaging die is worn, which could cause an under swaged condition.	

	rev.	



Manual Swaging of Swagelok Fittings Scope: Manual swaging of Swagelok fittings onto: • 1/4", 3/8" and 1/2" OD tubing (Steps 1-10) • Swagelok port connectors and port adaptors (Steps 4-10 only)	Standard Work Instruction
--	---------------------------

Equipment List:

Description	Manufacturer	Manufacturer's Part Number
1/4" Non-Gaugable Pre-Swaging Die	Swagelok	MS-ST-400
3/8" Non-Gaugable Pre-Swaging Die	Swagelok	MS-ST-600
1/2" Non-Gaugable Pre-Swaging Die	Swagelok	MS-ST-810
Ultra-Fine Point Permanent Black Marker	Sharpie	37001
1/4" Depth marking tool	Swagelok	MS-DMT-400
3/8" Depth marking tool	Swagelok	MS-DMT-600
1/2" Depth marking tool	Swagelok	MS-DMT-810
1.75X Ring Light	Any	
Open-ended wrenches	Any	
Vise	Any	
Nylon brush	Any	
Microfiber Cloth	Any	

	,
WI.0197, rev. 1.1 Printed copy is uncontrolled Agility Fuel Solutions proprietary.	Page 3 of 4





Manual Swaging of Swagelok Fittings

Scope: Manual swaging of Swagelok fittings onto:

- 1/4", 3/8" and 1/2" OD tubing (Steps 1-10)
- Swagelok port connectors and port adaptors (Steps 4-10 only)

Standard Work Instruction

Job Breakdown:

Important Steps	Key Points	Reasons Why
1. Mark tube	Tube bottomed out in DMT	Provide reference for swaging and tightening.
2. Install three components	2. Only Swagelok	Mixed parts could leak.
	3. Nut, then back ferrule, then front ferrule	Missing, mis-located and mis-oriented parts could leak.
3. Tube into die 1. Die is clean and smooth Dirty or worn dies do not work properly.		Dirty or worn dies do not work properly.
	2. Tube bottomed out in die	The tube must be fully inserted into the die.
	Turn nut to hand tight	
4. Mark nut and die	1. At 6 o'clock	Provides visual aid to start turning
5. Turn nut 1. 1-1/4 turns Inco		Incorrect turns could cause a leak.
2. Stop at 9 o'clock Provides visua		Provides visual aid to finish turning.
	3. DMT line fully showing	Verify swage is complete
6. Remove tube	Gently rock tube back and forth	Too much force means the die is worn.

,	·	
WI.0197, rev. 1.1	Printed copy is uncontrolled Agility Fuel Solutions proprietary.	Page 4 of 4



Appendix B. WI.0441 Tightening of tube fittings



Tightening of Tube Fittings

Scope: Tightening of 1/2" Swagelok fittings, port

connectors and port adaptors. Note: "Substitute from WI.0198"

Standard Work Instruction

WHAT	Install swaged tube into fitting. Verify that both nut and fitting have same manufacturer markings.		WHAT 2	Tighten nut (by hand or with wrench) until top of nut is aligned with the bottom of the DMT mark.	
WHY	Swagelok/Parker fittings and nuts are NOT interchangeable.		WHY	This line shows the nut's correct starting location prior to tightening.	
what &	Mark across nut and fitting with blue paint pen	M	WHAT 4	Put a "backing wrench" on the adjacent fitting. Note: some products require holding a different component - this will be noted in the product-specific work instructions.	M
WHY	The marks are needed for step 5 and inspection.		WHY	The backing wrench prevents the fitting from rotating. This ensures that the nut is NOT under-tightened.	
WHAT 5	Using the blue marks as a visual reference, turn nut between 1/2 and 5/8 of a turn		WHAT	Check gap between nut and fitting with the GO-NOGO gap gage. If the GO section fits AND the NOGO section does not fit, the part is good. If the NO-GO section fits, then tighten the fitting and recheck. If the GO section does not fit, the tube must be removed and scrapped.	
WHY	If the nut is turned less than 1/2 turn, it may pass a leak test, but leak later in the field.		WHY	The gap indicates how tightly the ferrules are seated against the fitting. Too much gap will allow a leak. Not enough gap indicates too much swaging or tightening.	C

WI.0441, rev.1.0

Printed copy is uncontrolled. - Agility Fuel Solutions proprietary.





Tightening of Tube Fittings

Scope: Tightening of 1/2" Swagelok fittings, port

connectors and port adaptors. Note: "Substitute from WI.0198"

Standard Work Instruction

7	Add torque seal between nut and	8	T 2254
WHAT	fitting (only when specifically required by customer).	WHAT	
WHY		WHY	

Equipment List:

Description	Manufacturer	Manufacturer's Part Number	
1/4" gap inspection gage	Agility Fuel Solutions	TBD	
3/8" gap inspection gage	Agility Fuel Solutions	TBD	
1/2" gap inspection gage	Agility Fuel Solutions	TD 400394	
Blue paint pen	Dykem	84001	
Ultra-fine tip permanent black marker	Sharpie	37001	
Yellow torque seal	Dykem	83317	
Open-ended wrenches	Any	0.5000	
Vise	Any	(<u>~244)</u>	

Job Breakdown:

Important Steps	Key Points	Reasons Why	
1. Tube into fitting	Same manufacturers	Swagelok and Parker fittings are not interchangeable.	
	2. Tube bottomed out in fitting	The tube must be fully inserted into the fitting.	
	3. DMT line fully showing	Provides correct starting point.	
2. Mark parts	Across nut and fitting	Provides visual aid to start tightening.	
3. Turn nut	Use backing wrench	Holds everything in place to prevent leaks.	
	3. 1/2 turn	Incorrect turns could cause a leak.	
	4. Marks on opposite sides	Provides visual aid to finish tightening.	
	5. Verify gap	Verify tightening is complete, but not too much.	
4. Torque seal	Across nut and fitting	Shows if fitting was loosened.	

WI.0441, rev.1.0

Printed copy is uncontrolled. - Agility Fuel Solutions proprietary.



6. Warranty Information

This procedure is covered under warranty. Standard repair time (SRT) is 6.0 hours. Please refer to Warranty Manual, ENP-067, for warranty reimbursement procedures.

For parts and support, contact Agility Fuel Solutions Customer Care:

- +1 949 267 7745
- +1 855 500 2445, toll free

parts@agilityfs.com

Proprietary Statement

The information provided within this document is proprietary and confidential. All prior versions, including updates and revisions forwarded separately, are proprietary. The information provided by Agility® to its customers and clients is solely for the use of those customers and clients. No portion of this publication may be reproduced or distributed without express written consent of Agility®. Agility® reserves the right to utilize the intellectual property contained within this publication as content for any other publication produced by Agility®.

Trademark Notice

Agility[®] is a registered trademark of Agility Fuel Solutions LLC. Trademarks of other manufacturers are the property of their respective companies.

Agility® Fuel Solutions | 3335 Susan Street Suite 100 | Costa Mesa, CA 92626 USA www.agilityfuelsolutions.com

Revision	Description	Author	Approved By	Date
	Initial Release	C. Grasso	CCG Team	05/04/2020
А	ADDED: References to FT.0320 tracking and quality inspection document. REVISED: retrofit kit contents. DELETED: Non-required p/ns from corresponding install steps.	C. Grasso	CCG Team	05/07/2020
В	REVISED: Section 5.3 Step 1 disassembly sequence.	C. Grasso	CCG Team	05/28/2020