

SAFETY RECALL
NORTH AMERICA
High Pressure Fuel Pump



Reference: Z46 / NHTSA 22V-406

FCA US LLC



Remedy available for
2014 - 2020 (WK) Jeep Grand Cherokee



Remedy available for
2014 - 2019 (DS) RAM 1500 Pickup

Revision	Edition	Detail	Template Version 1.0
6	January 2025	Non-contaminated procedures, Parts Information, and Parts Return are updated.	

SYMPTOM DESCRIPTION

The High-Pressure Fuel Pump (HPFP) on about 138,640 of the above vehicles may fail prematurely. A HPFP failure may introduce internally failed component debris into the fuel system potentially causing fuel starvation. Vehicle occupants may notice a Malfunction Indicator Lamp illuminating, a fuel leak, abnormal engine noise, or a change in drive quality. Fuel starvation may result in an unexpected loss of motive power, which can cause vehicle crash without prior warning.

SCOPE

This recall applies only to the above vehicles equipped with a 3.0L engine (sales codes EXF and EXN).

NOTE: Some vehicles above may have been identified as not involved in this recall and therefore have been excluded from this recall.

IMPORTANT:

- Some of the involved vehicles may be in dealer new vehicle inventory. Federal law requires you to complete this recall service on these vehicles before retail delivery. Violation of this requirement by a dealer could result in a civil penalty of up to \$27,168 per vehicle.
- Some of the involved vehicles may be in dealer used vehicle inventory. Dealers should complete this recall service on these vehicles before retail delivery.
- Dealers should also perform this recall on vehicles in for service.

Involved vehicles can be determined by using the VIP inquiry process.

REPAIR TO BE PERFORMED

Vehicles delivered to the dealer in good running condition should complete HPFP replacement only. See Service Procedure A (non-contaminated system).

If the vehicle is brought to the dealer not running, the technician will follow the current diagnostic procedure to determine if there was an HPFP failure. If HPFP failure was determined, replacement of both the HPFP and fuel pump module is required, including fuel system cleaning. See Service Procedure B (contaminated system).

ALTERNATE TRANSPORTATION

Dealers should attempt to minimize customer inconvenience by placing the owner in a loaner vehicle if inspection determines that HPFP replacement is required, and the vehicle must be held overnight.

SAFETY RECALL
NORTH AMERICA
High Pressure Fuel Pump

Reference: Z46 / NHTSA 22V-406



FCA US LLC

COMPLETION REPORTING / REIMBURSEMENT

Claims for vehicles that have been serviced must be submitted on the DealerCONNECT Claim Entry Screen located on the Service tab. Claims paid will be used by FCA to record recall service completions and provide dealer payments.

Use the following labor operation numbers and time allowances:

Labor Description	Number	Hrs
Replace High Pressure Fuel Pump and Fuel Tubes and fuel filters (WK)	14-Z4-61-82	2.2
Clean Fuel Tank, Replace In-Tank Fuel Modules, Fuel Filters, Fuel Injectors, Fuel Rails, HP Fuel Tubes, and HP Fuel Pump (WK)	14-Z4-61-83	7.8
Replace High Pressure Fuel Pump and Fuel Tubes and fuel filter (DS)	14-Z4-61-82	1.9
Clean Fuel Tank, Replace In-Tank Fuel Modules, Fuel Filters, Fuel Injectors, Fuel Rails, HP Fuel Tubes, and HP Fuel Pump (DS)	14-Z4-61-83	5.9

Labor Description	Number	Allowance
Floor Plan Reimbursement	95-95-95-97	Calculate See Below

Floor Plan Reimbursement represents the vehicle's average daily allowance (see table below) multiplied by the number of days the vehicle was in dealer inventory and not available for sale. This reimbursement is limited to the number of days from the date of the stop sale to the date that the remedy was made available. Note: If the vehicle was received by your dealership (KZX date) AFTER the stop sale date, you will use the KZX date instead of the stop sale date. For this Recall, the stop sale was initiated on **06/16/2022**. The **WK** remedy was made available on **01/04/2024**, therefore the number of days cannot exceed **567** days. The **DS** remedy was made available on **2/29/2024**, therefore the number of days cannot exceed **623** days.

Vehicle	Average Daily Allowance
2014 – 2020 (WK) Jeep Grand Cherokee	██████████
2014 – 2019 (DS) RAM 1500 Pickup	██████████

Add the cost of the recall parts package plus applicable dealer allowance to your claim.

In addition, enter "MATL" in the Part Number section of your claim with the applicable Material Allowance where appropriate.

NOTE: See the Warranty Administration Manual, Recall Claim Processing Section, for complete recall claim processing instructions.

Related Operation	Number	Amount
Fuel Allowance for Safety Recall Z46	95-14-01-51	██████████
Disposal of Contaminated Diesel Fuel for Safety Recall Z46 (Receipt Required)	95-14-04-52	██████████

Optional Equipment	Number	Hrs
Drain Fuel - DS Models w/ 26 Gallon Tank Only	14-Z4-61-60	0.4
Drain Fuel - DS Models w/ 32 Gallon Tank Only	14-Z4-61-61	0.4
Drain Fuel - WK Models w/ 24.6 Gallon Tank Only	14-Z4-61-62	0.3

SAFETY RECALL

NORTH AMERICA

High Pressure Fuel Pump

Reference: Z46 / NHTSA 22V-406



FCA US LLC

PARTS INFORMATION

Part No.	Qty.	Part Name
WK PARTS		
ORDER THESE PARTS FOR NON-CONTAMINATED WK VEHICLES (NO HPFP FAILURE)		
CSSMZ461AA	1	High Pressure Fuel Pump
CSSMZ463AA	1	FUEL/WATER SEPARATOR KIT
04275086AE	1	AUTHORIZED MODIFICATION (LABEL)
CSFP01A1AA	1	SEE ORDERING INFORMATION BELOW THIS TABLE. (Contaminated and Non-Contaminated Vehicle)
	1	Owner's Manual Addendum
	1	Tip Card
	1	Fuel Door Decal

Process Steps to Order Campaign kit CSFP01A1AA:

1. Access the “DealerCONNECT” website.
2. Select the “Marketing” link in the header of DealerCONNECT.
3. Locate the “Product Information” section heading on the Marketing page.
4. Select the “Literature and Merchandising Materials” link in the product information section.
5. Locate the “MOPAR” section heading on the Literature and Merchandising Materials page.
6. Select the “Recall Labels / Cards” link listed in the MOPAR section.
7. Select Item > Update Cart > Submit Order.

Part No.	Qty.	Part Name
WK PARTS		
ORDER THESE PARTS FOR CONTAMINATED WK VEHICLES (WITH HPFP FAILURE)		
CSSMZ461AA	1	High Pressure Fuel Pump
68334956AA	1	Tube Kit
68211302AA	6	Fuel Injectors with NAS (50 state emissions)
CSSMZ465AA	6	Injector O-ring
	1	Fuel Rail Right
	1	Fuel Rail Left
	1	O-ring Fuel Pump Module
	1	Tube -fuel Injector supply (left) (NOT USED)
	4	Bolt and Washer, Driveshaft
	3	Bolt and Washer, Driveshaft
	2	Stud and Washer, Driveshaft
	1	Pickup Unit Level Module
CSGNZ961AA	1	Gasket, EGR Upper Tube
	1	Rubber Gasket, Upper EGR Tube
CSSMZ467AA	1	Fuel Pump (2011-2015)
	1	Fuel Pump Level Unit (Module)
	1	O-ring, Fuel Pump Module
CSSMZ468AA	1	Fuel Pump (2016-2020)
	1	Module Kit – Fuel Pump
	1	O-ring, Fuel Pump Module
CSSMZ463AA	1	Fuel/Water Separator Kit
55398183AA	1	Clamp, Tailpipe
04275086AE	1	AUTHORIZED MODIFICATION (LABEL)
CSFP01A1AA	1	SEE ORDERING INFORMATION BELOW

Strictly respect STELLANTIS Group safety, cleanliness, and environmental instructions for any vehicle service.
Document exclusively reserved for dealer information. Internal distribution to be ensured by dealer.

Reproduction forbidden without the written agreement of STELLANTIS Group. (C) 2023 STELLANTIS Group. All Rights Reserved

(djt)

SAFETY RECALL
NORTH AMERICA
High Pressure Fuel Pump



Reference: Z46 / NHTSA 22V-406

FCA US LLC

Part No.	Qty.	Part Name
		THIS TABLE. (Contaminated and Non- Contaminated Vehicle)
	1	Owner's Manual Addendum
	1	Tip Card
	1	Fuel Door Decal

Process Steps to Order Campaign kit
CSFP01A1AA:

1. Access the “DealerCONNECT” website.
2. Select the “Marketing” link in the header of DealerCONNECT.
3. Locate the “Product Information” section heading on the Marketing page.
4. Select the “Literature and Merchandising Materials” link in the product information section.
5. Locate the “MOPAR” section heading on the Literature and Merchandising Materials page.
6. Select the “Recall Labels / Cards” link listed in the MOPAR section.
7. Select Item > Update Cart > Submit Order.

SAFETY RECALL
NORTH AMERICA
High Pressure Fuel Pump

Reference: Z46 / NHTSA 22V-406



FCA US LLC

Part No.	Qty.	Part Name
DS PARTS		
ORDER THESE PARTS FOR NON-CONTAMINATED DS VEHICLES (NO HPFP FAILURE)		
CSSMZ461AA	1	High Pressure Fuel Pump
CSSMZ462AA	1	FUEL/WATER SEPARATOR KIT
04275086AE	1	AUTHORIZED MODIFICATION (LABEL)
CSFP01A1AA	1	SEE ORDERING INFORMATION BELOW THIS TABLE. (Contaminated and Non-Contaminated Vehicle)
	1	Owner's Manual Addendum
	1	Tip Card
	1	Fuel Door Decal

Process Steps to Order Campaign kit CSFP01A1AA:

1. Access the “DealerCONNECT” website.
2. Select the “Marketing” link in the header of DealerCONNECT.
3. Locate the “Product Information” section heading on the Marketing page.
4. Select the “Literature and Merchandising Materials” link in the product information section.
5. Locate the “MOPAR” section heading on the Literature and Merchandising Materials page.
6. Select the “Recall Labels / Cards” link listed in the MOPAR section.
7. Select Item > Update Cart > Submit Order.

Part No.	Qty.	Part Name
DS PARTS		
ORDER THESE PARTS FOR CONTAMINATED DS VEHICLES (WITH HPFP FAILURE)		
CSSMZ461AA	1	High Pressure Fuel Pump
CSSMZ46DAA	6	Injector O-ring
	6	Fuel Injectors
	1	Fuel Rail Right
	1	Fuel Rail Left
	1	O-ring Fuel Pump Module
	1	Fuel Pump Module
CSGNZ961AA	1	Gasket, EGR Upper Tube
	1	Rubber Gasket, Upper EGR Tube
CSSMZ462AA	1	Fuel/Water Separator Kit
68334956AA	1	Tube Kit (9 tubes)
04275086AE	1	AUTHORIZED MODIFICATION (LABEL)
CSFP01A1AA	1	SEE ORDERING INFORMATION BELOW THIS TABLE. (Contaminated and Non-Contaminated Vehicle)
	1	Owner's Manual Addendum
	1	Tip Card
	1	Fuel Door Decal

Process Steps to Order Campaign kit CSFP01A1AA:

1. Access the “DealerCONNECT” website.
2. Select the “Marketing” link in the header of DealerCONNECT.
3. Locate the “Product Information” section heading on the Marketing page.
4. Select the “Literature and Merchandising Materials” link in the product information section.
5. Locate the “MOPAR” section heading on the Literature and Merchandising Materials page.
6. Select the “Recall Labels / Cards” link listed in the MOPAR section.
7. Select Item > Update Cart > Submit Order.

SAFETY RECALL

NORTH AMERICA

High Pressure Fuel Pump

Reference: Z46 / NHTSA 22V-406



FCA US LLC

PARTS RETURN

Return the High-Pressure Fuel Pump to the PDC following the standard core return policy. Dealers will be reimbursed for the core once received by the PDC.

SPECIAL TOOLS

Number	Description
NPN	wiTECH MicroPod II / MDP
NPN	Laptop Computer
NPN	wiTECH Software
VM.10345	Tool, High Pressure Pump Installation
1023	Puller (Originally Shipped in Kit Number(s) 8678)
APS35IB	Blue Point Spanner Wrench or equivalent
2025400090	Remover-Installer, Fuel Rail Bolt
VM.10358A	Remover, Fuel Injector
9717	Brush, Injector Bore (Originally Shipped in Kit Number 9910)
8978A	Decay Tool, Fuel
9340	SAE Fuel Pump Lock Ring Wrench (Originally Shipped In Kit Number(s) 9327, 9327CC, 9397, 9575

DEALER NOTIFICATION

To view this notification on DealerCONNECT, select "Global Recall System" on the Service tab, then click on the description of this notification.

OWNER NOTIFICATION / SERVICE SCHEDULING

All involved vehicle owners known to FCA are being notified of the service requirement by first class mail. They are requested to schedule appointments for this

service with their dealers. A generic copy of the owner letter is attached.

VEHICLE LISTS, GLOBAL RECALL SYSTEM, VIP AND DEALER FOLLOW UP

All involved vehicles have been entered into the DealerCONNECT Global Recall System (GRS) and Vehicle Information Plus (VIP) for dealer inquiry as needed.

GRS provides involved dealers with an updated VIN list of their incomplete vehicles. The owner's name, address and phone number are listed if known. Completed vehicles are removed from GRS within several days of repair claim submission.

To use this system, click on the "Service" tab and then click on "Global Recall System." Your dealer's VIN list for each recall displayed can be sorted by those vehicles that were unsold at recall launch, those with a phone number, city, zip code, or VIN sequence.

Dealers must perform this repair on all unsold vehicles before retail delivery. Dealers should also use the VIN list to follow up with all owners to schedule appointments for this repair.

Recall VIN lists may contain confidential, restricted owner name and address information that was obtained from the Department of Motor Vehicles of various states. Use of this information is permitted for this recall only and is strictly prohibited from all other use.

ADDITIONAL INFORMATION

If you have any questions or need assistance in completing this action, please contact your Service and Parts District Manager.

Customer Services / Field Operations
FCA US LLC.

SAFETY RECALL

NORTH AMERICA

High Pressure Fuel Pump

Reference: Z46 / NHTSA 22V-406



FCA US LLC

SERVICE PROCEDURE - WK

For vehicles with a non-contaminated fuel system, use the procedure below.

A. Replace HPFP – Non-Contaminated System

WARNING: Observe the following precautions when working on fuel systems: No sparks, open flames or smoking. Avoid inhaling and swallowing fuel. Avoid eye and skin contact with fuel. Pour fuels only into suitable and appropriately marked containers. Wear protective clothing. Failure to observe these precautions may result in fire, explosion, property damage, and serious or fatal injury.

WARNING: High-pressure fuel lines deliver fuel under extreme pressure from the injection pump to the injectors. This may be as high as 1800 bar (26,106 psi). Use extreme caution when inspecting for high-pressure fuel leaks. Inspect high-pressure fuel leaks with a sheet of cardboard. Wear safety goggles and adequate protective clothing when servicing fuel system. Fuel under this amount of pressure can penetrate skin causing serious or fatal injury.

NOTE: The fuel injection pump can be replaced without having to perform the entire base engine valve timing procedure. This procedure gives instruction on how to remove and install the new fuel injection pump without performing the base engine timing. Do not rotate the pump shaft after removing from the vehicle. The alignment of the pump shaft must be measured and recorded using a commercially available degree wheel after the pump is removed and before transferring the pump gear over to the new pump. This is done to align the pump to the same position during installation. If the base engine valve timing must be performed as part of the repair, refer to Service Library 09 - Engine/Valve Timing/Standard Procedure.

NOTE: When key is cycled to the off position, fuel system pressure automatically bleeds down.

NOTE: Service Library has been updated to indicate that the high pressure fuel pipes may be reused for a non-contaminated repair.

1. Remove the High Pressure Fuel Pump. See 14 - Fuel System / Fuel Delivery, Diesel / PUMP, Fuel Injection, High Pressure / Removal in Service Library.
2. Install a **NEW** High Pressure Fuel Pump. See 14 - Fuel System / Fuel Delivery, Diesel / PUMP, Fuel Injection, High Pressure / Installation in Service Library.
3. Remove the Fuel and Water Separator and Filter assembly from the vehicle. See Service Library at 14 - Fuel System / Fuel Delivery, Diesel / SEPARATOR and FILTER, Fuel and Water / Removal.

SAFETY RECALL
NORTH AMERICA
High Pressure Fuel Pump

Reference: Z46 / NHTSA 22V-406



FCA US LLC

4. Clean the outside of the housing. Remove and discard each fuel filter cover and the fuel filter element from the bottom of the fuel filter/water separator (Figure 1).



Figure 1 – Remove Old Filter Covers and Elements

5. From the top of the fuel filter/water separator, remove the cover (Figures 2 & 3).



Figure 2 – Remove Fuel Filter/Water Separator Cover




Figure 3 – Fuel Filter/Water Separator Cover Removed

SAFETY RECALL

NORTH AMERICA

High Pressure Fuel Pump



Reference: Z46 / NHTSA 22V-406

FCA US LLC

NOTE: The NEW Fuel Filter Kit contains two filter elements, a cover O-ring (not shown) and a filter screen (Figure 4)

6. Thoroughly clean the inside of the housing and cover.




Figure 4 – New Fuel Filter Kit

7. Remove and discard the old cover O-ring. Lubricate the **NEW** seal with clean diesel and install it into the channel in the cover (Figure 5).




Figure 5 – Cover O-ring

SAFETY RECALL

NORTH AMERICA

High Pressure Fuel Pump



Reference: Z46 / NHTSA 22V-406

FCA US LLC

8. Install the **NEW** screen into the housing. Check that the screen is fully and evenly seating into the housing (Figure 6).




Figure 6 – Screen Installed

9. Install the cover. Apply fresh LocTite 270 or equivalent to the cover screws and tighten to 24 N·m (18 ft. lbs.).
10. Lubricate the **NEW** O-ring seal (2) on filter covers (1) with clean diesel (Figure 7).




Figure 7 – Filter Cover O-ring

SAFETY RECALL

NORTH AMERICA

High Pressure Fuel Pump

Reference: Z46 / NHTSA 22V-406



FCA US LLC

11. Position and push down on **NEW** fuel filters (2) to install filter onto the cover (3) (Figure 8).
12. Lubricate the rubber seal (1) with clean diesel fluid (Figure 8).




Figure 8 – Filter Seal

13. Install each fuel filter. Tighten each cover (1) to 20 N·m (15 ft. lbs.) (Figure 9).
14. Install the Fuel and Water Separator and Filter assembly to the vehicle. See Service Library at 14 - Fuel System / Fuel Delivery, Diesel / SEPARATOR and FILTER, Fuel and Water / Installation.



Figure 9 – Filters Installed

SAFETY RECALL

NORTH AMERICA

High Pressure Fuel Pump



Reference: Z46 / NHTSA 22V-406

FCA US LLC

SERVICE PROCEDURE - WK

For vehicles with a contaminated fuel system, use the procedure below.

B. Replace HPFP – Contaminated System

WARNING: Observe the following precautions when working on fuel systems: No sparks, open flames or smoking. Avoid inhaling and swallowing fuel. Avoid eye and skin contact with fuel. Pour fuels only into suitable and appropriately marked containers. Wear protective clothing. Failure to observe these precautions may result in fire, explosion, property damage, and serious or fatal injury.

WARNING: High-pressure fuel lines deliver fuel under extreme pressure from the injection pump to the injectors. This may be as high as 1800 bar (26,106 psi). Use extreme caution when inspecting for high-pressure fuel leaks. Inspect high-pressure fuel leaks with a sheet of cardboard. Wear safety goggles and adequate protective clothing when servicing fuel system. Fuel under this amount of pressure can penetrate skin causing serious or fatal injury.

NOTE: The fuel injection pump can be replaced without having to perform the entire base engine valve timing procedure. This procedure gives instruction on how to remove and install the new fuel injection pump without performing the base engine timing. Do not rotate the pump shaft after removing from the vehicle. The alignment of the pump shaft must be measured and recorded using a commercially available degree wheel after the pump is removed and before transferring the pump gear over to the new pump. This is done to align the pump to the same position during installation. If the base engine valve timing must be performed as part of the repair, refer to Service Library 09 - Engine/Valve Timing/Standard Procedure.

NOTE: When key is cycled to the off position, fuel system pressure automatically bleeds down.

1. Cycle the ignition to the Off position. Be certain that all electrical accessories are turned off.
2. Position the passenger front seat forward.

NOTE: Shown with seat removed for clarity.

3. Remove the battery cover (1) (Figure 10).

NOTE: If equipped with an Intelligent Battery Sensor (IBS), disconnect the IBS connector first before disconnecting the negative battery cable.

4. Disconnect and isolate the negative battery cable from the battery.




Figure 10 – Battery Cover

SAFETY RECALL

NORTH AMERICA

High Pressure Fuel Pump



Reference: Z46 / NHTSA 22V-406

FCA US LLC

5. Release the hose clamp (1) and set the degas hose (2) aside (Figure 11).




Figure 11 – Degas Hose

6. Disconnect the quick-connect fitting (1) and set the vacuum line (2) aside (Figure 12).




Figure 12 – Vacuum Line

SAFETY RECALL

NORTH AMERICA

High Pressure Fuel Pump

Reference: Z46 / NHTSA 22V-406



FCA US LLC

7. Remove the screws (1) that secure the cover (2) for the high-pressure fuel pump (Figure 13).




Figure 13 – Cover Screws

8. Remove the engine cover (1) (Figure 14).



Figure 14 – Engine Cover

9. Remove the cowl extension (1) and the side extensions (2, 5) (Refer to 23 - Body/Exterior/SILENCER, Cowl Extension/Removal) (Figure 15).




Figure 15 – Engine Cover

Strictly respect STELLANTIS Group safety, cleanliness, and environmental instructions for any vehicle service.

Document exclusively reserved for dealer information. Internal distribution to be ensured by dealer.

Reproduction forbidden without the written agreement of STELLANTIS Group. (C) 2023 STELLANTIS Group. All Rights Reserved

(djt)

SAFETY RECALL

NORTH AMERICA

High Pressure Fuel Pump

Reference: Z46 / NHTSA 22V-406



FCA US LLC

10. Remove the bolts (2) and pull up on the engine wire harness assembly (1) to release retainers from the intake manifold (Figure 16).

WARNING: No sparks, open flames or smoking. Risk of poisoning from inhaling and swallowing fuel. Risk of injury to eyes and skin from contact with fuel. Pour fuels only into suitable and appropriately marked containers. Wear protective clothing.

NOTE: Use a backing wrench on the fuel injector when unscrewing the union nut.




Figure 16 – Engine Wiring Harness

11. Remove the left Charge Air Cooler (CAC) tube.
12. Remove the fuel injector silencers (1) (Figure 17).




Figure 17 – Silencer Pad

SAFETY RECALL

NORTH AMERICA

High Pressure Fuel Pump

Reference: Z46 / NHTSA 22V-406



FCA US LLC

13. Disconnect the fuel pressure solenoid wire harness connector (1) (Figure 18).
14. Disconnect the fuel rail return line (2) and position aside (Figure 18).




Figure 18 – Harness Connector and Return Line

15. Remove the upper EGR tube bolts (1) (Figure 19) and (2) (Figure 20).
16. Remove and discard both gaskets.




Figure 19 – Upper EGR Tube Bolts




Figure 20 – Upper EGR Tube Bolts at Intake

SAFETY RECALL

NORTH AMERICA

High Pressure Fuel Pump

Reference: Z46 / NHTSA 22V-406



FCA US LLC

17. Unscrew the union nuts (1 and 3) and remove and discard the left and right-side fuel tubes (2) (Figure 21).
18. Install protective caps onto the fuel injectors and fuel rail.




Figure 21 – Fuel Tubes (Left Side Shown, Right Side Similar)

19. Remove the nut (1) securing the right high-pressure fuel tube (3) to cylinder head cover (Figure 22).
20. Remove the union nuts (2, 4) and the right high-pressure fuel tube (3), discard the fuel tube (Figure 22).
21. Remove the bolt (6) securing the high-pressure crossover fuel tube (7) to top of intake manifold (Figure 22).
22. Loosen the union nuts (5, 8) and remove the high-pressure crossover fuel tube (7), discard the fuel tube (Figure 22).
23. Remove the bolt (9) securing the left side fuel tube (11) to EGR air flow control valve (Figure 22).
24. Loosen the union nuts (10, 12) and remove the left high pressure fuel tube (11), discard the fuel tube (Figure 22).




Figure 22 – Right Side Fuel Tubes

NOTE: The fuel injection pump can be replaced without having to perform the entire base engine valve timing procedure. This procedure gives instruction on how to remove and install the new fuel injection pump without performing the base engine timing. Do not rotate the pump shaft after removing from the vehicle. The alignment of the pump shaft must be measured and recorded using a commercially available degree wheel after the pump is removed and before transferring the pump gear over to the new pump. This is done to align the pump to the same position during installation. If the base engine valve timing must be performed as part of the repair (Refer to 09 - Engine/Valve Timing/Standard Procedure).

NOTE: When key is cycled to the off position, fuel system pressure automatically bleeds down.

SAFETY RECALL

NORTH AMERICA

High Pressure Fuel Pump

Reference: Z46 / NHTSA 22V-406



FCA US LLC

25. Disconnect the low-pressure fuel supply lines (3) (Figure 23).
26. Disconnect the fuel quantity solenoid wire harness connector (2) (Figure 23).




Figure 23 – HPFP Connections

27. Remove the upper bolts (1) from the high-pressure pump (2) (Figure 24).
28. Using Tool, High Pressure Pump Installation VM.10345 Install the studs in the upper locations.




Figure 24 – Upper Bolts

SAFETY RECALL

NORTH AMERICA

High Pressure Fuel Pump

Reference: Z46 / NHTSA 22V-406



FCA US LLC

29. Remove the lower bolt (1) from the HPFP and remove it from the vehicle (Figure 25).

NOTE: The fuel injection pump needs to be timed using a commercially available degree wheel.




Figure 25 – HPFP Lower Bolt

30. Install the degree wheel onto the pump and record the position of the hole in the gear on the degree wheel (Figure 26).



Figure 26 – Installing a Printed Paper Degree Wheel from the Internet

SAFETY RECALL

NORTH AMERICA

High Pressure Fuel Pump

Reference: Z46 / NHTSA 22V-406



FCA US LLC

NOTE: The use of Puller 1023 or a commercially available gear puller is required to remove the fuel injection pump gear (2) (Figure 27).

CAUTION: Do Not Force the high-pressure pump into the right timing cover or attempt to seat it by drawing it in with the bolts. The pump gear must be properly aligned with the drive gear on the camshaft before the high-pressure pump will seat on the cylinder head mounting surface. Failure to properly align drive gears will damage the high-pressure pump or camshaft drive gear.




Figure 27 – Drive Gear on the HPFP

31. Using a commercially available spanner wrench such as Blue Point APS351B, Snap-on APS351C or equivalent (2) to hold fuel injection pump gear. Remove the fuel injection pump gear nut (1) (Figure 28).



Figure 28 – HPFP Gear Removal

SAFETY RECALL

NORTH AMERICA

High Pressure Fuel Pump

Reference: Z46 / NHTSA 22V-406



FCA US LLC

32. Install a **NEW** O-ring seal (1) to the **NEW** fuel injection pump (Figure 29).

33. Install the gear (2) and nut (1) onto the fuel injection pump (3) and tighten the nut (1) finger tight (Figure 27).

34. Using a commercially available spanner wrench (2) such as Blue Point APS35IB or equivalent and tighten the nut (1) to 50 N·m (37 Ft. Lbs.) (Figure 28).

35. Install the degree wheel and rotate the pump shaft so that the hole aligns with the reference mark on the degree wheel referenced during the removal (Figure 26).




Figure 29 – HPFP O-ring

36. Disconnect the injector electrical connector (1) (Figure 30).

37. Lift up on the locking retaining tab on the fuel return lines (2) to unlock the lock. Remove the fuel return hose (3) by wiggling hose free at the fuel injector (4) (Figure 30).




Figure 30 – Fuel Injector Return Line and Locking Tab

SAFETY RECALL

NORTH AMERICA

High Pressure Fuel Pump

Reference: Z46 / NHTSA 22V-406



FCA US LLC

38. Remove the fuel injector return line (1) from the main low pressure return line (2) (Figure 31).




Figure 31 – Fuel Injector Return Line to Low Pressure Return Line

39. Disconnect the right fuel rail pressure sensor wire harness connector (1) (Figure 32).




Figure 32 – Fuel Rail Pressure Sensor Connector

SAFETY RECALL

NORTH AMERICA

High Pressure Fuel Pump

Reference: Z46 / NHTSA 22V-406



FCA US LLC

40. Using the Remover-Installer, Fuel Rail Bolt 2025400090 (1) remove the bolts from both fuel rails and remove and discard the rails from the engine (Figure 33).
41. Clean the area around the fuel injector to be removed, so no debris falls into the injector bore.

NOTE: Use care not to drop or lose the old washer.



Figure 33 – Fuel Rail Bolts

42. Remove the fuel injector hold-down bolt (2), washer (3), and retaining claw (4) (Figure 34).
43. Using your hand, pull fuel injector (1) straight up from cylinder head for removal. Discard lower sealing washer and injector (Figure 34).




Figure 34 – Fuel Injector Removal

SAFETY RECALL

NORTH AMERICA

High Pressure Fuel Pump

Reference: Z46 / NHTSA 22V-406



FCA US LLC

44. If the fuel injector can't be removed by hand, install the Remover, Fuel Injector VM.10358A (1) to remove the fuel injector (2) (Figure 35).

NOTE: Check and make sure that the copper sealing washer did not remain in the cylinder head.

NOTE: Before cleaning the injector bore, seal the injector holes in the injector bore with the appropriate cap to prevent debris from falling into the cylinder.

45. Using a lint-free rag, wipe the cylinder head around the fuel injector.
46. Wipe out injector bore with a lint-free cloth.

CAUTION: Make sure the injector bore bottom is clean of debris otherwise a leak could occur.

47. Clean the bottom of the fuel injector bore with Brush, Injector Bore 9717 and **make sure the old copper sealing washer (2) is not stuck in the bore** (Figure 36).
48. Blow out the recess with shop air and clean again with a lint-free cloth and cover over.
49. Perform these steps for each injector recess.

NOTE: Do Not apply anti-seize lubricant to the injector nozzle, only apply anti-seize lubricant to the injector body.

50. Lubricate the **NEW** fuel injector body with Nickel Anti-Seize lubricant.

NOTE: Always replace the seals in the cylinder head cover and replace the copper sealing washer on the bottom of injector.

NOTE: Any time a new injector is installed, or if an existing injector is installed in any location other than its original location, the injector quantity adjustment procedure must be performed (Refer to 14 - Fuel System/Fuel Injection - Standard Procedure).

51. Remove protective cap from the appropriate injector bore.

NOTE: Make sure the old copper sealing washer is not stuck in bore.




Figure 35 – Fuel Injector Removal Tool




Figure 36 – Fuel Injector

SAFETY RECALL

NORTH AMERICA

High Pressure Fuel Pump

Reference: Z46 / NHTSA 22V-406



FCA US LLC

52. Install a **NEW** fuel injector seal (1) in the cylinder head cover (2) (Figure 37).

NOTE: Do Not apply any lubricant to the fuel injector nozzle. Care must be taken not to restrict the discharge orifices in the nozzle.

53. Install a **NEW** sealing washer (2) onto the fuel injector (1) (Figure 36).
54. Lubricate the injector body with Nickel Anti-Seize Lubricant.

NOTE: Make a note of the seven-digit alphanumeric codes and the physical location of each injector. You will need to enter them into the scan tool during the Injector Quantity Adjustment procedure.

55. Install the fuel injector (1), tensioning claws (4), washer (3) and bolt (2). Tighten the bolt (2) to 33 N·m (24 ft. lbs.) (Figure 34).

NOTE: Fuel tubes are a one-time only use and must be replaced anytime they have been removed.

56. Install the fuel rails. Using the Remover-Installer, Fuel Rail Bolt 2025400090 (1), tighten bolts to 25 N·m (18 ft. lbs.) (Figure 33).

57. Connect the right fuel rail pressure sensor wire harness connector (1) (Figure 30).

NOTE: The one-way check valves on the fuel injector lines are NOT serviceable and should not be taken apart. If the one-way check valve is bad then a **NEW fuel injector return line will need to be installed.**

NOTE: Before installing the fuel injector return line assembly, verify the arrow on the one-way valve point towards the fuel tank

NOTE: Do not use any type of lubrication when installing the fuel injector return line.

NOTE: BE SURE THE FUEL INJECTOR RETURN LINE LOCK TAB (2) IS IN THE UNLOCKED POSITION.

58. Inspect the fuel injector return line for cracks and inspect the O-ring seals for damage. Replace the fuel injector return line if a problem exists.
59. Install the fuel injector return line (1) to the main low pressure return line (2) (Figure 29).
60. Install the fuel injector return line (3) and **BE SURE IT IS FULLY SEATED**, then push down on the lock tab (2) to lock in place. (Figure 28).
61. Connect the fuel injector harness connector (1) (Figure 28).




Figure 37 – Fuel Injector Seal

SAFETY RECALL

NORTH AMERICA

High Pressure Fuel Pump



Reference: Z46 / NHTSA 22V-406

FCA US LLC

CAUTION: Do Not Force the high-pressure pump into the right timing cover or attempt to seat it by drawing it in with the bolts. The pump gear must be properly aligned with the drive gear on the camshaft before the high-pressure pump will seat on the cylinder head mounting surface. Failure to properly align drive gears will damage the high-pressure pump or camshaft drive gear.

62. Install the Tool, High Pressure Pump Installation VM.10345 into the studs installed in the upper timing cover.
63. Install the lower fuel injection pump (2) and hand tighten the bolt (1) (Figure 23).
64. Remove the Tool, High Pressure Pump Installation VM.10345 from the upper bolts location and install the bolts.
65. Tighten the bolts (1) that secure the fuel injection pump to 25 N·m (18 ft. lbs.) (Figure 22 & 23).
66. Connect the fuel injection pump electrical connector (2) (Figure 23).
67. **Do not** connect the low-pressure fuel supply and return lines (3) at this time (Figure 23).

NOTE: Fuel tubes are a one-time only use and must be replaced anytime they have been removed.

68. Install the **NEW** left high pressure fuel tube (11) and tighten the union nut (10, 12) finger tight (Figure 22):
 - Tighten the union nut (10) to 5 N·m (44 in. lbs.) plus an additional 75 degrees turn.
 - Tighten the union nut (12) to 11 N·m (8 ft. lbs.) plus an additional 75 degrees turn.
69. Install the bolt (9) securing the left side high pressure fuel tube (11) to EGR air flow control valve and tighten to 11 N·m (8 ft. lbs.) (Figure 22).
70. Install the **NEW** high pressure crossover fuel tube (7) and tighten the union nuts (5, 8) finger tight (Figure 22):
 - Tighten the union nut (5, 8) to 5 N·m (44 in. lbs.) plus an additional 75 degrees turn.
71. Install the bolt (6) securing the high-pressure crossover fuel tube (7) to intake manifold and tighten to 11 N·m (8 ft. lbs.) (Figure 22).
72. Install the **NEW** right high-pressure fuel tube (3) and tighten union nut (2, 4) finger tight (Figure 22):
 - Tighten the union nut (4) to 5 N·m (44 in. lbs.) plus an additional 75 degrees turn.
 - Tighten the union nut (2) to 11 N·m (8 ft. lbs.) plus an additional 75 degrees turn.
73. Install the nut (1) securing the right-side high-pressure fuel tube (3) to right side cylinder head cover and tighten to 11 N·m (8 ft. lbs.) (Figure 22).
74. Remove the protective caps from the fuel injectors and fuel rail.

NOTE: Use a backing wrench on the fuel injector when tightening the union nut.

75. Install the **NEW** right side fuel tubes (2) and tighten the union nuts (1, 3) finger tight (Figure 22):
 - Tighten the union nut (1) to 5 N·m (44 in. lbs.) plus an additional 75 degrees turn.
 - Tighten the union nut (3) to 11 N·m (8 ft. lbs.) plus an additional 75 degrees turn.

SAFETY RECALL

NORTH AMERICA

High Pressure Fuel Pump



Reference: Z46 / NHTSA 22V-406

FCA US LLC

76. Remove the protective caps from the fuel injectors and fuel rail.
77. Install **NEW** left side fuel tubes (2) and tighten the union nuts (1 and 3) finger tight (Figure 22):
 - Tighten the union nut (1) to 5 N·m (44 in. lbs.) plus an additional 75 degrees turn.
 - Tighten the union nut (3) to 11 N·m (8 ft. lbs.) plus an additional 75 degrees turn.
78. Clean all gasket sealing areas (Figures 19 & 20).
79. Install a **NEW** O-ring gasket (1) onto the intake manifold (2) (Figure 20).
80. Install a **NEW** gasket to the EGR pipe (Figure 19).
81. Install the EGR tube (1) and tighten the bolts (2) to 11 N·m (8 ft. lbs.) (Figure 20).
82. Install the EGR tube bolts (1) and tighten to 25 N·m (18 ft. lbs.) (Figure 19).
83. Install the cowl extension (1) and the side extensions (2, 5) (Refer to 23 - Body/Exterior/SILENCER - Installation) (Figure 14).

NOTE: If the fuel system has been contaminated with Metal or Other Foreign Objects, the following procedure must be followed.

NOTE: With the electric fuel pump not operating, the fuel tank must be removed and drained through the fuel pump module opening of the fuel tank.

84. Raise and support the vehicle (Refer to 04 - Vehicle Quick Reference/Hoisting - Standard Procedure).
85. Remove fuel pump module (Refer to 14 - Fuel System/Fuel Delivery/MODULE, Fuel Pump - Removal).
86. After fuel pump module has been removed, drain fuel into an approved diesel fuel draining station.

CAUTION: Dispose of petroleum-based products in a manner consistent with all applicable Local, State, Federal, and Provincial regulations.

87. Ensure the swirl pot indentation below the in-tank electric fuel pump inlet is completely drained of any contaminated fuel and thoroughly clean the fuel tank.
88. Install the **NEW** Fuel Pump and **New** Transfer Pump.
89. Install the fuel tank and fill with clean diesel fuel. **Do Not** connect the low pressure return line at this time.
90. Remove the transmission skid plate (Refer to 13 - Frame and Bumpers/Under Body Protection/PLATE, Skid - Removal).

SAFETY RECALL

NORTH AMERICA

High Pressure Fuel Pump



Reference: Z46 / NHTSA 22V-406

FCA US LLC

91. Loosen the drain plug (2) and drain the diesel fuel into a suitable container (Figure 38).

92. Securely tighten the drain plug (2) (Figure 38).




Figure 38 – Drain Plug

93. Remove the nuts (2) and the fuel filter shield (1) (Figure 39).




Figure 39 – Fuel Filter Shield

SAFETY RECALL

NORTH AMERICA

High Pressure Fuel Pump

Reference: Z46 / NHTSA 22V-406



FCA US LLC

94. Disconnect the fuel filter/water separator outlet fuel line (1) (Figure 40).
95. Disconnect the fuel filter/water separator inlet fuel line (2) (Figure 40).
96. Disconnect the combination fuel heater/temperature sensor wire harness connector (3) (Figure 40).




Figure 40 – Inlet and Outlet Lines

97. Disconnect the Water In Fuel (WIF) sensor wire harness connector (1) (Figure 41).




Figure 41 – WIF Sensor Connector

SAFETY RECALL

NORTH AMERICA

High Pressure Fuel Pump

Reference: Z46 / NHTSA 22V-406



FCA US LLC

98. Remove the nuts (1), bolt (3), and the fuel filter/water separator assembly (2) (Figure 42).




Figure 42 – Fuel Filter/Water Separator

99. Clean the outside of the housing. Remove and discard each fuel filter cover and the fuel filter element from the bottom of the fuel filter/water separator (Figure 43).



Figure 43 – Remove Old Filter Covers and Elements

SAFETY RECALL
NORTH AMERICA
High Pressure Fuel Pump



Reference: Z46 / NHTSA 22V-406

FCA US LLC

100. From the top of the fuel filter/water separator, remove the cover (Figures 44 & 45).



Figure 44 – Remove Fuel Filter/Water Separator Cover




Figure 45 – Fuel Filter/Water Separator Cover Removed

SAFETY RECALL

NORTH AMERICA

High Pressure Fuel Pump

Reference: Z46 / NHTSA 22V-406



FCA US LLC

NOTE: The NEW Fuel Filter Kit contains two filter elements, a cover O-ring (not shown) and a filter screen (Figure 46).

101. Thoroughly clean the inside of the housing and cover.




Figure 46 – New Fuel Filter Kit

102. Remove and discard the old cover O-ring. Lubricate the **NEW** seal with clean diesel and install it into the channel in the cover (Figure 47).




Figure 47 – Cover O-ring

SAFETY RECALL

NORTH AMERICA

High Pressure Fuel Pump

Reference: Z46 / NHTSA 22V-406



FCA US LLC

103. Install the **NEW** screen into the housing as shown in Figure 58. Check that the screen is fully and evenly seating into the housing (Figure 48).

104. Install the cover. Apply fresh LocTite 270 or equivalent to the cover screws and tighten to 24 N·m (18 ft. lbs.).



Figure 48 – Screen Installed

105. Lubricate the **NEW** O-ring seal (2) on filter covers (1) with clean diesel (Figure 49).




Figure 49 – Filter Cover O-ring

SAFETY RECALL
NORTH AMERICA
High Pressure Fuel Pump

Reference: Z46 / NHTSA 22V-406



FCA US LLC

106. Position and push down on **NEW** fuel filters (2) to install filter onto the cover (3) (Figure 50).

107. Lubricate the rubber seal (1) with clean diesel fluid (Figure 50).




Figure 50 – Filter Seal

108. Install each fuel filter. Tighten each cover (1) to 20 N·m (15 ft. lbs.) (Figure 51).



Figure 51 – Filters Installed

SAFETY RECALL

NORTH AMERICA

High Pressure Fuel Pump



Reference: Z46 / NHTSA 22V-406

FCA US LLC

109. Install the fuel filter/water separator assembly (2) to the vehicle. Tighten the two nuts (1), and one bolt (3) to 20 N·m (15 ft. lbs.) (Figure 42).

110. Connect the Water In Fuel (WIF) sensor wire harness connector (1) (Figure 41).

111. Connect the combination fuel heater/temperature sensor wire harness connector (3) (Figure 40).

112. Connect the fuel filter/water separator inlet fuel line (2) (Figure 40).

113. Connect the fuel filter/water separator outlet fuel line (1) (Figure 40).

114. Install the fuel filter shield (1). Tighten the nuts (2) 14 N·m (10 ft. lbs.) (Figure 39).

115. Lower the vehicle.

116. Connect the negative battery cable to the battery.

NOTE: If equipped with an Intelligent Battery Sensor (IBS), connect the IBS connector after connecting the negative battery cable.

117. Install the battery cover (1) (Figure 10).

118. Place a suitable container under the low-pressure fuel feed line previously left disconnected at the HPFP.

119. Using a diagnostic scan tool, activate the fuel pump to flush the low-pressure fuel lines from the tank to the HPFP.

120. Connect the low-pressure fuel feed at the HPFP.

121. Place a suitable container under the low-pressure fuel return line previously left disconnected at the fuel tank.

122. Using a diagnostic scan tool, activate the fuel pump to flush the low-pressure fuel return lines from the HPFP to the fuel tank.

123. Connect the low pressure fuel return line at the fuel tank.

INJECTOR CLASSIFICATION PROCEDURE

NOTE: The engine must not be running for this procedure.

124. Turn the ignition switch “ON”.

125. Using a scantool, select the “PCM View”, then “MISCELLANEOUS FUNCTIONS”.

126. Select the “Injector Quantity Adjustment”, then “NEXT”.

127. Select the injector(s) that has been replaced, access the keyboard function, and type the seven-digit alphanumeric code next to the cylinder number that corresponds to the physical location where the injector has been installed.

128. Click “NEXT”. The scan tool will prompt to turn the ignition switch off for 12 seconds.

SAFETY RECALL

NORTH AMERICA

High Pressure Fuel Pump



Reference: Z46 / NHTSA 22V-406

FCA US LLC

129. Repeat steps **127** and **128** for the other injectors that are new.
130. Once the seven-digit alphanumeric codes for all injectors have been entered into the PCM, cycle ignition to complete the procedure.

NOTE: Whenever a fuel injector is replaced run oxygen sensor value reset function.

131. Using the scan tool, perform “**Oxygen Sensor Value Reset**” function found under “**ENGINE MISCELLANEOUS FUNCTIONS**”.
132. Connect the vacuum line (Figure 12).
133. Connect the degas hose (Figure 11).
134. Start engine, allow to warm, turn engine off. Check and verify there are no leaks (Refer to 14 - Fuel System/Fuel Delivery, Diesel/Tube(s), Fuel/Diagnosis and Testing).
135. Install the fuel injection pump cover (2) and tighten the screws (1) securely (Figure 13).
136. Install the engine silencer pads (Figure 27) and engine cover (Figure 14).

SAFETY RECALL
NORTH AMERICA
High Pressure Fuel Pump

Reference: Z46 / NHTSA 22V-406



FCA US LLC

NOTE: For all platforms above and both contaminated and non-contaminated systems, complete step C. Install the Authorized Modifications Label.

C. Install the Authorized Modifications Label:

1. Type or print (with a ballpoint pen) the necessary information shown in (Figure 52) onto the authorized modifications Label.




Figure 52 – Authorized Modifications Label

2. Remove the paper backing from the clear film on the front of the authorized modifications label then carefully apply the clear film over the front of the authorized modifications label (Figure 53).




Figure 53 – Apply Clear Film

SAFETY RECALL
NORTH AMERICA
High Pressure Fuel Pump



Reference: Z46 / NHTSA 22V-406

FCA US LLC

NOTE: The Authorized Modifications Label should be located near the Vehicle Emission Control Information (VECI) label (Figure 54).

3. Locate the VECI label on the underside of the engine compartment hood (Figure 54).

NOTE: For vehicles missing a VECI label, locate a flat protected area on the underside of the hood to apply the authorized modifications label.

4. Clean the surface near the VECI label with isopropyl alcohol or equivalent and a soft cloth.



**Figure 54 – Apply Authorized Modifications Label
Near VECI Label
(Specific Vehicle May Look Different)**

5. Remove the authorized modifications label from its paper backing.
6. Apply the authorized modifications label next to the VECI label (Figure 54).
7. Firmly press and smooth the authorized modifications label to ensure good adhesion.
8. Close the engine compartment hood.
9. Complete the Proof of Correction Form for California Residents, **Section D**.

SAFETY RECALL
NORTH AMERICA
High Pressure Fuel Pump



Reference: Z46 / NHTSA 22V-406

FCA US LLC

D. Complete Proof of Correction Form for California Residents:

This recall is subject to the **State of California Registration Renewal/Emissions Recall Enforcement Program**. Complete a Vehicle Emission Recall Proof of Correction Form (**Form No. 81-016-1053**) and **supply it to vehicle owners residing in the state of California** for proof that this recall has been performed when they renew the vehicle registration.

Process Steps to obtain the California Proof of Correction form:

- a. Access the “**DealerCONNECT**” website.
- b. Select the “**Service**” tab.
- c. Under the “**Publications**” heading, select the “**ePublishing**” link.
- d. Sign in using your **Dealer Code** and **Password**.
- e. Select the “**Proof of Correction form**”.

E. Owner's Manual Addendum and Tip Card:

From Campaign kit CSFP01A1AA, place the Owner's Manual Addendum in the glovebox with the Owner's Manual.

Place the Tip Card in a conspicuous location that will be visible to the driver so that they will review it. Suggestions would be the top of the instrument panel, in front of the instrument cluster, etc. Please review the information on the card with the owner when the vehicle is returned to them.

SAFETY RECALL

NORTH AMERICA

High Pressure Fuel Pump



Reference: Z46 / NHTSA 22V-406

FCA US LLC

F. Fuel Door Label:

NOTE: Do not apply the label over an existing label. Apply the label on a flat surface on the inside of the fuel door. For example, on the top of the fuel door hinge (Figure 56).

From Campaign kit CSFP01A1AA, install the fuel door decal.

1. Open the fuel door.
2. Clean the top surface of the hinge with isopropyl alcohol or equivalent and a soft cloth. Repeat as needed until the soft cloth comes off the surface clean.
3. Remove the fuel door label from its paper backing.
4. Apply the fuel door label (Figure 55) to the top of the fuel door hinge (Figure 56).
5. Firmly press and smooth the fuel door label to ensure good adhesion.
6. Close the fuel door.



Figure 55 – Fuel Door Label



Figure 56 – Fuel Door Hinge Location

SAFETY RECALL

NORTH AMERICA

High Pressure Fuel Pump



Reference: Z46 / NHTSA 22V-406

FCA US LLC

SERVICE PROCEDURE - DS

For vehicles with a non-contaminated fuel system, use the procedure below.

G. Replace HPFP – Non-Contaminated System

WARNING: Observe the following precautions when working on fuel systems: No sparks, open flames or smoking. Avoid inhaling and swallowing fuel. Avoid eye and skin contact with fuel. Pour fuels only into suitable and appropriately marked containers. Wear protective clothing. Failure to observe these precautions may result in fire, explosion, property damage, and serious or fatal injury.

WARNING: High-pressure fuel lines deliver fuel under extreme pressure from the injection pump to the injectors. This may be as high as 1800 bar (26,106 psi). Use extreme caution when inspecting for high-pressure fuel leaks. Inspect high-pressure fuel leaks with a sheet of cardboard. Wear safety goggles and adequate protective clothing when servicing fuel system. Fuel under this amount of pressure can penetrate skin causing serious or fatal injury.

NOTE: The fuel injection pump can be replaced without having to perform the entire base engine valve timing procedure. This procedure gives instruction on how to remove and install the new fuel injection pump without performing the base engine timing. Do not rotate the pump shaft after removing from the vehicle. The alignment of the pump shaft must be measured and recorded using a commercially available degree wheel after the pump is removed and before transferring the pump gear over to the new pump. This is done to align the pump to the same position during installation. If the base engine valve timing must be performed as part of the repair, refer to Service Library 09 - Engine/Valve Timing/Standard Procedure.

NOTE: When key is cycled to the off position, fuel system pressure automatically bleeds down.

NOTE: Service Library has been updated to indicate that the high pressure fuel pipes may be reused for a non-contaminated repair.

1. Remove the High Pressure Fuel Pump. See 14 - Fuel System / Fuel Delivery, Diesel / PUMP, Fuel Injection, High Pressure / Removal in Service Library.
2. Install a NEW High Pressure Fuel Pump. See 14 - Fuel System / Fuel Delivery, Diesel / PUMP, Fuel Injection, High Pressure / Installation in Service Library.
3. Raise the vehicle.

SAFETY RECALL

NORTH AMERICA

High Pressure Fuel Pump

Reference: Z46 / NHTSA 22V-406



FCA US LLC

4. Loosen the drain plug (1) and drain the fuel filter/water separator (2) into a suitable container (Figure 57).
5. Securely tighten the drain plug (1) (Figure 57).
6. Using a commercially available oil filter strap wrench, remove the filter cover (2) and the fuel filter (Figure 57).




Figure 57 – Fuel Filter Drain Plug

7. While holding the fuel filter cover (3), pull up on the fuel filter (1) to separate from cover (3) (Figure 58).
8. Lubricate and install a **NEW** O-ring seal (2) onto the filter covers (3) (Figure 58).
9. Position and push down on the **NEW** fuel filters (2) to install filter onto the cover (3) (Figure 58).
10. Lubricate the rubber grommet seal with clean diesel fluid.
11. Using a commercially available oil filter strap wrench, install the fuel filter and tighten the cover (3) to 25 N·m (18 ft. lbs.).
12. Remove the support and lower the vehicle.
13. Connect the negative battery cable(s) (Refer to 08 - Electrical/Battery System/Standard Procedure).
14. Prime the fuel system (Refer to 14 - Fuel System/Fuel Delivery/Standard Procedure).
15. Start engine and check for leaks.



Figure 58 – Fuel Filter

SAFETY RECALL

NORTH AMERICA

High Pressure Fuel Pump



Reference: Z46 / NHTSA 22V-406

FCA US LLC

SERVICE PROCEDURE - DS

For vehicles with a contaminated fuel system, use the procedure below.

H. Replace HPFP – Contaminated System

WARNING: Observe the following precautions when working on fuel systems: No sparks, open flames or smoking. Avoid inhaling and swallowing fuel. Avoid eye and skin contact with fuel. Pour fuels only into suitable and appropriately marked containers. Wear protective clothing. Failure to observe these precautions may result in fire, explosion, property damage, and serious or fatal injury.

WARNING: High-pressure fuel lines deliver fuel under extreme pressure from the injection pump to the injectors. This may be as high as 1800 bar (26,106 psi). Use extreme caution when inspecting for high-pressure fuel leaks. Inspect high-pressure fuel leaks with a sheet of cardboard. Wear safety goggles and adequate protective clothing when servicing fuel system. Fuel under this amount of pressure can penetrate skin causing serious or fatal injury.

NOTE: The fuel injection pump can be replaced without having to perform the entire base engine valve timing procedure. This procedure gives instruction on how to remove and install the new fuel injection pump without performing the base engine timing. Do not rotate the pump shaft after removing from the vehicle. The alignment of the pump shaft must be measured and recorded using a commercially available degree wheel after the pump is removed and before transferring the pump gear over to the new pump. This is done to align the pump to the same position during installation. If the base engine valve timing must be performed as part of the repair, refer to Service Library 09 - Engine/Valve Timing/Standard Procedure.

NOTE: When key is cycled to the off position, fuel system pressure automatically bleeds down.

1. Disconnect and isolate the negative battery cable(s).
2. Remove the retainers (1) that secure the cover (2) for the high-pressure fuel pump (Figure 59).




Figure 59 – HPFP Cover

SAFETY RECALL

NORTH AMERICA

High Pressure Fuel Pump

Reference: Z46 / NHTSA 22V-406



FCA US LLC

3. Remove the bolts (1) securing the sound proofing (2) to the fuel injection pump (Figure 60).




Figure 60 – HPFP Sound Proofing

4. Remove the fuel rail supply tubes (1, 4) (Refer to 14 - Fuel System/Fuel Delivery/TUBE(S), Fuel/Removal and Installation) (Figure 61).
5. Disconnect the low-pressure fuel supply lines (3) (Figure 61).
6. Disconnect the fuel quantity solenoid wire harness connector (2) (Figure 61).




Figure 61 – HPFP Tubes and Lines

NOTE: The fuel injection pump can be replaced without having to perform the entire base engine valve timing procedure. Do not rotate the pump shaft after removing from the vehicle. The alignment of the pump shaft must be measured and recorded using a commercially available degree wheel after the pump is removed and before transferring the pump gear over to the new pump. This is done to align the pump to the same position during installation. If the base engine valve timing must be performed as part of the repair (Refer to 09 - Engine/Valve Timing/Standard Procedure).

SAFETY RECALL

NORTH AMERICA

High Pressure Fuel Pump

Reference: Z46 / NHTSA 22V-406



FCA US LLC

7. Remove the upper bolts (1) from the high-pressure pump (2) (Figure 62).
8. Using Tool, High Pressure Pump Installation VM.10345 Install the studs in the upper locations.




Figure 62 – HPFP Upper Bolts

9. Remove the lower bolt (1) from the HPFP and remove it from the vehicle (Figure 63).




Figure 63 – HPFP Lower Bolts

SAFETY RECALL

NORTH AMERICA

High Pressure Fuel Pump

Reference: Z46 / NHTSA 22V-406



FCA US LLC

10. Install the degree wheel onto the pump and record the position of the hole in the gear on the degree wheel (Figure 64).




Figure 64 – Installing a Printed Paper Degree Wheel from the Internet

NOTE: The use of Puller 1023 or a commercially available gear puller is required to remove the fuel injection pump gear (2) (Figure 65).




Figure 65 - Gear Removal and Installation

SAFETY RECALL

NORTH AMERICA

High Pressure Fuel Pump



Reference: Z46 / NHTSA 22V-406

FCA US LLC

11. Remove the Fuel Tubes from the engine (all 6 injector tubes, right and left fuel tubes, and the crossover tube). See 14 - Fuel System / Fuel Delivery, Diesel / TUBE(S), Fuel / Removal / FUEL TUBES.
12. Remove the fuel injector return lines from the injectors. See 14 - Fuel System / Fuel Delivery, Diesel / TUBE(S), Fuel / Removal / FUEL INJECTOR RETURN LINES.
13. Remove all 6 fuel injectors and clean the injector bores. See 14 - Fuel System / Fuel Injection, Diesel / INJECTOR(S), Fuel / Removal / LEFT BANK and RIGHT BANK.
14. Remove the fuel rails. See 14 - Fuel System / Fuel Delivery, Diesel / RAIL, Fuel / Removal / LEFT FUEL RAIL and RIGHT FUEL RAIL.
15. Install **NEW** fuel rails. See 14 - Fuel System / Fuel Delivery, Diesel / RAIL, Fuel / Installation / LEFT FUEL RAIL and RIGHT FUEL RAIL.
16. Install all 6 **NEW** fuel injectors. See 14 - Fuel System / Fuel Injection, Diesel / INJECTOR(S), Fuel / Installation / LEFT BANK and RIGHT BANK.
17. Install the fuel injector return lines to the injectors. See 14 - Fuel System / Fuel Delivery, Diesel / TUBE(S), Fuel / Installation / FUEL INJECTOR RETURN LINES.
18. Install the **NEW** Fuel Tubes to the engine (all 6 injector tubes, right and left fuel tubes, and the crossover tube). See 14 - Fuel System / Fuel Delivery, Diesel / TUBE(S), Fuel / Installation / FUEL TUBES.

WARNING: High-pressure lines deliver diesel fuel under extreme pressure from the injection pump to the fuel injectors. This may be as high as 2000 bar (29,008 psi). Use extreme caution when inspecting for high-pressure fuel leaks. Fuel under this amount of pressure can penetrate skin causing personal injury or death. Inspect for high-pressure fuel leaks with a sheet of cardboard. Wear safety goggles and adequate protective clothing when servicing fuel system.

WARNING: Observe the following precautions when working on fuel systems: No sparks, open flames or smoking. Avoid inhaling and swallowing fuel. Avoid eye and skin contact with fuel. Pour fuels only into suitable and appropriately marked containers. Wear protective clothing. Failure to observe these precautions may result in fire, explosion, property damage, and serious or fatal injury.

CAUTION: Do Not Force the high-pressure pump into the right timing cover or attempt to seat it by drawing it in with the bolts. The pump gear must be properly aligned with the drive gear on the camshaft before the high-pressure pump will seat on the cylinder head mounting surface. Failure to properly align drive gears will damage the high-pressure pump or camshaft drive gear.

NOTE: The high-pressure pump needs to be timed before it can be installed. Use a commercially available degree wheel to time the high-pressure pump.

NOTE: The fuel injection pump can be replaced without having to perform the entire base engine valve timing procedure. Do not rotate the pump shaft after removing from the vehicle. The alignment of the pump shaft must be measured and recorded using a commercially available degree wheel after the pump is removed and before transferring the pump gear over to the new pump. This is done to align the pump to the same position during installation. If the base engine valve timing must be performed as part of the repair (Refer to 09 - Engine/Valve Timing/Standard Procedure).

SAFETY RECALL

NORTH AMERICA

High Pressure Fuel Pump



Reference: Z46 / NHTSA 22V-406

FCA US LLC

NOTE: The fuel injection pump can be replaced without having to perform the entire base engine valve timing procedure. Do not rotate the pump shaft after removing from the vehicle. The alignment of the pump shaft must be measured and recorded using a commercially available degree wheel after the pump is removed and before transferring the pump gear over to the new pump. This is done to align the pump to the same position during installation. If the base engine valve timing must be performed as part of the repair (Refer to 09 - Engine/Valve Timing/Standard Procedure).

19. Install a **NEW** O-ring seal (1) to the fuel injection pump (Figure 66).




Figure 66 – HPFP O-ring

20. If removed, install the gear (2) and nut (1) onto the fuel injection pump (3) and tighten the nut (1) finger tight (Figure 65).
21. Using a commercially available spanner wrench (2) such as Blue Point APS351B or equivalent and tighten the nut (1) to 50 N·m (37 Ft. Lbs.) (Figure 67).



Figure 67 – Spanner Wrench and Drive Gear on the HPFP

SAFETY RECALL

NORTH AMERICA

High Pressure Fuel Pump



Reference: Z46 / NHTSA 22V-406

FCA US LLC

22. Install the degree wheel and rotate the pump shaft so that the hole aligns with the reference mark on the degree wheel that was recorded after the removal of the pump (Figure 64).
23. Install the Tool, High Pressure Pump Installation VM.10345 into the studs installed in the upper timing cover and install the HPFP to the engine (Figure 62).
24. Install the lower fuel injection pump (2) and hand tighten the bolt (1) (Figure 62).
25. Remove the Tool, High Pressure Pump Installation VM.10345 from the upper bolts location and install the bolts.
26. Tighten the bolts that secure the fuel injection pump to 25 N·m (18 Ft. Lbs.).
27. Connect the fuel injection pump electrical connector (2) (Figure 61).
28. Connect the low-pressure fuel return line (3) to the HPFP (Figure 61). **DO NOT** connect the low-pressure fuel supply line to the HPFP at this time.
29. Install the fuel rail supply tubes (1, 4) to the HPFP (Figure 82). Refer to 14 - Fuel System/Fuel Delivery/TUBE(S), Fuel/Removal and Installation.
30. Connect the negative battery cable(s). (Refer to 08 - Electrical/Battery System/Standard Procedure).
31. Remove all fuel from the fuel tank. Refer to 14 - Fuel System/Fuel Delivery - Standard Procedure. Use an appropriate fuel container. Dispose of the contaminated fuel using the proper procedures.

CAUTION: Dispose of petroleum-based products in a manner consistent with all applicable Local, State, Federal, and Provincial regulations.

32. Remove the fuel tank. Refer to 14 - Fuel System/Fuel Delivery/TANK, Fuel - Removal.
33. Remove the Fuel Pump Module. Refer to 14 - Fuel System / Fuel Delivery, Diesel / MODULE, Fuel Pump / Removal.
34. Ensure the swirl pot indentation below the in-tank electric fuel pump inlet is completely drained of any contaminated fuel and thoroughly clean the fuel tank.
35. Install the **NEW** fuel filter. Refer to 14 - Fuel System / Fuel Delivery, Diesel / FILTER, Fuel / Removal.
36. Install the **NEW** Fuel Pump Module. Refer to 14 - Fuel System / Fuel Delivery, Diesel / MODULE, Fuel Pump / Installation.
37. Install the fuel tank. **DO NOT** connect the low-pressure return line at this time. Fill the tank with clean diesel fuel.
38. Connect a clean hose to the low-pressure supply line fitting at the HPFP and place the other end in a suitable clean container.
39. Turn the ignition **ON** and collect the fuel escaping from the low-pressure supply line into a clean container.
40. Connect the low-pressure supply line to the HPFP.

SAFETY RECALL
NORTH AMERICA
High Pressure Fuel Pump



Reference: Z46 / NHTSA 22V-406

FCA US LLC

41. Connect a clean hose to the low pressure return line fitting at the tank and place the other end in a suitable clean container.
42. Turn the ignition **ON** and collect the fuel escaping from the low pressure return into a clean container.
43. Install the fuel injection pump cover (2) and tighten the screws (1) securely (Figure 60).
44. Install the cover and secure with the retainers (Figure 59).
45. Start engine and check for leaks.

NOTE: For all platforms above and both contaminated and non-contaminated systems, complete step I. Install the Authorized Modifications Label.

I. Install the Authorized Modifications Label:

1. Type or print (with a ballpoint pen) the necessary information shown in (Figure 68) onto the authorized modifications Label.




Figure 68 – Authorized Modifications Label

2. Remove the paper backing from the clear film on the front of the authorized modifications label then carefully apply the clear film over the front of the authorized modifications label (Figure 69).




Figure 69 – Apply Clear Film

SAFETY RECALL
NORTH AMERICA
High Pressure Fuel Pump

Reference: Z46 / NHTSA 22V-406



FCA US LLC

NOTE: The Authorized Modifications Label should be located near the Vehicle Emission Control Information (VECI) label (Figure 70).

3. Locate the VECI label on the underside of the engine compartment hood (Figure 70).

NOTE: For vehicles missing a VECI label, locate a flat protected area on the underside of the hood to apply the authorized modifications label.

4. Clean the surface near the VECI label with isopropyl alcohol or equivalent and a soft cloth.



**Figure 70 – Apply Authorized Modifications Label
Near VECI Label
(Specific Vehicle May Look Different)**

5. Remove the authorized modifications label from its paper backing.
6. Apply the authorized modifications label next to the VECI label (Figure 70).
7. Firmly press and smooth the authorized modifications label to ensure good adhesion.
8. Close the engine compartment hood.
9. Complete the Proof of Correction Form for California Residents, **Section J**.

SAFETY RECALL
NORTH AMERICA
High Pressure Fuel Pump

Reference: Z46 / NHTSA 22V-406



FCA US LLC

J. Complete Proof of Correction Form for California Residents:

This recall is subject to the **State of California Registration Renewal/Emissions Recall Enforcement Program**. Complete a Vehicle Emission Recall Proof of Correction Form (**Form No. 81-016-1053**) and **supply it to vehicle owners residing in the state of California** for proof that this recall has been performed when they renew the vehicle registration.

Process Steps to obtain the California Proof of Correction form:

- a. Access the “**DealerCONNECT**” website.
- b. Select the “**Service**” tab.
- c. Under the “**Publications**” heading, select the “**ePublishing**” link.
- d. Sign in using your **Dealer Code** and **Password**.
- e. Select the “**Proof of Correction form**”.

K. Owner's Manual Addendum and Tip Card:

From Campaign kit CSFP01A1AA, place the Owner's Manual Addendum in the glovebox with the Owner's Manual.

Place the Tip Card in a conspicuous location that will be visible to the driver so that they will review it. Suggestions would be the top of the instrument panel, in front of the instrument cluster, etc. Please review the information on the card with the owner when the vehicle is returned to them.

L. Fuel Door Label:

NOTE: Do not apply the label over an existing label. Apply the label on a flat surface on the inside of the fuel door. For example, on the top of the fuel door hinge (Figure 72).

From Campaign kit CSFP01A1AA, install the fuel door decal.

1. Open the fuel door.
2. Clean the top surface of the hinge with isopropyl alcohol or equivalent and a soft cloth. Repeat as needed until the soft cloth comes off the surface clean.
3. Remove the fuel door label from its paper backing.



Figure 71 – Fuel Door Label

SAFETY RECALL

NORTH AMERICA

High Pressure Fuel Pump



Reference: Z46 / NHTSA 22V-406

FCA US LLC

4. Apply the fuel door label (Figure 71) to the top of the fuel door hinge (Figure 72).
5. Firmly press and smooth the fuel door label to ensure good adhesion.
6. Close the fuel door.



Figure 72 – Fuel Door Hinge Location

This notice applies to your vehicle.

[Model Year and Model]

VIN XXXXXXXXX XXXXXXXXX

Z46/NHTSA 22V-406

LOGO

VEHICLE PICTURE

YOUR SCHEDULING OPTIONS

1. RECOMMENDED OPTION

Call your authorized Chrysler / Dodge / Jeep® / RAM Dealership.

2. Call the FCA Recall Assistance Center at 1-800-853-1403. An agent can confirm part availability and help schedule an appointment.

3. Visit recalls.mopar.com, scan the QR code below, or download the Mopar Owner's Companion App.

QR Code

Get access to recall notifications, locate your nearest dealer, and more through this website or Mopar Owner's Companion App. You will be asked to provide your Vehicle Identification Number (VIN) to protect and verify your identity. The last eight characters of your VIN are provided above.

DEALERSHIP INSTRUCTIONS

Please reference Safety Recall Z46.

IMPORTANT SAFETY RECALL

High Pressure Fuel Pump

Dear [Name],

This notice is sent to you in accordance with the National Traffic and Motor Vehicle Safety Act.

FCA US LLC has decided that a defect, which relates to motor vehicle safety, exists in certain [2014-2019 (DS) Ram 1500 Pickup and 2014-2020 (WK) Jeep® Grand Cherokee] vehicles.

It is extremely important to take steps now to repair your vehicle to ensure the safety of you and your passengers.

WHY DOES MY VEHICLE NEED REPAIRS?

The High-Pressure Fuel Pump (HPFP) on your vehicle ^[1] that could fail prematurely. A HPFP failure may introduce internally failed component debris into the fuel system potentially causing fuel starvation. **Fuel starvation may result in an unexpected loss of motive power, which can cause a vehicle to crash without prior warning.**

HOW DO I RESOLVE THIS IMPORTANT SAFETY ISSUE?

FCA US will repair your vehicle ^[2] free of charge (parts and labor). To do this, your dealer will replace the HPFP, and inspect and, if necessary, replace additional fuel system components. The estimated repair time is two to eight hours. In addition, your dealer will require your vehicle for proper check-in, preparation, and check-out during your visit, which may require more time. Your time is important to us, so we recommend that you schedule a service appointment to minimize your inconvenience. Please bring this letter with you to your dealership.

**TO SCHEDULE YOUR FREE REPAIR,
CALL YOUR CHRYSLER, DODGE, JEEP OR RAM DEALER TODAY**

CALIFORNIA RESIDENTS

The State of California requires the completion of emission recall repairs prior to vehicle registration renewal. Your dealer will provide you with a Vehicle Emission Recall Proof of Correction Form after the Safety Recall service is performed. Be sure to save this form since the California Department of Motor Vehicles may require that you supply it as proof that the Safety Recall has been performed.

In order to ensure your full protection under the emissions warranty provisions, it is recommended that you have your vehicle serviced as soon as possible. Failure to do so could be determined as lack of proper maintenance of your vehicle.

WHAT IF I ALREADY PAID TO HAVE THIS REPAIR COMPLETED?

If you have already experienced this specific condition and have paid to have it repaired, you may visit www.fcarecallreimbursement.com to submit your reimbursement request online. ^[3] Once we receive and verify the required documents, reimbursement will be sent to you within 60 days. If you have had previous repairs performed and/or already received reimbursement, you may still need to have the recall repair performed.

We apologize for any inconvenience, but are sincerely concerned about your safety. Thank you for your attention to this important matter.



**Mr. Mrs. Customer
1234 Main Street
Hometown, MI 48371**

[1] If you no longer own this vehicle, please help us update our records. Call the FCA Recall Assistance Center at 1-800-853-1403 to update your information.

[2] If your dealer fails or is unable to remedy this defect without charge and within a reasonable time, you may submit a written complaint to the Administrator, National Highway Traffic Safety Administration, 1200 New Jersey Ave., S.E., Washington, DC 20590, or you can call the toll-free Vehicle Safety Hotline at 1-888-327-4236 (TTY 1-800-424-9153), or go to safercar.gov.

[3] You can also mail in your original receipts and proof of payment to the following address for reimbursement consideration: FCA Customer Assistance, P.O. Box 21-8004, Auburn Hills, MI 48321-8007, Attention: Recall Reimbursement.

Note to lessors receiving this recall notice: Federal regulation requires that you forward this recall notice to the lessee within 10 days.