

Technical product information

Topic	Air spring fault finding
Market area	Hongkong-Macau (5HK),Russische Föderation (5RU),China 796 VW Import Comp. Ltd (Vico), Beijing (6796),Germany E02 Bentley rest Europe (6E02),Russian Federation 935 Volkswagen Group RUS (6935),United States E05 Bentley USA and rest America (6E05)
Brand	Bentley
Transaction No.	2030217/5
Level	EH
Status	Approval
Release date	

New customer code

Object of complaint	Complaint type	Position
running gear -> shock absorber/suspension control -> self-levelling suspension	functionality -> without function / defect	
running gear -> running gear, springs, shock absorbers -> shock absorber	leaks -> leaking	rear left
running gear -> running gear, springs, shock absorbers -> shock absorber	leaks -> leaking	rear right
running gear -> running gear, springs, shock absorbers -> shock absorber	leaks -> leaking	front left
running gear -> running gear, springs, shock absorbers -> shock absorber	leaks -> leaking	front right
running gear -> shock absorber/suspension control -> automatic shock absorber adjustment	functionality -> without function / defect	
running gear -> running gear, springs, shock absorbers	leaks	
running gear -> adaptive suspension, pitch and roll compensation	functionality	

New workshop code

Object of complaint	Complaint type	Position
running gear -> running gear, springs, shock absorbers -> shock absorber	leaks -> leaking	front left
running gear -> running gear, springs, shock absorbers -> shock absorber	leaks -> leaking	rear left
running gear -> running gear, springs, shock absorbers -> shock absorber	leaks -> leaking	front right
running gear -> running gear, springs, shock absorbers -> shock absorber	leaks -> leaking	rear right
running gear -> running gear, springs, shock absorbers -> shock absorber	leaks -> leaking	> not specified <
running gear -> adaptive suspension, pitch and roll compensation -> ride height / shock absorber control unit	functionality -> without function / defect	

Vehicle data

Continental Series and Flying Spur

Sales types

Type	MY	Brand	Designation	Engine code	Gearbox code	Final drive code
39*	2012	E		*	*	*
39*	2013	E		*	*	*
39*	2014	E		*	*	*
39*	2015	E		*	*	*
39*	2016	E		*	*	*
39*	2017	E		*	*	*
39**	2018	E		*	*	*
3W*	2004	E		*	*	*
3W*	2005	E		*	*	*
3W*	2006	E		*	*	*
3W*	2007	E		*	*	*
3W*	2008	E		*	*	*
3W*	2009	E		*	*	*
3W*	2010	E		*	*	*
3W*	2011	E		*	*	*
3W*	2012	E		*	*	*
3W*	2013	E		*	*	*
4W2*	2014	E		*	*	*

4W2*	2015	E		*	*	*
4W2*	2016	E		*	*	*
4W2*	2017	E		*	*	*
4W2*	2018	E		*	*	*

Mulsanne

Sales types

Type	MY	Brand	Designation	Engine code	Gearbox code	Final drive code
3Y212A	2018	E	Mulsanne 377/V8 8AG	CZMB	RRV	NHJ
3Y213A	2018	E	Mulsanne Speed 395/V8 8AG	CZMA	RRV	NHJ
3Y612A	2018	E	Mulsanne Lang 377/V8 8AG	CZMB	RRV	NHJ

New Continental GT

Sales types

Type	MY	Brand	Designation	Engine code	Gearbox code	Final drive code
3S31AB	2018	E	Cont GT(MSB) BY634 447/W128AG	DDB	SVZ	-
3S31BB	2018	E	Cont GT(MSB) BY634 467/W128AG	DDB	TPT	-
3S31BB	2018	E	Cont GT(MSB) BY634 467/W128AG	DDB	SVZ	-

Bentayga

Sales types

Type	MY	Brand	Designation	Engine code	Gearbox code	Final drive code
4V14A9	2018	E	SUV BY636 447/W128AG	DDBB	RGQ	QUS
4V14A9	2018	E	SUV BY636 447/W128AG	DDBB	QTZ	QUS
4V14A9	2018	E	SUV BY636 447/W128AG	DDBB	SHT	QUS
4V14B9	2018	E	SUV Diesel BY636 310/V8 8AG	CZAA	SKQ	QUS
4V14B9	2018	E	SUV Diesel BY636 310/V8 8AG	CZAA	RWF	QUS
4V14B9	2018	E	SUV Diesel BY636 310/V8 8AG	CZAA	SWY	QUS
4V14B9	2018	E		DCDB	RWF	QUS
4V14C9	2018	E	SUV Diesel BY636 320/V8 8AG	CZAC	RWF	QUS
4V14C9	2018	E	SUV Diesel BY636 320/V8 8AG	CZAC	SKQ	QUS
4V14C9	2018	E	SUV Diesel BY636 320/V8 8AG	CZAC	SWY	QUS
4V14D9	2018	E	SUV KoVOMo BY636 404/V8 8AG	DCUA	RWH	QUT

Documents

Document name
master.xml



Customer statement / workshop findings

The front and/or rear suspension appears to have dropped

Technical background

The Bentley vehicles listed below are fitted with air springs as part of the suspension system. Should air leak from the air springs this will cause the suspension to drop. However, the dropping of the suspension does not necessarily mean that the air spring is faulty.

The Measure section of this TPI describes how and where to check for air leaks on the front and rear air springs, the air pump compressor, pipes, valve unit and air reservoir. This includes potential air leak points on the air spring and also the locations of an air leak that can be repaired without the need to replace an air spring.

Please follow and complete the check list within the Measure section of this TPI to help in diagnosing the issue (*the check list does not need to be sent as an attachment should a DISS technical query be raised*).

Should a leak be found from an air spring please raise a DISS technical query and include as much information as possible including photograph/s of the leak/s location. Once the DISS ticket has been submitted please await clarification from your TSC before commencing with replacing any of the suspected faulty air springs.

▪

Mandatory reporting is applicable for all air spring related issues.

Production change

Not applicable

Measure

Position the vehicle on a flat and level surface and allow it to cool down.

- **Important:** Set the vehicle suspension into "Jack" mode.

Adhere strips of masking tape (**1**) from the centre of each wheel to the highest part of the wheelarch as shown, making sure they are applied taut. Using a tape measure (**2**), also measure and take note of the ride heights (**A-A**) at all four corners of the vehicle. See Figure 1.



Figure 1

Leave the vehicle overnight and again measure the ride heights (**A-A**) at all four corners of the vehicle. Compare these values with those taken previously.

If there is **NO** difference in ride heights, and the strips of masking tape are still 'taut' then no air leak is present. Please explain to the customer the long term storage or changing climate conditions would cause a drop in ride height which is normal. As soon as the vehicle is started, the compressor will level the vehicle automatically. No further action is required.

If there **IS** a difference in ride heights, and the strips of masking tape (**1**) have 'sagged' (shown in Figure 2), then refer to the following leak finding procedures below.



Figure 2

•

It should be noted that if these checks involve a claim through warranty then photographic evidence of the vehicle sagging and air leak should be included.

Always select "Jack mode" before raising the vehicle and exhausting the air from the suspension system. Refer to Elsapro. Repair Group 43.

Section 1 - Front suspension air spring fault finding

•


Before any other checks are made to the front air springs check to confirm the pipes are fully inserted and firmly connected within the brass fitting.

Air leakage may not be audible. A possible symptom of air leakage is excessive operation of the air pump located above the rear diffuser. If no air leakage is apparent at the pipe unions and there is excessive operation of the air pump compressor, there may be a damaged air supply pipe to an air spring.

With the air suspension fully charged, use leak detector spray or a mild soap solution to check the connections for leaks as shown in the accompanying table.

Place an X in the appropriate column next to each check.


Front air spring check points - Continental series (*pre 2018*) and Flying Spur

Check	Yes	No	Comments
Brass fitting to air spring (1) Brass intermediate connection (2) Air feed pipe connection (3) Top of air spring (4) Airspring gaiter condition (5) Air canister and canister to air spring (6 & 7) Bottom of the air spring (8) Top of the air spring (9). Within engine compartment, pull dust seal back to inspect!			
			

If this air supply pipe is leaking, refer to the Elsapro, "Air Supply Pipe - To Repair" - Repair Group 43.


Front air spring check points – Mulsanne

Check	Yes	No	Comments
Air connection to air spring (1) Upper air spring (2) Top of air spring (3) Air spring gaiter condition (4) Bottom of the air spring (5)			




The diagram illustrates a front air spring assembly. It features a central vertical air spring with a corrugated gaiter in the middle. At the top, there is a mounting plate with two air lines connected. Red arrows and numbers point to specific inspection areas: (1) points to the air line connection on the left; (2) points to the upper air spring chamber; (3) points to the top mounting plate on both sides; (4) points to the corrugated gaiter; and (5) points to the bottom mounting plate on both sides.

Front air spring check points – Bentayga

Check	Yes	No	Comments
Air connection to air spring (1) Top of airspring (2&3) Upper areas of air spring gaiter (4 & 6) Airspring upper gaiter condition (5) Lower areas of air spring gaiter (7 & 9) Airspring upper gaiter condition (8)			
			

Front air spring check points – New Continental GT

Check	Yes	No	Comments
Air connection to air spring (1)			
Sealing area of top nut (2)			
Top crimp area (3)			
Top of air spring (4)			
Air spring gaiter condition (5)			
Lower areas of air spring gaiter (6)			
Switching valves, solenoids and welds (7&8)			
			

Section 2 - Rear suspension air spring fault finding


Before any other checks are made to the rear air springs check to confirm the pipes are fully inserted and firmly connected within the brass fitting.

Air leakage may not be audible. A possible symptom of air leakage is excessive operation of the air pump located above the rear diffuser. If no air leakage is apparent at the pipe unions and there is excessive operation of the air pump compressor, there may be a damaged air supply pipe to an air spring.


With the air suspension fully charged, use leak detector spray or a mild soap solution to check the connections for leaks as shown in the accompanying table.

Place an X in the appropriate column next to each check.


Rear air spring check points - Continental series (*pre 2018*) and Flying Spur

Check	Yes	No	Comments
Brass fitting to air spring (1) Top of airspring (2&3) Airspring bellows (4) Air feed pipe connection (5) Airspring gaiter condition (6) Air canister and canister to air spring (7,8 & 9) Electrical cable route for airescaping (10)			
			

Rear air spring checkpoints - Mulsanne


Check	Yes	No	Comments
Air feed pipe connection (1) Top of air spring (2&3) Upper air spring bellows (4&5) Lower air spring bellows (6&7) Air spring gaiter condition (8&9) 			

Rear air spring checkpoints - Bentayga

Check	Yes	No	Comments
Air feed pipe connection (1)			
Top of air spring (2)			
Air spring gaiter condition (3 & 4)			
Lower areas of air spring (5 & 6)			
			

Rear air spring check points – New Continental GT

Check	Yes	No	Comments
Air feed pipe connection (1) Top of air spring (2) Air spring gaiter condition (3 & 4) Lower area of air spring (5)			




The diagram shows a rear air spring assembly. Callout 1 points to the air feed pipe connection at the top. Callout 2 points to the top of the air spring. Callout 3 points to the upper gaiter area. Callout 4 points to the lower gaiter area. Callout 5 points to the lower area of the air spring, specifically the lower gaiter and the lower part of the spring body.


Section 3 - Air supply unit checkpoints

Check for any air leaks on or around the air supply (compressor) unit.
Place an X in the appropriate column next to each check.


Air supply check points - Continental series (pre 2018) and Flying Spur

Check	Yes	No	Comments
Air pipe connections (1 to 6)			
			


Air supply check points – Mulsanne

Check	Yes	No	Comments
Air pipe connections (1 to 6)			
			

Air supply check points – Bentayga

Check	Yes	No	Comments
Air pipe connections (arrows)			
			

Air supply check points – New Continental GT


Check	Yes	No	Comments
Air pipe connections (2&3)			
			

Section 4 - Air reservoir unit check points


Check for any air leaks on or around the air reservoir.

Place an X in the appropriate column next to each check.



Air supply check points - Continental series (*pre 2018*) and Flying Spur

Check	Yes	No	Comments
Air pipe connections (arrow) Location - GT & Flying Spur: LH rear wheelarch Location – GTC: Behind backboard trim panel			
			


Air supply check points – Mulsanne

Check	Yes	No	Comments
Air pipe connections (arrow) Location: Boot floor			
			

Air supply check points – Bentayga

Check	Yes	No	Comments
Airpipe connections on the twin tanks (arrows). Location: Rear footwells			
 			

Air supply check points – New Continental GT

Check	Yes	No	Comments
Air pipe connection (2) Location: Underside of boot floor 			

Section 5 - Air pipe repairs

In the event of an air leak from the air pipe/ brass fittings on the supply unit the brass fittings and internal olive can be replaced individually.

To repair an air pipe, refer to Elsapro, "Air Supply Pipe - To Repair" - Repair Group 43.

Using a "Vehicle Tester", recharge the air system. Refer to Elsapro, "To discharge and charge" - Repair Groups 40 and 42.

Warranty accounting instructions

It should be noted that if checks involve a claim through warranty then photographic evidence of the vehicle sagging and air leak should be included with the DISS technical query where possible.

Pictures should include the following:

- Tape (1) applied before and after, showing the tape sagging. See Figure 4.
- All ride height measurements (A-A) before and after. See Figure 4.
- Soap solution bubbling at the point of air leak (where possible).




Figure 4