

## CDR File Information

Vehicle Identification Number	1G2WJ12M1TF*****
Investigator	
Case Number	
Investigation Date	
Crash Date	
Filename	2006-11-058-V1.CDR
Saved on	xxxxx
Collected with CDR version	Crash Data Retrieval Tool 2.800
Reported with CDR version	Crash Data Retrieval Tool 2.900
Event(s) recovered	Non-Deployment

## SDM Data Limitations

### SDM Recorded Crash Events:

There are two types of SDM recorded crash events. The first is the Non-Deployment Event. A Non-Deployment Event is an event severe enough to wake up the sensing algorithm but not severe enough to deploy the air bag(s). The SDM can store up to one Non-Deployment Event. This event can be overwritten by an event that has a greater SDM recorded forward velocity change. This event will be cleared by the SDM after the ignition has been cycled 125 times.

The second type of SDM recorded crash event is the Deployment Event. The SDM can store up to two different Deployment Events. The first Deployment Event will be stored in the #1 Deployment Event file (this would have been the event that deployed the air bag) and the second Deployment Event will be stored in the #2 Deployment Event file. Deployment Events cannot be overwritten or cleared from the SDM. Once the SDM has two Deployment Events recorded, the SDM must be replaced.

The data in the Non-Deployment Event file will be locked after a Deployment Event, if the Non-Deployment Event occurred within 7.65 seconds before the unless a Deployment Level Event occurs within 5 seconds after the Deployment Event, then the deployment level event will overwrite the Non-Deployment Event file.

### SDM Data Limitations:

-SDM Recorded Vehicle Forward Velocity Change reflects the change in forward velocity that the sensing system experienced during the recorded portion of the event. SDM Recorded Vehicle Forward Velocity Change is the change in velocity during the recording time and is not the speed the vehicle was traveling before the event, and is also not the Barrier Equivalent Velocity. This data should be examined in conjunction with other available physical evidence from the vehicle and scene when assessing occupant or vehicle forward velocity change. The SDM records the first 300 milliseconds of Vehicle Forward Velocity Change after Algorithm Enable. The maximum value that can be recorded for Vehicle Forward Velocity Change is 28 MPH.

-Driver's Belt Switch Circuit Status indicates the status of the driver's seat belt switch circuit.

-The Time between Non-Deployment and Deployment Events is displayed in seconds. If the time between the two events is greater than five seconds, ?N/A? is displayed in place of the time.

-If power to the SDM is lost during a crash event, all or part of the crash record may not be recorded. An indication of a loss of power would be if the ignition cycles at the event is recorded as zero. Data recorded after that may not be reliable, such as Time Between Non-Deployment and Deployment Events and Driver Belt Switch Circuit Status.


### SDM Data Source:

All SDM recorded data is measured, calculated, and stored internally, except for the following:

-The Driver's Belt Switch Circuit is wired directly to the SDM.

## System Status At Non-Deployment

SIR Warning Lamp Status	OFF
Driver's Belt Switch Circuit Status	UNBUCKLED
Ignition Cycles At Non-Deployment	16419
Ignition Cycles At Investigation	16423
Algorithm Enable to Maximum SDM Recorded Velocity Change (msec)	16.25
Maximum SDM Recorded Velocity Change (MPH)	-0.77
A Deployment was Commanded Prior to this Event	No



Time (milliseconds)	10	20	30	40	50	60	70	80	90	100	110	120	130	140	150
Recorded Velocity Change (MPH)	-0.66	-0.66	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00
Time (milliseconds)	160	170	180	190	200	210	220	230	240	250	260	270	280	290	300
Recorded Velocity Change (MPH)	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00

## Hexadecimal Data

```
B600: 25 01 80 01 00 00 00 00
B608: 00 00 00 55 00 41 F9 AD
B610: F9 F9 F9 F9 F9 F9 00 64
B618: 02 75 FD 53 AA FB 00 00
B620: AA AA 00 00 00 00 00 00
B628: 00 00 00 00 00 00 00 00
B630: 00 00 00 00 00 00 00 00
B638: 00 00 00 00 00 00 00 00
B640: 00 00 00 00 00 00 00 00
B648: 00 00 00 00 00 00 00 00
B650: 00 00 00 00 00 00 00 00
B658: 00 00 00 00 00 00 00 00
B660: 00 00 00 00 00 00 00 00
B668: 00 00 00 00 00 00 00 00
B670: 00 00 00 00 00 00 00 00
B678: 00 00 00 00 00 00 00 00
B680: 00 00 00 00 00 00 00 00
B688: 7D 00 00 00 0D 07 06 06
B690: 00 00 00 00 00 00 00 00
B698: 00 00 00 00 00 00 00 00
B6A0: 00 00 00 00 00 00 00 00
B6A8: 00 00 00 00 40 23 00 00
B6B0: 55 AA AA AA AA 00 00 00
B6B8: 7D 00 00 7D 00 00 7D 00
B6C0: 00 7D 00 00 7D 00 00 7D
B6C8: 00 00 7D 00 00 00 00 00
B6D0: 00 00 00 90 20 43 76 05
B6D8: 46 62 10 41 53 09 02 4B
B6E0: 00 00 00 33 57 01 00 00
B6E8: 00 00 00 00 00 00 10 20
B6F0: F3 70 06 F0 05 50 25 64
B6F8: FF FF FF FF FF FF FF FF
B700: FF FF FF 60 60 60 60 60
B708: 60 60 60 60 60 60 60 7F
B710: 9F A5 AA B1 B9 C1 C8 D1
B718: D9 E3 EC F8 41 43 46 48
B720: 4B 4E 50 53 55 58 5B 5E
B728: 60 63 65 67 6A 6D 70 73
B730: 76 7A 7C 80 82 85 87 89
B738: 8B 8D 8E 90 91 92 94 95
B740: 96 97 97 98 99 99 9A 9B
B748: 9B 9B 9C 9D 9D 9D 9E 9E
B750: 9F 9F 9F 9F 9F 9F A0 A0
B758: A0 A0 A0 A0 10 1C 39 00
B760: 00 00 00 00 00 00 00 00
B768: 00 00 00 00 00 00 15 17
B770: 18 19 1C 1E 20 23 24 25
B778: 27 29 2B 00 00 00 00 00
B780: 00 00 00 00 00 00 00 00
B788: 00 00 00 00 00 00 00 00
B790: 00 00 00 00 00 00 00 AA
B798: 00 13 00 13 00 2D 4B 16
B7A0: 06 18 01 02 AA 02 4B 4C
B7A8: FF FF FF FF FF FF FF FF
B7B0: FF FF FF 57 57 57 57 57
B7B8: 57 57 57 57 57 57 57 5B
B7C0: 60 60 60 62 62 64 66 68
B7C8: 68 6A 6D 70 85 85 85 85
B7D0: 85 85 85 85 87 8A 8F 91
B7D8: 91 97 99 9C 9F A2 A5 A7
B7E0: AA AC AE B0 B2 B4 B6 B7
B7E8: B9 BA BC BD BE C0 CB D3
B7F0: DA E0 E6 FF FF FF FF FF
```

B7F8: CA 8C A5 A5 A5 A5 00 00