

TOYOTA

TOYOTA MOTOR NORTH AMERICA, INC.

WASHINGTON OFFICE

601 THIRTEENTH STREET, NW, SUITE 910 SOUTH, WASHINGTON, DC 20005

TEL: (202) 775-1700

FAX: (202) 463-8513

October 8, 2009

Mr. Daniel C. Smith
Associate Administrator for Enforcement
National Highway Traffic Safety Administration
1200 New Jersey Avenue, S.E.
Washington, D.C. 20590

RE: Dealer Communications - Certain Toyota and Lexus Vehicles
Potential Floor Mat Interference with Accelerator Pedal


Dear Mr. Smith:

On behalf of Toyota Motor Corporation, please find the enclosed copy of the consumer advisory information as transmitted to our dealers regarding this issue.

Should you have any questions about this information, please let me know at (202) 775-1707.

Sincerely,

TOYOTA MOTOR NORTH AMERICA, INC.



Chris Santucci
Assistant Manager
Technical & Regulatory Affairs

George Morino / TMS Toyota Customer Services
Quality Compliance
September 29, 2009
Approved By: Bob Waltz

To: All Toyota Dealers
From: Toyota Customer Services

Toyota Consumer Safety Advisory
Potential Floor Mat Interference with Accelerator Pedal
*******URGENT*******

Toyota Motor Sales, USA, Inc. takes public safety very seriously. It believes its vehicles to be among the safest on the road today.

Recent events have prompted Toyota to take a closer look at the potential for an accelerator pedal to get stuck in the full open position due to an unsecured or incompatible driver's floor mat. A stuck open accelerator pedal may result in very high vehicle speeds and make it difficult to stop the vehicle, which could cause a crash, serious injury or death.

Toyota considers this a critical matter and will soon launch a safety campaign on specific Toyota and Lexus vehicles. Throughout the process of developing the details of the action plan, it will advise the National Highway Traffic Safety Administration (NHTSA).

Today, we are releasing the attached Toyota Consumer Safety Advisory to our customers. Until Toyota develops a campaign remedy, we are asking owners of specific Toyota and Lexus models to take out any removable driver's floor mat and NOT replace it with any other floor mat. The following models are affected:

- 2007 – 2010 Camry
- 2005 – 2010 Avalon
- 2004 – 2009 Prius
- 2005 – 2010 Tacoma
- 2007 – 2010 Tundra

- 2007 – 2010 ES350
- 2006 – 2010 IS250 and IS350

In the event owners choose not to remove their floor mat, Toyota strongly recommends that they ensure that the correct floor mat is being used, that it is properly installed and secured, that it is not flipped over with bottom-side up, and that one floor mat is not stacked over another. Information on proper floor mat installation can be found on <http://www.toyota.com> and <http://www.lexus.com>.

If a customer requires your dealership's assistance, please assist them by utilizing the attached instructions and application chart.

- Please direct all customer inquiries to the Toyota Customer Experience Center at 1-800-331-4331 or Lexus Customer Experience Center at 1-800-255-3987.
- If you are a dealership associate and have any questions, please contact your District Service/Parts Manager.
- Due to the nature of this activity, it is imperative that all media contacts (local and national) receive a consistent message. In this regard, **all media contacts** must be directed to Brian Lyons (310) 468-2552, in Toyota Corporate Communications. (Please do not provide these numbers to customers. Dealership associates should contact their Region/PD representative for any questions).

The following Q&A has been provided for your reference.

Toyota/Lexus Consumer Safety Advisory Q&A

Q1: Is this Toyota/Lexus Consumer Safety Advisory a recall?

A1: This is a Consumer Safety Advisory based on the potential for an accelerator pedal to get stuck in the full open position due to an unsecured or incompatible driver's floor mat on certain Toyota and Lexus vehicles.

Q2: Why did Toyota issue the Consumer Safety Advisory?

A2: Recent events have prompted Toyota to take a closer look at the potential for an accelerator pedal to get stuck in the full open position due to an unsecured or incompatible driver's floor mat. A stuck open accelerator pedal may result in very high vehicle speeds and make it difficult to stop the vehicle which could cause a crash, serious injury or death.

Q3: Was there a specific incident related to the Consumer Advisory?

A3: On August 28th, 2009, California Highway Patrol Officer Mark Saylor and three members of his family tragically lost their lives on a highway near San Diego, California, while driving a 2009 ES350 loaned to them by a local Lexus dealer.

Preliminary information from law enforcement investigators indicates that the ES350 involved in the crash contained a driver's all-weather floor mat from a different model Lexus. If incompatible driver's floor mats are installed in any vehicle, or if the floor mat is not properly secured by the retaining hooks, this could cause it to interfere with the accelerator pedal.

Q3a: Electronic systems, such as drive by wire, have been suggested as a possible culprit in the persistence of sudden unintended acceleration incidents. Is this part of the investigation of the San Diego accident.

A3a: All aspects of the vehicle are being studied, but preliminary indications are that an all weather floor mat not designed for the ES350 was installed at the time of the Saylor crash. We have seen no evidence that electronic engine control systems were the cause.

Q4: Which models and model years are impacted?

A4: Toyota

2007 – 2010 Camry
2005 – 2010 Avalon
2004 – 2009 Prius
2005 – 2010 Tacoma
2007 – 2010 Tundra

Lexus

2007 – 2010 ES350
2006 – 2010 IS250 and IS350

Q4a: How many vehicles are involved?

A4a: We are currently determining the number of vehicles.

Q5: Is Toyota planning another recall for the all-weather floors mats or other components as a result of this Consumer Advisory?

A5: Toyota considers this a critical matter and will soon launch a safety campaign on specific Toyota and Lexus vehicles. Throughout the process of developing the details of the action plan, it will advise the National Highway Traffic Safety Administration (NHTSA).

Until we develop a campaign remedy, we recommend that owners remove **any** driver-side floor mat from the specific models identified and **NOT** replace it with any other floor mat.

Q5a: Why didn't the previous all-weather floor mat recall alleviate this problem?

A5a: The previous floor mat recall was aimed at replacing accessory all weather floor mats with a newly designed one as well as advising users not to place all weather mats on top of any other floor mats. Despite this effort, unsecured or incompatible driver's floor mats can present a hazard and Toyota is exploring remedies that can further reduce the likelihood of an crash that could result from misinstallation.

Q6: What should customers do?

A6: Toyota is committed to finding the right solution for this condition. Until the campaign remedy is developed and customers receive notice from Toyota, we request that customers take out any removable driver's floor mat and NOT replace it with any other floor mat.

Q6a: What if a customer chooses not to remove their floor mat?

A6a: In the event a customer chooses not to remove their floor mat, Toyota strongly recommends that they ensure that the correct floor mat is being used, that it is properly installed and secured, that it is not flipped over with bottom-side up, and that one floor mat is not stacked over another. Information on proper floor mat installation can be found on <http://www.toyota.com> and <http://www.lexus.com>.

Q6b: What if a customer requires assistance in checking the floor mat?

A6b: If a customer chooses not to remove their floor mat and requires assistance, they may check with any local Lexus or Toyota dealership's Parts or Service Department to verify the application. Dealers will re-install only those floor mats designed specifically for that model and model year.

Q6c: What if a customer needs retaining hooks (clips)?

A6c: Replacement retaining hooks (clips) for Lexus and Toyota carpeted and all-weather floor mats are available at any Lexus or Toyota dealership. Please check with the dealer for details.

Q7: What if a floor mat is an aftermarket rubberized floor mat?

A7: Driver's floor mat interference is possible in any make or model vehicle with any combination of floor mats. Therefore, consumers need to make sure the floor mats are compatible for their model and model year. Also, they need to be sure they are properly secured using the appropriate retention device (clips). Driver's floor mats should never be stacked. Consumers should never place any floor mat – aftermarket or not -- on top of another driver's floor mat. Mats should also not be flipped over with the bottom-side up.

Q8: What if a driver experiences accelerator pedal interference. What should they do?

A8: Should the vehicle continue to accelerate rapidly after releasing the accelerator pedal, this could be an indication of floor mat interference. If this occurs, Toyota recommends the driver take the following actions:

First, if it is possible and safe to do so, pull-back the floor mat and dislodge it from the accelerator pedal; then pull over and stop the vehicle.

If the floor mat cannot be dislodged, then firmly and steadily step on the brake pedal with both feet. Do not pump the brake pedal repeatedly as this will increase the effort required to slow the vehicle. If you are still unable to stop the vehicle, then do the following:

Shift the transmission gear selector to the Neutral (N) position and use the brakes to make a controlled stop at the side of the road and turn off the engine.

If unable to put the vehicle in Neutral, turn the engine OFF. This will not cause loss of steering or braking control, but the power assist to these systems will be lost.

-If the vehicle is equipped with an Engine Start/Stop button, firmly and steadily push the button for at least three seconds to turn off the engine. Do NOT tap the Engine Start/Stop button.

-If the vehicle is equipped with a conventional key-ignition, turn the ignition key to the ACC position to turn off the engine. Do NOT remove the key from the ignition as this will lock the steering wheel.

Q8a: Why does the Engine Start/Stop button require 3 seconds to shut off?

A8a: This is to prevent accidentally shutting off the engine in case the button is bumped or mistaken for another control. The resulting loss of engine power could cause a loss of the power assist to the brakes and steering, and possibly an unsafe situation.

Q9: What if an owner has additional questions or concerns?

Owners with questions or concerns, are asked to please contact the Toyota Customer Experience Center (1 800 331-4331) or Lexus Customer Assistance Center (1 800 255-3987), or consult the information posted at <http://www.toyota.com> and <http://www.lexus.com>.

Toyota and Lexus Carpeted / All-Weather Floor Mat Inspection, Application and Installation Instructions



Read these important Warnings BEFORE installing ANY type of Floor Mat.


A. General Floor Mat Warnings


- Only install floor mats designed specifically for that model and model year. Check for correct model name and part number on the packaging label to confirm vehicle application.
 - Never install a floor mat if you are uncertain of the model application.
 - Never install the floor mat upside down or turned over for any reason.
 - Only install the driver's floor mat in the driver's foot area.
- Always properly secure the driver's floor mat using the retaining hooks (clips) supplied in the bag with the floor mats (in the case of Lexus with the carpet floor mats). Follow the floor mat retention clip installation instruction supplied with the clips. If the mat is properly secured and you have confirmed vehicle applicability, it will not interfere with the accelerator pedal.
 - Never install the front driver's floor mat without all retaining hooks (clips) securing the mat firmly in place.
- The retaining hooks (clips) are designed to accommodate only one floor mat at a time.
 - Do not install another floor mat(s) on top of an existing driver's floor mat.
- After installation, always check the operation of the accelerator, brake and clutch (if applicable) pedals to assure the floor mat does not interfere with them.
- Carefully read the warning tag attached to the driver's floor mat regarding installation.

B. Floor Mat Inspection Instructions and Application Information

- Before placing a floor mat in a vehicle be familiar with the procedure outlined below.
 - Identify the correct driver's floor mat for the specific vehicle application.
 - Correctly install the driver's floor mat.
- Regularly verify the correct floor mat is securely installed in the appropriate model using the retaining hooks (clips).

NOTE: Use the Application Information Chart provided or the Accessory Parts Catalog to verify mat-to-vehicle application.






Driver's floor mat part number is located on the bottom of the back side of the mat.


(Sample of Application Information Chart)

Model	Year							Mat Description		Part Number	
	2003	2004	2005	2006	2007	2008	2009	2010	Color		Piece Set No.
Camry	x	x	x	x					Oak	4 pc set	PT206-03036-16
Camry (Front Mats)					x	x			Black	1 pc	PT908-0307F-02
Camry (Front Mats)					x	x			Brown	1 pc	PT908-0307F-14
Camry					x				Black	4 pc set	PT908-32070-02
Camry					x				Brown	4 pc set	PT908-32070-14



1. Make sure the driver's floor mat is properly secured by the retaining hooks (clips). Confirm that the retaining hooks (clips) are secured into the grommet holes in the vehicle's floor (carpet).

Warning: Do not stack the floor mats in any vehicle. The retaining hooks (clips) are designed to accommodate only one floor mat at a time.



2. Check the following pedal operation (fully depress the pedal) to assure the floor mat does not interfere with it. Make sure the vehicle is turned off and in the "Park" position when testing:
 - Accelerator Pedal
 - Brake Pedal
 - Clutch Pedal (if equipped)

3. Verify the driver's floor mat involved in SSC 70F & 7LB has been removed from your vehicle

DO NOT USE THESE MATS

SSC 70F Part Number:
 PT908-32070-02 (Blk)
 PT908-32070-14 (Brn)

SSC 7LB Part Number:
 PT908-33070-02 OR PT908-33071-02 (Blk)
 PT908-33070-11 OR PT908-33071-11 (Gr)
 PT908-33070-14 OR PT908-33071-14 (Brn)

Robin LeFevre
Lexus Customer Service
September 29, 2009
Approved By: Al Smith

To: All Lexus Dealers
From: Lexus Customer Services

Lexus/Toyota Consumer Safety Advisory
Potential Floor Mat Interference with Accelerator Pedal
*******URGENT*******

Toyota Motor Sales, USA, Inc. takes public safety very seriously. We believe our vehicles to be among the safest on the road today.

Recent events have prompted Lexus and Toyota to take a closer look at the potential for an accelerator pedal to get stuck in the full open position due to an unsecured or incompatible driver's floor mat. A stuck open accelerator pedal may result in very high vehicle speeds and make it difficult to stop the vehicle, which could cause a crash, serious injury or death.

Lexus considers this a critical matter and will soon launch a safety campaign on specific Lexus and Toyota vehicles. Throughout the process of developing the details of the action plan, it will advise the National Highway Traffic Safety Administration (NHTSA).

Today, we are releasing a Consumer Safety Advisory to our customers. Until Lexus/Toyota develops a campaign remedy, we are asking owners of specific Lexus and Toyota models to take out any removable driver's floor mat and NOT replace it with any other floor mat. The following models are affected:

- 2007 – 2010 ES350
- 2006 – 2010 IS250 and IS350

- 2007 – 2010 Camry
- 2005 – 2010 Avalon
- 2004 – 2009 Prius
- 2005 – 2010 Tacoma
- 2007 – 2010 Tundra

In the event owners choose not to remove their floor mat, Lexus strongly recommends that they ensure that the correct floor mat is being used, that it is properly installed and secured, that it is not flipped over with bottom-side up, and that one floor mat is not stacked over another. Information on proper floor mat installation can be found on <http://www.lexus.com>.

If a customer requires your dealership's assistance, please assist them by utilizing the attached instructions and application chart.

- Please direct all customer inquiries to the Lexus Customer Assistance Center at 1-800-255-3987.
- If you are a dealership associate and have any questions, please contact your District Service/Parts Manager.
- Due to the nature of this activity, it is imperative that all media contacts (local and national) receive a consistent message. In this regard, **all media contacts** must be directed to Brian Lyons (310) 468-2552, in Toyota Corporate Communications. (Please do not provide these numbers to customers. Dealership associates should contact their Area representative for any questions).

The following Q&A has been provided for your reference.

Lexus Consumer Safety Advisory Q&A

Q1: Is this Lexus Consumer Safety Advisory a recall?

A1: This is a Consumer Safety Advisory based on the potential for an accelerator pedal to get stuck in the full open position due to an unsecured or incompatible driver's floor mat on certain Lexus and Toyota vehicles.

Q2: Why did Lexus issue the Consumer Safety Advisory?

A2: Recent events have prompted Lexus to take a closer look at the potential for an accelerator pedal to get stuck in the full open position due to an unsecured or incompatible driver's floor mat. A stuck open accelerator pedal may result in very high vehicle speeds and make it difficult to stop the vehicle which could cause a crash, serious injury or death.

Q3: Was there a specific incident related to the Consumer Advisory?

A3: On August 28th, 2009, California Highway Patrol Officer Mark Saylor and three members of his family tragically lost their lives on a highway near San Diego, California, while driving a 2009 ES350 loaned to them by a local Lexus dealer.

Preliminary information from law enforcement investigators indicates that the ES350 involved in the crash contained a driver's all-weather floor mat from a different model Lexus. If incompatible driver's floor mats are installed in any vehicle, or if the floor mat is not properly secured by the retaining hooks, this could cause it to interfere with the accelerator pedal.

Q3a: Electronic systems, such as drive by wire, have been suggested as a possible culprit in the persistence of sudden unintended acceleration incidents. Is this part of the investigation of the San Diego accident.

A3a: All aspects of the vehicle are being studied, but preliminary indications are that an all weather floor mat not designed for the ES350 was installed at the time of the Saylor crash. We have seen no evidence that electronic engine control systems were the cause.

Q4: Which models and model years are impacted?

A4: Lexus

2007 – 2010 ES350
2006 – 2010 IS250 and IS350

Toyota

2007 – 2010 Camry
2005 – 2010 Avalon
2004 – 2009 Prius
2005 – 2010 Tacoma
2007 – 2010 Tundra

Q4a: How many vehicles are involved?

A4a: We are currently determining the number of vehicles.

Q5: Is Lexus planning another recall for the all-weather floors mats or other components as a result of this Consumer Advisory?

A5: Lexus considers this a critical matter and will soon launch a safety campaign on specific Lexus and Toyota vehicles. Throughout the process of developing the details of the action plan, it will advise the National Highway Traffic Safety Administration (NHTSA).

Until we develop a campaign remedy, we recommend that owners remove **any** driver-side floor mat from the specific models identified and **NOT** replace it with any other floor mat.

Q5a: Why didn't the previous all-weather floor mat recall alleviate this problem?

A5a: The previous floor mat recall was aimed at replacing accessory all weather floor mats with a newly designed one as well as advising users not to place all weather mats on top of any other floor mats. Despite this effort, unsecured or incompatible driver's floor mats can present a hazard and Lexus/Toyota is exploring remedies that can further reduce the likelihood of an crash that could result from mis-installation.

Q6: What should customers do?

A6: Lexus/Toyota is committed to finding the right solution for this condition. Until the campaign remedy is developed and customers receive notice from Lexus, we request that customers take out any removable driver's floor mat and NOT replace it with any other floor mat.

Q6a: What if a customer chooses not to remove their floor mat?

A6a: In the event a customer chooses not to remove their floor mat, Lexus strongly recommends that they ensure that the correct floor mat is being used, that it is properly installed and secured, that it is not flipped over with bottom-side up, and that one floor mat is not stacked over another. Information on proper floor mat installation can be found on <http://www.lexus.com>.

Q6b: What if a customer requires assistance in checking the floor mat?

A6b: If a customer chooses not to remove their floor mat and requires assistance, they may check with any local Lexus dealership's Parts or Service Department to verify the application. Dealers will re-install only those floor mats designed specifically for that model and model year.

Q6c: What if a customer needs retaining hooks (clips)?

A6c: Replacement retaining hooks (clips) for Lexus carpeted and all-weather floor mats are available at any Lexus dealership. Please check with the dealer for details.

Q7: What if a floor mat is an aftermarket rubberized floor mat?

A7: Driver's floor mat interference is possible in any make or model vehicle with any combination of floor mats. Therefore, consumers need to make sure the floor mats are compatible for their model and model year. Also, they need to be sure they are properly secured using the appropriate retention device (clips). Driver's floor mats should never be stacked. Consumers should never place any floor mat – aftermarket or not -- on top of another driver's floor mat. Mats should also not be flipped over with the bottom-side up.

Q8: What if a driver experiences accelerator pedal interference. What should they do?

A8: Should the vehicle continue to accelerate rapidly after releasing the accelerator pedal, this could be an indication of floor mat interference. If this occurs, Lexus recommends the driver take the following actions:

First, if it is possible and safe to do so, pull-back the floor mat and dislodge it from the accelerator pedal; then pull over and stop the vehicle.

If the floor mat cannot be dislodged, then firmly and steadily step on the brake pedal with both feet. Do not pump the brake pedal repeatedly as this will increase the effort required to slow the vehicle. If you are still unable to stop the vehicle, then do the following:

Shift the transmission gear selector to the Neutral (N) position and use the brakes to make a controlled stop at the side of the road and turn off the engine.

If unable to put the vehicle in Neutral, turn the engine OFF. This will not cause loss of steering or braking control, but the power assist to these systems will be lost.

-If the vehicle is equipped with an Engine Start/Stop button, firmly and steadily push the button for at least three seconds to turn off the engine. Do NOT tap the Engine Start/Stop button.

-If the vehicle is equipped with a conventional key-ignition, turn the ignition key to the ACC position to turn off the engine. Do NOT remove the key from the ignition as this will lock the steering wheel.

Q8a: Why does the Engine Start/Stop button require 3 seconds to shut off?

A8a: This is to prevent accidentally shutting off the engine in case the button is bumped or mistaken for another control. The resulting loss of engine power could cause a loss of the power assist to the brakes and steering, and possibly an unsafe situation.

Q9: What if an owner has additional questions or concerns?

Owners with questions or concerns, are asked to please contact the Lexus Customer Assistance Center (1 800 255-3987), or consult the information posted at <http://www.lexus.com>.



Lexus All Weather Floor Mats (Sorted By Model)

Printed September 29, 2009

Model	Part Number	Model Year					Mat Description
		2004	2005	2006	2007	2008	
ES 330	PT908-33050-02	X	X	X	X	X	Black 4 pc set
ES 330	PT908-33050-11	X	X	X	X	X	Gray 4 pc set
ES 330	PT908-33050-14	X	X	X	X	X	Brown 4 pc set
	PT908-33070-02*						Black 4 pc set
	PT908-33070-11*						Gray 4 pc set
	PT908-33070-14*						Brown 4 pc set
	PT908-33071-02*						Black 4 pc set
	PT908-33071-11*						Gray 4 pc set
	PT908-33071-14*						Brown 4 pc set
ES 350	PT908-33072-02	X	X	X	X	X	Black 4 pc set
ES 350	PT908-33072-11	X	X	X	X	X	Gray 4 pc set
ES 350 (Front Mats)	PT908-33072-02	X	X	X	X	X	Brown 4 pc set
ES 350 (Front Mats)	PT908-33072-11	X	X	X	X	X	Black 4 pc set
ES 350 (Front Mats)	PT908-33072-14	X	X	X	X	X	Gray 1 pc set
GS 350/430/460 2WD	PT908-30050-14	X	X	X	X	X	Brown 4 pc set
GS 350/430/460 2WD	PT908-30050-02	X	X	X	X	X	Black 4 pc set
GS 350 4WD	PT908-30051-02	X	X	X	X	X	Brown 4 pc set
GS 350 4WD	PT908-30051-14	X	X	X	X	X	Black 4 pc set
GS 450H	PT908-30050-14	X	X	X	X	X	Brown 4 pc set
GS 450H	PT908-30050-02	X	X	X	X	X	Black 4 pc set
GX 470 w/ & w/o RSE	PT206-6030X-03	X	X	X	X	X	Gray 4 pc set
GX 470 w/ & w/o RSE	PT206-6030X-16	X	X	X	X	X	Black 4 pc set
GX 470 w/ RSE	PT908-6006X-02	X	X	X	X	X	Brown 4 pc set
GX 470 w/ RSE	PT908-6006X-14	X	X	X	X	X	Black 4 pc set
GX 470 w/o RSE	PT908-6006X-02	X	X	X	X	X	Brown 4 pc set
GX 470 w/o RSE	PT908-6006X-14	X	X	X	X	X	Black 4 pc set
GX 480	PT908-60100-02	X	X	X	X	X	Brown 4 pc set
IS 300 - Sport Cross (Front)	PT206-5303F-03	X	X	X	X	X	Black 4 pc set
IS 300 - Sport Cross (Rear)	PT206-5303F-03	X	X	X	X	X	Gray 2 pc set
IS 300 - Sport Cross (Front)	PT206-5303F-16	X	X	X	X	X	Black 2 pc set
IS 300 - Sport Cross (Rear)	PT206-5303F-16	X	X	X	X	X	Oak 2 pc set
IS 250/350 2WD	PT908-53050-02	X	X	X	X	X	Black 4 pc set
IS 250/350 4WD	PT908-53051-02	X	X	X	X	X	Black 4 pc set
IS 250/350 4WD	PT908-53070-02	X	X	X	X	X	Black 4 pc set
IS 250/350 4WD	PT908-53070-14	X	X	X	X	X	Black 4 pc set
HS 250H	PT908-53050-02	X	X	X	X	X	Black 4 pc set
HS 250H	PT908-53070-02	X	X	X	X	X	Black 4 pc set
LS 430	PT908-50070-02	X	X	X	X	X	Gray 4 pc set
LS 430	PT908-50070-14	X	X	X	X	X	Oak 4 pc set
LS 460 SWB	PT908-50070-02	X	X	X	X	X	Brown 4 pc set
LS 460 SWB	PT908-50070-14	X	X	X	X	X	Black 4 pc set
LS 460 LWB	PT908-50071-02	X	X	X	X	X	Brown 4 pc set
LS 460 LWB	PT908-50071-14	X	X	X	X	X	Black 4 pc set
LS 460 LWB 4WD	PT908-LSH80-02	X	X	X	X	X	Brown 4 pc set
LS 460 LWB 4WD	PT908-LSH80-14	X	X	X	X	X	Black 4 pc set
LS 460 SWB 4WD	PT206-6003F-03	X	X	X	X	X	Gray 2 pc set
LS 460 SWB 4WD	PT206-6003F-16	X	X	X	X	X	Oak 2 pc set
LS 460 SWB 4WD	PT206-6003B-03	X	X	X	X	X	Gray 2 pc set
LS 460 SWB 4WD	PT206-6003B-16	X	X	X	X	X	Oak 2 pc set
LS 460 SWB 4WD	PT908-60050-02	X	X	X	X	X	Black 4 pc set
LS 460 SWB 4WD	PT908-60050-14	X	X	X	X	X	Brown 4 pc set
LS 460 SWB 4WD	PT908-60051-02	X	X	X	X	X	Black 1 pc
LS 460 SWB 4WD	PT908-60051-14	X	X	X	X	X	Black 1 pc
LS 600H	PT908-LSH80-02	X	X	X	X	X	Brown 4 pc set
LS 600H	PT908-LSH80-14	X	X	X	X	X	Black 4 pc set
LX 470 (Front)	PT206-6003F-03	X	X	X	X	X	Gray 2 pc set
LX 470 (Front)	PT206-6003F-16	X	X	X	X	X	Oak 2 pc set
LX 470 (Rear)	PT206-6003B-03	X	X	X	X	X	Gray 2 pc set
LX 470 (Rear)	PT206-6003B-16	X	X	X	X	X	Oak 2 pc set
LX 470	PT908-60050-02	X	X	X	X	X	Black 4 pc set
LX 470	PT908-60050-14	X	X	X	X	X	Brown 4 pc set
LX 470 - 3* Row	PT908-60051-02	X	X	X	X	X	Black 1 pc
LX 470 - 3* Row	PT908-60051-14	X	X	X	X	X	Black 1 pc
LX 570	PT908-60080-02	X	X	X	X	X	Brown 4 pc set
LX 570	PT908-60080-14	X	X	X	X	X	Black 4 pc set
LX 570 - 3* Row	PT908-60080-02	X	X	X	X	X	Brown 4 pc set
LX 570 - 3* Row	PT908-60080-14	X	X	X	X	X	Black 1 pc
LX 570 - 3* Row	PT908-60081-02	X	X	X	X	X	Brown 4 pc set
LX 570 - 3* Row	PT908-60081-14	X	X	X	X	X	Black 4 pc set
RY 330/350	PT908-4806-16	X	X	X	X	X	Gray 4 pc set
RY 330/350	PT908-4806-02	X	X	X	X	X	Black 4 pc set
RY 400H	PT908-4806-14	X	X	X	X	X	Black 4 pc set
RY 400H	PT908-4806-02	X	X	X	X	X	Black 4 pc set
RX350/450h	PT908-48100-02	X	X	X	X	X	Black 4 pc set

* These mats were recalled in SSC TLA. Regularly verify that all AWP/AM involved in SSC TLA have been purged from your parts inventory and demand unrecalled. Please use part number PT908-33072-02 (Black), PT908-33072-11 (Gray) or PT908-33072-14 (Brown) in place of the recalled AWP/AM. Refer to SSC TLA on 7/30 for further information.

**Toyota Carpet Floor Mats
(Sorted By Model)**

Model	Year										Part Number	
	2003	2004	2005	2006	2007	2008	2009	2010	Color	Piece Set No.		
4 Runner	X	X	X	X	X	X	X	X				PT206-89030-04
4 Runner	X	X	X	X	X	X	X	X				PT206-89030-21
4 Runner	X	X	X	X	X	X	X	X				PT206-89034-20
Avalon	X	X	X	X	X	X	X	X				PT206-07006-08
Avalon	X	X	X	X	X	X	X	X				PT206-07046-10
Avalon	X	X	X	X	X	X	X	X				PT206-07006-08
Avalon	X	X	X	X	X	X	X	X				PT206-07006-15
Avalon	X	X	X	X	X	X	X	X				PT206-07046-04
Avalon	X	X	X	X	X	X	X	X				PT206-07000-15
Avalon	X	X	X	X	X	X	X	X				PT206-07000-23
Avalon	X	X	X	X	X	X	X	X				PT206-07040-21
Avalon	X	X	X	X	X	X	X	X				PT206-07000-23
Avalon	X	X	X	X	X	X	X	X				PT548-07050-10
Avalon	X	X	X	X	X	X	X	X				PT548-07050-22
Avalon	X	X	X	X	X	X	X	X				PT548-07050-11
Avalon	X	X	X	X	X	X	X	X				PT548-07050-12
Avalon	X	X	X	X	X	X	X	X				PT548-07070-10
Avalon	X	X	X	X	X	X	X	X				PT548-07070-22
Avalon	X	X	X	X	X	X	X	X				PT548-07070-11
Avalon	X	X	X	X	X	X	X	X				PT548-07070-12
Avalon	X	X	X	X	X	X	X	X				PT206-07060-02
Avalon	X	X	X	X	X	X	X	X				PT206-07060-17
Avalon	X	X	X	X	X	X	X	X				PT206-07060-18
Avalon	X	X	X	X	X	X	X	X				PT206-07060-16
Camry	X	X	X	X	X	X	X	X				PT206-32020-91
Camry	X	X	X	X	X	X	X	X				PT206-32020-21
Camry	X	X	X	X	X	X	X	X				PT206-32020-04
Camry - SE	X	X	X	X	X	X	X	X				PT206-32031-01
Camry - SE	X	X	X	X	X	X	X	X				PT206-32030-11
Camry / Camry Hybrid	X	X	X	X	X	X	X	X				PT206-32060-12
Camry / Camry Hybrid	X	X	X	X	X	X	X	X				PT206-32060-14
Camry / Camry Hybrid	X	X	X	X	X	X	X	X				PT206-32078-40
Camry Hybrid	X	X	X	X	X	X	X	X				PT206-32100-45
Camry / Camry Hybrid	X	X	X	X	X	X	X	X				PT206-32100-12
Camry / Camry Hybrid	X	X	X	X	X	X	X	X				PT206-20030-11
Corolla - Sport Edition (w/ Rear Heater)	X	X	X	X	X	X	X	X				PT206-02030-03
Corolla (w/ Rear Heater)	X	X	X	X	X	X	X	X				PT206-02030-11
Corolla (w/ Rear Heater)	X	X	X	X	X	X	X	X				PT206-02030-16
Corolla - Sport Edition (w/ Rear Heater)	X	X	X	X	X	X	X	X				PT206-02031-03
Corolla (w/ Rear Heater)	X	X	X	X	X	X	X	X				PT206-02031-11
Corolla (w/ Rear Heater)	X	X	X	X	X	X	X	X				PT206-02031-16
Corolla - Sport Edition (w/ Rear Heater)	X	X	X	X	X	X	X	X				PT206-02040-03
Corolla (w/ Rear Heater)	X	X	X	X	X	X	X	X				PT206-02040-11
Corolla (w/ Rear Heater)	X	X	X	X	X	X	X	X				PT206-02040-16
Corolla - Sport Edition (w/ Rear Heater)	X	X	X	X	X	X	X	X				PT206-02041-03
Corolla (w/ Rear Heater)	X	X	X	X	X	X	X	X				PT206-02041-11
Corolla (w/ Rear Heater)	X	X	X	X	X	X	X	X				PT206-02041-16
Corolla (w/ Rear Heater)	X	X	X	X	X	X	X	X				PT206-02051-01
Corolla (w/ Rear Heater)	X	X	X	X	X	X	X	X				PT206-02051-01
Corolla (w/ Rear Heater)	X	X	X	X	X	X	X	X				PT206-02060-12
Corolla	X	X	X	X	X	X	X	X				PT206-02060-41
Corolla	X	X	X	X	X	X	X	X				PT206-02060-12
Corolla	X	X	X	X	X	X	X	X				PT206-02060-41
Corolla	X	X	X	X	X	X	X	X				PT206-02063-11
Corolla	X	X	X	X	X	X	X	X				PT206-02063-41
Corolla	X	X	X	X	X	X	X	X				PT206-02102-45
Corolla	X	X	X	X	X	X	X	X				PT206-02103-45
Echo (2 door w/ rear heater)	X	X	X	X	X	X	X	X				PT206-52030-11
Echo (2 door w/ rear heater)	X	X	X	X	X	X	X	X				PT206-52030-11
Echo (2 door w/ rear heater)	X	X	X	X	X	X	X	X				PT206-52030-44
Echo (2 door w/ rear heater)	X	X	X	X	X	X	X	X				PT206-52033-44
Echo (4 door w/ rear heater)	X	X	X	X	X	X	X	X				PT206-52031-11
Echo (4 door w/ rear heater)	X	X	X	X	X	X	X	X				PT206-52034-11
Echo (4 door w/ rear heater)	X	X	X	X	X	X	X	X				PT206-52034-44
Echo (4 door w/ rear heater)	X	X	X	X	X	X	X	X				PT206-52036-11
F1 Cruiser	X	X	X	X	X	X	X	X				PT206-56100-01
Highlander	X	X	X	X	X	X	X	X				PT206-86100-01
Highlander	X	X	X	X	X	X	X	X				PT206-86100-10

Toyota Carpet Floor Mats (Sorted By Part Number)

Part Number	Model	Year							Mat Description
		2003	2004	2005	2006	2007	2008	2009	
PT206-12032-14	Matrix - 2WD	X							4 pc set
00200-35564-16	Tacoma - Access Cab		X						4 pc set
PT206-02030-03	Corolla - Sport Edition (w/ Rear Heater)	X							Dark Charcoal Oak
PT206-02030-11	Corolla (w/ Rear Heater)	X							Gray
PT206-02030-16	Corolla (w/ Rear Heater)	X							Light Gray Oak
PT206-02031-03	Corolla - Sport Edition (w/ Rear Heater)	X							Gray
PT206-02031-11	Corolla (w/ Rear Heater)	X							Light Gray Oak
PT206-02031-16	Corolla (w/ Rear Heater)	X							Light Gray Oak
PT206-02040-03	Corolla - Sport Edition (w/ Rear Heater)	X	X	X	X	X	X	X	Gray
PT206-02040-11	Corolla (w/ Rear Heater)	X	X	X	X	X	X	X	Light Gray Oak
PT206-02040-16	Corolla (w/ Rear Heater)	X	X	X	X	X	X	X	Light Gray Oak
PT206-02041-03	Corolla - Sport Edition (w/ Rear Heater)	X	X	X	X	X	X	X	Gray
PT206-02041-11	Corolla (w/ Rear Heater)	X	X	X	X	X	X	X	Light Gray Oak
PT206-02041-16	Corolla (w/ Rear Heater)	X	X	X	X	X	X	X	Light Gray Oak
PT206-02051-01	Corolla (w/ Rear Heater)	X	X	X	X	X	X	X	Gray
PT206-02051-12	Corolla	X	X	X	X	X	X	X	Dark Charcoal Oak
PT206-02051-17	Corolla	X	X	X	X	X	X	X	Dark Charcoal Oak
PT206-02052-11	Corolla	X	X	X	X	X	X	X	Dark Charcoal Oak
PT206-02052-12	Corolla	X	X	X	X	X	X	X	Dark Charcoal Oak
PT206-02053-11	Corolla	X	X	X	X	X	X	X	Dark Charcoal Oak
PT206-02053-12	Corolla	X	X	X	X	X	X	X	Dark Charcoal Oak
PT206-02053-17	Corolla	X	X	X	X	X	X	X	Dark Charcoal Oak
PT206-02102-45	Corolla	X	X	X	X	X	X	X	Dark Charcoal Oak
PT206-02103-45	Corolla	X	X	X	X	X	X	X	Dark Charcoal Oak
PT206-06030-10	Solara - Hard Top	X							Ivory
PT206-06030-11	Solara - Hard Top	X							Ivory
PT206-06031-10	Solara - Convertible	X							Dark Charcoal Oak
PT206-06031-11	Solara - Convertible	X							Dark Charcoal Oak
PT206-06060-10	Solara - Coupe	X	X	X	X	X	X	X	Dark Charcoal Oak
PT206-06060-11	Solara - Coupe	X	X	X	X	X	X	X	Dark Charcoal Oak
PT206-06068-10	Solara - Convertible	X	X	X	X	X	X	X	Dark Charcoal Oak
PT206-06068-11	Solara - Convertible	X	X	X	X	X	X	X	Dark Charcoal Oak
PT206-06068-21	Solara - Convertible	X	X	X	X	X	X	X	Dark Charcoal Oak
PT206-06080-10	Solara - Coupe	X	X	X	X	X	X	X	Dark Charcoal Oak
PT206-06080-11	Solara - Coupe	X	X	X	X	X	X	X	Dark Charcoal Oak
PT206-06088-10	Solara - Convertible	X	X	X	X	X	X	X	Dark Charcoal Oak
PT206-06088-11	Solara - Convertible	X	X	X	X	X	X	X	Dark Charcoal Oak
PT206-06088-21	Solara - Convertible	X	X	X	X	X	X	X	Dark Charcoal Oak
PT206-07050-06	Avalon	X							Graphite
PT206-07050-17	Avalon	X							Graphite
PT206-07050-18	Avalon	X							Light Gray Oak
PT206-09067-04	Sienna - 7 pass	X	X	X	X	X	X	X	Dark Charcoal Oak
PT206-09067-21	Sienna - 7 pass	X	X	X	X	X	X	X	Dark Charcoal Oak
PT206-09068-04	Sienna - 8 pass	X	X	X	X	X	X	X	Dark Charcoal Oak
PT206-09068-21	Sienna - 8 pass	X	X	X	X	X	X	X	Dark Charcoal Oak
PT206-09067-12	Sienna - 7 pass	X	X	X	X	X	X	X	Dark Charcoal Oak
PT206-09067-41	Sienna - 7 pass	X	X	X	X	X	X	X	Dark Charcoal Oak
PT206-09068-12	Sienna - 8 pass	X	X	X	X	X	X	X	Dark Charcoal Oak
PT206-09068-41	Sienna - 8 pass	X	X	X	X	X	X	X	Dark Charcoal Oak
PT206-0C030-11	Sequoia	X	X	X	X	X	X	X	Light Charcoal Oak
PT206-0C030-14	Sequoia	X	X	X	X	X	X	X	Light Charcoal Oak
PT206-0C050-09	Sequoia	X	X	X	X	X	X	X	Taupe
PT206-0C050-11	Sequoia	X	X	X	X	X	X	X	Light Charcoal Oak
PT206-0T050-20	Venza	X	X	X	X	X	X	X	Black
PT206-12030-03	Matrix - AWD (w/ heater)	X							Gray
PT206-12031-03	Matrix - 2WD (w/ heater)	X							Gray
PT206-12032-03	Matrix - 2WD (w/ heater)	X							Gray
PT206-12040-03	Matrix - AWD (w/ Rear Heater)	X	X	X	X	X	X	X	Gray
PT206-12041-03	Matrix - 2WD (w/ Rear Heater)	X	X	X	X	X	X	X	Gray
PT206-12042-03	Matrix - 2WD (w/ Rear Heater)	X	X	X	X	X	X	X	Gray
PT206-12070-03	Matrix (w/ heater)	X	X	X	X	X	X	X	Gray
PT206-12071-03	Matrix (w/ heater)	X	X	X	X	X	X	X	Gray
PT206-12080-14	Matrix - AWD	X	X	X	X	X	X	X	Dark Charcoal Oak
PT206-12083-14	Matrix - AWD	X	X	X	X	X	X	X	Dark Charcoal Oak
PT206-20030-11	Camry - Hybrid	X	X	X	X	X	X	X	Dark Charcoal Oak
PT206-32060-11	Camry - Hybrid	X	X	X	X	X	X	X	Dark Charcoal Oak

George Morino / TMS Toyota Customer Services
Quality Compliance
October 1, 2009
Approved By: Bob Waltz

To: All Toyota Dealers
From: Toyota Customer Services

Toyota-Lexus Consumer Safety Advisory
Potential Floor Mat Interference with Accelerator Pedal
*******URGENT*******

Toyota greatly appreciates your patience during this activity. Here is additional information about the Toyota-Lexus Consumer Safety Advisory ("Consumer Safety Advisory"), to add to our communication of September 29th.

A Safety Campaign will be launched soon with clear dealer instructions and an owner notification to visit their local Toyota dealership regarding the affected vehicles. Until the Safety Campaign is launched, Toyota recommends the following action(s) be taken by your staff:

Overall Dealership Operations

- Conduct a management meeting to familiarize all department heads with the Consumer Safety Advisory. Service, Loaner Vehicle (TRAC), Carwash, New Vehicle, New Car Preparation, Used Vehicle, Used Vehicle Reconditioning, Parts, and Body Shop operations should be familiar with the Consumer Safety Advisory and its contents.
- Each Dealership should designate two management level associates with complementary schedules to become intimately familiar with all aspects of the Consumer Safety Advisory, Q&A as well as other materials we have provided. These two associates should coordinate all operations related to this activity.
- New, Used, and Loaner Vehicle (TRAC) departments should coordinate with the Service Department to assure the driver's floor mat is semi-permanently installed. This should be conducted on the following involved vehicles until the safety campaign has been launched.

Toyota Models

- 2007 – 2010 Camry
- 2005 – 2010 Avalon
- 2004 – 2009 Prius
- 2005 – 2010 Tacoma
- 2007 – 2010 Tundra

Customer Handling

- Please welcome concerned owners that visit your dealership and answer any questions that they may have. Please utilize the Q&A to assure a consistent message is communicated.
- Assist any customer who asks to verify correct application and secure installation.
- Please encourage owners to make sure the floor mats are compatible for their model and model year. Also, they need to be sure they are properly secured using the appropriate retention device (clips). Driver's floor mats should never be stacked. Consumers should never place any floor mat – aftermarket or not -- on top of another driver's floor mat. Mats should also not be flipped over with the bottom-side up.
- Information on proper floor mat installation can be found on <http://www.toyota.com>.
- Owners with additional questions or concerns, are asked to please contact the Toyota Customer Experience Center (1 800 331-4331).

Service Department

- Please coordinate with other dealership departments to **semi-permanently** install the driver's position floor mat in involved new, used, loaner (TRAC) and demo vehicles. Read and follow the attached technical instructions. The necessary materials are available at local hardware and office supply stores. This will assure the floor mats are **not removable**. We recommend the Service Department designate associates to conduct this specific installation to assure that the involved vehicles are handled consistently.
- Owners' vehicles in for service should all be inspected for proper installation of the correct floor mats at the time of delivery (including after the car wash) and document this on the Repair Order (RO).
 - If an involved vehicle owner expresses concern over the safety of their vehicle, recommend removal of the driver's side floor mat (place in the trunk) until they are contacted by Toyota regarding the forthcoming Safety Campaign. Document this action on the RO.
 - If the owner prefers to have the floor mat semi-permanently installed, please follow the attached instructions.
- If your dealership provides "car washes on demand", proper floor mat installation should be ensured on every vehicle after this service, as well.

Sales Department

- Sales deliveries of involved Avalon, Camry, Prius, Tacoma and Tundra new, CPO or used vehicles should include semi-permanently installed driver's position floor mats that are designed specifically for that model. As many customers will be sensitive to the recent Consumer Safety Advisory, we recommend that they be informed that the driver's floor mat is semi-permanently installed and not removable. Toyota will notify customers when the Safety Campaign is initiated to return their vehicle for the remedy. The driver's floor mat will be rendered removable at that time.
- Owners may also choose to have the driver's floor mat placed in the trunk until the safety campaign remedy is available. Please advise the owner of this option.
- Document the condition of the driver's floor mat at vehicle delivery (e.g. "the correct driver's side floor mat is **semi-permanently** installed" or "removed driver's side floor mat") in a one-line RO.
- All dealership demos should be checked regularly to confirm the use of correct and properly installed floor mats.

Parts Department

Any Toyota All Weather Floor Mat (AWFM) in your inventory should be removed from inventory and returned:

- Dealers should prepare either a TMP-134 Claim (Toyota) listing the part numbers and quantities of each AWFM they are requesting to return. These claims should be submitted to the facing PDC using the normal method in Dealer Daily.
- The return code for each part should be indicated as R-2, Manufacturing Defect.
- When your dealership receives authorization from your facing PDC to make the return, please return the AWFM's immediately. The different AWFM's should be grouped by part number to assist the PDC in accurately accounting for the returned quantities.

If you are approached by the media, please direct them to Toyota Corporate Communications at 310.468.2552 or 310.468.4718. When you must speak to any media representatives, please reference the information we've provided, on how to identify and properly install the correct floor mats, as well as your efforts to instruct owners about the importance of the proper installation of floor mats designed specifically for their vehicle.

We hope this information is helpful. Please direct any additional questions you may have to your Region/PD/Area representative so that we can continue to address your issues as we work through this experience together.

Toyota Floor Mat Inspection, Application and Semi-Permanent Installation Instructions



Read these important warnings **BEFORE** installing ANY type of Floor Mat.


A. General Floor Mat Warnings

- Only install floor mats designed specifically for that model and model year. Check for correct model name and part number on the packaging label to confirm vehicle application.
 - Never install a floor mat if you are uncertain of the model application.
 - Never install the floor mat upside down or turned over for any reason.
 - Only install the driver's floor mat in the driver's foot area.
- Always properly secure the driver's floor mat using the retaining hooks (clips) supplied in the bag with the floor mats. Follow the floor mat retention clip installation instruction supplied with the clips. If the mat is properly secured and you have confirmed vehicle applicability, it will not interfere with the accelerator pedal.
- After the driver's mat is secured by the retaining hooks (clips) semi-permanently install the floor mat to the vehicles using the self-locking nylon tie-wraps mentioned in the instructions below.
 - Never install the front driver's floor mat without all retaining hooks (clips) securing the mat firmly in place and the self-locking nylon tie-wraps semi-permanently installing the floor mat to the vehicle.
- The retaining hooks (clips) are designed to accommodate only one floor mat at a time.
 - Do not install another floor mat(s) on top of an existing driver's floor mat.
- After installation, always check the operation of the accelerator, brake and clutch (if applicable) pedals to assure the floor mat does not interfere with them.
- Carefully read the warning tag attached to the driver's floor mat regarding installation.

B. Floor Mat Inspection Instructions and Application Information

- **Before placing a floor mat in a vehicle, be familiar with the procedure outlined below.**
 - Identify the correct driver's floor mat for the specific vehicle application.
 - Correctly install the driver's floor mat.
- Regularly verify the correct floor mat is securely installed in the appropriate model using the retaining hooks (clips).
- Regularly verify the correct driver's floor mat is semi-permanently installed in the appropriate model using the self-locking nylon tie-wraps.

NOTE: Use the Application Information Chart provided or the Accessory Parts Catalog to verify mat-to-vehicle application.




PT208-47060

Driver's floor mat part number is located on the bottom of the back side of the mat. (Location may vary by mat)

06
07
08

(Sample of Application Information Chart)

Model	Part Number									Mat Description	
		'03	'04	'05	'06	'07	'08	'09	'10	Color	Pc Set No.
Prius	PT208-47045-11	x	x	x	x	x	x	x		Dark Gray	4 pc set
Prius	PT208-47060-12									Dark Blue	4 pc set
Prius	PT926-47100-10								x	Misty Gray	4 pc set



1. Make sure the driver's floor mat is properly secured by the retaining hooks (clips). Confirm that the retaining hooks (clips) are secured into the grommet holes in the vehicle's floor (carpet).

Warning: Do not stack the floor mats in any vehicle. The retaining hooks (clips) are designed to accommodate only one floor mat at a time.

C. Driver's Position Semi-Permanent Installation

1. Necessary Materials
 - Self-locking nylon Tie-Wraps (Must be UV-resistant, rated at 50 pounds minimum & 0.19 inches wide)
 - Easy Peel Labels (Use Avery® 5260™)
 - Thin Flat-Head Screwdriver
 - Fine-Pointed Punch
 - Ruler
 - Diagonal Cutting Pliers

George Morino / TMS Toyota Customer Services
Quality Compliance
October 1, 2009
Approved By: Bob Waltz

To: All Toyota Dealers
From: Toyota Customer Services

Toyota-Lexus Consumer Safety Advisory
Potential Floor Mat Interference with Accelerator Pedal
*******URGENT*******

Toyota greatly appreciates your patience during this activity. Here is additional information about the Toyota-Lexus Consumer Safety Advisory ("Consumer Safety Advisory"), to add to our communication of September 29th.

A Safety Campaign will be launched soon with clear dealer instructions and an owner notification to visit their local Toyota dealership regarding the affected vehicles. Until the Safety Campaign is launched, Toyota recommends the following action(s) be taken by your staff:

Overall Dealership Operations

- Conduct a management meeting to familiarize all department heads with the Consumer Safety Advisory. Service, Loaner Vehicle (TRAC), Carwash, New Vehicle, New Car Preparation, Used Vehicle, Used Vehicle Reconditioning, Parts, and Body Shop operations should be familiar with the Consumer Safety Advisory and its contents.
- Each Dealership should designate two management level associates with complementary schedules to become intimately familiar with all aspects of the Consumer Safety Advisory, Q&A as well as other materials we have provided. These two associates should coordinate all operations related to this activity.
- New, Used, and Loaner Vehicle (TRAC) departments should coordinate with the Service Department to assure the driver's floor mat is semi-permanently installed. This should be conducted on the following involved vehicles until the safety campaign has been launched.

Toyota Models

- 2007 – 2010 Camry
- 2005 – 2010 Avalon
- 2004 – 2009 Prius
- 2005 – 2010 Tacoma
- 2007 – 2010 Tundra

Customer Handling

- Please welcome concerned owners that visit your dealership and answer any questions that they may have. Please utilize the Q&A to assure a consistent message is communicated.
- Assist any customer who asks to verify correct application and secure installation.
- Please encourage owners to make sure the floor mats are compatible for their model and model year. Also, they need to be sure they are properly secured using the appropriate retention device (clips). Driver's floor mats should never be stacked. Consumers should never place any floor mat – aftermarket or not -- on top of another driver's floor mat. Mats should also not be flipped over with the bottom-side up.
- Information on proper floor mat installation can be found on <http://www.toyota.com>.
- Owners with additional questions or concerns, are asked to please contact the Toyota Customer Experience Center (1 800 331-4331).

Service Department

- Please coordinate with other dealership departments to **semi-permanently** install the driver's position floor mat in involved new, used, loaner (TRAC) and demo vehicles. Read and follow the attached technical instructions. The necessary materials are available at local hardware and office supply stores. This will assure the floor mats are **not removable**. We recommend the Service Department designate associates to conduct this specific installation to assure that the involved vehicles are handled consistently.
- Owners' vehicles in for service should all be inspected for proper installation of the correct floor mats at the time of delivery (including after the car wash) and document this on the Repair Order (RO).
 - If an involved vehicle owner expresses concern over the safety of their vehicle, recommend removal of the driver's side floor mat (place in the trunk) until they are contacted by Toyota regarding the forthcoming Safety Campaign. Document this action on the RO.
 - If the owner prefers to have the floor mat semi-permanently installed, please follow the attached instructions.
- If your dealership provides "car washes on demand", proper floor mat installation should be ensured on every vehicle after this service, as well.

Sales Department

- Sales deliveries of involved Avalon, Camry, Prius, Tacoma and Tundra new, CPO or used vehicles should include semi-permanently installed driver's position floor mats that are designed specifically for that model. As many customers will be sensitive to the recent Consumer Safety Advisory, we recommend that they be informed that the driver's floor mat is semi-permanently installed and not removable. Toyota will notify customers when the Safety Campaign is initiated to return their vehicle for the remedy. The driver's floor mat will be rendered removable at that time.
- Owners may also choose to have the driver's floor mat placed in the trunk until the safety campaign remedy is available. Please advise the owner of this option.
- Document the condition of the driver's floor mat at vehicle delivery (e.g. "the correct driver's side floor mat is **semi-permanently** installed" or "removed driver's side floor mat") in a one-line RO.
- All dealership demos should be checked regularly to confirm the use of correct and properly installed floor mats.

Parts Department

Any Toyota All Weather Floor Mat (AWFM) in your inventory should be removed from inventory and returned:

- Dealers should prepare either a TMP-134 Claim (Toyota) listing the part numbers and quantities of each AWFM they are requesting to return. These claims should be submitted to the facing PDC using the normal method in Dealer Daily.
- The return code for each part should be indicated as R-2, Manufacturing Defect.
- When your dealership receives authorization from your facing PDC to make the return, please return the AWFM's immediately. The different AWFM's should be grouped by part number to assist the PDC in accurately accounting for the returned quantities.

If you are approached by the media, please direct them to Toyota Corporate Communications at 310.468.2552 or 310.468.4718. When you must speak to any media representatives, please reference the information we've provided, on how to identify and properly install the correct floor mats, as well as your efforts to instruct owners about the importance of the proper installation of floor mats designed specifically for their vehicle.

We hope this information is helpful. Please direct any additional questions you may have to your Region/PD/Area representative so that we can continue to address your issues as we work through this experience together.

Toyota Floor Mat Inspection, Application and Semi-Permanent Installation Instructions (10/02/09)



Read these important warnings BEFORE installing ANY type of Floor Mat.

A. General Floor Mat Warnings

- Only install floor mats designed specifically for that model and model year. Check for correct model name and part number on the packaging label to confirm vehicle application.
 - Never install a floor mat if you are uncertain of the model application.
 - Never install the floor mat upside down or turned over for any reason.
 - Only install the driver's floor mat in the driver's foot area.
- Always properly secure the driver's floor mat using the retaining hooks (clips) supplied in the bag with the floor mats. Follow the floor mat retention clip installation instruction supplied with the clips. If the mat is properly secured and you have confirmed vehicle applicability, it will not interfere with the accelerator pedal.
- After the driver's mat is secured by the retaining hooks (clips) semi-permanently install the floor mat to the vehicles using the self-locking nylon tie-wraps mentioned in the instructions below.
 - Never install the front driver's floor mat without all retaining hooks (clips) securing the mat firmly in place and the self-locking nylon tie-wraps semi-permanently installing the floor mat to the vehicle.
- The retaining hooks (clips) are designed to accommodate only one floor mat at a time.
 - Do not install another floor mat(s) on top of an existing driver's floor mat.
- After installation, always check the operation of the accelerator, brake and clutch (if applicable) pedals to assure the floor mat does not interfere with them.
- Carefully read the warning tag attached to the driver's floor mat regarding installation.

B. Floor Mat Inspection Instructions and Application Information

- Before placing a floor mat in a vehicle, be familiar with the procedure outlined below.
 - Identify the correct driver's floor mat for the specific vehicle application.
 - Correctly install the driver's floor mat.
- Regularly verify the correct floor mat is securely installed in the appropriate model using the retaining hooks (clips).
- Regularly verify the correct driver's floor mat is semi-permanently installed in the appropriate model using the self-locking nylon tie-wraps.

NOTE: Use the Application Information Chart provided or the Accessory Parts Catalog to verify mat-to-vehicle application.


PT208-47060

06
07
08

Driver's floor mat part number is located on the bottom of the back side of the mat. (Location may vary by mat)

(Sample of Application Information Chart)

Model	Part Number									Mat Description	
		'03	'04	'05	'06	'07	'08	'09	'10	Color	Pc Set No.
Prius	PT208-47045-10		x	x						Ivory	4 pc set
Prius	PT208-47045-11		x	x	x	x	x			Dark Gray	4 pc set
Prius	PT208-47060-14				x	x	x	x		Drk Bisque	4 pc set
Prius	PT926-47100-10								x	Misty Gray	4 pc set



1. Make sure the driver's floor mat is properly secured by the retaining hooks (clips). Confirm that the retaining hooks (clips) are secured into the grommet holes in the vehicle's floor (carpet).


Warning: Do not stack the floor mats in any vehicle. The retaining hooks (clips) are designed to accommodate only one floor mat at a time.

C. Driver's Position Semi-Permanent Installation

1. Necessary Materials

- Self-locking nylon tie-wraps (Must be UV-resistant, rated at 50 pounds minimum, 0.19 inches wide, and 17 inches long)
- Easy Peel Labels (Use Avery® 5260™)
- Thin Flat-Head Screwdriver
- Fine-Pointed Punch
- Ruler
- Diagonal Cutting Pliers

Applicable to '05 – '10 Avalon, '07 – '10 Camry, '04 – '09 Prius, '05 – '10 Tacoma, '07 – '10 Tundra vehicles only.
Toyota Floor Mat Inspection, Application and Semi-Permanent Installation Instructions



2. Locate, align & punch driver's floor mat.

- a) Align & punch directly in front of the driver's seat mounting bracket in the three locations shown (see red circles in illustration).
- b) Punch two holes into the lower left driver's floor mat as indicated in step 2a. If necessary, enlarge the holes with a thin flat-head screwdriver.



3. Route & fasten self-locking nylon tie-wraps.

STOP Self-locking nylon tie-wraps must be UV-resistant, rated at 50 pounds minimum, be 0.19 inches wide and 17 inches long.

- a) Route and fasten the self-locking nylon tie-wraps through the floor mat and under the seat mounting bracket as illustrated.
- b) Repeat step 2 a) for the right side of driver's floor mat, except puncture only one hole in the mat.
- c) Tighten the self-locking nylon tie-wraps to remove slack, but do not apply tension or displace the secured floor mat from the clipped position.

NOTE:

- Some models may require two tie-wraps joined in series to complete routing.
- Do not remove seat mounting bracket covers, equipped in some models, during the routing process.



4. Verify correct installation.

STOP

- a) Confirm clearance to electrical wiring connectors and any moving components.
- b) Verify the self-locking nylon tie-wraps are not too loosely or too tightly fastened as illustrated.
- c) Verify the floor mat does not interfere with the accelerator pedal throughout its range of travel.

NOTE:

- Trim excess portion of self-locking nylon tie-wraps and conceal the self-locking portion of the tie-wrap under the seat bracket and/or floor mat.




5. Install Labels

STOP

- a) Install a label on both of the self-locking nylon tie-wraps, secured to the two seat mounting brackets.

NOTE: Print on Avery® 5260™ using the template provided.

- b) Make sure to fold over the label so the text is visible from both sides.



6. Check the following pedal operation (fully depress the pedal) to assure the floor mat does not interfere with it. Make sure the vehicle is turned off and in the "Park" position when testing:
- Accelerator Pedal
 - Brake Pedal
 - Clutch Pedal (if equipped)

Lexus Consumer Safety Advisory Potential Floor Mat Interference with Accelerator Pedal **URGENT******

Lexus Customer Services /Lexus
Robin LeFevre
Approved By Al Smith
Published on: 09/30/2009 12:00 AM

To: All Lexus Dealers

From: Lexus Customer Service

Lexus Consumer Safety Advisory

Potential Floor Mat Interference with Accelerator Pedal

*******URGENT*******

Lexus greatly appreciates your patience during this activity. Enclosed is additional information about the Lexus Consumer Safety Advisory (Consumer Safety Advisory), to add to our communication of September 29th.

A Safety Campaign will be launched soon with clear dealer instructions and an owner notification to visit their local Lexus dealership regarding the involved vehicles. Until the Safety Campaign is launched, Lexus recommends the following actions be taken by your staff:

Overall Dealership Operations

Conduct a management meeting to familiarize all department heads with the Consumer Safety Advisory. Service, Loaner, Carwash, New Vehicle, New Car Preparation, Certified Pre-Owned (CPO)/Used Vehicle, Used Vehicle Reconditioning, Parts, and Body Shop operations should be familiar with the Consumer Safety Advisory and its contents.

Each dealership should designate two management level associates with complementary schedules to become intimately familiar with all aspects of the Consumer Safety Advisory, Q&A as well as other materials we have provided. These two associates should coordinate all operations related to this activity.

New, CPO/Used and Loaner Vehicle departments should coordinate with the Service Department to assure the drivers floor mat is semi-permanently installed. This should be conducted on all the following involved vehicles until the safety campaign has been launched.

2007 2010 ES

2006 2010 IS

Customer Handling

Please welcome concerned owners that visit your dealership and answer any questions they may have and utilize the previously provided Q&A to assure a consistent message is communicated.

Assist any customer who asks to verify correct application and secure installation.

Encourage owners to make sure the floor mats are compatible for their model and model year. Also, they need to be sure the floor mats are properly secured using the appropriate retention device (clips). Drivers floor mats should never be stacked. Consumers should never place any floor mat aftermarket or not – on top of another drivers floor mat. Mats should also not be flipped over with the bottom-side up.

Information on proper floor mat installation can be found on <http://www.lexus.com>.

Owners with additional questions or concerns may also contact the Lexus Customer Assistance Center at 1 800 255-3987.

Service Department

Please coordinate with other dealership departments to semi-permanently install the drivers position floor mat in involved new, CPO, used, loaner and demo vehicles. Read and follow the attached technical instructions using specified materials which can be found at local hardware and office supply stores. This will assure the floor mats are not removable. We recommend the Service Department designate associates to conduct this installation to assure that the involved vehicles are handled consistently.

Owners' vehicles in for service should all be inspected for proper installation of the correct floor mats at the time of delivery (including after the car wash); document this on the Repair Order (RO).

If an affected ES/IS owner expresses concern over the safety of their vehicle, recommend removal of the driver's side floor mat (place in the trunk) until they are contacted by Lexus regarding the forthcoming Safety Campaign. Document this action on the RO.

If the owner prefers to have the floor mat semi-permanently installed, please follow the attached instructions and document this action on the RO.

If your dealership provides "car washes on demand", proper floor mat installation should be ensured on every vehicle after this service, as well.

Sales Department

Sales deliveries of involved ES and IS new, CPO or used vehicles should include semi-permanently installed drivers position floor mats that are designed specifically for the model. As many customers will be sensitive to the recent Consumer Safety Advisory, we recommend that they be informed that the drivers floor mat is semi-permanently installed and not removable. Lexus will notify customers when the Safety Campaign is initiated to return their vehicle for the remedy. The drivers floor mat will be rendered removable at that time.

Owners may also choose to have the drivers floor mat placed in the trunk until the safety campaign remedy is available. Please advise the owner of this option.

Document the condition of the driver's floor mat at vehicle delivery (e.g. "the correct driver's side floor mat is semi-permanently installed" or "removed driver's side floor mat") in a one-line RO.

All dealership demos should also be checked regularly to confirm the use of correct and properly installed floor mats.

Parts Department

Lexus Floor Mat Inspection, Application and Semi-Permanent Installation Instructions (10/02/09)



Read these important warnings **BEFORE** installing ANY type of Floor Mat.


A. General Floor Mat Warnings

- Only install floor mats designed specifically for that model and model year. Check for correct model name and part number on the packaging label to confirm vehicle application.
 - Never install a floor mat if you are uncertain of the model application.
 - Never install the floor mat upside down or turned over for any reason.
 - Only install the driver's floor mat in the driver's foot area.
- Always properly secure the driver's floor mat using the retaining hooks (clips) supplied in the bag with the floor mats (in the case of Lexus with the carpet floor mats). Follow the floor mat retention clip installation instruction supplied with the clips. If the mat is properly secured and you have confirmed vehicle applicability, it will not interfere with the accelerator pedal.
- After the driver's mat is secured by the retaining hooks (clips) semi-permanently install the floor mat to the vehicles using the self-locking nylon tie-wraps mentioned in the instructions below.
 - Never install the front driver's floor mat without all retaining hooks (clips) securing the mat firmly in place and the self-locking nylon tie-wraps semi-permanently installing the floor mat to the vehicle.
- The retaining hooks (clips) are designed to accommodate only one floor mat at a time.
 - Do not install another floor mat(s) on top of an existing driver's floor mat.
- After installation, always check the operation of the accelerator, brake and clutch (if applicable) pedals to assure the floor mat does not interfere with them.
- Carefully read the warning tag attached to the driver's floor mat regarding installation.

B. Floor Mat Inspection Instructions and Application Information

- **Before placing a floor mat in a vehicle, be familiar with the procedure outlined below.**
 - Identify the correct driver's floor mat for the specific vehicle application.
 - Correctly install the driver's floor mat.
- Regularly verify the correct floor mat is securely installed in the appropriate model using the retaining hooks (clips).
- Regularly verify the correct driver's floor mat is semi-permanently installed in the appropriate model using the self-locking nylon tie-wraps.

NOTE: Use the Application Information Chart provided or the Accessory Parts Catalog to verify mat-to-vehicle application.




U6
07
08

PT548-33070

(Sample of Application Information Chart)

Model	Part Number									Mat Description	
		'04	'05	'06	'07	'08	'09	'10	Color	Piece Set No.	
ES 350	PT548-33070-02				x	x	x	x	Black	4 pc set	
ES 350	PT548-33070-11				x	x	x	x	Light Gray	4 pc set	
ES 350	PT548-33070-10				x	x	x	x	Cashmere	4 pc set	
ES 350	PT548-33080-02					x	x	x	Black	4 pc set	

Driver's floor mat part number is located on the bottom of the back side of the mat. (Location may vary by mat)



1. Make sure the driver's floor mat is properly secured by the retaining hooks (clips). Confirm that the retaining hooks (clips) are secured into the grommet holes in the vehicle's floor (carpet).


Warning: Do not stack the floor mats in any vehicle. The retaining hooks (clips) are designed to accommodate only one floor mat at a time.

C. Driver's Position Semi-Permanent Installation

1. Necessary Materials

- Self-locking nylon tie-wraps (Must be UV-resistant, rated at 50 pounds minimum, 0.19 inches wide and 17 inches long)
- Easy Peel Labels (Use Avery® 5260™)
- Thin Flat-Head Screwdriver
- Fine-Pointed Punch
- Ruler
- Diagonal Cutting Pliers

Applicable to 2007 – 2010 MY ES and 2006 – 2010 MY IS vehicles only.



2. Locate, align & punch driver's floor mat.

- a) Align & punch directly in front of the driver's seat mounting bracket in the three locations shown (see red circles in illustration).



- b) Punch two holes into the lower left driver's floor mat as indicated in step 2a. If necessary, enlarge the holes with a thin flat-head screwdriver.

3. Route & fasten self-locking nylon tie-wraps.

STOP Self-locking nylon tie-wraps must be UV-resistant, rated at 50 pounds minimum, be 0.19 inches wide and 17 inches long.

- a) Route and fasten the self-locking nylon tie-wraps through the floor mat and under the seat mounting bracket as illustrated.
- b) Repeat step 2 a) for the right side of driver's floor mat, except puncture only one hole in the mat.
- c) Tighten the self-locking nylon tie-wraps to remove slack, but do not apply tension or displace the secured floor mat from the clipped position.

NOTE:

- Some models may require two tie-wraps joined in series to complete routing.
- Do not remove seat mounting bracket covers, equipped in some models, during the routing process.



4. Verify correct installation.

STOP

a) Confirm clearance to electrical wiring connectors and any moving components.

b) Verify the self-locking nylon tie-wraps are not too loosely or too tightly fastened as illustrated.

c) Verify the floor mat does not interfere with the accelerator pedal throughout its range of travel.

NOTE:

- Trim excess portion of self-locking nylon tie-wraps and conceal the self-locking portion of the tie-wrap under the seat bracket and/or floor mat.




5. Install Labels

STOP

a) Install a label on both of the self-locking nylon tie-wraps, secured to the two seat mounting brackets.

NOTE: Print on Avery® 5260™ using the template provided.

b) Make sure to fold over the label so the text is visible from both sides.



6. Check the following pedal operation (fully depress the pedal) to assure the floor mat does not interfere with it. Make sure the vehicle is turned off and in the "Park" position when testing:
- Accelerator Pedal
 - Brake Pedal
 - Clutch Pedal (if equipped)

Lexus Consumer Safety Advisory Potential Floor Mat Interference with Accelerator Pedal - Updated 10-02-2009 **URGENT******

Lexus Customer Services /Lexus
Robin LeFevre
Approved By Al Smith
Published on 10/02/2009 12:00 AM

To: All Lexus Dealers

From: Lexus Customer Service

Lexus Consumer Safety Advisory**Potential Floor Mat Interference with Accelerator Pedal*********URGENT*******

Lexus greatly appreciates your patience during this activity. Enclosed is additional information about the Lexus Consumer Safety Advisory (Consumer Safety Advisory), to add to our communication of September 29th.

A Safety Campaign will be launched soon with clear dealer instructions and an owner notification to visit their local Lexus dealership regarding the involved vehicles. Until the Safety Campaign is launched, Lexus recommends the following actions be taken by your staff:

Overall Dealership Operations

- Conduct a management meeting to familiarize all department heads with the Consumer Safety Advisory. Service, Loaner, Carwash, New Vehicle, New Car Preparation, Certified Pre-Owned (CPO)/Used Vehicle, Used Vehicle Reconditioning, Parts, and Body Shop operations should be familiar with the Consumer Safety Advisory and its contents.
- Each dealership should designate two management level associates with complementary schedules to become intimately familiar with all aspects of the Consumer Safety Advisory, Q&A as well as other materials we have provided. These two associates should coordinate all operations related to this activity.
- New, CPO/Used and Loaner Vehicle departments should coordinate with the Service Department to assure the drivers floor mat is semi-permanently installed. This should be conducted on all the following involved vehicles until the safety campaign has been launched.
 - 2007- 2010 ES
 - 2006 - 2010 IS

Customer Handling

- Please welcome concerned owners that visit your dealership and answer any questions they may have and utilize the previously provided Q&A to assure a consistent message is communicated.

- Assist any customer who asks to verify correct application and secure installation.
- Encourage owners to make sure the floor mats are compatible for their model and model year. Also, they need to be sure the floor mats are properly secured using the appropriate retention device (clips). Drivers floor mats should never be stacked. Consumers should never place any floor mat aftermarket or not -- on top of another drivers floor mat. Mats should also not be flipped over with the bottom-side up.
- Information on proper floor mat installation can be found on <http://www.lexus.com>.
- Owners with additional questions or concerns may also contact the Lexus Customer Assistance Center at 1 800 255-3987.

Service Department

- **Please coordinate with other dealership departments to semi-permanently install the drivers position floor mat in involved new, CPO, used, loaner and demo vehicles. Read and follow the attached technical instructions using specified materials which can be found at local hardware and office supply stores. This will assure the floor mats are not removable.** We recommend the Service Department designate associates to conduct this installation to assure that the involved vehicles are handled consistently.
- Owners' vehicles in for service should all be inspected for proper installation of the correct floor mats at the time of delivery (including after the car wash); document this on the Repair Order (RO).
- If an affected ES/IS owner expresses concern over the safety of their vehicle, recommend removal of the driver's side floor mat (place in the trunk) until they are contacted by Lexus regarding the forthcoming Safety Campaign. Document this action on the RO.
- If the owner prefers to have the floor mat semi-permanently installed, please follow the attached instructions and document this action on the RO.
- If your dealership provides "car washes on demand", proper floor mat installation should be ensured on every vehicle after this service, as well.

Sales Department

- Sales deliveries of involved ES and IS new, CPO or used vehicles should include semi-permanently installed drivers position floor mats that are designed specifically for the model. As many customers will be sensitive to the recent Consumer Safety Advisory, we recommend that they be informed that the drivers floor mat is semi-permanently installed and not removable. Lexus will notify customers when the Safety Campaign is initiated to return their vehicle for the remedy. The drivers floor mat will be rendered removable at that time.
- Owners may also choose to have the drivers floor mat placed in the trunk until the safety campaign remedy is available. Please advise the owner of this option.
- Document the condition of the driver's floor mat at vehicle delivery (e.g. "the correct driver's side floor mat is semi-permanently installed" or "removed driver's side floor mat") in a one-line RO.

- All dealership demos should also be checked regularly to confirm the use of correct and properly installed floor mats.

Parts Department

- Any Lexus All Weather Floor Mat (AWFM) in your inventory should be returned.
 - Dealers should prepare a PRR Claim listing the part numbers and quantities of each AWFM they are requesting to return. These claims should be submitted to the facing PDC using the normal method in Dealer Daily.
 - The return code for each part should be indicated as R-2, Manufacturing Defect.
 - When your dealership receives authorization from your facing PDC, please return the AWFMs immediately. The different AWFMs should be grouped by part number to assist the PDC in accurately accounting for the returned quantities.

If you are approached by the media, please direct them to Lexus Corporate Communications at 310-468-2552 or 310-468-4718. When you must speak to any media representatives, please reference the information we've provided previously on how to identify and properly install the correct floor mats, as well as your efforts to instruct owners about the importance of the proper installation of floor mats designed specifically for their vehicle.

Please direct any additional questions you may have to your Area representative so that we can continue to address your issues as we work through this experience together.

1. [Click here to see Semi-Perm - Installation-Application Instructions - Lexus.pdf](#)

2. [Click here to see Semi-Permanent Floor Mat Installation Label 10-01-09.pdf](#)

3. [Click here to see FINAL Lexus Carpet Floor Mat Application Information Chart.pdf](#)

Toyota and Lexus Carpeted / All-Weather Floor Mat Inspection, Application and Installation Instructions



Read these important Warnings BEFORE installing ANY type of Floor Mat.


A. General Floor Mat Warnings


- Only install floor mats designed specifically for that model and model year. Check for correct model name and part number on the packaging label to confirm vehicle application.
 - Never install a floor mat if you are uncertain of the model application.
 - Never install the floor mat upside down or turned over for any reason.
 - Only install the driver's floor mat in the driver's foot area.
- Always properly secure the driver's floor mat using the retaining hooks (clips) supplied in the bag with the floor mats (in the case of Lexus with the carpet floor mats). Follow the floor mat retention clip installation instruction supplied with the clips. If the mat is properly secured and you have confirmed vehicle applicability, it will not interfere with the accelerator pedal.
 - Never install the front driver's floor mat without all retaining hooks (clips) securing the mat firmly in place.
- The retaining hooks (clips) are designed to accommodate only one floor mat at a time.
 - Do not install another floor mat(s) on top of an existing driver's floor mat.
- After installation, always check the operation of the accelerator, brake and clutch (if applicable) pedals to assure the floor mat does not interfere with them.
- Carefully read the warning tag attached to the driver's floor mat regarding installation.

B. Floor Mat Inspection Instructions and Application Information

- Before placing a floor mat in a vehicle be familiar with the procedure outlined below.
 - Identify the correct driver's floor mat for the specific vehicle application.
 - Correctly install the driver's floor mat.
- Regularly verify the correct floor mat is securely installed in the appropriate model using the retaining hooks (clips).

NOTE: Use the Application Information Chart provided or the Accessory Parts Catalog to verify mat-to-vehicle application.






AWFM part number is located on the bottom of the back side of the mat.


(Sample of Application Information Chart)

Model	Year							Mat Description		Part Number	
	2003	2004	2005	2006	2007	2008	2009	2010	Color		Piece Set No.
Camry	x	x	x	x					Oak	4 pc set	PT206-03036-16
Camry (Front Mats)					x	x			Black	1 pc	PT908-0307F-02
Camry (Front Mats)					x	x			Brown	1 pc	PT908-0307F-14
Camry					x				Black	4 pc set	PT908-32070-02
Camry					x				Brown	4 pc set	PT908-32070-14



1. Make sure the AWFM is properly secured by the retaining hooks (clips). Confirm that the retaining hooks (clips) are secured into the grommet holes in the vehicle's floor (carpet).

Warning: Do not stack the floor mats in any vehicle. The retaining hooks (clips) are designed to accommodate only one floor mat at a time.



2. Check the following pedal operation (fully depress the pedal) to assure the floor mat does not interfere with it. Make sure the vehicle is turned off and in the "Park" position when testing:
 - Accelerator Pedal
 - Brake Pedal
 - Clutch Pedal (if equipped)
3. Verify the driver's floor mat involved in SSC 70F & 7LB has been removed from your vehicle

DO NOT USE THESE MATS

SSC 70F Part Number:

PT908-32070-02 (Blk)

PT908-32070-14 (Brn)

SSC 7LB Part Number:

PT908-33070-02 OR PT908-33071-02 (Blk)

PT908-33070-11 OR PT908-33071-11 (Gr)

PT908-33070-14 OR PT908-33071-14 (Brn)



Lexus Carpeted Floor Mats
(Sorted By Part Number)

Part Number	Model	Mat Description														
		70	90	95	100	105	110	115	120	125	130	Color	Piece Set No.			
PT208-33034-02	ES 300/330	X	X	X											Black	4 pc set
PT208-33034-12	ES 300/330	X	X	X											Charcoal	4 pc set
PT208-33034-20	ES 300/330	X	X	X											Ivory	4 pc set
PT208-33044-02	ES 300/330 (sport design)	X	X	X											Black	4 pc set
PT208-33044-12	ES 300/330 (sport design)	X	X	X											Light Charcoal	4 pc set
PT208-33054-11	ES 300/330	X	X	X											Gray	4 pc set
PT208-33054-30	ES 300/330	X	X	X											Ivory	4 pc set
PT208-33060-02	ES 300/330	X	X	X											Black	4 pc set
PT208-33060-30	ES 300/330	X	X	X											Gray	4 pc set
PT208-33070-10	ES 350														Cashmere	4 pc set
PT208-33070-11	ES 350														Light Gray	4 pc set
PT208-33090-15	ES 350														Brown	4 pc set
PT208-33090-15	ES 350														Charcoal	4 pc set
PT208-33090-25	ES 350														Black	4 pc set
PT208-48040-10	RX 330/350	X	X	X											Ivory	4 pc set
PT208-48040-11	RX 330/350	X	X	X											Black	4 pc set
PT208-48040-12	RX 330/350	X	X	X											Light Gray	4 pc set
PT208-48050-10	RX 400h	X	X	X											Black	4 pc set
PT208-48050-11	RX 400h	X	X	X											Ivory	4 pc set
PT208-48050-12	RX 400h	X	X	X											Light Gray	4 pc set
PT208-48060-11	RX 330														Black	4 pc set
PT208-48060-05	RX 350														Gray	4 pc set
PT208-48090-A0	RX 350														Ivory	4 pc set
PT208-48090-B0	RX 350														Light Gray	4 pc set
PT208-48092-05	RX 400h														Light Brown	4 pc set
PT208-48100-09	RX350/450h														Dark Brown	4 pc set
PT208-48100-22	RX350/450h														Black	4 pc set
PT208-LX098-01	LX 570														Gray	3 pc set
PT208-LX098-10	LX 570														Ivory	3 pc set
PT208-LX098-11	LX 570														Gray	3 pc set
PT208-LX098-12	LX 570														Ivory	3 pc set
PT208-LX098-14	LX 570														Dark Brown	3 pc set
PT208-LX098-07	LX570														Black	4 pc set
PT208-24010-02	SC 300/430	X	X	X											Black	4 pc set
PT208-24010-20	SC 300/430	X	X	X											Ecru	4 pc set
PT208-24010-34	SC 300/430	X	X	X											Black w/ Spindle	4 pc set
PT208-24030-02	SC 430	X	X	X											Black	4 pc set
PT208-24030-20	SC 430	X	X	X											Ecru	4 pc set
PT208-24030-34	SC 430	X	X	X											Black w/ Spindle	4 pc set
PT208-24044-20	SC 430	X	X	X											Ecru	4 pc set
PT208-24055-03	SC 430														Red	4 pc set
PT208-24060-03	SC 430														Carnel	4 pc set
PT208-24070-02	SC 430														Carnel	4 pc set
PT208-24080-14	SC 430														Black	4 pc set
PT208-24080-14	SC 430														Carnel	4 pc set
PT208-24090-12	SC 430														Black	4 pc set
PT208-24090-10	GX 470 w/ RSE	X													Ivory	4 pc set
PT208-30040-11	GS 300/400/430	X													Dark Gray	4 pc set
PT208-30041-01	GS 300/400/430	X													Black	4 pc set
PT208-30047-10	GX 470 w/ RSE	X													Ivory	4 pc set
PT208-30050-30	GS 350/460 2WD	X													Dark Gray	4 pc set
PT208-30050-30	GS 450H	X													Cashmere	4 pc set
PT208-30050-31	GS 350/460 2WD	X													Ash	4 pc set
PT208-30050-32	GS 450H	X													Ebony	4 pc set
PT208-30050-33	GS 450H	X													Ebony	4 pc set
PT208-30050-30	GS 350/460 AWD	X													Cashmere	4 pc set
PT208-30050-31	GS 350/460 AWD	X													Ash	4 pc set
PT208-30050-32	GS 350/460 AWD	X													Ebony	4 pc set
PT208-30060-02	GS 350/460 2WD	X													Black	4 pc set
PT208-30060-01	GS350 GS450H GS460 2WD	X													Brown	4 pc set
PT208-30061-32	GS350 GS450H GS460 2WD	X													Ebony w/ Red Logo	4 pc set
PT208-30061-33	GS350 GS450H GS460 2WD	X													Ebony w/ Red Logo	4 pc set
PT208-30060-01	GS350 AWD	X													Black	4 pc set
PT208-30060-02	GS350 AWD	X													Brown	4 pc set
PT208-30060-03	GS 300/400	X													Black	4 pc set
PT208-30060-08	GS 300/400	X													Charcoal	4 pc set
PT208-30071-01	LS 460	X													Ivory	4 pc set
PT208-30071-02	LS 460	X													Gray	4 pc set
PT208-30071-04	LS 460	X													Black	4 pc set
PT208-30071-05	LS 460	X													Brown	4 pc set
PT208-30073-01	LS 460	X													Gray	4 pc set
PT208-30073-04	LS 460	X													Black	4 pc set
PT208-30073-10	LS 460	X													Brown	4 pc set
PT208-30075-01	LS 460	X													Cashmere	4 pc set
PT208-30075-02	LS 460	X													Gray	4 pc set
PT208-30075-03	LS 460	X													Black	4 pc set
PT208-30075-04	LS 460	X													Cashmere	4 pc set
PT208-30075-10	LS 460	X													Gray	4 pc set
PT208-30075-01	LS 460/600h	X													Black	4 pc set
PT208-30075-02	LS 460/600h	X													Black	4 pc set



(Sorted By Part Number - Continued...)

Part Number	Model	Mat Description	Price Set No.	Color	95	96	97	98	99	00	01
PT208-50075-04	LS 450/600h		4 pc set	Brown	X	X	X	X	X	X	X
PT208-50075-10	LS 450/600h		4 pc set	Cashmere	X	X	X	X	X	X	X
PT208-50083-01	LS 450/600h		4 pc set	Gray	X	X	X	X	X	X	X
PT208-50083-02	LS 450/600h		4 pc set	Black	X	X	X	X	X	X	X
PT208-50083-04	LS 450/600h		4 pc set	Brown	X	X	X	X	X	X	X
PT208-50083-10	LS 450/600h		4 pc set	Cashmere	X	X	X	X	X	X	X
PT208-53004-02	IS 300 - Sport Cross		4 pc set	Black	X	X	X	X	X	X	X
PT208-53020-10	IS 300 - Sport Cross		4 pc set	Ivory	X	X	X	X	X	X	X
PT208-53033-10	IS 300 - Sport Cross		4 pc set	Black	X	X	X	X	X	X	X
PT208-53033-01	IS 300 - Sport Cross		4 pc set	Gray	X	X	X	X	X	X	X
PT208-53039-02	IS 300 - Sport Cross		4 pc set	Black	X	X	X	X	X	X	X
PT208-53048-01	IS 300 - Sport Cross		4 pc set	Black	X	X	X	X	X	X	X
PT208-53048-02	IS 300 - Sport Cross		4 pc set	Black	X	X	X	X	X	X	X
PT208-53050-30	IS 250/350 2WD		4 pc set	Cashmere	X	X	X	X	X	X	X
PT208-53052-02	IS 250/350 2WD		4 pc set	Black	X	X	X	X	X	X	X
PT208-53062-30	IS 250/350 4WD		4 pc set	Cashmere	X	X	X	X	X	X	X
PT208-53067-42	IS 250/350 4WD		4 pc set	Black	X	X	X	X	X	X	X
PT208-53067-30	IS 250/350 2WD		4 pc set	Cashmere	X	X	X	X	X	X	X
PT208-53068-02	IS 250/350 4WD		4 pc set	Black	X	X	X	X	X	X	X
PT208-53068-30	IS 250/350 4WD		4 pc set	Cashmere	X	X	X	X	X	X	X
PT208-53087-01	IS 250/350 2WD		4 pc set	Black	X	X	X	X	X	X	X
PT208-53087-02	IS - F (V6)		4 pc set	Black	X	X	X	X	X	X	X
PT208-53088-01	IS 250/350 4WD		4 pc set	Black	X	X	X	X	X	X	X
PT208-53089-06	IS 250/350 Convertible		4 pc set	Blue	X	X	X	X	X	X	X
PT208-53093-02	IS 250/350 F-Sport 2WD		4 pc set	Black	X	X	X	X	X	X	X
PT208-53098-02	IS 250/350 F-Sport 4WD		4 pc set	Black	X	X	X	X	X	X	X
PT208-60036-10	GX 470 w/o RSE		4 pc set	Black	X	X	X	X	X	X	X
PT208-60036-11	GX 470 w/o RSE		4 pc set	Dark Gray	X	X	X	X	X	X	X
PT208-60031-10	LX 470		3 pc set	Ivory	X	X	X	X	X	X	X
PT208-60031-11	LX 470		3 pc set	Charcoal	X	X	X	X	X	X	X
PT208-60037-10	GX 470 w/ RSE		4 pc set	Ivory	X	X	X	X	X	X	X
PT208-60037-11	GX 470 w/ RSE		4 pc set	Dark Gray	X	X	X	X	X	X	X
PT208-60071-12	LX 470		4 pc set	Black w/ Gray	X	X	X	X	X	X	X
PT208-60081-02	GX 470 - Sport (w/o RSE)		4 pc set	Black	X	X	X	X	X	X	X
PT208-75003-04	HS 250h		4 pc set	Black	X	X	X	X	X	X	X
PT208-75005-20	HS 250h		4 pc set	Dark Brown	X	X	X	X	X	X	X
PT208-75010-20	ES 350		4 pc set	Black	X	X	X	X	X	X	X
PT208-83070-10	ES 350		4 pc set	Black	X	X	X	X	X	X	X
PT208-83070-11	ES 350		4 pc set	Cashmere	X	X	X	X	X	X	X
PT208-83070-12	ES 350		4 pc set	Light Gray	X	X	X	X	X	X	X
PT208-83090-02	ES 350		4 pc set	Black	X	X	X	X	X	X	X
PT208-83090-10	ES 350		4 pc set	Cashmere	X	X	X	X	X	X	X
PT208-83090-11	ES 350		4 pc set	Light Gray	X	X	X	X	X	X	X
PT208-83090-12	ES 350		4 pc set	Brown	X	X	X	X	X	X	X
PT208-80030-02	ES 350		4 pc set	Charcoal	X	X	X	X	X	X	X
PT208-80030-10	ES 350		3 pc set	Black	X	X	X	X	X	X	X
PT208-80030-11	ES 350		3 pc set	Ivory	X	X	X	X	X	X	X
PT208-80030-12	ES 350		3 pc set	Gray	X	X	X	X	X	X	X
PT208-80030-02	ES 350		4 pc set	Black	X	X	X	X	X	X	X
PT208-80030-10	ES 430		4 pc set	Black	X	X	X	X	X	X	X
PT208-80030-11	ES 430		4 pc set	Ivory	X	X	X	X	X	X	X
PT208-80030-12	ES 430		4 pc set	Light Charcoal	X	X	X	X	X	X	X
PT208-50031-13	LS 450		4 pc set	Black	X	X	X	X	X	X	X
PT208-50031-14	LS 450		4 pc set	Black	X	X	X	X	X	X	X
PT208-50040-10	LS 430		4 pc set	Black	X	X	X	X	X	X	X
PT208-50040-11	LS 430		4 pc set	Cashmere	X	X	X	X	X	X	X
PT208-50040-12	LS 430		4 pc set	Ash	X	X	X	X	X	X	X
PT208-46100-01	RX 350/450h		4 pc set	Ivory	X	X	X	X	X	X	X
PT208-46100-12	RX 350/450h		4 pc set	Gray	X	X	X	X	X	X	X
PT208-46100-20	RX 350/450h		4 pc set	Black	X	X	X	X	X	X	X
PT208-50077-01	LS 450		4 pc set	Black	X	X	X	X	X	X	X
PT208-50077-02	LS 450		4 pc set	Black	X	X	X	X	X	X	X
PT208-50077-04	LS 450		4 pc set	Black	X	X	X	X	X	X	X
PT208-50077-10	LS 450		4 pc set	Brown	X	X	X	X	X	X	X
PT208-50077-02	LS 450		4 pc set	Cashmere	X	X	X	X	X	X	X
PT208-50077-01	LS 450		4 pc set	Gray	X	X	X	X	X	X	X
PT208-50077-02	LS 450		4 pc set	Black	X	X	X	X	X	X	X
PT208-50077-04	LS 450		4 pc set	Brown	X	X	X	X	X	X	X
PT208-50077-10	LS 450		4 pc set	Cashmere	X	X	X	X	X	X	X
PT208-50075-01	LS 450/600h		1 pc	Gray	X	X	X	X	X	X	X
PT208-50075-02	LS 450/600h		1 pc	Black	X	X	X	X	X	X	X
PT208-50075-04	LS 450/600h		1 pc	Brown	X	X	X	X	X	X	X
PT208-50075-10	LS 450/600h		1 pc	Cashmere	X	X	X	X	X	X	X
PT208-50085-01	LS 450/600h		4 pc set	Black	X	X	X	X	X	X	X
PT208-50085-02	LS 450/600h		4 pc set	Black	X	X	X	X	X	X	X
PT208-50085-04	LS 450/600h		4 pc set	Cashmere	X	X	X	X	X	X	X
PT208-50085-10	LS 450/600h		4 pc set	Dark Brown	X	X	X	X	X	X	X
PT208-75004-04	HS 250h		4 pc set	Black	X	X	X	X	X	X	X