



# HYUNDAI Technical Service Bulletin

Group	CAMPAIGN
Number	06-01-010
Date	OCTOBER, 2006
Model	2007 ENTOURAGE

Subject  
**STOP LAMP SWITCH WIRING  
 SERVICE CAMPAIGN 078**

<b>CIRCULATE TO:</b>	<input type="checkbox"/> GENERAL MANAGER	<input checked="" type="checkbox"/> PARTS MANAGER	<input checked="" type="checkbox"/> TECHNICIAN
<input checked="" type="checkbox"/> SERVICE ADVISOR	<input checked="" type="checkbox"/> SERVICE MANAGER	<input checked="" type="checkbox"/> WARRANTY MGR	<input type="checkbox"/> SALES MANAGER

**IMPORTANT: DEALERS MUST PERFORM THIS CAMPAIGN ON ALL AFFECTED VEHICLES PRIOR TO CUSTOMER RETAIL DELIVERY AND WHENEVER AN AFFECTED VEHICLE IS IN THE SHOP FOR ANY MAINTENANCE OR REPAIR.**

**IMPORTANT: WHEN A VEHICLE ARRIVES AT THE SERVICE DEPARTMENT, ACCESS HYUNDAI MOTOR AMERICA'S "WARRANTY VEHICLE INFORMATION" SCREEN VIA DCS ON-LINE TO IDENTIFY OPEN CAMPAIGNS.**

**DESCRIPTION:**

Some 2007 MY Entourage limited vehicles with the Power Adjustable Foot Pedal feature may have interference between the stop lamp switch wiring and the steering column universal joint.

This bulletin describes the procedure to reroute the stop lamp switch wiring away from the steering column universal joint.

**VEHICLES AFFECTED:**


- Model: 2007 Entourage limited vehicles equipped with Power Adjustable Foot Pedal.
- Affected production date range: Start of production through May 17, 2006.

**PARTS REQUIRED:**

Two Wire Ties approximately 20 cm (~8 inches) long.

**SERVICE PROCEDURE:**


1. Move Power Adjustable Foot Pedal all the way down.



2. Slide the driver's seat all the way back.



3. Locate the stop lamp switch wiring as shown in photo.





# HYUNDAI Technical Service Bulletin

Group

CAMPAIGN


Number

06-01-010

4. Tie the stop lamp switch wiring and the front wiring harness with a plastic tie wrap as shown in the photo. This procedure will pull the stop lamp switch wiring to the arrow direction to create a gap between the wiring and the steering column shaft.



5. Tie wrap the stop lamp switch wiring to the steering column shaft guide bar. Verify that the clearance between the stop lamp switch wiring and the steering column shaft is 26 mm (~1 inch) or more.
6. Cut off the excess plastic tie wrap. Be careful not to damage the vehicle's wiring.



## CAMPAIGN CLAIM INFORMATION:

OP CODE	OPERATION	OP TIME
60B021A1	Stop Lamp Switch Wire Adjustment	0.2 M/H

**NOTE: Submit claim using the Campaign Claim Screen.**