

## Safety Recall # 17V392

### Repair Procedure

#### Materials Supplied:

12 - #5 X ½" Robertson flat head screws

12 - Plastic mirror retainer clips with rubber bumpers

1 – 3/32" drill bit

1 - #1 Robertson screwdriver bit

- 1) With the closet door in the open position, measure 2" in from the mirror edge on all four corners (Top right, top left, lower right and lower left). Place a mark on the door frame next to the mirror at the 2" locations.



- 2) Measure down from the top of the mirror 16 ½" on each side and make a mark on the door frame.



- 3) At the marks made in step 1 & 2 measure ¼" onto the door frame and make a cross mark.



- 4) Using a 3/32" bit, drill a pilot hole 3/8" deep into the door frame at the cross marks made in step 1, 2 & 3. Be sure to go no more than 3/8" deep into the frame. As a precaution mask the drill bit at the 3/8" mark or use a bit stop set to the 3/8" mark.



- 5) Insert the #5 X 1/2" screws through the mirror retainer clips. Screw the retainer clips into the door using the pilot holes in step 4. Tighten the screw until the retainer clip can no longer be turned. The retainer clip should be at 90 degrees to the door frame. There should be six retainer clips per mirror.



Time for this repair: 1 hour