## **Tech Tip** L-TT-0093-12

| Engine Misfire Du<br>P030# and/or Inter   | -               |   | Market<br>USA |
|---|-----------------|---|---------------|
| Service Category<br>Vehicle Interior  |                 | <sup>Section</sup><br>Meter/Gauge/Display |               |
| Applicability<br>IS250; GS300   |                 |   |               |
|   |                 |   |               |
| APPLICABLE VEHICLES   | _               |   |               |
| 2006-2010<br>2010   | IS250<br>IS250C | 2006                                      | GS300         |
| 2010  | 132300          |   |               |
| CONDITION   |                 |   |               |
| <ul> <li>Some IS250 and GS300 vehicles may exhibit one or more of the following conditions:</li> <li>MIL "ON" DTC P0300, P0301, P0302, P0303, P0304, P0305, and/or P0306</li> <li>Intermittently runs rough after coming to a stop with the engine at operating temperature</li> <li>Intermittently runs rough with engine misfires present after a cold soak startup</li> </ul> <b>NOTE:</b> The recommendations in this document apply to an <u>intermittent</u> misfire concern. If a vehicle exhibits a steady misfire, the root cause is not related to the referenced service bulletins and the repair manual should be referenced for diagnosis. |                 |   |               |
|   |                 |   |               |
| RECOMMENDATIONS   |                 |   |               |
| <ul> <li>Confirm and duplicate the condition by performing the following:</li> <li>1. Prior to starting the vehicle, start recording an Engine "All Data" snapshot on the Techstream</li> <li>2. If the engine is cold, start and allow the vehicle to reach operating temperature while monitoring for misfire activity</li> </ul>   |                 |   |               |
| <ul> <li>3. Once the engine is at operating temperature per the "Coolant Temp" data parameter, repeat the following steps: <ul> <li>Increase engine speed to 4000 RPM and hold for 30 seconds</li> <li>After 30 seconds, momentarily rev the engine above 4000 RPM and allow the engine to return to idle</li> <li>Monitor the data list for misfire activity once the engine returns to idle</li> <li>Perform steps a) through c) up to 10 cycles maximum or until a multiple misfire count</li> </ul> </li> </ul>   |                 |   |               |
| event is duplicated<br>4. Create a TA case and attach the Techstream file with any relevant data<br>5. Contact the TAS hotline for further assistance prior to starting any repairs   |                 |   |               |
| LINK REFERENCES   |                 |   |               |
| <ul> <li><u>L-SB-0124-12: '06-'10 IS 250/250C: MIL "ON" DTC P030#, Intermittently Runs Rough, and/or Engine Oil Consumption</u></li> <li><u>L-SB-0125-12: '06 GS 300: MIL "ON" DTC P030#, Intermittently Runs Rough, and/or Engine Oil Consumption</u></li> </ul>   |                 |   |               |
| Tech Tip       09/09/2014       Rev2       © 2012, Lexus, a Division of Toyota Motor Sales, USA       Page 1 of 1         Ver. 2.0 01/01/2012 L   |                 |   |               |