

Tire Positioning Before New Vehicle Delivery

Service

Category General

Section Pre-Delivery Service Market USA



Applicability

MODEL(S)	ADDITIONAL INFORMATION	
CT200H, ES300H,		
ES350, GS350,		
GS450H, GX460,		
IS250, IS250C, IS350	,	
IS350C, LS460,		
LS600H, LX570,		
NX200T, NX300H,		
RC F, RC350, RX350	,	
RX450H		
	CT200H, ES300H, ES350, GS350, GS450H, GX460, IS250, IS250C, IS350 IS350C, LS460, LS600H, LX570, NX200T, NX300H, RC F, RC350, RX350	CT200H, ES300H, ES350, GS350, GS450H, GX460, IS250, IS250C, IS350, IS350C, LS460, LS600H, LX570, NX200T, NX300H, RC F, RC350, RX350,

REVISION NOTICE

November 6, 2014 Rev1:

 Applicability has been updated to include 2015 model year NX 200t, NX 300h, RC 350, and RC F vehicles.

Any previous printed versions of this bulletin should be discarded.

Introduction

During the manufacturing process, tires are mounted on the vehicle as matched sets to help reduce conditions such as pulling or drifting. If the wheels are replaced or refinished before vehicle delivery, it is important that the tires remain on the vehicle in the same location and in the same direction of rotation.

Please refer to the following procedure to ensure that the original tires stay in the same location on the vehicle.

Warranty Information

OP CODE	DESCRIPTION	TIME	OFP	T1	T2
N/A	Not Applicable to Warranty	1	_	-	-



Tire Positioning Before New Vehicle Delivery

Installation Procedure

1. Mark the tire installation position on the inward facing tire sidewall.

Rev1

- Example: Front Right = FR, Front Left = FL, Rear Right = RR, Rear Left = RL
- 2. Install the original tires on the new or refinished wheels with the marked side facing inwards.
- 3. Balance tire/wheel assemblies on the vehicle in the marked positions.
- 4. Place the tire/wheel assemblies on the vehicle in the marked positions.

NOTE

Torque the wheel nuts to the proper torque value in sequence.