



SERVICE BULLETIN

Classification: EC14-011	Reference: NTB14-109	Date: November 25, 2014
-----------------------------	-------------------------	----------------------------

PERMANENT DTC (P-DTC) INFORMATION

APPLIED VEHICLES: 2010 and newer – see Applied Vehicles chart on page 4.

SERVICE INFORMATION

Starting with 2010 Model Year, Nissan vehicles have been gradually incorporating a new type of DTC known as “Permanent DTC or P-DTC”. Please refer to the P-DTC Applied Vehicles list on page 4.

- If a vehicle is equipped with P-DTCs, all emission related DTCs will also set a P-DTC if the MIL is turned ON.
- A listing of which DTCs that will also set a P-DTC is found in the DTC Index in the EC-Engine Control section of the Electronic Service Manual (ESM).

If a DTC repair is performed and the DTC erased, a vehicle may fail an Emission Inspection and Maintenance test if the P-DTC is not also erased.

P-DTC's can be erased by following the correct driving pattern:

- Use CONSULT-III plus (C-III plus) to confirm a P-DTC and determine the correct driving pattern to erase it (see page 2).
- Refer to the ESM, section EC-Engine Control, for driving pattern information. Look under How to Erase a Permanent DTC and Diagnosis Description.
- Details for driving pattern B and D are included in this bulletin, starting on page 2.

NOTE: In most cases, if repairs are complete, P-DTCs will erase with the customer driving their vehicle in their normal daily use.

Nissan Bulletins are intended for use by qualified technicians, not 'do-it-yourselfers'. Qualified technicians are properly trained individuals who have the equipment, tools, safety instruction, and know-how to do a job properly and safely. NOTE: If you believe that a described condition may apply to a particular vehicle, DO NOT assume that it does. See your Nissan dealer to determine if this applies to your vehicle.

Example of Permanent DTC (P-DTC)

Permanent DTC Status

Turn ignition switch to the OFF position, wait for at least 10 seconds, and then turn ignition switch to the ON position. Repeat procedure to update status.
For driving pattern B and D, refer to the Service Manual.

System	Permanent DTC	Driving Pattern B	Driving Pattern D
ENGINE	P0196 EOT SENSOR	INCMP	INCMP

Permanent DTC

Driving patterns required to erase the Permanent DTC

System	Monitor Item	Value	Unit
ENGINE	ENG SPEED	0	rpm
ENGINE	B/FUEL SCHDL	7.7	ms

Driving Patterns B and D for Erasing P-DTCs

NOTE:

- The DTC Index in the ESM, for vehicles equipped with P-DTCs, includes a Group classification of “A” or “B” for DTCs that also set P-DTCs. P-DTC with a Group classification of B requires completion of driving pattern B and D to erase the P-DTC. In most cases, completion of driving pattern B will also complete driving pattern D.
- With C-III plus, use PERMANENT DTC WORK SUPPORT while performing driving patterns.
- Make sure to obey all traffic laws and speed limits when performing driving patterns.

Continued on the next page

Driving Pattern B

Driving pattern B means a trip satisfying the following conditions:

- Engine speed reaches 400 rpm or more.
- Engine coolant temperature reaches 70°C (158°F) or more.
- Vehicle speed of 70 – 120 km/h (44 – 75 MPH) is maintained for 60 seconds or more.
- Vehicle speed of 30 – 60 km/h (19 – 37 MPH) is maintained for 10 seconds or more.
- Vehicle speed of 4 km/h (2 MPH) or less with idling for 12 seconds or more.
- Vehicle speed of 10 km/h (7 MPH) or more for 10 minutes or more in total.
- 22 minutes or more elapsed time after engine start.

NOTE:

- Drive the vehicle at steady speeds when a “maintained” speed is required.
- When the same malfunction (DTC) is detected regardless of driving conditions, driving pattern B must be restarted.

Driving Pattern D

Driving pattern D means a trip satisfying the following conditions:

- Vehicle speed of 40 km/h (25 MPH) or more for 300 seconds or more.
- Maintain continuous idle speed for 30 seconds or more.
- 600 seconds or more elapsed time after engine start.

NOTE: When the same malfunction (DTC) is detected regardless of driving conditions, driving pattern D must be restarted.

Applied Vehicles (vehicles that use P-DTCs):

- All 2015 models, except LEAF, have P-DTCs.
- 2010 to 2014 as follows:

MODEL	ENGINE	2010	2011	2012	2013	2014
CUBE	MR18DE	Yes	Yes	Yes	Yes	Yes
Versa Sedan	MR18DE / HR16DE	Yes	Yes	Yes	Yes	Yes
Versa Hatchback	MR18DE	Yes	Yes	Yes	N/A	N/A
Versa Note	HR16DE	N/A	N/A	N/A	N/A	Yes
JUKE / JUKE NISMO / JUKE NISMO RS	MR16DDT	N/A	Yes	Yes	Yes	Yes
SENTRA	MR20DE / MR18DE	Yes	Yes	Yes	Yes	Yes
SENTRA SE-R	QR25DE	Yes	Yes	Yes	N/A	N/A
ALTIMA	QR25DE	Yes	Yes	Yes	Yes	Yes
ALTIMA	VQ35DE	Yes	Yes	Yes	Yes	Yes
ALTIMA COUPE	QR25DE	Yes	Yes	Yes	Yes	N/A
ALTIMA COUPE	VQ35DE	Yes	Yes	Yes	N/A	N/A
ALTIMA Hybrid	QR25DE Hybrid	No	No	N/A	N/A	N/A
MAXIMA	VQ35DE	Yes	Yes	Yes	Yes	Yes
370Z / 370Z Roadster / 370Z Nismo	VQ37VHR	Yes	Yes	Yes	Yes	Yes
GT-R	VQ38DETT	No	No	Yes	Yes	Yes
NV200 Cargo Van	MR20DE	N/A	N/A	N/A	Yes	Yes
NV200 New York City Taxi Version	MR20DE	N/A	N/A	N/A	Yes	Yes
ROGUE	QR25DE	Yes	Yes	Yes	Yes	Yes
ROGUE SELECT	QR25DE	N/A	N/A	N/A	N/A	Yes
QUEST	VQ35DE	N/A	Yes	Yes	Yes	Yes
MURANO	VQ35DE	Yes	Yes	Yes	Yes	Yes
MURANO Cross Cabriolet	VQ35DE	N/A	Yes	Yes	Yes	Yes
PATHFINDER	VQ40DE / VQ35DE	Yes	Yes	Yes	Yes	Yes
PATHFINDER	VK56DE	No	No	No	N/A	N/A
PATHFINDER Hybrid	QR25DER Hybrid	N/A	N/A	N/A	N/A	Yes
FRONTIER	QR25DE	No	No	No	Yes	Yes
FRONTIER	VQ40DE	Yes	Yes	Yes	Yes	Yes
XTERRA	VQ40DE	Yes	Yes	Yes	Yes	Yes
TITAN	VK56DE / VK56DE FFV	No	No	No	No	Yes
ARMADA	VK56DE / VK56DE FFV	No	No	No	No	Yes
NV1500/ NV2500 Cargo Van NV3500 Passenger Van	VQ40DE	N/A	N/A	Yes	Yes	Yes
NV2500 / NV3500 Cargo Van NV3500 Passenger Van	VK56DE	N/A	N/A	No	No	Yes
LEAF		No	No	No	No	No