

SB-10058864-7073**1 5 07-15****Service Information Bulletin**

SUBJECT	DATE
SPN 1590(CPC)(GHG14) and SPN 1590 (CPC)(EPA07;EPA10)	May 2015

Additions, Revisions, or Updates

Publication Number / Title	Platform	Section Title	Change
DDC-SVC-MAN-0084 DDC-SVC-MAN-S084	DD Platform	SPN 1590/ FMI 9- GHG14	The diagnostic procedures have been separated and new information has been added to GHG14 for the Detroit Assurance option.
		SPN 1590/ FMI 9- EPA07 - EPA10	

DiagnosticLink users: Please update the troubleshooting guides in DiagnosticLink with this newest version. To update the tool troubleshooting guide, open DiagnosticLink and from the Help - Troubleshooting Guides menu, select the appropriate troubleshooting manual, then click Update.



13400 Outer Drive, West, Detroit, Michigan 48239-4001
 Telephone: 313-592-5000
www.demanddetroit.com

2 SPN 1590/FMI 9 - GHG14

Adaptive Cruise Control Message Not Received

Table 1.

SPN 1590/FMI 9	
Description	Adaptive Cruise Control Message Not Received
Monitored Parameter	PGR034 adaptive cruise control enable
Typical Enabling Conditions	Key is on, CPC is online, CAN network is online, Adaptive Cruise Control System is equipped, 10 seconds after the engine has been cranked.
Monitor Sequence	None
Execution Frequency	Continuous when enabling conditions met
Typical Duration	2 seconds
Dash Lamps	None
Engine Reaction	None
Verification	Engine running for 1 minute

1. Connect DiagnosticLink[®].
2. Turn the ignition ON (key ON, engine OFF).
3. Verify that the vehicle is equipped with an adaptive cruise system. Is the vehicle equipped with adaptive cruise?
 - a. Yes; Go to step 5.
 - b. No; Go to step 4.
4. Verify that the "adaptive cruise control enable" parameter PGR043 is disabled; refer to the Application and Installation (A&I) manual. Is parameter PGR043 disabled?
 - a. Yes; replace the Common Powertrain Controller (CPC). Verify repair.
 - b. No; change the "adaptive cruise control enable" parameter PGR043 to disabled. Verify repair.
5. For vehicles equipped with Detroit Assurance, parameter PGR043 should be set to 0 (zero) disable. Is parameter PGR043 set to disable?
 - a. Yes; replace the CPC. Verify repair.
 - b. No; change parameter PGR043 to disable. Verify repair.


Parameters Engine: DDEC13-DD15 Transmission: DT12-DT12 DA DiagnosticLink

Parameter	Value	Units	M...	Maxi...	Description
PGR030 Engine Configuration					
PGR031 Vehicle Parameters III					
PGR032 Coolant Level Sensor					
PGR035 Digital Outputs					
PGR037 Fault Management					
PGR038 Vehicle Speed Governor					
PGR039 Vehicle Mass					
PGR040 Anti Tampering					
PGR041 Component ID					
PGR042 Dss					
PGR043 Acc					
ACC accept Resume Time	30	s	0	255	(043/001) Time span after reception of CCVS Pause command from Wabco Ac...
Adaptive Cruise Control Enable	disable				(043/002) vehicle equipped with ACC system
Fast ACC Gov Engine brake mode	none				(043/003) New ACC Gov Engine brake mode
Manual Cruise Enable	enable				(043/004) Manual Cruise Enable(via double toggle) after Acc system failure
ACC1 Tx Mode Selection	disable				(043/005) CPC to send ACC1 message to support legacy products
PGR044 SynGov					
PGR046 Diesel Particulate Filter					
PGR047 Ag					
PGR048 Ptconf					
PGR049 Reserved					
PGR050 HDMS Fan					
PGR051 Idle Volume					
PGR053 Soft Cruise					

Parameters were successfully read from the device. Send... Information

d500216

Figure 1. GHG14 Adaptive Cruise Control



d500215

Figure 2. GHG14 Adaptive Cruise Control Options


3 SPN 1590/FMI 9 - EPA07 - EPA10

Adaptive Cruise Control Message Not Received

Table 2.


SPN 1590/FMI 9	
Description	Adaptive Cruise Control Message Not Received
Monitored Parameter	PGR034 adaptive cruise control enable
Typical Enabling Conditions	Key is on, CPC is online, CAN network is online, Adaptive Cruise Control System is equipped, 10 seconds after the engine has been cranked.
Monitor Sequence	None
Execution Frequency	Continuous when enabling conditions met
Typical Duration	2 seconds
Dash Lamps	None
Engine Reaction	None
Verification	Engine running for 1 minute

1. Connect DiagnosticLink[®] Standard.
2. Turn the ignition ON (key ON, engine OFF).
3. Verify that the vehicle is equipped with an adaptive cruise system. Is the vehicle equipped with adaptive cruise?
 - a. Yes; Go to step 5.
 - b. No; Go to step 4.
4. Verify that the "adaptive cruise control enable" parameter PGR043 is disabled; refer to the Application and Installation (A&I) manual. Is parameter PGR043 disabled?
 - a. Yes; replace the Common Powertrain Controller (CPC). Verify repair.
 - b. No; change the "adaptive cruise control enable" parameter PGR043 to disabled. Verify repair.
5. Verify that the "adaptive cruise control enable" parameter PGR043 is enabled; refer to the Application and Installation (A&I) manual. Is parameter PGR043 enabled with the correct Adaptive Cruise Control System?
 - a. Yes; refer to OEM literature to diagnose the concern. Verify repair.
 - b. No; change parameter PGR043 to enabled. Verify repair.



d500217

Figure 3. EPA10 Adaptive Cruise Control Enable



d500218

Figure 4. EPA10 Adaptive Cruise Control Enable Options