

Subject: Engineering Information – Malfunction Indicator Lamp Illuminated with One or More Glow Plug Control DTCs Set

Attention: Proceed with this EI ONLY if the customer has commented about this concern AND the PIE number is listed in the Global Warranty Management / Investigate History link (GWM/IVH). If the customer has not commented about this condition or the EI does not show in GWM/IVH, disregard the PI and proceed with diagnostics found in published service information. THIS IS NOT A RECALL — refer to the latest version of Service Bulletin 04-00-89-053 for more details on the use of Engineering Information bulletins.

Brand:	Model:	Model Year:		VIN:		Engine:	Transmission:
		from	to	from	to		
Chevrolet	Silverado	2017	2017			L5P	All
GMC	Sierra	2017	2017			L5P	All

Involved Region or Country	North America
Additional Options (RPO)	Equipped with ENGINE-DIESEL, 8 CYL, 6.6L, DI, V8, TURBO, DURAMAX (RPO L5P)

<p>Condition</p>	<p>Important: If the customer did not bring their vehicle in for this concern, DO NOT proceed with this EI.</p> <p>Some customers may comment on a malfunction indicator lamp illuminated.</p> <p>During diagnosis a technician may find one or more of the following DTCs set:</p> <ul style="list-style-type: none"> • P06C5 • P06C6 • P06C7 • P06C8 • P06C9 • P06CA • P06CB • P06CC • P066A • P066C • P066E • P067A • P067C • P067E • P068C • P068E • P0671 • P0672 • P0673 • P0674 • P0675 • P0676 • P0677 • P0678 • P1337 • P1338 • P133A • P133B • P133C • P133D • P133E • P133F
<p>Cause</p>	<p>GM Engineering is attempting to determine the root cause of the above condition. Engineering has a need to gather information on vehicles PRIOR to repair that may exhibit this condition. As a result, this information will be used to "root cause" the customer's concern and develop/validate a field fix.</p>

Correction

If you encounter a vehicle with the above concern, follow SI procedures for any of the DTCs other than P06C5-C or P1337-F.

If any of the DTCs listed in this section are set, clear the codes and relearn the glow plugs. Refer to *Glow Plug Learn* in SI.

After the glow plug learn procedure has been completed, let the vehicle sit a minimum of 4 hours before starting.

After 4 hours, start the vehicle and verify if any MIL and any DTCs are set.

Contact the engineer listed below to report findings and for further instructions.

Contact Information

Engineer Name	Phone Number
Curtis Tyson	(248) 639-8483

Please include the following information if leaving a message:

- Technician name
- Dealer name and phone number
- Complete VIN and repair order (R.O) number

On the repair order, document the date and time the call was placed (even if the engineer was not reached).

If engineering is unable to return the call within one hour, proceed with diagnosis and repair based on information found in SI.

Warranty Information

If engineer was contacted or required information was provided, use:

Labor Operation	Description	Labor Time
4081568*	Engineering Information – Malfunction Indicator Lamp Illuminated with One or More Glow Plug Control DTCs Set	0.5 hr

*This is a unique Labor Operation for Bulletin use only. It will not be published in the Labor Time Guide.