Service Alert

Mazda North American Operations Irvine, CA 92618-2922



Subject:

2019-2020 MAZDA3 SERVICE CAUTIONS FOR NEW AND REVISED FEATURES

Service Alert No.: SA-012/20

Last Issued: 02/04/2020

BULLETIN NOTES

This Service Alert supersedes the previously issued Service Alert(s) listed below: The changes are noted in Red.

Previous Service Alert(s):	Date(s) Issued:
SA-012/20	01/24/20 and 01/15/20
SA-010/19	09/16/19, 08/14/19, 08/06/19, 07/19/19, 07/12/19, 06/13/19, 06/07/19,05/09/19,05/02/19, 04/25/19,04/11/19, 03/29/19, 03/21/19, 03/15/19,03/08/19, 03/06/19, 03/05/19, 02/25/19

APPLICABLE MODEL(S)/VINS

2019-2020 Mazda3

DESCRIPTION

The 2019-2020 Mazda3 has new and revised features that are different from previous models, and may be difficult to understand. This Service Alert provides valuable information to support potential dealer and customer concerns.

Index

PDI fuse

Apple CarPlay™ / Android Auto™ Install Kit

Blind Spot Monitoring System (BSM)

Front Wiper Service Caution

i-ACTIVSENSE Switch

Traffic Sign Recognition (TSR) (2019 Mazda3)

Speed Limit Alert (2020 Mazda3)

MAZDA CONNECT Power Function

MAZDA CONNECT Center Display View

In-Vehicle Digital Owner's Manual

Page **1** of **34**

Navigation System
SIRIUSXM Data Service
Power Door Locks
Auxiliary Key
Transmitter Battery Saving Function
Keyless Entry Using Auxiliary Key
Rear Door Child Safety Locks Operation
Theft-Deterrent System
Link Seat & Climate Control Temperatures
Seat Warmer Will Not Turn ON After Previous Usage
Electric Parking Brake (EPB)
Tire Pressure Monitoring System (TPMS)
Condition Based Maintenance
M-MDS (MDARS)
Part Replacement

Item Service Information

Page **2** of **34**

- the left side of the steering wheel.
- 5. Go to SA-017/19 for details.

Page 3 of 34

15 A

CONSUMER NOTICE: The information and instructions in this bulletin are intended for use by skilled technicians. Mazda technicians utilize the proper tools equipment and take training to correctly and safely maintain Mazda vehicles. These instructions should not be performed by "do-it-yourselfers." Customers should not assume this bulletin applies to their vehicle or that their vehicle will develop the described concern. To determine if the information applies, customers should contact their nearest authorized Mazda dealership. Mazda North American Operations reserves the right to alter the specifications and contents of this bulletin without obligation or advance notice. All rights reserved. No part of this bulletin may be reproduced in any form or by any means, electronic or mechanical---including photocopying and recording and the use of any kind of information storage and retrieval system ---without permission in writing.

F8

F7

F6

F4

F3

F19

F18

F17

F16

F15

Apple CarPlay™ / Android Auto™ Install Kit

 The Mazda3 sedan (4 door base model) is not equipped with Apple CarPlay™ / Android Auto™.


Apple CarPlay™ / Android Auto™ Smartphone Screen Mirroring Kit accessory is not available for the Mazda3 sedan (4 door base model).

See SA-001/19 - APPLE CARPLAY™ / ANDROID AUTO™ FREQUENTLY ASKFD OUFSTIONS (FAO)

Blind Spot Monitoring (BSM) System

- 1. BSM system indicates vehicle on the opposite side.
- 2. i-ACTIVSENSE indicator ring will not turn green
- 3. Rear Cross Traffic Alert (RCTA) does not work
- 4. Rear side radar sensor aiming may fail
- 5. TPMS DTC(s) stored

This may be caused by BSM rear side radar sensor(s) installed facing the wrong direction.



Page 4 of 34


Front Wiper Service Caution

- 1. Wiper arm park position is located under the hood.
- 2. When servicing front wipers, front wiper service mode is required or damage to wiper arms may occur (see Service Information).
- 3. If wiper arms are replaced, M-MDS is needed for wiper arm adjustment (see Service Information)
- 4. DO NOT use wiper arms as markers when in dealer inventory.


See Owner's Manual -Maintenance and Care Replacing Windshield Wiper Blades

MGSS: WINDSHIELD WIPER ARM
AND BLADE ADJUSTMENT


Page **5** of **34**



Page **6** of **34**




Page **7** of **34**



Page 8 of 34

Service Alert No.: SA-012/20	Last Issued: 02/04/2020




Page 9 of 34

	Warning		
	System		
	(LDWS)		
2.	Blind Spot		
	Monitoring		
	(BSM)		
3.	Distance		
	Speed Alert		
	(DSA)		
4.	Rear Cross		
	Traffic Alert		
	(RCTA)		
5.	Lane-keep		
	Assist System		
	(LAS)		
6.	Smart Brake		
	Support (SBS)		
7.	Smart Brake		
	Support [Rear]		
_	(SBS-R)		
8.	Smart Brake		
	Support [Rear		
	Crossing] (SBS		
_	RC)		
	turn the system		
	ck to ON , press		
	e i-ACTIVSENSE		
SW	itch once.NOTE:		
1.	When the		
1.	ignition is		
	turned OFF -		
	ON, i-		
	ACTIVSENSE		
	switches to		
	ON.		
		OFF (Compalled Chahar)	
For	⁻ 2020 (built	OFF (Cancelled Status) :	
Jul	y 30, 2019) with	I-ACTIVSENSE OFF INDICATOR IS ILLUMINATED	
VIN		-ACTIVSENSE OFF INDICATOR IS ILLUIVIINATED	

Last Issued: 02/04/2020

Service Alert No.: SA-012/20

Page 10 of 34



Page **11** of **34**

NC	TE:				
1.	When the ignition is turned OFF - ON, i- ACTIVSENSE switches to ON.				
2.	If MRCC is activated, i-ACTIVSENSE switches to ON .				
3.	deactivated, i- ACTIVSENSE remains ON .				
4.	The i- ACTIVSENSE switch does not cancel SBS. SBS can be deactivated using infotainment system settings.				
	-				

Last Issued: 02/04/2020


Service Alert No.: SA-012/20

Page 12 of 34


Traffic Sign Recognition (TSR) * (2019 Mazda3 Only)

NOTE:

- 1. TSR function is only available with a dealer installed in-vehicle navigation system accessory.
- 2. TSR function requires Forward Sensing Camera (FSC) recognition or navigation SD card map data when the vehicle is driven.**
- 3. TSR function is not displayed in the Active Driving Display.
- 4. TSR function includes Speed Limit Alert and is only displayed in the instrument cluster.
- 5. TSR function is disabled when Apple CarPlay™ or Android Auto™ is connected.
- * Some models




MAZDA CONNECT
Speed Limit Alert OFF
(Default Setting)




See Owner's Manual - When Driving - i-ACTIVSENSE - i-ACTIVSENSE - Traffic Sign Recognition System (TSR)

MGSS: Traffic Sign Recognition (TSR)

Page 13 of 34



Page 14 of 34



MAZDA CONNECT Speed Limit Alert Customer Settings

- 1. Speed Limit Alert Settings
 - 1. OFF
 - 2. Visual
 - 3. Visual + Audible
- 2. Speed Limit Alert Threshold
 - 1. 0 mph
 - 2. +5 mph
 - 3. +10 mph
- ** SD Card maps may contain information about the speed limits of the roads. The navigation system is able to warn driver if they exceed

Page **15** of **34**


the current limit. This information may not be available in some areas or may not be fully correct for all roads on the map.

Speed Limit Alert* (2020 Mazda3 only)

NOTE:

- 1. Speed Limit Alert function is only available with a dealer installed in-vehicle navigation system accessory**.
- 2. Speed Limit Alert function is displayed in the Instrument Cluster and the Active Driving Display.
- 3. Speed Limit Alert function is disabled when Apple CarPlay™ or Android Auto™ is connected.

* Some models



See Owner's Manual - When Driving - i-ACTIVSENSE - i-**ACTIVSENSE - Excessive Speed** Warning

- 1. Active Driving Display
- 2. Instrument Cluster
- 3. Basic Display
- 4. i-ACTIVSENSE Display
- **Speed Limit Indication**

Page 16 of 34

MAZDA CONNECT Speed Limit Alert Customer Settings

- 1. Speed Limit Alert Settings
 - 1. OFF
 - 2. Visual
 - 3. Visual + Audible
- 2. Speed Limit Alert Threshold
 - 1. 0 mph
 - 2. +5 mph
 - 3. +10 mph

** SD Card maps may contain information about the speed limits of the roads. The navigation system is able to warn driver if they exceed the current limit. This information may not be available in some areas or may not be fully correct for all roads on the map.

MAZDA CONNECT New Power Off Function



1. Audio Mute - Short press the volume knob (Press again to cancel)

Power Off - Press and hold the volume knob (Press and hold again to Power ON)



See Owner's Manual -Interior Features - Mazda Connect

MGSS: ENTERTAINMENT SYSTEM

In-vehicle Owner's Manual installation

Page 17 of 34



Page **18** of **34**

In-Vehicle Digital Owner's Manual

The in-vehicle digital OM can be displayed on the center display while the vehicle is stopped. Customer can search descriptions and watch videos of vehicle features and functions by operating the commander switch.



NOTE:

- 1. The digital owner's manual must be installed during PDI. Due to printing deadlines and later updates to the digital manual, the content of the digital manual may differ from the printed manual.
- 2. USB memory flash drive FAT16 or FAT32 format is required for installation.
- The vehicle's infotainment system will only accept file names [contents.tar] and [contents.sig]. File names with additional suffixes will not be accepted.
- 4. The infotainment system may inadvertently be powered OFF if the diagnostic assist function buttons are not pressed correctly. Simply press and hold the volume knob to power back ON.

Page **19** of **34**

Navigation System

The 2019-2020 Mazda3 is not equipped with factory installed navigation system, however, it is available as a dealer installed accessory.

NOTE: Gen 6.5 Navi SD card with part number prefix BHP1 (2014-2018 Mazda3) installed in the Gen 7 2019-2020 Mazda3 will not function.

Gen 7

Gen 7

Gen 6.5

USA/CAN/MEX
BDGF 66 EZ1
Maps by HERE
Made in Japan

P/N prefix BDGF
Japan built vehicle

Interchangeable

Gen 7

Gen 6.5

USA/CAN/MEX
BDTS 66 EZ1
Maps by HERE
Made in Mexico

USA/CAN/MEX
BHP1 5 EZ1H
VPGMVF 155L100-IE
Mard by: HERE
Made in the USA

P/N prefix BDTS
Mexico built vehicle

P/N prefix BHP1

SIRIUSXM Data Service No Free Trial (Preferred Package and above)

- 1. Only available as a paid subscription.
- The 2019-2020 Mazda3 is not equipped with a factory installed navigation system, however, it is available as a dealer installed accessory.
- 3. SiriusXM Traffic Plus feature requires in-vehicle navigation SD card.

See Owner's Manual - Interior Features - Mazda Connect -Appendix

SA-007/19 - SIRIUSXM DATA SERVICES

Page **20** of **34**

Power Door Locks

Doors Lock With Keys In The Vehicle When Liftgate Lock Switch Is Pressed.

(Japan built) vehicles with VINs lower than JM1BP*****1142789 (produced before May 28, 2019)




DO NOT leave keys in the vehicle. The doors will lock with the keys in the vehicle when the liftgate lock switch is pressed and the liftgate is closed, but the liftgate will not lock in the above condition.

NOTE: This is currently under investigation.

Doors cannot be unlocked using the outside door handle touch sensor The door handle touch sensor system may not operate normally under the following conditions:

- 1. The front passenger (without key) grabs and holds the outside door handle before the driver (with key) touches the drivers outside door handle unlock touch sensor.
- 2. The driver touches the sensing area of the door lock touch sensor and the sensing area of the door release touch sensor at the same time.

See Owner's Manual -Before Driving - Doors and Locks



Page **21** of **34**

Service Alert No.: SA-012/20	Last Issued: 02/04/2020	

Page **22** of **34**


Last Issued: 02/04/2020

Service Alert No.: SA-012/20

Page **23** of **34**

Insert the auxiliary key.

Install the transmitter lower cover by inserting the tabs of the lower cover into the slots of the transmitter.





- 1. If one auxiliary key is lost, some key machines can trace cut a new replacement key.
- If both auxiliary keys are lost, key cutting machines do not recognize vehicle key code and will not cut new replacement keys. Replace the front door key cylinder set.

NOTE: If the front door key cylinder set is replaced, eMDCS system key code information will need to be changed. Contact Helpdesk by phone (949 727-6434) or email (HelpDesk@mazdausa.com) and provide:

- 1. VIN
- 2. Replacement part key code.

Transmitter Note:

Page **24** of **34**

Service Alert No.: SA-012/20	Last Issued: 02/04/2020



- 1. If one transmitter is lost, inform the customer to take cautions not to lose the 2nd transmitter.
- 2. If both transmitters are lost, the vehicle will be disabled. Use MDARS to program new transmitters.
- 3. Replacement battery type is CR2032 (3V, 225mAh), which is different then previous 6th generation transmitter battery type CR2025 (3V, 160mAh). If the wrong battery is installed, the transmitter might not work properly (malfunction).

Page **25** of **34**

Service Alert No.: SA-012/20	Last Issued: 02/04/2020

Transmitter Battery Saving Function (Key Fob)

The Mazda3 has a "power saving" function built into the keyless entry system where <u>some</u> key fob functions are disabled. This feature could accidentally be enabled and some concerns with the vehicle may be:

- 1. Engine does not start.
- 2. Engine does not start unless you hold the fob to the start/stop button.
- 3. Doors do not unlock using the door handle, but unlock with the remote.
- 4. Doors do not lock using the door handle, but lock with the remote.
- 5. Transmitter indicator light does not turn on/flash.

Turning on the power saving function

After you have turned on the power saving function according to the following procedure, the hazard warning lights and sound operate* one time.

- 1. Press the lock button on the transmitter 4 times within 3 seconds to turn on the operation indicator light.
- 2. Press the lock button continuously for 1.5 seconds or longer while the operation indicator light turns on (for 5 seconds).
- 3. Press any of the buttons on the transmitter to make sure that the operation indicator light does not turn on/flash.

Turning off the power saving function

After you have turned off the power saving function according to the following procedure, the hazard warning lights and sound operate* one time.

- 1. Press any of the buttons on the transmitter to make sure that the operation indicator light does not turn on/flash.
- 2. Press the lock button on the transmitter 4 times within 3 seconds to turn on the operation indicator light.
- 3. Press the lock button continuously for 1.5 seconds or


Page 26 of 34

ervice Alert No.: SA-012/20	.: SA-012/20		
	longer while the operation indicator light turns on (for 5 seconds).		
	*: with the advanced keyless function		
	Also see Owner's Manual - Before Driving - Keys - Power saving function		

Page 27 of 34

Keyless Entry Using Auxiliary Key

If the vehicle battery is discharged and/or the key battery is dead, vehicle entry is possible using the auxiliary key.



See Owner's Manual -Before Driving - Keys - Auxiliary Key

Then refer to Owner's Manual -Before Driving - Doors and Locks -Unlocking with Auxiliary Key

Rear Door Child Safety Locks Operation


The auxiliary key is required to enable (lock) and disable (unlock) the rear door child safety locks.



- 1. Auxiliary Key
 - 2. Lock
 - 3. Unlock

See Owner's Manual -Before Driving - Doors and Locks -Rear Door Child Safety Locks

Page **28** of **34**



Page 29 of 34

Service Alert No.: SA-012/20 Last Issued: 02/04/2020 Seat Warmer and Heated Steering Wheel Auto Mode The driver and front passenger's seater warmers* and the heated steering wheel* can be set to be automatically controlled (turned on and off) by the climate control system, depending on the set temperature. Auto Mode Go to MAZDA CONNECT home screen and select "Settings" 2. Select "Vehicle Settings". 3. Enable "Link Seat Climate Control Temperatures". 4. Press the climate control AUTO switch. See Owner's Manual -Essential Safety Equipment - Seat Link Seat Climate Control Temperatures Climate Control Auto Warmer/Heated Steering Wheel Switch Setting Seat Warmer / Heated Steering Wheel **Vehicle Settings** Rain-Sensing Wipers Turn Signals Link Seat & Climate Control Temperatures * if equipped Seat Warmer Will Not Turn ON After Previous Usage

JM1 (Japan built) vehicles produced after

December 17, 2018

3MZ (Mexico built) vehicles produced after March 19, 2019 After SA-059/19 repair.

- 1. DTC B1030:13 (SEAT WARMER UNIT (LH) CIRCUIT MALFUNCTION (HEATER SIDE)) is stored.
- 2. Front seat warmer functions after seat cool down and ignition OFF - ON cycle.


Contact Hotline for latest repair information.

Page **30** of **34**

Electric Parking Brake (EPB)

Parking Brake Auto Operation

When the ignition is switched OFF, the parking brake will be applied automatically. The EPB indicator light in the instrument cluster and the EPB switch indicator light turn ON.



Canceling the Parking Brake Auto Operation

Parking brake auto operation can be canceled using the procedure in the Owner's Manual.

NOTE: When the ignition is cycled back ON, the parking brake auto operation is restored.

Parking Brake Automatic Release

If the accelerator pedal is depressed with the parking brake applied and all of the following conditions are met, the parking brake is automatically release. When the parking brake is released, the EPB indicator light in the instrument cluster and the EPB switch indicator light turn off.

A/T	M/T	
Engine is running		
Driver's door is closed		
Driver's seat belt is fastened		
Selector lever is in the D, M, or R position	Shift lever is in a position othen neutral	
position	Clutch pedal is depressed half	

See Owner's Manual - When Driving - Brake - EPB Auto operation

Page **31** of **34**

Service Alert No.: SA-012/20	Last Issued: 02/04/2020	

Page **32** of **34**

Tire Pressure Monitoring System (TPMS) Change

The TPMS system uses a new rubber type direct TPMS.

NOTE: The new rubber type is not reusable. If the TPMS sensor is removed from the wheel, it must be replaced.



New Rubber Type Old Metal Type

MGSS: TIRE PRESSURE MONITORING SYSTEM (TPMS)

Condition Based Maintenance (Except Canada)

The vehicle calculates the maintenance (oil change) timing.

1. This function cannot be turned OFF.

- 2. Distance until the oil change is available in MAZDA CONNECT.
- 3. Reset is required after every oil change.

MGSS: MAINTENANCE MONITOR OPERATION PROCEDURE

New M-MDS (MDARS)

A new M-MDS diagnostic tester (MDARS) for 7th generation vehicles (starting with the 2019 Mazda3) is used.

- 1. Performs more maintenance service functions
- 2. Performs more complicated vehicle electrical system diagnostic
- 3. Reprograms more ECU's



MGSS: BASIC KNOWLEDGE

Page **33** of **34**

I	
Parts Replacement When replacing vehicle parts such as ECU's, motors, seatsetc, always refer to MGSS. Some new components may not operate if MGSS new part replacement procedure is not performed.	

Last Issued: 02/04/2020

Service Alert No.: SA-012/20

Page **34** of **34**