

### Diagnostic Equipment Standards

---

Vehicle Type: **All Porsche Models**

Subject: **Porsche Center Standards for Diagnostic Testers (PT4G) and associated Equipment**

Information: As previously communicated on PPN, via the AfterSales Newsletter, and Field Communication - Porsche AfterSales Technical Support, Porsche Diagnostic Tester Support, and Porsche Special Tools & Equipment has identified the need for a new standard pertaining to diagnostic equipment. With the complexity of the modern vehicles and the time involved in programing, more diagnostic testers are needed than we have used in the past. Having multiple diagnostic testers allows the Technician to continue to work while the tester is programing a vehicle. This reduces downtime of the Technician waiting for a tester. PCNA has made the decision to use working bay count to determine tester count. The number of Technicians in the Porsche Center is no longer the basis for calculating diagnostic tester count.

**With the launch of the PT4G, PCNA has set the diagnostic equipment standard and minimum requirement at: One PT4G, VCI, and Battery Charger (VAS5908) per Working Bay in the Porsche Center Workshop.**

A "Working Bay" is defined as:

Any stall with a vehicle lift installed

Any stall where a car is parked or located while being serviced (also know as a "flat stall")

Any stall where programing or campaigns are completed

Non-Working Bays are defined as followed:

Alignment rack

Wheel and tire changing and balancing machine area

Car wash bay or car wash machine

Dedicated Detail bay

Service drive and service write-up area

Outdoor parking and storage

Dedicated parking space where no service work or programing is completed

To request Working Bay count corrections:

Open a Tester Support PRMS ticket and state your requested Working Bay count adjustment. Attach a photo of the complete service department in one picture or, the building plans and drawings.

PCNA will provide documentation to be completed and returned. A request does not guarantee a change.

\*Technician count is no longer a factor when determining diagnostic tester and equipment requirements.\*

IMPORTANT NOTE:

All Diagnostic Equipment is MRT (Minimum Required Tools) as described in the Porsche Dealership agreement.

### Diagnostic Equipment Standards



### PT4G - PIWIS Tester 4th Generation

**P90999**



Model lines	All Porsche
Use	Vehicle Diagnostic Tester
Workshop Manual	General Diagnostic
Order Number	V04014999J 004
Supplier	PCNA via PRMS Only
Availability	Open a Tester Support PRMS to place an order
Location	One per working bay
Note	MRT Standard: One PT4G per Working Bay



### VCI - Vehicle Communication Interface

**VCI**



Model lines	Taycan
Use	Vehicle Communication Interface for PT4G
Workshop Manual	General Diagnostic
Order Number	V04014999F 204
Supplier	PCNA via PRMS Only
Availability	Open a Tester Support PRMS to place an order
Location	One per working bay
Note	MRT Standard: One VCI per Working Bay

### Diagnostic Equipment Standards



### Test Equipment / MEI

<b>MEI - KIT</b>	★
Model lines	Taycan
Use	Measuring Equipment
Workshop Manual	General Diagnostic
Order Number	00072199000420
Supplier	PCNA via PRMS Only
Availability	Open a Tester Support PRMS to place an order
Location	In Shop
Note	MRT Standard: One MEI per Porsche Center Workshop



### Battery Charger

<b>VAS5908</b>	★
Model lines	All
Use	Charge and maintain battery voltage
Workshop Manual	9X00IN
Order Number	VAS5908KIT
Supplier	SBS - Porsche.Snapon.com
Availability	Orderable
Location	One per working bay
Note	MRT Standard: One VAS5908 per Working Bay

### Diagnostic Equipment Standards

#### General

#### Information: **Ordering Process:**

Tools identified with a prefix of VAS, VAG and "T":

Place orders via [porsche.snapon.com](https://porsche.snapon.com).

Tools with a prefix of 000 721, 918 721, PNA or "P"

Place orders via POLARIS (PPL).

Diagnostic Equipment:

Open a PRMS ticket. Technical Support >> [Tester Support](#)

#### **Special Tool Support:**

For questions related to VAS, VAG, and "T" tools:

contact SBS customer care at 1-855-895-2013 or [PorscheTEP@SnapOn.com](mailto:PorscheTEP@SnapOn.com).



For Polaris numbers 000.721, 918.721, PNA and "P" tools:

Open a PRMS ticket. Technical Support >> [Special Tools](#)

Diagnostic Equipment:

Open a PRMS ticket. Technical Support >> [Tester Support](#)

#### **Workshop Equipment Classification**

- ★ Servicing and maintenance
- ★★ Replacement of units and assemblies
- ★★★ Disassembly of units and assemblies
- ★★★★ Rental
-  Body & Paint
-  High-voltage