

Mack Chassis - Door Adjustment - Model TE

Published 28 June 2024

Valid For



Mack - TE - All Model Years

TerraPro Door Adjustment Procedure



1. Perform a paper pull test in all door corners to determine proper sealing as well as to identify any obstructions. Note or repair any screws, trim not properly installed, or door alignment not allowing it to fit inside the door aperture.
2. Adjust door gap to provided clearances:
 1. Loosen door hinge
 2. Manipulate to desired position to obtain good door sealing
 3. Add or remove shims to achieve proper door gap according to diagram specs.
 4. Tighten hinge
 5. Check alignment according to diagram specs.


Part Number	Description	QTY
78755095	1 mm Shim	As Needed
78755096	1.5 mm Shim	As Needed

Section A-A





Section B-B







Section C-C



Section D-D



3. After hinge adjustment, adjust striker if necessary.
4. Door stabilizer (Dove tail and receiver) may also need to be adjusted for proper door closure.



5. If necessary, using duck billed clamps, gently tilt Door Ring Weld Flange inward to allow door to pull closer to the dove tail and striker.



Related links and attachments

No links or attachments available



Share

to others that might find it helpful



Feedback

[Give feedback](#)

to help improve the content of this article