

# 2026 bZ Woodland Pre-Delivery Service (PDS)

**Service Category** General

**Section** Pre-Delivery Service

**Market** USA

Toyota Supports  
 ASE Certification 

## Applicability

YEAR(S)	MODEL(S)	ADDITIONAL INFORMATION
2026	bZ Woodland	

## Introduction

Pre-Delivery Service (PDS) is a critical step in satisfying our new car customers. Customer feedback indicates the following areas deserve special attention when performing PDS:

- Careful inspection for paint chips/scratches and body dents/dings.
- Proper operation of electrical accessories (including interior light, clock, and radio reset).
- Interior cleanliness.
- Proper function of mechanical systems.

The PDS process helps identify potential vehicle concerns before customer delivery. After completing the PDS process, maintain accurate PDS records by ensuring the required documents listed below are completed and recorded in accordance with Toyota Warranty Policy.

- GTS+ Health Check
- Completed PDS Check Sheet
- Battery Charge Test Print Out
- GTS+ Tire Pressure Information

Customer retention and proper maintenance of vehicles are and have always been a major focus for Toyota. To help remind customers that regular service is essential to the proper maintenance of the vehicle, dealers are required to install a service reminder sticker before delivery. By doing this, customers will be reminded to return to your dealership for service. Your current service reminder sticker may be used. (See PDS Check Sheet item 7 of “Final Inspection and Cleaning.”)

## 2026 bZ Woodland Pre-Delivery Service (PDS)

---

### Introduction (continued)

This bulletin contains the PDS procedures that apply specifically to 2026 model year bZ Woodland vehicles.

Refer to [T-SB-0023-25](#), the universal *Check Sheet* that contains PDS steps that apply to all 2026 model year Toyota vehicles. To properly perform a complete PDS, you must complete all procedures contained in this TSB as well as the universal PDS Check Sheet. In addition, if the vehicle is stored for over 30 days, refer to [T-SB-0002-26](#), *Long-Term Vehicle Storage Guidelines*.

Refer to the table below for a definition of terms that may be used in this bulletin.

**Table 1.**

TERM	ACRONYM	DEFINITION
Conventional Vehicle	CV	A vehicle with only a gasoline engine for propulsion
Electrified Vehicle	EV	A vehicle that utilizes a hybrid, plug-in hybrid, fuel cell, or battery electric system for propulsion
Hybrid Electric Vehicle	HEV	A vehicle with both a gasoline engine and an HV battery
Plug-in Hybrid Electric Vehicle	PHEV	A vehicle with both a gasoline engine and an HV battery that can be charged externally
Battery Electric Vehicle	BEV	A vehicle with only an HV battery that can be charged externally
Fuel Cell Electric Vehicle	FCEV	A vehicle with both a hydrogen fuel cell and an HV battery
State of Charge	SOC	The remaining capacity available in a battery
12-Volt	12V	Standard 12V battery used to power electrical systems separate from high voltage components
High Voltage	HV	HV battery used to power the electrified vehicle

## 2026 bZ Woodland Pre-Delivery Service (PDS)

---

### Table of Contents

- [Warranty Policy](#)..... 4
- [Warranty Information](#)..... 4
- [Required Tools & Equipment](#) ..... 4
- [D/C Cut Fuse Installation](#) ..... 5
- [Front License Plate and Mounting Bracket Installation](#)\* ..... 6
- [Front and Rear Emergency Towing Eyelet Removal and Hole Cover Installation](#)..... 8
- [Check Torque of Wheel Fasteners](#)..... 9
- [Power Back Door Initialization](#)\* ..... 10
- [Tire Pressure Warning System \(TPWS\) Initialization](#)..... 10
- [Seat Position Control ECU Initialization](#)\* ..... 10
- [Head Unit System Reset](#)..... 11
- [Dealer Contact Information for Call Dealer Head Unit Function](#)..... 11
- [Navigation — Set Date & Time by GPS](#) ..... 11

\*If applicable.

## 2026 bZ Woodland Pre-Delivery Service (PDS)

---

### Warranty Policy

If the need for additional repairs or adjustment is noted during PDS, the required service should be performed under warranty. Reimbursement will be managed under the warranty policy.

**The Warranty Policy and Procedures Manual requires that you maintain the completed Check Sheet in the customer’s file.** If you cannot produce a completed form for each retailed vehicle upon TMS and/or Region/Distributor audit, the PDS payment amount will be subject to debit.

An additional Repair Order completed in conjunction with normal PDS MUST have time punch/flags for service. If multiple repairs are performed, separate time flags MUST be punched for each repair.

### Warranty Information

OP CODE	DESCRIPTION	MODEL	TIME	OFF	T1	T2
001013	Pre-Delivery Service (PDS)	bZ Woodland	1.1	–	–	–

### Required Tools & Equipment

REQUIRED EQUIPMENT	SUPPLIER	PART NUMBER	QTY
TECHSTREAM ADVi *	ADE	TSADVUNITECP	1
Techstream Lite		TSLP3DLR01	
Techstream Lite (Green Cable)		TSLP2DLR01	

\*Essential SST.

**NOTE**

- Only ONE of the Techstream units listed above is required.
- GTS+ version 2025.04.002.02 or later is required.
- Additional Techstream units may be ordered by calling Approved Dealer Equipment (ADE) at 1-800-368-6787 or by visiting *TIS – Diagnostics – Tools & Equipment – Techstream Order Portal*.


## 2026 bZ Woodland Pre-Delivery Service (PDS)

### D/C Cut Fuse Installation

Check the location of the D/C Cut fuse (30A). It may have been removed at the assembly plant and temporarily stored in the blank space of the relay block in the engine compartment to minimize battery discharge during transportation and storage.

- If the D/C Cut fuse (30A) is still in its original location in the relay block, proceed with performing a Health Check using GTS+.
- If the D/C Cut fuse (30A) is NOT in its original location, it is necessary to remove the D/C Cut fuse (30A) from the blank space in the relay block and reinstall it to its original location as shown. After installation, confirm ALL related DTCs are cleared.

**Figure 1.**



**NOTE**

- With the D/C Cut fuse (30A) removed, if ANY DTCs are detected when the ignition is turned ON during transportation, use GTS+ to clear ALL DTCs AFTER ensuring that there are NO malfunctions.
- While the vehicle is stored at the dealership, disconnect the negative (-) battery terminal to prevent battery discharge. Refer to [T-SB-0005-26](#), *Battery Inspection and Maintenance During PDS*, for battery maintenance information.

## 2026 bZ Woodland Pre-Delivery Service (PDS)

### Front License Plate and Mounting Bracket Installation


The front license plate bracket and two self-tapping screws are loaded in the vehicle at the assembly plant. Follow this procedure to install the front license plate bracket and front license plate in states where it is required by law.

1. Align attachment point “A” of the mounting bracket with the dimples on the radiator lower grille.

**NOTE**

- Attachment point “A” is used for installation of the mounting bracket to the radiator lower grille.
- Attachment point “B” is used for the installation of the front license plate to the mounting bracket.

**Figure 2.**



<b>A</b>	<b>Attachment point “A” for Mounting Bracket</b>
<b>B</b>	<b>Attachment point “B” for Front License Plate</b>
<b>1</b>	<b>Mounting Bracket</b>
<b>2</b>	<b>Self-tapping screws</b>
<b>3</b>	<b>Dimples</b>

## 2026 bZ Woodland Pre-Delivery Service (PDS)


### Front License Plate and Mounting Bracket Installation (continued)

2. Install the mounting bracket to the radiator lower grille by attaching the two self-tapping screws into the dimples.

**NOTICE**

Do **NOT** overtighten the self-tapping screws.

**Figure 3.**




<b>1</b>	<b>Self-tapping Screws</b>
<b>2</b>	<b>Bolts</b>
<b>3</b>	<b>Front License Plate</b>
<b>4</b>	<b>Mounting Bracket</b>

3. Install the front license plate to the mounting bracket using two noncorroding bolts with the following dimensions:

**Length: 15.0 mm (0.59 in.)**

**Diameter: 6.0 mm (0.24 in.)**

**Figure 4.**



<b>1</b>	<b>Length</b>
<b>2</b>	<b>Diameter</b>

## 2026 bZ Woodland Pre-Delivery Service (PDS)


### Front and Rear Emergency Towing Eyelet Removal and Hole Cover Installation

1. Remove the front and rear emergency towing eyelets from the front and rear bumpers by turning them counterclockwise.

**HINT**

If it is difficult to loosen the emergency towing eyelets, use a steel bar.

**Figure 5.**




1	Front Emergency Towing Eyelets
2	Rear Emergency Towing Eyelet

2. Place one of the removed emergency towing eyelets into the luggage tray in the luggage compartment.

**NOTE**

Dispose of the other removed emergency towing eyelets.

**Figure 6.**



1	Emergency Towing Eyelet
---	-------------------------

## 2026 bZ Woodland Pre-Delivery Service (PDS)


### Front and Rear Emergency Towing Eyelet Removal and Hole Cover Installation (continued)

3. Install the front and rear emergency towing eyelet hole covers, which are stored in the console box, onto the front and rear bumpers.
  - A. Insert the arrow-shaped part of the emergency towing eyelet hole cover "A" into the eyelet hole "B" as shown.
  - B. Install the emergency towing eyelet hole cover to the hole of the bumper.

**NOTE**

Make sure the front emergency towing eyelet cover is installed in the front, and the rear emergency towing eyelet cover is installed in the rear.

**Figure 7.**



<b>A</b>	Arrow-shaped Part
<b>B</b>	Eyelet Hole
<b>1</b>	Front Emergency Towing Eyelet Hole Covers
<b>2</b>	Rear Emergency Towing Eyelet Hole Cover

### Check Torque of Wheel Fasteners

Using a calibrated torque wrench, verify the wheel fasteners on each wheel are tightened to at least the specified torque listed in the Repair Manual.

- [2026 bZ Woodland](#):  
*General – Maintenance – Tire and Wheel – Installation*

**NOTICE**

**Do NOT continue to tighten once verified.**

## 2026 bZ Woodland Pre-Delivery Service (PDS)

---

### Power Back Door Initialization

As a result of the removal of the D/C Cut fuse with the back door open, the “automatic open and close” function of the power back door will be inoperative due to loss of the back door position memory stored in the ECU.

Refer to the applicable Repair Manual for the power back door initialization procedure.

- [2026](#) bZ Woodland:  
*Vehicle Exterior – Door / Hatch – Back Door Closer ECU – Initialization*

### Tire Pressure Warning System (TPWS) Initialization

Refer to the applicable Repair Manual for the TPWS initialization procedure.

- [2026](#) bZ Woodland:  
*Suspension – Tire Pressure Monitoring – Tire Pressure Warning Receiver – Initialization*

#### NOTE

- When the outside temperature is significantly colder than the shop’s temperature, or there is a significant ambient temperature change overnight, use GTS+ to determine the proper tire pressure.
- From the Health Check Result Status pane, select the refresh button within the Compensation Pressure data display.
- This model has four TPWS sensors.

### Seat Position Control ECU Initialization

The seat ECU must be initialized after reinstalling the D/C Cut fuse during PDS.

Refer to the applicable Repair Manual for the seating position control ECU Initialization procedure (procedure 2).

- [2026](#) bZ Woodland:  
*Vehicle Interior – Seat – Front Power Seat Control System (w/ Memory) – Registration*

## 2026 bZ Woodland Pre-Delivery Service (PDS)

---

### Head Unit System Reset

Prior to vehicle delivery confirm radio displays the welcome screen with language options when Ignition is ON.

If the welcome screen with language options does not display complete the following steps:

1. Turn the engine switch (power switch) to the ON position (ON mode).
2. Enter the Following menus: *Settings – Info & Security – Info & Security Reset.*
3. Select yes when the system reset dialogue box appears.
4. Cycle engine switch (power switch) OFF – On to confirm welcome screen appears.

### Dealer Contact Information for Call Dealer Head Unit Function

Refer to the *Multimedia System Owner's Manual* to add dealer contact information.

- [2026](#) bZ Woodland:  
*Section 2-9 Vehicle Settings – Setting Dealer Information*

### Navigation — Set Date & Time by GPS

Prior to vehicle delivery, it is necessary to turn the Set date & time by GPS setting to the ON position.

1. Turn the engine switch (power switch) to the ON position (ON mode).
2. Navigate the following menus in the head unit: *Settings – General – Date & Time – Set Date & Time by GPS.*
3. Ensure the Set date & time by GPS function is set to the ON position.